

PartNo	PartDescription	MRP	HSN	IGST
10051290ABSG	Solis Tractor BUSH (STEERING ARM)	66	84835090	18
11000615AAGF	Solis Tractor CLUTCH PLATE 04-PAD	4401	87089300	18
04000135062SG	Solis Tractor RADIAL B/BEARING 35/62X14 (6007)	329	84820000	18
04000135072SG	Solis Tractor BALL BEARING 6207	305	84821090	18
04000135080SG	Solis Tractor BALL BEARING 6307	572	84821090	18
04000140080SG	Solis Tractor BALL BEARING 6208	401	84821090	18
04000145085SG	Solis Tractor BALL BEARING 6209	421	84821090	18
04000150090SG	Solis Tractor BALL BEARING 6210	537	84821090	18
04000155100SG	Solis Tractor BALL BEARING 6211	505	84821090	18
04000750090SG	Solis Tractor TAPPER ROLLER BRG 30210 (DIA50*90*21.75)	794	84822090	18
04000755100SG	Solis Tractor TAPPER ROLLER BRG 32211	916	84822090	18
04000963113SG	Solis Tractor TAPPER ROLLER BEARING 3982 / 3920	1136	84822090	18
04001216021SG	Solis Tractor NEEDLE BEARING JL - 108	88	84824000	18
04010103025SG	Solis Tractor SPLIT PIN DIA 3*25	8	73182300	18
04010116020SG	Solis Tractor SPLIT PIN DIA 1.6*20	7	73182300	18
04030400008SG	Solis Tractor SPRING WASHER B-8	6	73182300	18
04030400010SG	Solis Tractor SPRING WASHER B-10	7	73182300	18
04030400012SG	Solis Tractor SPRING WASHER B-12	7	73182300	18
04030400014SG	Solis Tractor SPRING WASHER B-14	8	73182300	18
04030400016SG	Solis Tractor SPRING WASHER B-16	9	73182300	18
04030400018SG	Solis Tractor SPRING WASHER B-18	14	73182300	18
04031400006SG	Solis Tractor SPRING WASHER B-6 (BLACKNED)	6	73182300	18
04031400010SG	Solis Tractor HELICAL SPRING LOCK WASHER 10 AC SA2JD	7	73182300	18
04040106014SG	Solis Tractor Hex. head screw M6 x 1.00-14 8-8 SA2JS	8	73182300	18
04040106020SG	Solis Tractor HEX SCREW M6*1*20	8	73182300	18
04040106025SG	Solis Tractor HEX SCREW M6X25	8	73182300	18
04040110025SG	Solis Tractor HEX HEAD SCREW M10X1.5 - 25 8.8 SA2JS-Z	13	73182300	18
04040116025SG	Solis Tractor HEX SCREW M16*2*25	39	73182300	18
04040708045SG	Solis Tractor HEX. HEAD BOLT M8 X 1.25-45 (8-8) SA2JS	12	73182300	18
04040708065SG	Solis Tractor HEX. HEAD BOLT M8 X 1.25-65 8-8 SA2JS-Z	13	73182300	18
04040708080SG	Solis Tractor HEX BOLT M8*1.25X80 (SA2JS-Z)	14	73181500	18
04040710060SG	Solis Tractor H.H.Bolt M10X60	21	73182300	18
04040710110SG	Solis Tractor H.H.BOLT M10X110-Z	43	73182300	18
04040800010SG	Solis Tractor HEX NUT M10	8	73182300	18
04041000005SG	Solis Tractor HEX NYLOCK NUT M5	7	73182300	18
04041000010SG	Solis Tractor HEX NYLOCK NUT M10	11	73182300	18
04041000012SG	Solis Tractor HEX NYLOCK NUT M12	18	73182300	18
04042905015SG	Solis Tractor SLOTTED CHEESE HD SCREW M5*15	7	73182300	18
10002389ABSG	Solis Tractor SUCTION PIPE (WITH SUPPORT)	214	87081010	18
10002398AASG	Solis Tractor HOSE (RADIATOR TO THERMOSTAT)	112	40091100	18
10003247AASG	Solis Tractor PTO DISC [DRIVEN PLATE] 3028PT200	3119	87089300	18
10003275AESG	Solis Tractor TRACTOR REAR WHEEL [W13*28] (UNPAINTED)	16790	87087000	18
10003306AASG	Solis Tractor HEX BOLT FOR FENDER MTG.	129	73182300	18
10003795AASG	Solis Tractor BRAKE SPRING	25	73201011	18
10003802AASG	Solis Tractor HEX. NUT(BRAKE ADJUSTER)	18	73182300	18
10004236BBSG	Solis Tractor LIGHT FOR REGISTRATION PLATE (E-MARKED)	321	87081010	18
10004256AASG	Solis Tractor LINCH PIN ASSY	21	73182300	18
10004704ADSG	Solis Tractor HYDRAULIC OIL FILTER ASSY.	212	84219900	18
10004900AASG	Solis Tractor LINCH PIN	16	73182300	18
10005014AASG	Solis Tractor WASHER	15	73182300	18

10005015AASG	Solis Tractor NUT	34	73182300	18
10005206AFSG	Solis Tractor KNOB RV	77	87089900	18
10005355AASG	Solis Tractor ACTUATOR FORK (RH THRD)	86	87089900	18
10005356ABSG	Solis Tractor ACTUATOR FORK LT	87	87089900	18
10005405AASG	Solis Tractor MALE QUICK CONNECT COUPLER-1/2"BSP	349	84811000	18
10005406AASG	Solis Tractor FEMALE DUST PLUG-RED SPAV.13002	87	87089900	18
10005409ABSG	Solis Tractor FEMALE QUICK CONNECT COUPLING-1/2 BSP	627	73182300	18
10005750ALSG	Solis Tractor TOP LINK ASSY.	2903	87089900	18
10006018ACSG	Solis Tractor HANDLE FOR PUSH PULL ROD	101	87089900	18
10006018ADSG	Solis Tractor HANDLE FOR PUSH PULL ROD	122	87089900	18
10006050AFSG	Solis Tractor DRIVE SHAFT Z-18	3676	87084000	18
10006078GASG	Solis Tractor BELL HOUSING (FINISHED)	13784	87084000	18
10006125AESG	Solis Tractor C.A.GUIDE	1177	87089300	18
10006286ABSG	Solis Tractor SPRING (GEAR SHIFTER ROD)	6	73201011	18
10006291BASG	Solis Tractor LOCKING PIN	25	73182300	18
10006291BBSG	Solis Tractor LOCKING PIN	24	73182300	18
10006349ADSG	Solis Tractor C.A.GUIDE	1110	87084000	18
10006353ACSG	Solis Tractor C.A. FORK (FOR DOUBLE CLUTCH OF PTO)	751	87089300	18
10006354ADSG	Solis Tractor DOUBLE CLUTCH (FOR IND. PTO)	28244	87089300	18
10006448CBSG	Solis Tractor C.A. FORK	704	87089900	18
10006487BFSG	Solis Tractor DOG. GEAR ASSY. Z-41 (FOR DI 60)	2449	87084000	18
10006487BHSG	Solis Tractor DOGCLUTCH GEAR 1ST ASSY. Z-41	2426	87084000	18
10006722BCSG	Solis Tractor SHIFTER FORK (2ND & 3RD)	609	87084000	18
10006982AASG	Solis Tractor SPRING (UNLOADING VALVE)	10	73201011	18
10007128ABSG	Solis Tractor SEALING PLUG	7	40161000	18
10007220AASG	Solis Tractor WASHER(FOR BRAKE PEDAL SHAFT)	13	73182300	18
10007302ADSG	Solis Tractor WHEEL BOLT REAR	51	73182300	18
10007399BBSG	Solis Tractor MAIN SPINDLE 4-WD	2202	87085000	18
10007673ACSG	Solis Tractor (M 18*1.5) 8 REAR AXLE	42	73182300	18
10007770AASG	Solis Tractor REAR COVER PLATE	306	87089900	18
10007772ABSG	Solis Tractor END PIECE	51	87089900	18
10007881BASG	Solis Tractor TENSION SPRING	27	73201011	18
10007909AFSG	Solis Tractor TAIL PINION CARRIER	1367	87085000	18
10008029AASG	Solis Tractor WASHER(REAR AXLE)	18	73182300	18
10008066ABSG	Solis Tractor SCREW STOPPER	19	73182300	18
10008120AASG	Solis Tractor WELDING PLUG (DIA 8)	11	87089900	18
10008121AASG	Solis Tractor SPL. PLUG (DIA 8)	11	73182300	18
10008477CBSG	Solis Tractor TUBE SENSOR	1076	87084000	18
10008477CCSG	Solis Tractor TUBE SENSOR	1076	87089900	18
10008590ABSG	Solis Tractor SPECIAL BOLT FOR PARKING BRAKE	39	73182300	18
10008601ELSG	Solis Tractor DIFFERENTIAL HOUSING (3-CYLINDER,SOLIS-3	52944	87085000	18
10008601EOSG	Solis Tractor DIFFERENTIAL HOUSING WITHOUT DIFF LOCK	61220	87081010	18
10008921AESG	Solis Tractor INNER SHAFT	559	87084000	18
10009098AISG	Solis Tractor TOP LINK ASSY	3826	87089900	18
10009155ADSG	Solis Tractor NEUTRAL SAFETY SWITCH	323	85361010	18
10009661BBSG	Solis Tractor FENDER SUPPORT BAR ASSY (BLACK)	279	87089900	18
10011154ABSG	Solis Tractor SPECIAL BOLT M16X1.5	106	73182300	18
10011155ACSG	Solis Tractor SPECIAL HEX SCREW M16X1.5	66	73182300	18
10011587AGSG	Solis Tractor DIFFERENTIAL HOUSING (W/O DIFF LOCK)	55883	87085000	18
10011654ABSG	Solis Tractor FLEXIBLE OIB PIPE ASSY.	765	87081010	18
10012045AASG	Solis Tractor STICKER FOR ENGINE START/IGNITION	8	39199010	18

10012447ABSG	Solis Tractor FEMALE QUICK CONNECT	554	84811000	18
10012571ABSG	Solis Tractor BONDED SEAL FOR M14	33	40161000	18
10012693ACSG	Solis Tractor RUBBER WASHER	9	40169100	18
10012711AASG	Solis Tractor REAR AXLE	8948	87085000	18
10012881ACSG	Solis Tractor DOG GEAR ASSY 3RD Z-25	1670	87084000	18
10014214ACSG	Solis Tractor ZF MOUNTING BRACKET (POWER STEERING)	1992	87089400	18
10014994AASG	Solis Tractor PTO END COVER	576	87084000	18
10022134AFSG	Solis Tractor ADOPTER M16X1.5/ G-1/2"A	82	87089900	18
10022135ACSG	Solis Tractor ADOPTER M18X1.5/G1/2A	82	87081010	18
10023081AASG	Solis Tractor TOOL BOX ASSY. (BLACK)	1664	87081010	18
10023538ABSG	Solis Tractor PIPE (RADIATOR TO COOLANT TANK)	88	87089100	18
10023567AASG	Solis Tractor BONNET ASSY 2 CYL SKY BLUE	15649	87089900	18
10023999AASG	Solis Tractor SPACER (ROCK SHAFT)	89	87081010	18
10024069ACSG	Solis Tractor COVER (BRAKE HSG. LEFT)(OIB)	1499	87083000	18
10024077AASG	Solis Tractor PULL ROD (OIB)	145	87089900	18
10024093AESG	Solis Tractor DISC ACTUATING (OIB)	779	87083000	18
10024118ABSG	Solis Tractor BRAKE HOUSING (RIGHT) (OIB)	4334	87083000	18
10024954AASG	Solis Tractor SHIM THICKNESS 0.150 MM	18	73182300	18
10025568CBSG	Solis Tractor SPRING SEAT	34	73201011	18
10025903BCSG	Solis Tractor FUEL PIPE (OVER FLOW F.I.P. TO FUEL TAN	483	73061929	18
10026286ACSG	Solis Tractor HOSE PIPE(SUCTION)	100	40091100	18
10026400AASG	Solis Tractor ANTI RUSTING COOLING AGENT	229	38200000	18
10026473AASG	Solis Tractor MOUNTING BRACKET (FENDER SUPPORT BAR)(BL	114	87089900	18
10026957AASG	Solis Tractor CAP RADIATOR 0.5-PSI	124	87089100	18
10027162AASG	Solis Tractor PLATE FOR RUBBER BOOT	62	40161000	18
10027339AESG	Solis Tractor HYDRAULIC FILTER	705	84213990	18
10027339AGSG	Solis Tractor HYDRAULIC FILTER	711	84212300	18
10027437AASG	Solis Tractor DOG CLUTCH GEAR ASSY Z-34	1438	87084000	18
10028334ACSG	Solis Tractor SPHERICAL BUSHING	444	84829900	18
10028506AISG	Solis Tractor AXLE HOUSING & BUSH SUB ASSY NON EPA MOD	36080	87085000	18
10028524AASG	Solis Tractor FLEXIBLE PIPE ASSY. (REAR COVER TO BRAKE	641	40091100	18
10028884AASG	Solis Tractor TOOL BOX ASSY.(PLASTIC)	667	87089900	18
10029006AASG	Solis Tractor WHEEL RIM 4.5X16 (SILVER PAINT)	3073	87087000	18
10029312AGSG	Solis Tractor ZF MOUNTING BKT (POWER STEERING-W/O IPTO	1836	87089400	18
10029553ABSG	Solis Tractor WET BRAKE ASSY LT (3 CYL FOR JMFT)	16600	87083000	18
10029554ABSG	Solis Tractor WET BRAKE ASSY RT (3 CYL FOR JMFT)	16600	87083000	18
10029666AESG	Solis Tractor ADJUSTABLE STAY BAR ASSY. (RH)	1582	87089900	18
10029942BASG	Solis Tractor FLEXIBLE PIPE FROM STG UNIT L TO STG CYL	733	73061929	18
10029942BDSG	Solis Tractor FLEXIBLE UNIT STG CYL L TO STG UNIT RH	607	40091100	18
10029943BESG	Solis Tractor STARTER SWITCH	647	85360000	18
10029988AASG	Solis Tractor ADOPTER OIB	184	87089900	18
10036268ACSG	Solis Tractor FRONT AXLE ASSY. DANA	167575	87081010	18
10036426AASG	Solis Tractor TOP LINK PIN- CAT-I	152	87089900	18
10037164AASG	Solis Tractor TRUMPET HOUSING (FINISH)	21944	87085000	18
10037233BASG	Solis Tractor INPUT SHAFT (Z-19) DUAL CLUTCH	2361	87084000	18
10037261BASG	Solis Tractor GEAR SHIFTER ROD 4TH -5TH	360	87084000	18
10037263AASG	Solis Tractor GEAR SHIFTER ROD 2ND-3RD	366	87084000	18
10037326AASG	Solis Tractor IDLER-REV GEAR Z-25	1339	87084000	18
10037332BASG	Solis Tractor SHIFTER BUSH- REV LOW	328	87089900	18
10037427ABSG	Solis Tractor SLEEVE 4TH & 5TH GEAR	658	87084000	18
10037428BBSG	Solis Tractor HUB FOR 4TH & 5TH GEAR	374	87084000	18

10037524ABSG	Solis Tractor DOG CLUTCH REV GEAR ASSY Z-41	2811	87084000	18
10037713BASG	Solis Tractor INPUT SHAFT Z-20 (DC) (PART NO.)	2344	87084000	18
10037727ABSG	Solis Tractor SHIFTER HOUSING (FINISH)	1546	87089900	18
10037941ACSG	Solis Tractor THREADED BUSH	118	87084000	18
10038107AASG	Solis Tractor WHEEL RIM 4.5X16 (SILVER PAINT) (IN)	2872	87087000	18
10038294ABSG	Solis Tractor FUEL COCK ASSEMBLY	251	87089900	18
10038401ABSG	Solis Tractor DOG CLUTCH GEAR ASSY Z-41	2371	87084000	18
10038451BASG	Solis Tractor COVER(BRAKE HSG. LEFT)	1124	73250000	18
10038454BASG	Solis Tractor COVER(BRAKE HSG. RIGHT)	1124	73250000	18
10038512ADSG	Solis Tractor CRANK POSITION ASSY.	744	84834000	18
10038569AASG	Solis Tractor DOG CLUTCH GEARS ASSY Z-41	2041	87084000	18
10038722AASG	Solis Tractor SUCTION PIPE FROM FILTER TO HYDRAULIC PU	762	87081010	18
10038726ABSG	Solis Tractor ADOPTER M24X1.5 - G1/2"	128	87084000	18
10038732AASG	Solis Tractor ADOPTER FOR HYDRAULIC FILTER	953	87081010	18
10038758ABSG	Solis Tractor REAR COVER OPTION OIB WITH DCV AT BACK E	23901	87089900	18
10038760ABSG	Solis Tractor DCV LEVER ASSY PAINTED	185	87089900	18
10039330AASG	Solis Tractor UNIVERSAL JOINT ASSY (FRONT AXLE 4WD)	23478	73071190	18
10039471BASG	Solis Tractor PIPE FROM STEERING UNIT L TO STEERING CY	977	73061929	18
10045044AESG	Solis Tractor FRONT MTG ASSY FOR FLOOR LH	700	87089900	18
10045045AESG	Solis Tractor FRONT MTG ASSY FOR FLOOR RH	756	87089900	18
10045215AESG	Solis Tractor BRACKET FOR SHUTTLE LEVER	217	87089900	18
10045437ACSG	Solis Tractor FRONT REMOVABLE WEIGHT 25 KG	4271	87089900	18
10045811ACSG	Solis Tractor BONNET SIDE SEALING PLATE RH WITH BLUE P	270	87089900	18
10045878ABSG	Solis Tractor SPRING GRAB HANDLE BONNET	8	73201011	18
10046155AASG	Solis Tractor FENDER SEAT GUARD	1794	87089900	18
10046191ADSG	Solis Tractor ASSY DASHBOARD MTG BKT LH	26	87089900	18
10046192ADSG	Solis Tractor ASSY DASHBOARD MTG BKT RH	26	87089900	18
10046336AISG	Solis Tractor DASHBOARD ASSY FACELIFT RX - MORR BLUE	5907	87089900	18
10046597ABSG	Solis Tractor SHUTTLE LEVER ROD (MST FACELIFT)	476	87084000	18
10046755AASG	Solis Tractor CLUSTER ASSY HIGH END	8018	90292020	28
10051006AESG	Solis Tractor STEERING ARM (SINGLE)	0	87089400	18
10051007AISG	Solis Tractor Front Axle Hsg	2001	73251000	18
10051009ACSG	Solis Tractor FRONT AXLE	1950	87081010	18
10051021BBSG	Solis Tractor SLEEVE (T.P. SHAFT)	150	87084000	18
10051054ACSG	Solis Tractor Bevel Gear Z-27	1854	87084000	18
10051061ACSG	Solis Tractor Bush (Front Axle Hsg.)	87	84833000	18
10051114AASG	Solis Tractor ADJUSTABLE TIE ROD (CLUTCH PEDAL)G.T.	388	87089300	18
10051278ADSG	Solis Tractor SPACER (PTO)	45	87089900	18
10051290ACSG	Solis Tractor Bush (Steering Arm)	74	84833000	18
10051293AESG	Solis Tractor ASSY STEERING ARM (SINGLE)	897	87089400	18
10051293AFSG	Solis Tractor ASSY STEERING ARM (SINGLE)	897	87089400	18
10052508ADSG	Solis Tractor RADIATOR HOSE (RADIATOR TO WATER PUMP)24	294	40091100	18
10053135ACSG	Solis Tractor ASSY STEERING ARM (DOUBLE)	1226	87089900	18
10053135ADSG	Solis Tractor ASSY STEERING ARM (DOUBLE)	1312	87089400	18
10053155BASG	Solis Tractor 90° ADJUSTABLE STUD ELBOW 12 X G1/2-A	280	73070000	18
10053354ADSG	Solis Tractor MID FLOOR	365	87089900	18
10053407ABSG	Solis Tractor ACTUATING LUG ASSY	218	87089900	18
10053753AASG	Solis Tractor PIN (FOR SWINGING DRAW BAR)	297	73182300	18
10053758AASG	Solis Tractor CLUTCH SAFETY SWITCH	679	85361010	18
10054076AASG	Solis Tractor HOSE THERMOSTAT TO RADIATOR	169	40091100	18
10054087AASG	Solis Tractor FUEL PIPE(FUEL FILTER TO FIP)	287	40091100	18

10054237AASG	Solis Tractor PTO SLIDING GEAR (Z-21) (FINISH NO.)	1144	87084000	18
10054340AASG	Solis Tractor HEX NUT M8X1.25 LH-SA2JS	6	73182300	18
10054799AASG	Solis Tractor CASE ASSY, THERMOSTAT	7711	84099111	28
10054803AASG	Solis Tractor GASKET, THERMOSTAT_31A46-11200	454	84099111	28
10054888AASG	Solis Tractor THERMOSTAT_K6516441	2364	84099111	28
10054901AASG	Solis Tractor GASKET, OIL DRAIN	84	84099111	28
10055213ABSG	Solis Tractor FRONT AXLE HOUSING	1735	87081010	18
10055225BASG	Solis Tractor STUB AXLE HOUSING	2046	87085000	18
10055248ABSG	Solis Tractor ASSY FRONT AXLE HOUSING	2164	87081010	18
10055389AASG	Solis Tractor CASSETTE SEAL TCWN00061(45X65X12) (PADDY	525	40161000	18
10055391ABSG	Solis Tractor OIL SEAL (25X40X10)	52	40161000	18
10055499ACSG	Solis Tractor FRONT THRESH GUARD SOLIS 26	557	87089900	18
10055924AASG	Solis Tractor NEUTRAL SAFETY SWITCH	503	85361010	18
10056240BASG	Solis Tractor REAR AXLE	3562	87085000	18
10056706AESG	Solis Tractor TRANSMISSION HOUSING (FINISH)	21436	87085000	18
10057513ABSG	Solis Tractor FUEL TANK ASSEMBLY	8829	87089900	18
10057566AESG	Solis Tractor CLUSTER PANEL	1260	87089900	18
10057935AASG	Solis Tractor BOLT	49	73181500	18
10065156AHSG	Solis Tractor BRAKE HOUSING	2733	87083000	18
10065198AESG	Solis Tractor SHIFTER FORK FOR SHUTTLE	889	87089900	18
10066304AASG	Solis Tractor DRIVEN PLATE ASSY	4348	87089300	18
10066305AASG	Solis Tractor DRIVEN PLATE ASSY	7847	87089300	18
10066717ADSG	Solis Tractor TRB HOLDER PLATE	1514	87085000	18
10067783AASG	Solis Tractor LIGHT FOR REGISTRATION PLATE	323	85122020	18
10067980AASG	Solis Tractor DRAIN LINE HOSE FOR 16 OD TUBE	79	40091100	18
10069146AASG	Solis Tractor PTO SHAFT FOR 60HP	2560	84831099	18
10069535AASG	Solis Tractor SUB ASSY1STGEAR	3065	87084000	18
10070750AFSG	Solis Tractor STARTER MOTOR COVER	156	87089900	18
10070794BASG	Solis Tractor KING PIN ASSY LEFT	3283	87089900	18
10070820AASG	Solis Tractor BETA PIN DIA 3 BN 915	15	87089900	18
10070831BASG	Solis Tractor KING PIN STUB ASSY RT	3233	87089900	18
10070894AESG	Solis Tractor FUEL TANK CAP (DOUBLE LOCK)HOMOLOGATION	312	87089900	18
10071354BDSD	Solis Tractor EXHAUST PIPE ASSEMBLY 3-CYL	3141	87089200	18
10079231AASG	Solis Tractor FENDER NUT PLATE SUPPORT BAR	28	87089900	18
10079418AASG	Solis Tractor ASSY BALL JOINT ACTUATOR	323	87089900	18
10079750ACSG	Solis Tractor FRONT AXLE BRACKET 3 CYL (PS)	28220	87081010	18
10079797ABSG	Solis Tractor TRIM PIN DIA 6	12	87089900	18
10080038ABSG	Solis Tractor LOCKING PLATE	65	87089900	18
10080039ABSG	Solis Tractor TUBE ASSY	309	40139049	18
10080040AFSG	Solis Tractor SHAFT LOWER LINK	1409	87089900	18
10080109ABSG	Solis Tractor LINCH PIN ASSY.(Ã~7)	16	73182300	18
10080884ABSG	Solis Tractor TANK UNIT	575	87089900	18
10080985AASG	Solis Tractor SCREW TE M8X35 UNI5737 ZN 8.8	19	73182300	18
10081946AFSG	Solis Tractor STEERING WHEEL FOR W.T. HI TECH	1138	87089400	18
10085035AASG	Solis Tractor FUEL FILTER	40	84213990	18
10090006ADSG	Solis Tractor Gear PTO 540E Z-71	3155	84834000	18
10090102BASG	Solis Tractor Shifter bush 3rd	284	87089900	18
10090104AASG	Solis Tractor Shifter bush high	326	87089900	18
10090110BBSG	Solis Tractor Bush reverse pinion	450	87089900	18
10090111BBSG	Solis Tractor Bush forward pinion	371	87089900	18
10090125BASG	Solis Tractor Bush reverse PTO wheel	436	87089900	18

10090125BBSG	Solis Tractor Bush reverse PTO wheel	436	87089900	18
10090131AASG	Solis Tractor Shifter fork PTO	477	87084000	18
10090154AASG	Solis Tractor Coupling PTO shaft	497	87084000	18
10090155ABSG	Solis Tractor SHIFTER FORK LOW MEDIUM	640	87089900	18
10090155ACSG	Solis Tractor SHIFTER FORK LOW MEDIUM	640	87089900	18
10090155ADSG	Solis Tractor SHIFTER FORK LOW MEDIUM	640	87089900	18
10090155AESG	Solis Tractor SHIFTER FORK LOW MEDIUM	774	87089900	18
10090185AASG	Solis Tractor Hub PTO	616	87084000	18
10090231BASG	Solis Tractor Gear idler PTO Z-26 / Z-34	1773	87084000	18
10090257ADSG	Solis Tractor Crown Wheel & Tail Pinion Set (12x38)	11579	87085000	18
10090257AESG	Solis Tractor Crown Wheel & Tail Pinion Set (12x38)	11579	87089900	18
10090266BASG	Solis Tractor Connecting shaft	2224	87084000	18
10090331BBSG	Solis Tractor Bush-1st wheel (collar shift)	505	87089900	18
10090349ABSG	Solis Tractor Drive shaft reverse PTO Z-23 dual clutch	2926	87084000	18
10090349ACSG	Solis Tractor Drive shaft reverse PTO Z-23 dual clutch	2979	87084000	18
10090367BCSG	Solis Tractor Input shaft, dual clutch	2554	87084000	18
10090452BBSG	Solis Tractor Bush PTO 540E wheel	393	87089900	18
10090452BCSG	Solis Tractor Bush PTO 540E wheel	416	87089900	18
10090472ABSG	Solis Tractor Shifter fork high	540	87089900	18
10090630BBSG	Solis Tractor Bush for PTO idler shaft	202	87084000	18
10090635BBSG	Solis Tractor Gear shifter rods 1st & 2nd	311	87084000	18
10090639BBSG	Solis Tractor Gear shifter rod HI	295	87084000	18
10090713BASG	Solis Tractor Gear reverse pinion	1505	87084000	18
10090778ADSG	Solis Tractor DIFFERENTIAL HOUSING WITHOUT DIFF LOCK	53258	87085000	18
10090848AASG	Solis Tractor Graded Spacer for Pinion Shaft 3.30	44	87089900	18
10090849AASG	Solis Tractor Graded Spacer for Pinion Shaft 3.45	45	87089900	18
10090864AASG	Solis Tractor Graded Spacer for Pinion Shaft 3.90	48	87089900	18
10090865ABSG	Solis Tractor HUB LOW-MED	700	87084000	18
10091033BASG	Solis Tractor INTERMEDIATE SHAFT Z-32 FOR CM	3349	87084000	18
10091129BBSG	Solis Tractor GEAR BOX HOUSING	32277	87084000	18
10091146ABSG	Solis Tractor GEAR 1ST PINION Z-32	914	87084000	18
10091152ACSG	Solis Tractor GEAR 1ST WHEEL Z-73 FOR CM	2476	87084000	18
10091175AASG	Solis Tractor GEAR 3RD WHEEL Z-47 FOR CM	1492	84834000	18
10091186AASG	Solis Tractor GEAR FORWARD PINION Z-41	1626	84834000	18
10091209CASG	Solis Tractor LAY SHAFT RANGE Z-26/39/76	8170	87084000	18
10091221ABSG	Solis Tractor GEAR 4TH WHEEL Z-40 FOR CM	1330	84834000	18
10093612AASG	Solis Tractor FRONT TOE PIN	440	87081010	18
11000297AASG	Solis Tractor KEY STARTING SWITCH	25	85361010	18
11000458AASG	Solis Tractor DIAPHRAGM SPRING	1323	87089300	18
11000577AASG	Solis Tractor LOCTITE-518 (50 ML)	939	35069999	18
11000587AASG	Solis Tractor LOCTITE 5060 25 GMS	186	82070000	18
11000681AASG	Solis Tractor ELEMENT ASSEMBLY, PRIMARY	722	84213990	18
11000682AASG	Solis Tractor ELEMENT ASSEMBLY, SAFETY	542	84213990	18
1141004043SG	Solis Tractor COM PAINT RED BOTTEL 300G SPRAY MAKE	454	32082090	18
1141004045SG	Solis Tractor COM PAINT DD GREY BOTTLE 300G SPRAY	452	32082090	18
1141004047SG	Solis Tractor HR BLACK COM PAINT BOTTEL 300 G SPRAY	504	32082090	18
1A8252-14770-0S	Solis Tractor NUT, M16	22	73181500	18
1A8252-14790-0S	Solis Tractor BOLT, M16X39	98	73181500	18
1A8252-51160-0S	Solis Tractor CLIP, HARNESS	7	85443000	18
20000104AASG	Solis Tractor HEX SCREW M6*10	7	73182300	18
20001089ABSG	Solis Tractor HEX. HEAD SCREW M8 X 1.25-25 8-8 SA4JS	12	73181600	18

20001096AASG	Solis Tractor HEX. HEAD SCREW M8 X 1.25 X 20 8-8 SA2JS	14	73182300	18
20001174ACSG	Solis Tractor CLAMP FOR PIPE	60	87089900	18
20001508AASG	Solis Tractor CLOGGING SENSOR	678	73182300	18
20001670AASG	Solis Tractor FLAT WASHER N8-22	8	73182300	18
20002015ABSG	Solis Tractor HEX HEAD SCREW M10X1.5X25 8-8 SA2JS	17	73182300	18
20002021AASG	Solis Tractor Hex head screw M12 x1.75x25 10.9 SA2JS	22	73182300	18
20002021ACSG	Solis Tractor HEX. HEAD SCREW M12X1.75X25	22	73182300	18
20002462AASG	Solis Tractor BEATA PIN	17	73182300	18
20002585AASG	Solis Tractor STICKER - DO NOT OVERRIDE CLUTCH PEDAL (	5	39191000	18
20002586AASG	Solis Tractor STICKER - DISENGAGE PTO LEVER BEFORE STA	6	39191000	18
20002589AASG	Solis Tractor STICKER - KEEP CLOTHING AWAY FROM FAN &	6	39191000	18
20002590AASG	Solis Tractor STICKER - COOLING SYSTEM IN RADIATOR UN	12	39191000	18
20003207AASG	Solis Tractor HEX HEAD SCREW M5*16	12	73182300	18
20003244AASG	Solis Tractor Hex screw M12x1.75x35 8-8 SA3NS	17	73181600	18
20003245ABSG	Solis Tractor HEX. SCREW M12X1.75X40	25	73182300	18
20003258AASG	Solis Tractor BEARING 32206	623	84821020	18
20003286ABSG	Solis Tractor HEX SCREW M8x1.25x35 (8-8) SA2JS	13	73182300	18
20003329ABSG	Solis Tractor HEX BOLT M8*1.25*60 8-8 SA2JS	14	73182300	18
20003352AASG	Solis Tractor HEX NUT M4-8 SA3NS	6	73182300	18
20003358AASG	Solis Tractor HEX NUT M12X1.75 -8 SA2JS	13	73182300	18
20003362ACSG	Solis Tractor HEX NUT M16X2 -8 SA2JS	24	73182300	18
20003510AASG	Solis Tractor SOCKET HEAD CAP SCREW 1M5 X 16 8-8 SA2J	14	73182300	18
20003517AASG	Solis Tractor HEX FLANGE SCREW M6*1*16-8.8 SA2JS	9	73182300	18
20003517ABSG	Solis Tractor HEX FLANGE SCREW M6*1*16-8.8 SA4JS	9	73181500	18
20003518AASG	Solis Tractor HEX FLANGE SCREW M6*1*20-8.8 SA2JS	10	73182300	18
20003519AASG	Solis Tractor HEX FLANGE SCREW M8*1.25*20-8.8 SA2JS	14	73182300	18
20003519ABSG	Solis Tractor HEX FLANGE SCREW M8*1.25*20-8.8 SA4JS	12	73182300	18
20003520AASG	Solis Tractor HEX FLANGE SCREW M8*1.25*25-8.8 SA2JS	15	73182300	18
20003636AASG	Solis Tractor HEX BOLT M16*2*80 8-8 SA2JS	74	73182300	18
20003673ACSG	Solis Tractor SPRING WASHER B-14 TYPE-A IS:3063-1972	6	73182990	18
20003760ABSG	Solis Tractor TAPPER ROLLER BEARING 32309	1517	84822090	18
20003920AASG	Solis Tractor HEX BOLT M18*2.5*80 - 10.9 SA2JS	70	73182300	18
20003920ABSG	Solis Tractor HEX BOLT M18X2.5X80 10.9 SA4JS	60	73181500	18
20003997AASG	Solis Tractor HEX BOLT M10X1.5X55 8.8 SA3NS	24	73182300	18
20004078ADSG	Solis Tractor HEX SCREW M10*1.25*25	13	73182300	18
20004098ABSG	Solis Tractor TR BEARING 32013X(65X100X23)	1145	84822090	18
20004119AASG	Solis Tractor BALL BEARING (6205)	194	84821090	18
20004121AASG	Solis Tractor TR BEARING 32006	635	84822011	18
20004122AASG	Solis Tractor BALL BEARING 63/22	226	84821090	18
20004123AASG	Solis Tractor BRG. 62/28	467	84824000	18
20004125AASG	Solis Tractor BALL BEARING 63/28	509	84820000	18
20004145AASG	Solis Tractor NEEDLE CAGE BEARING (31X25X17)	240	84824000	18
20004147AASG	Solis Tractor NEEDLE CAGE BEARING (24X18X12)	85	84824000	18
20004252AASG	Solis Tractor LOCTITE-638	17	35069999	18
20004253AASG	Solis Tractor LOCTITE-518	23	35069999	18
20004254AASG	Solis Tractor SOCKET HEAD SCREW (M8X1.25-16)	13	73182300	18
20004298AASG	Solis Tractor CASTLE NUT M16X1.5	44	73182300	18
20004346AASG	Solis Tractor BALL BEARING 6205NR (WITH SNAP RING)	213	84821020	18
20004346ABSG	Solis Tractor BALL BEARING 6205NR (WITH SNAP RING)	258	84821020	18
20004446AASG	Solis Tractor LOCTITE 5182(2L)	21	35069999	18
20004508AASG	Solis Tractor HEX BOLT M16X2X60 - 8.8-SA2JS	49	73182300	18

20004566AASG	Solis Tractor CLUTCH RELEASE BEARING TG 1956/1 GT4WD	805	84829900	18
20004595AASG	Solis Tractor HEX HEAD SCREW M8X1.25X55 8.8 SA2JS	12	73182300	18
20004652AASG	Solis Tractor TRUSS PHILIPS M/C SCREW M6X20	14	73182300	18
20004660ABSG	Solis Tractor SOCKET HEAD CAP SCREW	9	73182300	18
20004753AASG	Solis Tractor HEX BOLT M16X2X175 10.9 SA2JS	124	73182300	18
20004951AASG	Solis Tractor BALL BEARING 6304/22	213	84821090	18
20005121AASG	Solis Tractor LOCTITE-5188/MT--LOK-250	34	35069999	18
200403055ASG	Solis Tractor PISTON SET ASSY.-'P' type (Ø105)	3148	84099111	28
203403045ASG	Solis Tractor PISTON RING SET (102F)	659	84099111	28
203403056ASG	Solis Tractor PISTON RING SET (Ø105) FM	998	84099111	28
203407021ASG	Solis Tractor SPIN-ON OIL FILTER CARTRIDGE (500hrs.)	493	84212300	18
300001710ASG	Solis Tractor OUTER SEALING RING	152	40169320	18
300002731ASG	Solis Tractor ANCHOR CHAIN ASSY	893	87089900	18
300003579ASG	Solis Tractor BUSH 2ND/3RD WHEEL COLLAR SHIFT	552	87089900	18
300003596ASG	Solis Tractor BUSH IDLER SHAFT	131	87089900	18
300003646ASG	Solis Tractor SHIM (0.50)	17	73182910	18
300004074ASG	Solis Tractor SIDE MTG BRACKET ASSY RH	476	87081010	18
300004414ASG	Solis Tractor DROP BOX (4WD) CASTING	4014	73250000	18
300004535BSG	Solis Tractor INPUT CONNECTING SHAFT Z-15 (FINISH)	1304	87084000	18
300004535CSG	Solis Tractor INPUT CONNECTING SHAFT Z-15 (FINISH)	1319	87084000	18
300004588ASG	Solis Tractor CA Fork (FINISH)	539	87089900	18
300004599ASG	Solis Tractor SLEEVE12+4 (FINISH)	742	87084000	18
300008699CSG	Solis Tractor SHIFTER PIN SIDE LEVER	226	87084000	18
300009848BSG	Solis Tractor FRONT COVER	627	87085000	18
300012656ASG	Solis Tractor GOLDEN BEIGE MET BC YANMAR	1181	32080000	28
300023195ASG	Solis Tractor DASHBOARD HANDEL LH	73	87089900	18
300023546CSG	Solis Tractor BONNET ASSY 4-CYL WITH TOP MESH WITH TC_	9027	87089900	18
300023558CSG	Solis Tractor BONNET ASSY 3-CYL WITH TOP MESH WITH TC_	12660	87089900	18
300023558DSG	Solis Tractor BONNET ASSY 3-CYL WITH TOP MESH WITH TC_	22750	87089900	18
300024654BSG	Solis Tractor SHAFT FRONT PTO 4WD	2562	87089900	18
300025291BSG	Solis Tractor SPECIAL PIN	19	87089900	18
300025832BSG	Solis Tractor HEAD LAMP RHD LH SIDE	7547	85122010	18
300025833BSG	Solis Tractor HEAD LAMP RHD RH SIDE	7547	85122010	18
300031992BSG	Solis Tractor FRONT MESH ASSY W/O PAINT	791	87089900	18
300032116ASG	Solis Tractor HARNESS ASSY.	7620	85443000	18
300033664DSG	Solis Tractor FUEL TANK FRAME ASSY 65 LIT (W/O SHUTTLE	4537	87089900	18
300033667BSG	Solis Tractor FUEL TANK FRAME ASSY 55 LIT (W/O SHUTTLE	3755	87089900	18
300033667CSG	Solis Tractor FUEL TANK FRAME ASSY 55 LIT (W/O SHUTTLE	3755	87089900	18
300033667DSG	Solis Tractor FUEL TANK FRAME ASSY 55 LIT (W/O SHUTTLE	3755	87089900	18
300037261ASG	Solis Tractor FRONT TRASH GUARD (BLACKPAINT)	325	87089900	18
300040375ASG	Solis Tractor HDRAULIC CYLINDER-ECONOMICAL	6608	87089900	18
300040376ASG	Solis Tractor CLAMP ASSY	72	87089900	18
300043091BSG	Solis Tractor TUBE AND SIDE COVER ASSY (FOR OPERATING	891	87089900	18
300043305BSG	Solis Tractor KNOB ASSY.	34	87089900	18
300043425ASG	Solis Tractor POSITION LEVER (FOR OPERATING SECTOR ASS	132	87089900	18
300043426ASG	Solis Tractor DRAFT LEVER (FOR OPERATING SECTOR ASSEMB	182	87089900	18
300043426BSG	Solis Tractor DRAFT LEVER	146	87089900	18
300043872ASG	Solis Tractor STICKER FOR POSITION AND DRAFT INDICATIO	31	39191000	18
300043872BSG	Solis Tractor STICKER FOR POSITION AND DRAFT INDICATIO	16	39191000	18
300045872ESG	Solis Tractor DASHBOARD ASSY RX-FL MCPAINTED	7138	87089900	18
300051954ASG	Solis Tractor TUBE ADOPTER ASSY 1/2 INCH BSP	112	87089900	18

300054216ASG	Solis Tractor Cup - Face Seal	602	87085000	18
300055630ASG	Solis Tractor CRANK CASE w/Brg.CAP(3cyl.-NA_IW) CE-NT	52443	84099941	28
300062220ASG	Solis Tractor NEUTRAL SAFETY SWITCH	346	85361010	18
300066054ASG	Solis Tractor SIDE CENTRE PANEL LH 3 CYL	234	87089900	18
300066054BSG	Solis Tractor SIDE CENTRE PANEL 3 CYL GT RH GT STAGE-	291	87089900	18
300066056ASG	Solis Tractor SIDE CENTRE PANEL RH 3 CYL	234	87089900	18
300066056BSG	Solis Tractor SIDE CENTRE PANEL 3 CYL GT LH GT STAGE-	291	87089900	18
300067004ASG	Solis Tractor MUFFLER ASSY WITH ELBOW TWO BEFFELS	2827	87089200	18
300068767ASG	Solis Tractor HUB HI-GEAR (FINISH NO.)	570	87084000	18
300068770ASG	Solis Tractor HI-LOW INTERMEDIATE SHAFT (FINISH NO.)	1970	87084000	18
300068852BSG	Solis Tractor 3 CYL FENDER FOR NON ROPS LH TC_ MAG IIIn	14618	87089900	18
300068852CSG	Solis Tractor 3 CYL FENDER FOR NON ROPS LH TC_ MAG IIIn	9511	87089900	18
300068855BSG	Solis Tractor 3 CYL FENDER FOR NON ROPS RH TC_ MAG IIIn	15672	87089900	18
300068855CSG	Solis Tractor 3 CYL FENDER FOR NON ROPS RH TC_ MAG IIIn	9500	87089900	18
300070080ASG	Solis Tractor FIXED GEAR 5TH Z-50 (FINISH NO.)	1836	87084000	18
300070090ASG	Solis Tractor FIXED GEAR 5TH Z-51 (FINISH NO.)	2023	87084000	18
300070103ASG	Solis Tractor DOG CLUTCH GEAR 5TH ASSY. Z-17	1096	87084000	18
300070104ASG	Solis Tractor DOG CLUTCH GEAR 5TH ASSY. Z-17	819	87084000	18
300076437BSG	Solis Tractor FEATHERING VALVE ASSY	9442	84814000	18
300082044ASG	Solis Tractor HEAD SPOOL	114	87089900	18
300083767ASG	Solis Tractor STICKERÂ SOLIS 5015 LH	40	39191000	18
300083770ASG	Solis Tractor STICKERÂ SOLIS 4515 LH	40	39191000	18
300083775ASG	Solis Tractor BADGE SOLIS GT	323	83100010	18
300083777ASG	Solis Tractor STICKERÂ SOLIS 5015 RH	40	39191000	18
300083781ASG	Solis Tractor STICKERÂ Â SOLIS 4515 RH	40	39191000	18
300084215ASG	Solis Tractor STICKERÂ SOLIS CHROME FRONT LH	39	39191000	18
300084216ASG	Solis Tractor STICKERÂ SOLIS CHROME BACK LH	50	39191000	18
300084217ASG	Solis Tractor BADGE SOLIS LH	710	83100010	18
300084218ASG	Solis Tractor STICKERÂ SOLIS CHROME BACK RH	39	39191000	18
300084219ASG	Solis Tractor STICKERÂ SOLIS CHROME BACK RH	50	39191000	18
300086390ASG	Solis Tractor OIL SEAL (50X68X8)	57	40161000	18
300086570ASG	Solis Tractor BULL GEAR (Z-56) (PART NO.)	11538	87084000	18
300086593ASG	Solis Tractor AIR CLEANER MTG BKT	186	87089900	18
300087610BSG	Solis Tractor DASHBOARD ASSY RX FL(TC_ MAG RED II ND BC	7142	87089900	18
300089732ASG	Solis Tractor PCDC COVER	717	87089900	18
300089732BSG	Solis Tractor PCDC COVER	717	87089900	18
300090570ASG	Solis Tractor FLOOR MOUNTING BRACKET ASSEMBLY LH	825	87089900	18
300090684ASG	Solis Tractor SENSOR SPRING	710	73201011	18
300090684BSG	Solis Tractor SENSOR SPRING	728	73201011	18
300090684CSG	Solis Tractor SENSOR SPRING	727	87089900	18
300090753ASG	Solis Tractor RUBBER BOOT	304	84213990	18
300092738ASG	Solis Tractor FEATHERING VALVE ASSY	7277	84811000	18
300094178ASG	Solis Tractor Loctite 5182 (850mL)	19	35069999	18
300094634ASG	Solis Tractor HEAD GASKET FOR EXHAUST ELBOW4 MTG	41	84841010	18
300094634BSG	Solis Tractor HEAD GASKET FOR EXHAUST ELBOW4 MTG	51	84841090	18
300094643ASG	Solis Tractor GASKET_Exhaust	36	84841010	18
300094675ASG	Solis Tractor FUEL FILLER LID ASSEMBLY	645	87089900	18
300094845ASG	Solis Tractor LOCK ASSEMBLY	106	83012000	18
300097727ASG	Solis Tractor HEX HEAD SCREW M6X55 8-8 SA2JS	8	73181500	18
300107110ASG	Solis Tractor SIDE CENTER PANEL ASSY. 3 CYL LH	452	39269099	18
300107111ASG	Solis Tractor SIDE CENTER PANEL ASSY. 3 CYL RH	452	39269099	18

300107113ASG	Solis Tractor SIDE CENTER PANEL ASSY. 4CYL LH	490	87089900	18
300109052CSG	Solis Tractor REAR COVER (CASTING	11276	84213990	18
300109276CSG	Solis Tractor OIB ASSY LEFT (3 CYL.)	14722	87081010	18
300111332ASG	Solis Tractor POWER STEERING COLUMN	2757	87089400	18
300112020ASG	Solis Tractor DRAFT LEVER	399	87089900	18
300112977ASG	Solis Tractor TRUMPET HOUSING (FINISH)	12240	87085000	18
300114267ASG	Solis Tractor REARÂ VIEWÂ MIRRORÂ ASSYÂ RH (SOLIS)	827	70091090	18
300114868ASG	Solis Tractor SHUTTLE LEVER ASSY	273	87089900	18
300115396ASG	Solis Tractor POSITION LEVER	389	87089900	18
300115453ASG	Solis Tractor TIE ROD ASSTIE ROD ASSY CA SHAFT TO HUB	354	87084000	18
300115697ASG	Solis Tractor SHIELD PLATE LH W/O PAINT	333	87089900	18
300117623BSG	Solis Tractor TIE ROD IDLER HUB TO TRANSMISSION	134	87089900	18
300117664ASG	Solis Tractor RADIATOR TOP SEALING PLATE ASSY	340	87089900	18
300119657ASG	Solis Tractor BELL HSG. (3-CYL) FINISH	14975	87085000	18
300119840ASG	Solis Tractor IPTO LEVER	284	87084000	18
300121009BSG	Solis Tractor DRIVER SEAT ASSY SOLIS	8496	94012000	18
300121223ASG	Solis Tractor ZF MOUNTING BKT PS FOR IPTO	2113	87089400	18
300122496ASG	Solis Tractor RADIATOR ASSEMBLY 4 CYL	16829	87089100	18
300122496BSG	Solis Tractor RADIATOR ASSY.4 CYLENDER	20155	87089100	18
300122496CSG	Solis Tractor RADIATOR ASSY. 4 CYLENDER	16829	87089100	18
300123041ASG	Solis Tractor BRAKE HOUSING LEFT	5827	87083000	18
300123050ASG	Solis Tractor BRAKE HOUSING RIGHT (FINISH)	5857	87083000	18
300129582ASG	Solis Tractor STICKER SOLIS 4215 RH	39	39191000	18
300129584ASG	Solis Tractor STICKER SOLIS 4215 LH	39	73061929	18
300130972CSG	Solis Tractor CRANK DRAFT ASSY	120	87089900	18
300138378ASG	Solis Tractor INPUT SHAFT Z24 SOLIS	2727	87084000	18
300138378BSG	Solis Tractor INPUT SHAFT Z25 SOLIS GT26	1774	87084000	18
300139748ASG	Solis Tractor REAR TAIL LAMP ASSY.LH	1035	85122020	18
300139749ASG	Solis Tractor REAR TAIL LAMP ASSY. RH	1035	85122020	18
300143724BSG	Solis Tractor FRONT COVER 4WD ASSEMBLY.	519	87089900	18
300143744BSG	Solis Tractor REAR COVER 4WD ASSEMBLY.	457	87089900	18
300144350ASG	Solis Tractor BULB HB3 12V 60W_005.635-301	772	85129000	18
300146498ASG	Solis Tractor INNER BUSH ASSY 1	569	87084000	18
300146498BSG	Solis Tractor INNER BUSH ASSY 1	680	40161000	18
300146542ASG	Solis Tractor INNER BUSH ASSY 2 FOR MHI	483	87084000	18
300146665ASG	Solis Tractor HARNESS ASSY	7145	85443000	18
300146665BSG	Solis Tractor HARNESS ASSY	6853	85446090	18
300146970ASG	Solis Tractor UNIVERSAL JOINT COVER LH -SOLI	57	87089900	18
300146973ASG	Solis Tractor UNIVERSAL JOINT COVER RH -SOLI	57	87089900	18
300154094BSG	Solis Tractor POSITION LEVER SOLIS	50	87089900	18
300155650BSG	Solis Tractor KNOB POSITION LEVER	55	87089900	18
300155652BSG	Solis Tractor KNOB DRAFT LEVER	80	87089900	18
300156620ASG	Solis Tractor ROCKER LINK ASSY.	1729	87084000	18
300162754ASG	Solis Tractor SPRING SENSOR	706	73201011	18
300166416BSG	Solis Tractor TAIL PINION & CROWN WHEEL SET (12*38)	11167	87089900	18
300169027ASG	Solis Tractor SOLIS FRONT AXLE 4WD OIL 1LT.	438	87081010	18
300169028ASG	Solis Tractor SOLIS FRONT AXLE 4WD OIL 5LT.	2159	87081010	18
300176439ASG	Solis Tractor BULL GEAR Z-56 (FINISH)	12614	87084000	18
300177331ASG	Solis Tractor FRONT WHEEL RIM 4.5X16 (GOLDEN BEIGE)	3472	87087000	18
300177334ASG	Solis Tractor REAR WHEEL RIM W13X28(GOLDEN BEIGE)	15462	87087000	18
300181971ASG	Solis Tractor LIFT ROD ASSY.	946	87089900	18

300182001BSG	Solis Tractor RADIATOR COWL RX	578	87089100	18
300182001CSG	Solis Tractor RADIATOR COWL RX	791	87085000	18
300183983CSG	Solis Tractor FEATHERING VALVE ASSY	8196	84818090	18
300190851ASG	Solis Tractor NEUTRAL SAFETY SWITCH	332	85361010	18
300193003ASG	Solis Tractor COVER 4WD (FINISH NO.)	478	87085000	18
300196024ASG	Solis Tractor RADIATOR PRESSURE CAP	0	84210000	18
300196836ASG	Solis Tractor BULB 12V W60 HB3	0	94012000	18
300207898ASG	Solis Tractor PTO OUTPUT SHAFT (FINISH NO.)	1561	87084000	18
300248599ASG	Solis Tractor DRIVE SHAFT Z-18 DOUBLE CLUTCH FINISH	3327	87084000	18
300248972ASG	Solis Tractor DRIVE SHAFT Z-18 DUAL CLUTCH FINISH	3822	87084000	18
300249383BSG	Solis Tractor FRONT AXLE BEAM	12578	87089900	18
300255971ASG	Solis Tractor Ø280 DUAL CLUTCH ASSEMBLY (3CYL)	13387	87089300	18
300268993ASG	Solis Tractor SHIFTER BUSH HI SHIFTER FORK LOW MEDIU	1000	87089900	18
300289341ASG	Solis Tractor MUFFLER ASSY	2605	85443000	18
300316581ASG	Solis Tractor LYNCH PIN FOR STAY BAR ASSY	110	87089900	18
300320281ASG	Solis Tractor MUFFLER MESH GUARD	531	87084000	18
300349661ASG	Solis Tractor ASSY PROTECTION GUARD 4 CYL RH BLACK PAI	266	87089900	18
300349960ASG	Solis Tractor ASSY PROTECTION GUARD 4 CYL LH BLACK PAI	297	87089900	18
300358398ASG	Solis Tractor SEAL KIT OIPL_10008355AD	4482	87085000	18
40000642AASG	Solis Tractor FRONT WHEEL ASSY. WITH BOLTED DISC W 8-2	16776	87087000	18
40000735BBSG	Solis Tractor HYD.HOSE FROM RIGID PIPE TO R.H STR. CYL	596	40091100	18
700408113ASG	Solis Tractor HIGH PRESSURE PIPE (Ø1.8xØ6x500)4th.cyl	331	40161000	18
700408113CSG	Solis Tractor HIGH PRESSURE PIPE(Ã~1.8XÃ~6X500)3rd.	411	84099111	28
703002016ASG	Solis Tractor GASKET (SIDE COVER)	90	40161000	18
703008219ASG	Solis Tractor FUEL FILTER CARTRIDGE_ GARDEN TRACK	204	84213990	18
703013047BSG	Solis Tractor SUPPORT BRACKET_ Radiator (mwp)	51	87089900	18
703401071ASG	Solis Tractor BEARING LINER ¥76 (TOP) CU	139	84830000	18
703401072ASG	Solis Tractor BEARING LINER ¦#76 (BOTTOM) CU	139	84830000	18
703401073ASG	Solis Tractor BEARING LINER ¦#76 (REAR TOP)	189	84833000	18
703401074ASG	Solis Tractor Bearing Liner Ø76 (Rear-Bottom) Cu	137	84833000	18
703401080ASG	Solis Tractor THRUST BEARING (TOP-1) CU	87	84820000	18
703401087ASG	Solis Tractor CYLINDER LINER SEALING (Ã~105)	28	40161000	18
703401093ASG	Solis Tractor Thrust Bearing (Bottom-1) Cu	86	84833000	18
703401096ASG	Solis Tractor THRUST BEARING (TOP-2) CU	80	84820000	18
703402104BSG	Solis Tractor SHAFT Ã~35(11 Spline-Both side)Hyd. Pump	409	84831099	18
703402263CSG	Solis Tractor FRONT COVER (Almn.)_For Power Steering	2628	84833000	18
703402263ESG	Solis Tractor FRONT COVER (Almn.)_For Power Steering	4086	84099199	28
703403116ASG	Solis Tractor PISTON PIN	350	84099111	28
703403116BSG	Solis Tractor PISTON PIN-Ø35x80	427	84099111	28
703403161ASG	Solis Tractor PISTON OIL RING-3RD.(Ø102) HTCR	258	84099113	28
703403164BSG	Solis Tractor PISTON Ã~105 'P' Type	2445	84099111	28
703403166ASG	Solis Tractor BIG-END LINER Ø64_ CONN ROD (CU)	93	84834000	18
703403324ASG	Solis Tractor PISTON RING TOP_Ø73(FM) GARDENTRAC	274	84099111	28
703403325ASG	Solis Tractor PISTON RING COMPRESSSION Ø73(FM)GARDENTR	125	84099111	28
703404061GSG	Solis Tractor CAM GEAR (¥30)	858	84830000	18
703405057GSG	Solis Tractor GASKET CYL. HEAD (NA)	123	84841010	18
703405067ESG	Solis Tractor GASKET (EXHAUST FLANGE+CYL. HEAD)	24	84841010	18
703405377ASG	Solis Tractor GASKET_cylinder head (NA) NRT	198	84841010	18
703405377BSG	Solis Tractor GASKET CYLINDER HEAD (NA) NRT	121	84841010	18
703406122ASG	Solis Tractor Inter-mediate PLATE w.pump (mwp)	695	84131990	28
703413010BSG	Solis Tractor HOSE (RETURN LINE TO THERMOSTAT)	113	40091100	18

703413010CSG	Solis Tractor HOSE (RETURN LINE TO THERMOSTAT)	136	40091100	18
703413034BSG	Solis Tractor HOSE (Thermostat TO water pump)	91	40091100	18
703413034CSG	Solis Tractor HOSE (THERMOSTAT TO WATER PUMP)	108	40091100	18
703414100ASG	Solis Tractor HEX SOCKET CAP SCREW M5X20	9	73182300	18
723415122ASG	Solis Tractor LOCTITE 5060 _SILICONE SEALANT (Engine)	11	35069999	18
800402010BSG	Solis Tractor SIDE COVER Assy _Almn(with Breather) 4cyl	500	87089900	18
803402017BSG	Solis Tractor HYD. PUMP ASSY. _4 Mtg. (9.5cc) Lift	4015	84138190	18
803405068ESG	Solis Tractor CYL. HEAD _IW (Assy) `P' Type -Ã~100,102	7431	84099111	28
803405070HSG	Solis Tractor CYL. HEAD _IW (ASSY.) `P' TYPE -Ø105	6396	84099111	28
803406065CSG	Solis Tractor WATER PUMP ASSY. _V-Ø103-TC (MWP)	4173	84131990	28
803412033ASG	Solis Tractor AIR CLEANER ASSY. Dry Type (6" _Domestic)	2737	84213990	18
903403028ASG	Solis Tractor PISTON RING-1st.Ã~105	390	84099111	28
903403029ASG	Solis Tractor PISTON RING-2nd.Ã~105	117	84099111	28
903403030ASG	Solis Tractor PISTON RING-3rd.Ã~105	364	84099111	28
903403030BSG	Solis Tractor PISTON RING-3RD. DIA.105	219	84099913	28
903403053ASG	Solis Tractor PISTON Ã~102- `P'Type	2074	84099111	28
903403093ASG	Solis Tractor PISTON Ø105 (C R _16.4)	3178	84099111	28
903408044BSG	Solis Tractor STICKER (FILTER) 0.7LT.	18	39199010	18
00007442SG	Solis Tractor DUMMY GEAR BOX ASSY 7336	140939	87089900	18
040000209AASG	Solis Tractor WHEEL TYRE(REAR)13.6"*28"	45979	40117000	18
040000210AASG	Solis Tractor WHEELTYRE(REAR)16.9"*28"	62507	40117000	18
040000211AASG	Solis Tractor WHEEL TYRE (REAR) 14.9*28"	57475	40117000	18
040000212AASG	Solis Tractor WHEEL TYRE (FRONT)6"*16"	8333	40117000	18
040000214AASG	Solis Tractor WHEEL TYRE(FRONT)7.5"*16"	15632	40117000	18
040000252AASG	Solis Tractor WHEEL TUBE(FRONT)6"*16"	935	40139049	18
040000254AASG	Solis Tractor WHEEL TUBE (FRONT)7.5"*16"	1616	40139049	18
040000258AASG	Solis Tractor WHEEL TUBE (REAR)13.6"*28"	4767	40139049	18
040000259AASG	Solis Tractor WHEEL TUBE (REAR)16.9"*28"	6978	40139049	18
040000260AASG	Solis Tractor WHEEL TUBE (REAR)14.9"*28"	6187	40139049	18
04000130055SG	Solis Tractor RADIAL B/BEARING 30x55x13 (6006)	345	84820000	18
04000217040SG	Solis Tractor RADIAL B/BEARING 17/40X12 (6203)	154	84820000	18
04000417040SG	Solis Tractor RADIAL B/BEARING 17/40x12 (6203ZZ)	234	84824000	18
04000430062SG	Solis Tractor RADIAL B/BEARING 30/62X16 (6206NR)	505	84824000	18
04000635062AASG	Solis Tractor THRUST BEARING 51207	290	84833000	18
04000725052SG	Solis Tractor TAPPER ROLLER BRG 30205 (DIA25*52*16.25)	451	84822090	18
04000730062SG	Solis Tractor TAPPER ROLLER BRG 32206	379	84822090	18
04000760110SG	Solis Tractor TAPPER ROLLER BRG. 32212 (N)	1028	84822090	18
04000970120SG	Solis Tractor TAPPER ROLLER BEARING(482/472)69.85*120	1159	84822090	18
04001142046SG	Solis Tractor NEEDLE CAGE BEARING 46X42X51.4	386	84824000	18
04001230038SG	Solis Tractor NEEDLE BUSH DL - 3020	133	84824000	18
04001235043SG	Solis Tractor NEEDLE BUSH DL3516	278	84824000	18
04001245052SG	Solis Tractor NEEDLE BUSH DL - 455220P	336	84824000	18
04001400005SG	Solis Tractor STEEL BALL DIA 5	7	84829119	18
04001400006SG	Solis Tractor STEEL BALL 1/4	7	84829119	18
04001400008SG	Solis Tractor STEEL BALL 5/16	8	84829119	18
04001400013SG	Solis Tractor STEEL BALL 1/2	12	84829119	18
04001760110SG	Solis Tractor SPHERICAL ROLLER BEARING 60*110*28	1949	84824000	18
04010102025SG	Solis Tractor SPLIT PIN DIA 2*25	7	73182300	18
04010103050SG	Solis Tractor SPLIT PIN DIA 3*50	11	73182300	18
04010104025SG	Solis Tractor SPLIT PIN DIA 4*25	8	73182300	18
04010104040SG	Solis Tractor SPLIT PIN DIA 4*40	8	73182300	18

04010105040SG	Solis Tractor SPLIT PIN DIA 5*40	11	73182300	18
04010208014SG	Solis Tractor CYLINDRICAL PIN 8m6x14	11	87089900	18
04010208030SG	Solis Tractor CYLINDRICAL PIN DIA 8*30	27	73182300	18
04010305015SG	Solis Tractor SPRING COTTER SLEEVE DIA 5	10	73201011	18
04010305025SG	Solis Tractor SPRING COTTER SLEEVE DIA 5 * 25	11	73201011	18
04010305040SG	Solis Tractor SPRING COTTER SLEEVE DIA 5 * 40	14	73201011	18
04010305063SG	Solis Tractor SPRING COTTER SLEEVE DIA 5*63	12	73201011	18
04020100034SG	Solis Tractor INTERNAL CIRCLIP B - 34	11	73182300	18
04020100035SG	Solis Tractor INTERNAL CIRCLIP B-35	16	73182300	18
04020100040SG	Solis Tractor INTERNAL CIRCLIP B-40	15	73182300	18
04020100062SG	Solis Tractor INTERNAL CIRCLIP B-62	28	73182300	18
04020100072SG	Solis Tractor INTERNAL CIRCLIP B - 72	45	73182300	18
04020100080SG	Solis Tractor INTERNAL CIRCLIP B - 80	50	73182300	18
04020100090SG	Solis Tractor INTERNAL CIRCLIP B - 90	73	73182300	18
04020100100SG	Solis Tractor INTERNAL CIRCLIP DIA 100	88	73182300	18
04020200016SG	Solis Tractor EXTERNAL CIRCLIP A-16	11	73182300	18
04020200017SG	Solis Tractor EXTERNAL CIRCLIP A-17	7	73182300	18
04020200019SG	Solis Tractor INTERNAL CIRCLIP A-19	12	73182300	18
04020200020SG	Solis Tractor EXTERNAL CIRCLIP A-20	8	73182300	18
04020200022SG	Solis Tractor EXTERNAL CIRCLIP A-22	10	73182300	18
04020200030SG	Solis Tractor EXTERNAL CIRCLIP A - 30	14	73182300	18
04020200032SG	Solis Tractor EXTERNAL CIRCLIP A - 32	14	73182300	18
04020200035SG	Solis Tractor EXTERNAL CIRCLIP A-35	15	73182300	18
04020200040SG	Solis Tractor EXTERNAL CIRCLIP A - 40	18	73182300	18
04020200050SG	Solis Tractor EXTERNAL CIRCLIP - 50	29	73182300	18
04020200055SG	Solis Tractor EXTERNAL CIRCLIP A - 55	28	73182300	18
04020200060SG	Solis Tractor EXTERNAL CIRCLIP A - 60	41	73182300	18
04020400007SG	Solis Tractor CIRCLIP E-7	9	73182300	18
04020400012SG	Solis Tractor CIRCLIP C-12	11	73182300	18
04030208012SG	Solis Tractor SEALING RING 8/12X1-Cu	7	73182300	18
04030210013SG	Solis Tractor COPPER WASHER DIA 10.2*DIA13.4*1	11	87081010	18
04030210014SG	Solis Tractor Copper sealing ring - 10.2x13.4x1	10	87081010	18
04030212015SG	Solis Tractor SEALING WASHER DIA 12.2 * DIA 15.4 * 1.5	10	73182300	18
04030214018SG	Solis Tractor SEALING WASHER DIA 14.2*DIA17.9*1.5	11	40161000	18
04030214020SG	Solis Tractor SEALING WASHER DIA14.2*DIA19.9*1.5	15	73182300	18
04030216020SG	Solis Tractor SEALING WASHER DIA 16.2 * DIA 20 * 1.5	16	73182300	18
04030216022SG	Solis Tractor SEALING RING 16/22X1.5-Cu	11	40161000	18
04030218024SG	Solis Tractor SEALING RING 18x24x1.5-Cu	14	40161000	18
04030220026SG	Solis Tractor SEALING RING 20/26x1.5-Cu	15	40161000	18
04030222027SG	Solis Tractor SEALING RING 22/27X1.5-CU	13	40161000	18
04030222029SG	Solis Tractor SEALING WASHER DIA 22.2 * DIA 29 * 1.5	21	73182300	18
04030224032SG	Solis Tractor SEALING WASHER DIA 24.3 * DIA 32 * 2	34	40161000	18
04030226032SG	Solis Tractor SEALING RING 26/32X2-Cu	17	40161000	18
04030300006SG	Solis Tractor PUNCHED WASHER M6	6	73182300	18
04030300008SG	Solis Tractor PUNCHED WASHER M8	6	73182300	18
04030300010SG	Solis Tractor PUNCHED WASHER M10	7	73182300	18
04030400005SG	Solis Tractor SPRING WASHER B - 5	7	73182300	18
04030400006SG	Solis Tractor SPRING WASHER B-6	7	73182300	18
04030600005SG	Solis Tractor PLAIN WASHER DIA 5.3 *DIA 15*1.5	7	73182300	18
04030600006SG	Solis Tractor PLAIN WASHER DIA 6.4 *DIA 18 *1.5	8	73182300	18
04030600008SG	Solis Tractor PLAIN WASHER DIA 8.4 *DIA 17*1.6	8	73182300	18

04030600010SG	Solis Tractor PLAIN WASHER DIA 10.5 *DIA 30 *2.5	11	73182300	18
04030700019SG	Solis Tractor PUNCHED WASHER DIA 19.5 *DIA 33 *3	14	73182300	18
04030800006SG	Solis Tractor M/CD WASHER DIA 6.4 *DIA 12.4*1.6	6	73182300	18
04030800008SG	Solis Tractor M/CD WASHER DIA 8.4 *DIA 17*1.6	8	73182300	18
04030800010SG	Solis Tractor M/CD WASHER	7	73182300	18
04030800012SG	Solis Tractor M/CD WASHER DIA 13 *DIA 24*2.5	11	73182300	18
04030800017SG	Solis Tractor PUNCHED WASHER DIA 17 * DIA 30 * 3	12	73182300	18
04030900014SG	Solis Tractor M/CD WASHER DIA 15 *DIA 27*2.5	9	73182300	18
04031021026SG	Solis Tractor SEALING WASHER DIA 21* DIA26*1.5	15	73182300	18
04031030036SG	Solis Tractor SEALING WASHER DIA30*36*2	31	73182300	18
04031300008SG	Solis Tractor PUNCHED WASHER M8 (TRIVALENT)	4	73182990	18
04031400008SG	Solis Tractor HELICAL SPRING LOCK WASHER 08 AC SA2JD	7	73182300	18
04031400012SG	Solis Tractor SPRING WASHER B-12 (BLACKNED)	8	73182300	18
04032618022SG	Solis Tractor SEALING WASHER DIA 18.2*DIA 22*1.5(CU)	16	73182300	18
04040105016SG	Solis Tractor HEX SCREW M5X16-Z	7	73182300	18
04040106016SG	Solis Tractor HEX SCREW M6*16	10	73182300	18
04040106030SG	Solis Tractor HEX SCREW M6*30	12	73182300	18
04040108020SG	Solis Tractor HEX. HEAD BOLT M8 X 1.25-20(8-8) SA2JS	9	73182300	18
04040108025SG	Solis Tractor HEX. HEAD SCREW M8 X 1.25-25 8-8 SA2JS	9	73182300	18
04040108035SG	Solis Tractor HEX SCREW M8*1.25*35	14	73182300	18
04040110020SG	Solis Tractor Hex. head screw M10 x 1.50-20 8-8 SA2JS	14	73182300	18
04040110030SG	Solis Tractor HEX SCREW M10*30	12	73182300	18
04040210040SG	Solis Tractor Hex Head Screw M10x40-Z	12	73182300	18
04040305025SG	Solis Tractor SOCKET HEAD CAP SCREW M5*25	12	73182300	18
04040306016SG	Solis Tractor ALLEN BOLT M6X1PX16L_8.8	6	73182300	18
04040308016SG	Solis Tractor SOCKET HEAD CAP SCREW M8X16	12	73182300	18
04040308025SG	Solis Tractor HEX SOCKET HEAD CAP SCREW M8*25	15	73182300	18
04040308035SG	Solis Tractor SOCKET HEAD CAP SCREW-M8x35	12	73182300	18
04040310030SG	Solis Tractor SOCKET HEAD CAP SCREW-M10x30	21	73182300	18
04040408025SG	Solis Tractor Stud M8 x 1.25 - 25 10.9 TYPE C Phos-Z	11	73182300	18
04040408030SG	Solis Tractor STUD M8 X 1.25 - 30 10.9 TYPE C PHOS-Z	12	73182300	18
04040408040SG	Solis Tractor Stud M8 x 1.25 - 40 10.9 TYPE C Phospha	17	73182300	18
04040408055SG	Solis Tractor STUD M8 X 1.25 - 55 - 10.9 TYPE C PHOS-Z	14	73182300	18
04040706040SG	Solis Tractor M6*40	12	73182300	18
04040706045SG	Solis Tractor HEX BOLT M6*45	10	73182300	18
04040708030SG	Solis Tractor HEX. HEAD BOLT M8 X 1.25-30 8-8 SA2JS-Z	10	73182300	18
04040708035SG	Solis Tractor HEX BOLT M8X35-Z	11	73182300	18
04040708055SG	Solis Tractor HEX BOLT M8x55-Z	13	73182300	18
04040708100SG	Solis Tractor HEX BOLT M8X100-Z	18	73182300	18
04040710035SG	Solis Tractor Hex Bolt M10x35-Z	17	73182300	18
04040710040SG	Solis Tractor HEX BOLT M10*1.5*40	16	73182300	18
04040710050SG	Solis Tractor Hex Bolt M10x50	18	73182300	18
04040710065SG	Solis Tractor H.H.Bolt M10X65	27	73182300	18
04040710070SG	Solis Tractor Hex. head Bolt M10 x 1.5-70 8-8 SA2JS-Z	22	73182300	18
04040710085SG	Solis Tractor Hex Bolt M10x85-Z	31	73182300	18
04040710130SG	Solis Tractor HEX BOLT M10X130	42	73182300	18
04040712035SG	Solis Tractor HEX BOLT M12X35-Z	21	73182300	18
04040712040SG	Solis Tractor Hex Bolt M12x40-Z	21	73182300	18
04040714060SG	Solis Tractor HEX BOLT M14*2*60	47	73182300	18
04040800008SG	Solis Tractor NUT H M8 X 1.25 8 SA2JS	7	73182300	18
04040800012SG	Solis Tractor HEX NUT M12*1.75	12	73182300	18

04041000006SG	Solis Tractor HEX NYLOC NUT M6	7	73182300	18
04041000008SG	Solis Tractor HEX NYLOCK NUT M8*1.25	11	73182300	18
04041106035SG	Solis Tractor HEX. HEAD SCREW M6 X 1.00-35 8-8 SA2JS	9	73182300	18
04041108016SG	Solis Tractor Hex Screw M8x16-Z	9	73182300	18
04041114030SG	Solis Tractor HEX SCREW M14*30	25	73182300	18
04041116035SG	Solis Tractor HEX SCREW M16*1.5*35	66	73182300	18
04041208030SG	Solis Tractor HEX BOLT M8*1*30	12	73182300	18
04041410030SG	Solis Tractor STUD-C M10x30	25	73182300	18
04041500012SG	Solis Tractor HEX LOCK NUT M12	11	73182300	18
04042610035SG	Solis Tractor STUD M10*1.5*35	17	73182300	18
04042612032SG	Solis Tractor STUD M12 * 1.75 * 32	27	73182300	18
04042612037SG	Solis Tractor STUD M12*1.75*37	22	73182300	18
04042612042SG	Solis Tractor STUD M12*1.75*42	29	73182300	18
04042612057SG	Solis Tractor STUD M12*1.75*57	28	73182300	18
04042904015SG	Solis Tractor SLOTTED CHEESE HD SCREW M4*15	7	73182300	18
04042905012SG	Solis Tractor SLOTTED CHEESE HD SCREW M5*12	8	73182300	18
04042905025SG	Solis Tractor SLOTTED CHEESE HD SCREW M5*25	7	73182300	18
04042905030SG	Solis Tractor SLOTTED CHEESE HD SCREW M5*30	7	73182300	18
04042906045SG	Solis Tractor SLOTTED CHEESE HD SCREW M6*45	9	73182300	18
04043200008SG	Solis Tractor GREASE NIPPLE WITH CAP M8*1	16	87081010	18
04050206020SG	Solis Tractor KEY 'A' 6x6x20	13	87081010	18
04050210055SG	Solis Tractor KEY 'A' 10h9x8x55	28	87081010	18
04070218030SG	Solis Tractor OIL SEAL 30*18*7	27	40161000	18
04070225035SG	Solis Tractor OIL SEAL 35*25*7	36	40161000	18
04070235020SG	Solis Tractor OIL SEAL(035020) 20*35.2*7	42	40161000	18
04070250068SG	Solis Tractor OIL SEAL 50*68*10	97	40161000	18
04070263082SG	Solis Tractor OIL SEAL 82.6*63.5*10	60	40161000	18
04080100005SG	Solis Tractor BANJO BOLT B5	14	73182300	18
04080100010SG	Solis Tractor BENJO BOLT M10*1*19	16	73182300	18
04080100012SG	Solis Tractor BANJO BOLT M12*1.5	21	73182300	18
04080100014SG	Solis Tractor BENJO BOLT M14*1.5*26	29	73182300	18
04080100022SG	Solis Tractor BANJO BOLT M22*1.5*39	74	73182300	18
04080101006SG	Solis Tractor BANJO BOLT B6 (M10x1)	20	73182300	18
04080101010SG	Solis Tractor Banjo Screw B10 - M14 x 1.5	32	73182300	18
04080400020SG	Solis Tractor WORM DRIVE HOSE CLAMP-14 - 20A	18	73182300	18
04080400025SG	Solis Tractor WORM DRIVE HOSE CLAMP-25A	17	73261910	18
04080400036SG	Solis Tractor HOSE WARM CLIP DIA 36	19	73261910	18
04080400050SG	Solis Tractor WORM DRIVE HOSE CLAMP-50A	21	73182300	18
04080400060SG	Solis Tractor HOSE WARM CLIP DIA 60	24	73261910	18
04080400070SG	Solis Tractor HOSE WARM CLIP DIA 70	22	73261910	18
04080700014SG	Solis Tractor SPL BENJO BOLT M14*1.5*M10*1*26	31	73182300	18
04080700016SG	Solis Tractor BENJO BOLT M16*1.5*28 (4 HOLES)	35	73182300	18
042300207AAS	Solis Tractor GREASE M.P	0	27101990	18
10000257ABSG	Solis Tractor SEALING PLUG M16*1.5	46	87089900	18
10000267AASG	Solis Tractor LOCKING WASHER	19	73182300	18
10000268AASG	Solis Tractor WITHDRAWL NUT M50*1.5	129	73182300	18
10000269AASG	Solis Tractor WASHER FOR LAY SHAFT	80	73182300	18
10000460AFSG	Solis Tractor DRAIN PLUG ASSY	179	87089900	18
10000477AASG	Solis Tractor DUST COVER	17	73182300	18
10000608ABSG	Solis Tractor PLUG M14*1.5 (REPOSE VALVE ASSY)	46	73182300	18
10000636AASG	Solis Tractor RIVET DIA 3 (POP)	8	76161000	18

10000690ADSG	Solis Tractor O-RING Ã~24.7xÃ~1.9	12	40161000	18
10000751ABSG	Solis Tractor O-RING DIA 51.8XDIA 5.5	66	40161000	18
10000774ABSG	Solis Tractor DRAFT INDICATION STRIP	17	87089900	18
10000775ABSG	Solis Tractor POSITION INDICATION STRIP	17	87089900	18
10001046ACSG	Solis Tractor SPECIAL BOLT (M18*1.5)	98	73182300	18
10001047BDSG	Solis Tractor LOCKING WASHER	20	73181600	18
10001056AASG	Solis Tractor SHIM(REAR AXLE)	8	87085000	18
10001056BBSG	Solis Tractor SHIM (REAR AXLE)	7	73182910	18
10001057AASG	Solis Tractor SHIM(REAR AXLE)	8	87085000	18
10001057BBSG	Solis Tractor SHIM (REAR AXLE)	6	73182910	18
10001058AASG	Solis Tractor SHIM(REAR AXLE)	10	87085000	18
10001058BBSG	Solis Tractor SHIM (REAR AXLE)	8	73182910	18
10001059AASG	Solis Tractor SHIM(REAR AXLE)	10	87085000	18
10001059BBSG	Solis Tractor SHIM (REAR AXLE)	7	73182910	18
10001128AASG	Solis Tractor PIN (3 POINT LINK)	121	73182300	18
10001128ABSG	Solis Tractor PIN (3 POINT LINK)	121	73182300	18
10001142AASG	Solis Tractor GASKET FOR TRUMPET COVER	16	84841010	18
10001225ABSG	Solis Tractor O RING FOR SEAL CARRIER	87	40161000	18
10001691AASG	Solis Tractor TEMP. SENSOR UNIT	261	85361010	18
10001746AASG	Solis Tractor GROMMET(PULL STOP WIRE HOLD IN DASHBOARD	19	40161000	18
10001790ABSG	Solis Tractor CLAMP FOR WIRE HARNESS.	88	87089900	18
10001911BASG	Solis Tractor COVER ASSY (SC)	3995	87089300	18
10001987ABSG	Solis Tractor TAPPER ROLLER BRG. 32212 (T)	841	84824000	18
10002075AASG	Solis Tractor SEALING WASHER	11	73182990	18
10002093ABSG	Solis Tractor WASHER (OIB)	29	73182300	18
10002364AASG	Solis Tractor TSA CLEAR FOR SOLIS MODEL	504	38140010	18
10002365AASG	Solis Tractor THINNER(PU)	233	38140010	18
10002384AASG	Solis Tractor FAN ASSY._ PLASTIC (6 BLADE) Ã~380	485	87089100	18
10002387AASG	Solis Tractor SPACER DIA 72X15	80	87081010	18
10002390AASG	Solis Tractor WASHER (FAN LOCKING)	10	73182300	18
10002398ACSG	Solis Tractor HOSE (RADIATOR TO THERMOSTAT)	129	40091100	18
10002402ADSG	Solis Tractor HOSE (RADIATOR TO W.PUMP)B.SHAFT ENG	278	40091100	18
10002409ACSG	Solis Tractor T-BOLT HOSE CLAMP	128	82050000	18
10002415AASG	Solis Tractor T-BOLT HOSE CLAMP (ID 73.5)	116	73261910	18
10002417ABSG	Solis Tractor DEEP GROOVE BALL BEARING ASSY 6210(TURBO	387	84821011	18
10002428AASG	Solis Tractor STICKER OK FILTER	6	39199010	18
10002664ABSG	Solis Tractor WEAR RING (PADDY SPL)	153	40161000	18
10002668AASG	Solis Tractor FELT RING (STUB AXLE)	14	40161000	18
10002703AASG	Solis Tractor V-BELT (B-48)	382	40101110	18
10003133ACSG	Solis Tractor PLASTIC CAP (SOLIS 3)	10	40161000	18
10003298AESG	Solis Tractor TOOL BOX ASSY (PAINTED)	932	87089900	18
10003341ACSG	Solis Tractor FUEL TANK DRAIN PLUG	59	87089900	18
10003402AASG	Solis Tractor O - RING HOLDER	134	40161000	18
10003403ADSG	Solis Tractor WEAR RING (STUB AXLE)	155	40161000	18
10003404AASG	Solis Tractor WASHER STUB AXLE	67	73182300	18
10003405ABSG	Solis Tractor O-RING DIA 63.18 X DIA 3.1	47	40161000	18
10003409AASG	Solis Tractor FELT RING FOR AXLE ASSY	17	40161000	18
10003410AASG	Solis Tractor FELT RING FOR KING PIN	14	40161000	18
10003422BBSG	Solis Tractor MTG BRACKET (FOR HYD FILTER)	193	87089900	18
10003433AASG	Solis Tractor WRAPPED BUSH	106	84829900	18
10003791AASG	Solis Tractor LOCKING WASHER	12	73182300	18

10003794AASG	Solis Tractor PIN FOR BRAKE LEVER	29	87083000	18
10003795ACSG	Solis Tractor BRAKE SPRING	27	73201011	18
10003803ABSG	Solis Tractor SWIVEL BLOCK	46	87089900	18
10003810BASG	Solis Tractor MAINTENANCE FREE BATTERY (4 CYL)12V 88AH	13521	85070000	28
10003813ABSG	Solis Tractor WASHER (TAIL PINION)	79	73182300	18
10003814AASG	Solis Tractor LOCKING WASHER(TAIL PINION)	16	73182300	18
10003815AASG	Solis Tractor WITHDRAWL NUT (TAIL PINION)	92	73182300	18
10003872BASG	Solis Tractor TIE ROD. (SOLIS1)	179	87089900	18
10003876AASG	Solis Tractor COMPRESSION SPRING	11	73201011	18
10003943AASG	Solis Tractor LOCKING WIRE DIA 2*200	12	73182300	18
10003951ABSG	Solis Tractor SPRING SEAT	11	73200000	18
10003960ACSG	Solis Tractor O-RING FOR C.A.SHAFT	15	40161000	18
10004041AASG	Solis Tractor WHEEL BOLT FRONT	45	73182300	18
10004139AASG	Solis Tractor WASHER (LEVER ASSY)	14	73182300	18
10004163ABSG	Solis Tractor FRONT FORK	63	87089900	18
10004164ABSG	Solis Tractor PIN FOR ACCELATOR DIA 6X20	13	73182300	18
10004171AASG	Solis Tractor SPRING INNER BUSH	19	73201011	18
10004174ADSG	Solis Tractor LIFT ARM PIN	97	87089900	18
10004177ABSG	Solis Tractor PIN FOR ACCELATOR	15	73182300	18
10004210ACSG	Solis Tractor BATTERY CABLE NEGATIVE	563	85442090	18
10004212AASG	Solis Tractor CLAMP	13	82050000	18
10004214AESG	Solis Tractor PLOUGH LAMP ASSY.	925	85122010	18
10004227ACSG	Solis Tractor BRAKE SWITCH	175	85361010	18
10004232ABSG	Solis Tractor CLAMPING STRIP	16	87081010	18
10004235AASG	Solis Tractor CLAMP	16	87089900	18
10004235ABSG	Solis Tractor CLAMP	13	87089900	18
10004236BCSG	Solis Tractor LIGHT FOR REGISTRATION PLATE	388	85122020	18
10004241AASG	Solis Tractor GASKET (FRONT HUB CAP)	16	84841010	18
10004251AASG	Solis Tractor HEX. BOLT FOR FENDER MOUNTING	140	73182300	18
10004251ACSG	Solis Tractor HEX BOLT (FOR FENDER MTG.)	136	73181600	18
10004252AASG	Solis Tractor RUBBER FLAP	145	40161000	18
10004388ACSG	Solis Tractor RUBBER FLAP 410MM	58	40161000	18
10004402AASG	Solis Tractor THRUST WASHER (3.1MM)	131	73182300	18
10004495AASG	Solis Tractor WOODRUFF KEY SPECIAL	40	87081010	18
10004496AASG	Solis Tractor TENSION SPRING (BRAKE & CLUTCH MAJOR ASS	87	73201011	18
10004497AASG	Solis Tractor WASHER BRAKE PEDAL SHAFT	12	73182300	18
10004497ACSG	Solis Tractor WASHER BRAKE PEDAL SHAFT	10	73182990	18
10004498AASG	Solis Tractor FELT RING (BRAKE PEDAL SHAFT)	11	87083000	18
10004503AASG	Solis Tractor TENSION SPRING (CLUTCH PEDAL)	85	87089300	18
10004504ADSG	Solis Tractor STAY BAR MTG BKT (RIGHT)	1148	87089900	18
10004505ADSG	Solis Tractor STAY BAR MTG BKT (LEFT)	1148	87089900	18
10004575ACSG	Solis Tractor SLEEVE	132	87081010	18
10004578BBSG	Solis Tractor HANDLE FOR PARKING BRAKE	473	87083000	18
10004584ACSG	Solis Tractor PIN (FOR SWINGING DRAW BAR)	324	73182300	18
10004588AASG	Solis Tractor FELT PAD F.T. STRIP	12	40161000	18
10004589AASG	Solis Tractor RUBBER BUTTON (SMALL)	15	40161000	18
10004594ABSG	Solis Tractor ROD FOR FUEL TANK STRIP	15	87089900	18
10004600AASG	Solis Tractor RUBBER BUTTON (BIG) FOR FUEL TNK MTG PLT	31	40161000	18
10004656AASG	Solis Tractor LOCKING WIRE DIA. 2*400	14	73182300	18
10004661AASG	Solis Tractor SEALING RING (SUCTION PLATE)	9	40161000	18
10004680ABSG	Solis Tractor HOSE PIPE (SUCTION SIDE)	136	40091100	18

10004686ADSG	Solis Tractor CLUTCH WITH PTO DISC ASSY.	14219	87089300	18
10004704AESG	Solis Tractor OIL FILTER FOR HYD.	296	84219900	18
10004707AASG	Solis Tractor ADOPTER	94	87081010	18
10004729ACSG	Solis Tractor STICKER(FINAL INSPECTION)	10	39199010	18
10004798ACSG	Solis Tractor REAR WHEEL WEIGHT	7227	87087000	18
10004800BASG	Solis Tractor FUEL RETURN PIPE (INJECTOR TO FUEL TANK)	294	40091100	18
10004811AASG	Solis Tractor RUBBER WASHER(FOR FENDER SEAT GURAD)	11	40161000	18
10004824ABSG	Solis Tractor RUBBER BOOT SENSOR	53	40161000	18
10004836ABSG	Solis Tractor ELEMENT OIL LUBRICANT FILTER	242	84213990	18
10004836ACSG	Solis Tractor OIL FILTER ASSY	273	84219900	18
10004837AASG	Solis Tractor RUBBER RING FOR EXHAUST CLAMP ASSY.	8	40161000	18
10004844AASG	Solis Tractor KNOB(FUEL CUT OFF)	21	73182300	18
10004846AASG	Solis Tractor KNOB (ROD ASSY / HANDLER PTO)	21	87089900	18
10004846ABSG	Solis Tractor KNOB (ROD ASSY / HANDLER PTO)	21	87089900	18
10004860AASG	Solis Tractor CLAMPING STRIP	10	87081010	18
10004899AASG	Solis Tractor STICKER OK FILTERED (FOR DRAIN PLUG)	7	39199010	18
10004931AASG	Solis Tractor SPRING SEAT POSITION SECTOR	21	73200000	18
10004958ABSG	Solis Tractor CROSS (DIA 22)	1093	87085000	18
10004984AASG	Solis Tractor PLASTIC STRAP	13	40161000	18
10005008AASG	Solis Tractor DUST CAP	8	87089900	18
10005009ABSG	Solis Tractor RUBBER SLEEVE	12	40161000	18
10005009ACSG	Solis Tractor RUBBER SLEEVE	13	40161000	18
10005010AASG	Solis Tractor STICKER EXTRA HEAVY	9	39199010	18
10005014ABSG	Solis Tractor WASHER	18	73181600	18
10005015ABSG	Solis Tractor NUT	40	73181600	18
10005018AASG	Solis Tractor PIN FOR TRAILER HOOK MTG.	250	73182300	18
10005018ABSG	Solis Tractor PIN FOR TRAILER HOOK MTG.	231	73182300	18
10005019ABSG	Solis Tractor PIN ASSY (FOR TRAILOR HOOK)	421	73182300	18
10005046ACSG	Solis Tractor WHEEL BOLT (REAR)	50	73182300	18
10005046ADSG	Solis Tractor WHEEL BOLT (REAR)	49	73181600	18
10005164ACSG	Solis Tractor RUBBER PAD (FOR PLOUGH LAMP)	14	40161000	18
10005164ADSG	Solis Tractor RUBBER PAD (FOR PLOUGH LAMP)	11	40161000	18
10005187AASG	Solis Tractor LINK PIN	34	87089900	18
10005187ABSG	Solis Tractor LINK PIN	34	87089900	18
10005189AESG	Solis Tractor DRAG LINK ASSY. (DI 60 MECH)	2128	87089900	18
10005191AASG	Solis Tractor HEX. SCREW M14*2*20	32	73182300	18
10005191ABSG	Solis Tractor HEX. SCREW M14*2*20	19	73181600	18
10005206AGSG	Solis Tractor KNOB RV	93	87089900	18
10005331ACSG	Solis Tractor HAND TOOL KIT	819	82060010	18
10005331ADSG	Solis Tractor HAND TOOL KIT	824	82060090	18
10005345AASG	Solis Tractor SPECIAL HEX BOLT M 8*1.25*35	12	73182300	18
10005355ABSG	Solis Tractor ACTUATOR FORK RH	104	87083000	18
10005356ACSG	Solis Tractor ACTUATOR FORK LT	98	87083000	18
10005405ADSG	Solis Tractor MALE QUICK CONNECT COUPLER-1/2BSPUSH	332	84811000	18
10005407AASG	Solis Tractor MALE DUST PLUG-YELLOW SPAV. 13003	86	87089900	18
10005409ADSG	Solis Tractor FEMALE QUICK CONNECT COUPLING-1/2"BSP	758	84814000	18
10005457AASG	Solis Tractor WASHER	7	73182300	18
10005461BBSG	Solis Tractor HORN ASSY (HIGH TONE)	366	85123010	18
10005538AASG	Solis Tractor SPRING INNER BUSH	21	73201011	18
10005563ADSG	Solis Tractor O-RING 25.65X2.4	15	40161000	18
10005585AASG	Solis Tractor RUBBER BOOT (FOR SHIFTER HSG)	16	40161000	18

10005585ABSG	Solis Tractor RUBBER BOOT (FOR SHIFTER HSG)	12	40169310	18
10005613ADSG	Solis Tractor STICKER FOR CORRECT METHOD OF USING LIFT	39	39199010	18
10005625AASG	Solis Tractor WHEEL DISC FASTNERSS SET (1 BOLT+1 NUT)	116	73182300	18
10005626BBSG	Solis Tractor RADIATOR TOP TIE	32	87089100	18
10005647BASG	Solis Tractor FRONT HUB CAP	108	39231010	18
10005665ADSG	Solis Tractor REAR WHEEL WEIGHT	6797	73182300	18
10005680ABSG	Solis Tractor LOCKING WASHER	15	73182300	18
10005689AASG	Solis Tractor DRAW BAR	2364	87089900	18
10005750AMSG	Solis Tractor TOP LINK ASSY.	2576	87089900	18
10005759AASG	Solis Tractor CLAMP(DASH BOARD)	45	82050000	18
10006015ANS	Solis Tractor TRUMPET HOUSING	13465	87085000	18
10006018AESG	Solis Tractor HANDLE FOR PUSH PULL ROD	58	87089900	18
10006022ADSG	Solis Tractor SHIFTER BUSH 1ST/REV.	345	87084000	18
10006023AESG	Solis Tractor SHIFTER BUSH 2ND/3RD	359	87084000	18
10006024AESG	Solis Tractor SHIFTER BUSH 4TH	469	87084000	18
10006043BBSG	Solis Tractor GEAR PTO Z-56	3728	87084000	18
10006050AGSG	Solis Tractor DRIVE SHAFT Z-18 (DUAL CLUTCH) FINISH	3018	87084000	18
10006125AFSG	Solis Tractor C.A.GUIDE DUAL CLUTCH	1094	87084000	18
10006130BCSG	Solis Tractor BEARING HSG FRONT	564	84833000	18
10006132ABSG	Solis Tractor BEARING HSG. REAR 1ST (TRB)	344	84833000	18
10006171AASG	Solis Tractor COVER (BEARING HOUSING FRONT)	322	87084000	18
10006227AASG	Solis Tractor SPACER FOR LAY SHAFT	151	87081010	18
10006229AASG	Solis Tractor SPACER FOR LAY SHAFT	184	87081010	18
10006235BCSG	Solis Tractor SPACER (FOR CONNECTING SHAFT)	110	87081010	18
10006265AASG	Solis Tractor SHIM 0.5	23	73182300	18
10006269AASG	Solis Tractor SHIM 0.4	20	73182300	18
10006269ABSG	Solis Tractor SHIM FOR BEAING HSG REAR SIDE 1ST	20	73182910	18
10006280AASG	Solis Tractor SPECIAL SCREW	38	73182300	18
10006282AASG	Solis Tractor GASKET FOR BOTTOM WINDOW	18	84841010	18
10006282ABSG	Solis Tractor GASKET FOR BOTTOM WINDOW	45	68129922	18
10006283AASG	Solis Tractor GASKET FOR C.A. GUIDE	16	84841010	18
10006284AASG	Solis Tractor GASKET (FOR BEARING HSG FRONT)	16	84841010	18
10006285AASG	Solis Tractor GASKET FOR SHIFTER HSG	37	84841010	18
10006286AASG	Solis Tractor SPRING (GEAR SHIFTER ROD)	12	73201011	18
10006287AASG	Solis Tractor WASHER PTO	34	73182300	18
10006289AASG	Solis Tractor PIN (FOR SHIFTER BUSH SPRING)	25	73182300	18
10006291BCSG	Solis Tractor LOCKING PIN	29	87089900	18
10006292AASG	Solis Tractor SPACER	100	87081010	18
10006295ACSG	Solis Tractor INNER BUSH	498	87081010	18
10006297AASG	Solis Tractor 1GASKET (GEAR BOX REAR SIDE)	54	84841010	18
10006341EDSG	Solis Tractor BELL HSG.	15690	84099199	28
10006342ADSG	Solis Tractor DRIVE SHAFT Z-18 (FOR DOUBLE CLUTCH).	3628	87089300	18
10006349AESG	Solis Tractor C.A.GUIDE DOUBLE CLUTCH	1333	87084000	18
10006350ADSG	Solis Tractor INNER BUSH (TRANSMISSION)	1005	87081010	18
10006351ADSG	Solis Tractor INNER BUSH (PTO)	793	87081010	18
10006367AASG	Solis Tractor SPECIAL NUT(PARKING BRAKE)	11	73182300	18
10006404BCSG	Solis Tractor SHIFTER FORK (1ST-REV & HI-LOW)	772	87084000	18
10006404BDSG	Solis Tractor MMBEER FORK (1ST-REV & HI-LOW)	706	87089900	18
10006406ABSG	Solis Tractor LOCKING WASHER	10	73182300	18
10006448CDSG	Solis Tractor CLUTCH ACTUATOR FORK	892	87089900	18
10006450BCSG	Solis Tractor SHIFTER FORK (4TH)	620	87089900	18

10006458AASG	Solis Tractor DOWEL PIN (FOR G.B.HSG & BELL HSG)	20	73182300	18
10006458ABSG	Solis Tractor DOWEL PIN (FOR G.B.HSG & BELL HSG)	20	87089900	18
10006487BISG	Solis Tractor DOG. GEAR ASSY. Z-41 (FOR DI 60)	2346	87084000	18
10006492AASG	Solis Tractor GASKET FOR GEAR BOX FRONT SIDE	101	84841010	18
10006511AASG	Solis Tractor SPACER FOR SHIFTER BUSH 4TH(SIDE LEVER)	28	87081010	18
10006528AASG	Solis Tractor SPACER FOR LAY SHAFT	210	87081010	18
10006670ACSG	Solis Tractor O RING FOR C.A.SHAFT	15	40161000	18
10006695ABSG	Solis Tractor SHIFTER BUSH HI/LOW	376	87084000	18
10006721ACSG	Solis Tractor RUBBER BOOT FOR SHIFTER HSG)	59	40161000	18
10006722BDSG	Solis Tractor SHIFTER FORK (2ND & 3RD)	721	87089900	18
10006724AASG	Solis Tractor CONICAL SPRING FOR GEAR SHIFTER LEVER	50	73201011	18
10006726AASG	Solis Tractor PIN FOR GEAR SHIFTER HOUSING	14	87084000	18
10006731AASG	Solis Tractor WASHER(FOR SIDE LEVER)	10	73182300	18
10006738ABSG	Solis Tractor WASHER [BRACKE PEDAL]	31	73182300	18
10006757CASG	Solis Tractor AXLE HUB	1523	87085000	18
10006770ABSG	Solis Tractor WASHER FOR STUB AXLE	81	73182300	18
10006797ABSG	Solis Tractor WRAPPED BUSH FOR PIVOT PIN	110	84829900	18
10006802AGSG	Solis Tractor REAR TOE HOOK (3 CYL, SOLIS 3)	5668	87089900	18
10006904AASG	Solis Tractor VIBRATION DAMPER(SUCTION PIPE)	21	87081010	18
10006904ABSG	Solis Tractor VIBRATION DAMPER(SUCTION PIPE)	21	40169990	18
10006908AASG	Solis Tractor GASKET (STRAINER COVER)	12	84841010	18
10006909AASG	Solis Tractor PLAIN COVER(FOR STRAINER)	128	87085000	18
10006918AASG	Solis Tractor BUSH	89	84829900	18
10006922AASG	Solis Tractor POSITION LOCK	57	87089900	18
10006923ABSG	Solis Tractor SECTOR LOCK	193	87089900	18
10006925ABSG	Solis Tractor SLEEVE END	129	87081010	18
10006926AASG	Solis Tractor SPRING POSITION SECTOR	23	73201011	18
10006959AASG	Solis Tractor ADOPTER RV	183	87081010	18
10006964AASG	Solis Tractor CAP CHECK	95	87089900	18
10006974ABSG	Solis Tractor SCREW RV	57	73182300	18
10006975AASG	Solis Tractor SEAT SPRING	37	87081010	18
10006976ACSG	Solis Tractor SEAT VALVE	76	87089900	18
10006978ABSG	Solis Tractor SPRING CHECK	15	73201011	18
10006979AASG	Solis Tractor SPRING CONTROL	16	73201011	18
10006982ABSG	Solis Tractor SPRING (UNLOADING VALVE)	8	73201011	18
10006989ABSG	Solis Tractor PIN HOLLOW	321	73182300	18
10006990AESG	Solis Tractor ROCKER BASE	732	87089900	18
10006999AASG	Solis Tractor ADAPTER TUBE	231	87081010	18
10006999ABSG	Solis Tractor ADAPTER TUBE	185	87089900	18
10007010ACSG	Solis Tractor CONNECTING ROD	581	87089400	18
10007017ADSG	Solis Tractor GASKET FOR REAR COVER (NEW TRANSMITION)	85	87081010	18
10007018ABSG	Solis Tractor INSERT	170	87089900	18
10007040ACSG	Solis Tractor ADAPTER CYL	232	87089900	18
10007042AASG	Solis Tractor DOME CAP NUT M10 (IS2687-5S)	18	73182300	18
10007044ACSG	Solis Tractor PISTION SEAL SET(1 * 4 SEAL)	536	40161000	18
10007082AASG	Solis Tractor GASKET SHIFTER HOUSING	18	84841090	18
10007128AASG	Solis Tractor SEALING PLUG	11	73182300	18
10007129AASG	Solis Tractor GASKET(TRUMPET HSG)	41	84841010	18
10007137ABSG	Solis Tractor HOSE PIPE (FOR SUCTION STRAINER)	183	40091100	18
10007151AASG	Solis Tractor SPACER 12mm	38	87081010	18
10007157AASG	Solis Tractor WASHER FIBRE	52	73182300	18

10007157ACSG	Solis Tractor WASHER FIBRE	43	73182990	18
10007158AASG	Solis Tractor PIN	47	73182300	18
10007204AASG	Solis Tractor SPRING(SHIFTER BUSH PIN)	15	73201011	18
10007237AASG	Solis Tractor SPRING (PARKING BRAKE)	15	73201011	18
10007237ABSG	Solis Tractor SPRING (4WD LEVER)	15	73201011	18
10007256AASG	Solis Tractor BANJO BOLT M16X1.5	48	73182300	18
10007280AHSG	Solis Tractor B.P. SHAFT CARRIER RIGHT	4105	87085000	18
10007294ACSG	Solis Tractor COVER (FOR TRUMPET HSG.)	549	87089900	18
10007405AASG	Solis Tractor RETAINER FOR (4WD)	289	87085000	18
10007405ABSG	Solis Tractor RELAINER FOR (4WD)	349	87089900	18
10007406ABSG	Solis Tractor HUB (4WD)	709	87089900	18
10007412ACSG	Solis Tractor SLEEVE (4WD)	1297	87081010	18
10007418ABSG	Solis Tractor O-RING (FOR 4WD)	37	40161000	18
10007418ACSG	Solis Tractor O-RING (FOR 4WD)	45	40169320	18
10007419BDSG	Solis Tractor IDLER GEAR Z 31 (4WD)	1851	87084000	18
10007424ABSG	Solis Tractor BUSH FOR DRIVER GEAR	202	84829900	18
10007434AASG	Solis Tractor COVER (4WD)	377	87085000	18
10007437AASG	Solis Tractor SPACER MAIN SPINDLE (4WD)	62	87081010	18
10007438BBSG	Solis Tractor END COVER (4WD)	334	87081010	18
10007444AASG	Solis Tractor SHIM 0.15MM	15	73182300	18
10007445AASG	Solis Tractor SHIM 0.2MM	15	73182300	18
10007446AASG	Solis Tractor SHIM 0.5MM	19	73182300	18
10007454BASG	Solis Tractor GASKET FOR SPINDEL SMALL(4WD)	10	87081010	18
10007460BGSG	Solis Tractor SPINDLE SMALL 4WD	687	87089900	18
10007466BBSG	Solis Tractor SPACER BIG FOR MAIN SPINDLE (4WD)	453	87089900	18
10007529ABSG	Solis Tractor HOSE PIPE(FOR SUCTION STRAINER)	172	40091100	18
10007544AASG	Solis Tractor WASHER FOR (4WD)	15	73182300	18
10007588AASG	Solis Tractor LOCKING WASHER	7	73182300	18
10007595AASG	Solis Tractor FELT RING	17	40161000	18
10007618AASG	Solis Tractor CONNECTING SLEEVE	503	87084000	18
10007627BASG	Solis Tractor PLATE ASSY LH	775	87089900	18
10007630BASG	Solis Tractor PLATE ASSY RH	775	87089900	18
10007633AASG	Solis Tractor SHIM 0.15mm	37	73182300	18
10007634AASG	Solis Tractor SHIM 0.2mm	34	73182300	18
10007635AASG	Solis Tractor SHIM 0.4mm	54	73182300	18
10007636AASG	Solis Tractor SHIM 0.5mm	66	73182300	18
10007639ABSG	Solis Tractor SHIM (T.P. CARRIER)	18	73182300	18
10007640ABSG	Solis Tractor SHIM (T.P. CARRIER)	19	73182300	18
10007641ABSG	Solis Tractor SHIM (T.P. CARRIER)	21	73182300	18
10007642ABSG	Solis Tractor SHIM (T.P. CARRIER)	28	73182300	18
10007652AASG	Solis Tractor SLIDING PIN (PTO FORK)	75	73182300	18
10007771BBSG	Solis Tractor FRONT COVER PLATE	160	87089900	18
10007773AASG	Solis Tractor PIN (AUTORESPONSE FEATHRING)	52	73182300	18
10007774ADSG	Solis Tractor COVER UNLOADER	123	87089900	18
10007785ABSG	Solis Tractor BEARING HSG REAR 2ND (2 WHEEL DRIVE)	395	84833000	18
10007788CBSG	Solis Tractor PTO END COVER	653	73259910	18
10007788CCSG	Solis Tractor PTO END COVER	525	87089900	18
10007838ABSG	Solis Tractor PLUG RESPONSE VALVE ASSY.	31	87085000	18
10007839ACSG	Solis Tractor CLAMPING STRIP	8	87081010	18
10007841ACSG	Solis Tractor PIN ROCKER	179	87085000	18
10007842ADSG	Solis Tractor DIPSTICK	118	87085000	18

10007842AISG	Solis Tractor DIPSTICK ASSY	118	87089900	18
10007881BBSG	Solis Tractor TENSION SPRING	25	73182300	18
10007902CASG	Solis Tractor COVER PLATE (BELL HSG)	107	87089900	18
10007903CASG	Solis Tractor GASKET (COVER PLATE)	34	84841010	18
10007903CCSG	Solis Tractor GASKET (COVER PLATE)	45	68129922	18
10007909AHS	Solis Tractor T.P CARRIRER	1192	87089900	18
10007922AASG	Solis Tractor VIBRATION DAMPER	21	73182300	18
10007924ADSG	Solis Tractor B.P SHAFT CARRIER (LT)	5059	87085000	18
10007956AASG	Solis Tractor GASKET(COVER LT & RT)(DIFF LOCK)	8	84841010	18
10007961ACSG	Solis Tractor FORK (DIFF LOCK)	750	87084000	18
10007966AASG	Solis Tractor O RING	29	40161000	18
10007994AASG	Solis Tractor COVER LEFT (DIFF LOCK)	100	87085000	18
10007997BASG	Solis Tractor ROD (DIFF LOCK)	442	87089900	18
10008001BASG	Solis Tractor COVER RIGHT (DIFF. LOCK)	283	87089900	18
10008004ADSG	Solis Tractor SLEEVE PIN ASSY (DIFF LOCK)	1677	87089900	18
10008011ACSG	Solis Tractor SLEEVE PIN	25	87089900	18
10008019AASG	Solis Tractor WASHER (DIFF LOCK)	14	73182300	18
10008020ACSG	Solis Tractor SPRING (DIFF LOCK)	49	73201011	18
10008021ABSG	Solis Tractor LINK (DIFF. LOCK)	264	87085000	18
10008030ABSG	Solis Tractor SPRING F2	12	73201011	18
10008034AASG	Solis Tractor SPRING UNLOADER	13	73201011	18
10008063ABSG	Solis Tractor SPRING FEATHERING	15	87081010	18
10008066ACSG	Solis Tractor SCREW STOPPER	13	73181600	18
10008098AASG	Solis Tractor THRUST WASHER	134	73182300	18
10008100AGSG	Solis Tractor BULL PINION SHAFT (4CYL)	6061	87084000	18
10008144ABSG	Solis Tractor SUCTION PIPE HOSE	150	40091100	18
10008149ABSG	Solis Tractor ORIFICE DIA 1	16	87089900	18
10008203AASG	Solis Tractor PLUG DIA 12.5	20	73182300	18
10008353ABSG	Solis Tractor SLIDING PIN FOR FORK 4-WD	75	87089900	18
10008355ADSG	Solis Tractor HYD CYLINDER (FOR POWER STEERING)	16666	87089400	18
10008355BASG	Solis Tractor HYD CYLINDER (FOR POWER STEERING)	14749	87089900	18
10008356ABSG	Solis Tractor LOCKING BLOCK FOR KING PIN	350	87089900	18
10008357DBSG	Solis Tractor AXLE HUB	1759	87085000	18
10008363AASG	Solis Tractor SPOOL RV	85	87081010	18
10008366DBSG	Solis Tractor KING PIN STUB AXLE ASSY (RT) (LOADER SPL	4230	87085000	18
10008366EASG	Solis Tractor KING PIN STUB AXLE ASSY (RT) (LOADER SPL	4230	87089900	18
10008367DBSG	Solis Tractor KING PIN STUB AXLE ASSY(LEFT)(LOADER SPL	4230	87085000	18
10008367EASG	Solis Tractor KINGPIN STUB AXLE ASSY. LEFT	3403	87089900	18
10008376AASG	Solis Tractor CAP RV	138	87089900	18
10008453AASG	Solis Tractor PTO SHAFT COVER	63	87084000	18
10008458AASG	Solis Tractor CYLINDERICAL PIN DIA 5*33	15	87089900	18
10008460AASG	Solis Tractor GASKET (OPERATING SECTOR)	10	84841010	18
10008462CCSG	Solis Tractor RAM CYLINDER ARM	3198	87089900	18
10008466BCSG	Solis Tractor SUPPORT ACTUATOR	618	87084000	18
10008467ABSG	Solis Tractor PIN	51	73182300	18
10008468AASG	Solis Tractor SPACER POSITION	60	87081010	18
10008469BASG	Solis Tractor ROLLER GUIDE	120	87089900	18
10008470BCSG	Solis Tractor CAP ACTUATOR	40	87089900	18
10008472AASG	Solis Tractor ROLLER POSITION	53	87089900	18
10008474AESG	Solis Tractor ACTUATOR POSITION ASSY.	411	87089900	18
10008477CESG	Solis Tractor TUBE SENSOR	1313	87084000	18

10008480CASG	Solis Tractor SPINDLE SENSOR	207	87089900	18
10008481AASG	Solis Tractor HEAD SPOOL	194	87081010	18
10008491ABSG	Solis Tractor PIPE FEATHERING INLET	314	87081010	18
10008495BASG	Solis Tractor GASKET SENSOR TUBE	12	84841010	18
10008506BCSG	Solis Tractor STOPPER ASSY	323	87081010	18
10008508BASG	Solis Tractor PIN HEAD SPOOL	27	73182300	18
10008543ACSG	Solis Tractor CLUTCH ACTUATOR FORK	742	87089300	18
10008551DBSG	Solis Tractor FENDER SUPPORT BAR ASSY (UNPAINTED)	388	87089900	18
10008576AASG	Solis Tractor LOCKING PLATE	311	87089900	18
10008576BBSG	Solis Tractor LOCKING PLATE	257	87089900	18
10008584ABSG	Solis Tractor CAP FOR PEDAL	21	40161000	18
10008601EPSG	Solis Tractor DIFFERENTIAL HOUSING WITHOUT DIFF LOCK	60836	87081010	18
10008646ABSG	Solis Tractor CHECK VALVE ORIFICE	14	73260000	18
10008709ACSG	Solis Tractor GASKET REAR COVER -DIFFERENTIAL.	77	68129922	18
10008756ADSG	Solis Tractor GEAR INPUT Z-53	2314	87084000	18
10008801ABSG	Solis Tractor HUB (FOR INTERMEDIATE SHAFT)	594	87084000	18
10008811ACSG	Solis Tractor SLEEVE BIG	927	87084000	18
10008838ABSG	Solis Tractor PTO FIXED GEAR	1477	87084000	18
10008960AASG	Solis Tractor LOCKING WASHER 2.5MM(INTERMEDIATE SHAFT	156	73182300	18
10008966DBSG	Solis Tractor GUARD FOR FRONT PTO (REAR SIDE ,4-WD)	1881	87089900	18
10009021ABSG	Solis Tractor LOCKING SCREW M10*1	32	73182300	18
10009088ADSG	Solis Tractor MOUNTING BRACKET(7 PIN SOCKET)	133	87089900	18
10009098AJSG	Solis Tractor TOP LINK ASSY	3826	87089900	18
10009105ABSG	Solis Tractor ADOPTER HYDRAULIC FILTER	1443	84213990	18
10009106ADSG	Solis Tractor HYDRAULIC OIL FILTER ASSY.	527	84219900	18
10009118ABSG	Solis Tractor INNER FLANGE ASSY	207	87089900	18
10009119ADSG	Solis Tractor LOWER LINK ASSY	3779	87089900	18
10009152ACSG	Solis Tractor TANK UNIT PRICOL	357	87089900	18
10009158ACSG	Solis Tractor BRAKE LEVER (OIB)	138	87083000	18
10009179AASG	Solis Tractor O-RING HOLDER	134	40161000	18
10009223BASG	Solis Tractor LOCKING SCREW M8*1	20	73182300	18
10009244ADSG	Solis Tractor MTG. BRACKET (FOR TOOL BOX)	327	87089900	18
10009431ABSG	Solis Tractor service kit (feahering valve assy).	362	72149990	18
10009438AASG	Solis Tractor SPACER 12.5	17	87081010	18
10009441ABSG	Solis Tractor GASKET FOR BRAKE HSG (OIB).	40	84841010	18
10009472AASG	Solis Tractor PIN (FOR ADJUSTABLE STAY BAR)	258	73182300	18
10009473BCSG	Solis Tractor ADJUSTABLE STAY BAR WITH BRACKET	3692	87089900	18
10009483ABSG	Solis Tractor DRAFT INDICATION STRIP	10	83100010	18
10009620AESG	Solis Tractor BULL GEAR Z-56	9084	87084000	18
10009675AASG	Solis Tractor WHEEL RIM (FRONT)5.50F x 16 (SILVER)	6096	87087000	18
10009681AESG	Solis Tractor TRACTOR REAR WHEEL[W13*28] SILVER PAINT	15100	87087000	18
10009797AASG	Solis Tractor Dowel Pin (8X20)	25	73182300	18
10009864ADSG	Solis Tractor LOCK WASHER 2.5 MM	69	73182300	18
10009865ADSG	Solis Tractor LOCK WASHER 2.7 MM	93	73182300	18
10009866ADSG	Solis Tractor LOCK WASHER 2.9 MM	99	73182300	18
10009867ADSG	Solis Tractor LOCK WASHER 3.1 MM	79	73182300	18
10009868ADSG	Solis Tractor LOCK WASHER 3.3 MM	69	73182300	18
10009899BASG	Solis Tractor BULL GEAR	16373	87084000	18
10010428ABSG	Solis Tractor FIP LINK PIN	23	87089900	18
10010524AESG	Solis Tractor CLUTCH SPRING	28	73201011	18
10010585AASG	Solis Tractor SEALING RING & GLASS (MINDA CLUSTER)1100	252	40161000	18

10010972ADSG	Solis Tractor ADJUSTABLE STAY BAR ASSY. LH	1885	87089900	18
10011126ACSG	Solis Tractor REAR AXLE	10940	87085000	18
10011126BASG	Solis Tractor REAR AXLE	9226	87085000	18
10011154ACSG	Solis Tractor SPECIAL BOLT M16X1.5	120	73181600	18
10011155ADSG	Solis Tractor SPECIAL HEX SCREW M16X1.5	79	73181600	18
10011185ABSG	Solis Tractor LOCTITE-577	24	35069999	18
10011234AASG	Solis Tractor OIL PRESSURE SWITCH "NC" TYPE	234	90262000	18
10011254AASG	Solis Tractor SPRING DOWEL SLEEVE	25	73182300	18
10011298AASG	Solis Tractor ANGLE BRACKET (FOR DASHBOARD)	92	87089900	18
10011371AASG	Solis Tractor GEAR INPUT Z-54	2739	87084000	18
10011422BBSG	Solis Tractor SWIVEL HOUSING ASSY. (LEFT)	9287	87085000	18
10011423BBSG	Solis Tractor SWIVEL HOUSING ASSY. (RIGHT)	9410	87085000	18
10011436AASG	Solis Tractor FRICTION DISC SUB ASSY	3917	72165000	18
10011515AASG	Solis Tractor ACTUATING DISC ASSY	2058	73259910	18
10011516AJS	Solis Tractor STEERING TANK ASSY.	4206	87089900	18
10011561AASG	Solis Tractor Single Clutch Alingment Tool	761	82060090	18
10011564AASG	Solis Tractor Trail Pinion chuck nut C Type	554	82060090	18
10011567AASG	Solis Tractor Steering Arm Puller	935	82060090	18
10011568AASG	Solis Tractor Steering Wheel Puller For all Model	1506	82060090	18
10011572BBSG	Solis Tractor DIPSTIC	478	87089900	18
10011581AASG	Solis Tractor LEVER ASSY.	658	87089900	18
10011587AJS	Solis Tractor DIFFERENTIAL HOUSING WITHOUT DIFF LOCK	56712	87085000	18
10011653ACSG	Solis Tractor FLEXIBLE OIB PIPE ASSY.	998	40091100	18
10011654ACSG	Solis Tractor OIB PIPE ASSY.	834	73061929	18
10011676AASG	Solis Tractor FENDER SUPPORT BAR ASSY (UNPAINTED)	306	87089900	18
10011708ADSG	Solis Tractor STICKER FOR STEERING TANK	17	39199010	18
10011708AESG	Solis Tractor STICKER FOR STEERING TANK	17	39199010	18
10011708AFSG	Solis Tractor STICKER STEARING TANK	17	39191000	18
10011709AASG	Solis Tractor HOSE PIPE(SUCTION STRAINER)	211	40091100	18
10011822ACSG	Solis Tractor FOAM (SIDE)	90	39201099	18
10012008ABSG	Solis Tractor DISC SPRING(61X43)	43	87081010	18
10012010ACSG	Solis Tractor LIFT ARM RH	4079	87089900	18
10012011ACSG	Solis Tractor LIFT ARM LH	3282	87089900	18
10012165AASG	Solis Tractor COUPLING SLEEVE (FINISH)	658	87084000	18
10012177BBSG	Solis Tractor CONNECTING SHAFT (VM1 4WD) (FINISH NO)	2605	87084000	18
10012178BASG	Solis Tractor PTO SHAFT	4287	87084000	18
10012201AASG	Solis Tractor WHEEL TYRE (REAR)13.6"*28" HEAVY SOIL	34876	40117000	18
10012202AASG	Solis Tractor WHEEL TYRE (REAR)16.9"*28" HEAVY SOIL	48709	40117000	18
10012203AASG	Solis Tractor WHEEL TYRE (REAR)14.9"*28" HEAVY SOIL	38776	40117000	18
10012206AASG	Solis Tractor WHEEL TYRE (FRONT)7.5"*16" _MRF	10062	40117000	18
10012208AASG	Solis Tractor WHEEL TUBE (REAR)13.6*28 _MRF	3877	40139049	18
10012209AASG	Solis Tractor WHEEL TUBE (REAR)16.9"*28" _MRF	6137	40139049	18
10012210AASG	Solis Tractor WHEEL TUBE (REAR)14.9"*28" _MRF	4846	40139049	18
10012213AASG	Solis Tractor WHEEL TUBE (FRONT)7.5"*16" _MRF	1278	40139049	18
10012308AASG	Solis Tractor SPECIAL BOLT (M10X45)	20	73181500	18
10012313AASG	Solis Tractor SUCTION PIPE ASSEMBLY	388	87089900	18
10012314AASG	Solis Tractor SUCTION HOSE PIPE	205	40091100	18
10012331AASG	Solis Tractor KIT OF TIE ROD END ASSY.	790	87089900	18
10012391AASG	Solis Tractor INLET MANIFOLD ASSY.	877	87089900	18
10012392ACSG	Solis Tractor O-RING Ã~20xÃ~2.62	12	40161000	18
10012447AASG	Solis Tractor FEMALE QUICK CONNECT COUPLER 1/2 BSP	705	73079290	18

10012447ADSG	Solis Tractor FEMALE QUICK CONNECT COUPLER 1/2 BSP	628	84811000	18
10012484CASG	Solis Tractor DELIVERY ADOPTER	284	87089900	18
10012485AASG	Solis Tractor ADOPTER ACCUMULATOR	129	73071190	18
10012486AASG	Solis Tractor ORFS JIC 90° CONNECTION	226	73079290	18
10012487AASG	Solis Tractor ORFS JIC CONNECTION 45°	304	73079290	18
10012515AASG	Solis Tractor Seal Kit of ECO. HYD CYL.(PS)10029003AA	843	40161000	18
10012567AASG	Solis Tractor TEMPERATURE SENSOR(MHI) 30N9600950	1348	84099111	28
10012571AASG	Solis Tractor BONDED SEAL FOR M14	40	40161000	18
10012572AASG	Solis Tractor BONDED SEAL FOR M16	54	40161000	18
10012573AASG	Solis Tractor BONDED SEAL FOR M18	66	40161000	18
10012575AASG	Solis Tractor BONDED SEAL FOR M22	94	40161000	18
10012576AASG	Solis Tractor BONDED SEAL FOR M24	55	40161000	18
10012577AASG	Solis Tractor BONDED SEAL FOR M30	55	40161000	18
10012579ABSG	Solis Tractor BONDED SEAL FOR 1/2 ' bsp	51	40161000	18
10012585ABSG	Solis Tractor BONDED SEAL FOR 3/8 BSP	62	40161000	18
10012629ABSG	Solis Tractor BREATHER ASSY	141	87089900	18
10012630ABSG	Solis Tractor CLAMP ASSEMBLY	91	82050000	18
10012633AASG	Solis Tractor Filter of Metalltic Steering Tank	672	87089400	18
10012653AASG	Solis Tractor ADOPTER TUBE	264	87081010	18
10012653ABSG	Solis Tractor ADOPTER TUBE	219	87089900	18
10012673AASG	Solis Tractor SPACER 4.0	136	87081010	18
10012674AASG	Solis Tractor SPACER 4.2	136	87081010	18
10012675AASG	Solis Tractor SPACER 4.4	139	87081010	18
10012676AASG	Solis Tractor SPACER 4.6	139	87081010	18
10012677AASG	Solis Tractor SPACER 4.8	144	87081010	18
10012693ABSG	Solis Tractor RUBBER WASHER	11	40082990	18
10012769ABSG	Solis Tractor LIFT ARM	2341	87089900	18
10012770ABSG	Solis Tractor LIFT ROD ASSEMBLY	1964	87089900	18
10012771ABSG	Solis Tractor LEVELLING ROD ASSEMBLY	2697	87089900	18
10012785ABSG	Solis Tractor CLAMP ASSY.	45	87089900	18
10012849ABSG	Solis Tractor CLAMP ASSY	75	87089900	18
10012881ADSG	Solis Tractor DOG CLUTCH GEAR ASSY 3RD Z-25	1335	87084000	18
10012929AASG	Solis Tractor BATTERY CABLE -VE	280	85442090	18
10013009AESG	Solis Tractor MAIN SPINDLE (4WD) LOW COST	2225	87084000	18
10013056AASG	Solis Tractor GEAR BOX LOCK KIT	472	87084000	18
10013059AASG	Solis Tractor HYD ARM BUSH KIT FOR ALL SIDE GEAR NEW M	1071	84834000	18
10013063AASG	Solis Tractor THRUST WASHER KIT-CAGE ASSY(10027148AC)	672	73182990	18
10013233ABSG	Solis Tractor ADOPTER	349	87089900	18
10013355AASG	Solis Tractor O.RING	37	40161000	18
10013997AASG	Solis Tractor CONTROL VALVE _110056004	27286	87089900	18
10014023AASG	Solis Tractor CLAMP ASSY	58	87089900	18
10014055ACSG	Solis Tractor STICKER 4X4	25	39199010	18
10014057ADSG	Solis Tractor COOL TECH STICKER	26	39199010	18
10014058ADSG	Solis Tractor OIL IMMERSER BRAKE STICKER	23	39199010	18
10014060ADSG	Solis Tractor STICKER EPI	33	39199010	18
10014061ACSG	Solis Tractor REVERSE PTO STICKER	30	39199010	18
10014063ACSG	Solis Tractor DOUBLE PTO STICKER	24	39199010	18
10014066ACSG	Solis Tractor STICKER AUTO LIFT	32	39199010	18
10014069ADSG	Solis Tractor STICKER DC	25	39199010	18
10014073AASG	Solis Tractor STICKER HEAVY DUTY DOME	88	39199010	18
10014096ABSG	Solis Tractor HOSE FOR STRAINER 1	163	40091100	18

10014097ABSG	Solis Tractor HOSE FOR STRAINER 2	189	40091100	18
10014098ABSG	Solis Tractor BRACKET FOR STRAINER	221	73182300	18
10014181AASG	Solis Tractor GREASE NIPPLE FOR M10X1 WITH CAP	20	87081010	18
10014539AASG	Solis Tractor CLIPS FOR BONNET BEADING MOUNTING (HARDW	9	87089900	18
10014552ABSG	Solis Tractor SEALING PLATE BOTTOM W/O PAINT	115	87089900	18
10014555AASG	Solis Tractor LEVER KIT (CLUTCH ASSY. - 10004686AB)	2262	87089300	18
10014902ACSG	Solis Tractor O-RING DIA 13.2 X DIA1.8	10	40169320	18
10014965AASG	Solis Tractor PTO FIXED GEAR Z-38	1450	87084000	18
10017103AASG	Solis Tractor VIBRATION DAMPER FOR 25 OD PIPE	18	40169990	18
10017559ABSG	Solis Tractor FORK FOR PARKING BRAKE	90	87083000	18
10017559ADSG	Solis Tractor FORK FOR PARKING BRAKE	80	87083000	18
10017560ABSG	Solis Tractor ADOPTER 1/2" BSP	140	73079290	18
10017869ABSG	Solis Tractor CLOSING CAP FOR FENDER	27	40169310	18
10017869ACSG	Solis Tractor CLOSING CAP FOR FENDER	21	40169310	18
10017927ABSG	Solis Tractor BONNET EMBLEM	55	87089900	18
10017954AASG	Solis Tractor MAIN RELAY-CRDI-75	308	85361090	18
10018117AASG	Solis Tractor GROOMET FOR DISCHARGE HOSE	26	40161000	18
10018290AASG	Solis Tractor Adoptor for Tandem Pump	168	73071190	18
10018337ACSG	Solis Tractor WASHER FOR DCV LEVER ASSY	7	73182300	18
10019095AASG	Solis Tractor Loctite 243	24	35069999	18
10019095ABSG	Solis Tractor Thread Locking Agent1(loctite243/Ana113E	22	35069999	18
10020767AASG	Solis Tractor HEX. FLANGED SCREW M8X1.25X15	10	73182300	18
10020828AASG	Solis Tractor OIL SEAL (SHIFTER HOUSING)	77	40161000	18
10020861ABSG	Solis Tractor BALL 10 DIA GRADE 20 IS:2898	8	84821090	18
10020864ABSG	Solis Tractor BALL 8 DIA GRADE 20 IS:2898	8	84829119	18
10022118AASG	Solis Tractor SPECIAL HEX FLANGE BOLT M12*1.75*42	30	73182300	18
10022123AESG	Solis Tractor BULL GEAR Z-55	10039	87084000	18
10022134AHSG	Solis Tractor ADOPTER M16X1.5/ & G-1/2" A	99	73071190	18
10022135AFSG	Solis Tractor ADOPTER M18X1.5/ & G-1/2" A	82	87089900	18
10022202AFSG	Solis Tractor CLAMP FOR AIR CLEANER ASSY(LUMAX)	324	82057000	18
10022266ACSG	Solis Tractor SLEEVE FOR FRONT PTO SHAFT	1049	87084000	18
10022277ACSG	Solis Tractor HAZARD WARNING SWITCH	223	87081010	18
10022314AASG	Solis Tractor C.A. SHAFT ASSY	609	87089900	18
10022333AFSG	Solis Tractor PROTECTION GUARD (POWER STEERING CYL)	278	87089900	18
10022347AASG	Solis Tractor GEAR Z-45	1588	87084000	18
10022359ADSG	Solis Tractor DOG CLUTCH GEAR ASSY Z-26	1363	87084000	18
10022359AESG	Solis Tractor DOG CLUTCH GEAR ASSY Z-26	1668	87084000	18
10022398AASG	Solis Tractor TANK UNIT	414	87089900	18
10022402BESG	Solis Tractor STICKER FOR COREECT METHOD OF USING LIFT	93	39199010	18
10022424ACSG	Solis Tractor BACK FLOW FUEL PIPE(THERM TANK TO FT)	210	40091100	18
10022572ADSG	Solis Tractor DUAL CLUTCH ASSEMBLY ~ 280	14214	87089300	18
10022585AASG	Solis Tractor WASHER 40x20.5x5	35	73182300	18
10022898CASG	Solis Tractor GUARD FOR FRONT PTO 4WD (FRONT SIDE)	909	87089900	18
10022906AASG	Solis Tractor VENT BREATHER ASSY	105	87089900	18
10022909AGSG	Solis Tractor SHAFT FRONT PTO 4WD (3 CYL) BLACK	5940	87084000	18
10022950ABSG	Solis Tractor ACTUATOR FORK	153	87089900	18
10023016AFSG	Solis Tractor B.P SHAFT(LEFT) Z-11	6542	87085000	18
10023017AFSG	Solis Tractor B.P SHAFT RIGHT Z-11	6878	87085000	18
10023215BASG	Solis Tractor SCREW 10023372BA	32	73182300	18
10023218ABSG	Solis Tractor SUCTION PIPE WITH FLANGE	916	87081010	18
10023233ACSG	Solis Tractor PLASTIC CAP (NEW HYD & NEW LINKAGES)	8	40169980	18

10023277ADSG	Solis Tractor ADOPTER BRAKE M16X1.5 & M14X1.5	94	87083000	18
10023312AASG	Solis Tractor SMV EMBLEM (MOULDED)	285	87089900	18
10023341ACSG	Solis Tractor ACTUATOR FORK CUM TIE ROD	175	87083000	18
10023363ADSG	Solis Tractor HANDLE ASSY (PTO)	241	87089900	18
10023372BASG	Solis Tractor SPL. HEX. FLANGE BOLT M12*1.75*30	28	73182300	18
10023372BBSG	Solis Tractor SPL. HEX. FLANGE BOLT M12*1.75*30	34	73181600	18
10023484AASG	Solis Tractor FELT RING (BRAKE PEDAL SHAFT)	8	40161000	18
10023510AASG	Solis Tractor CLAMP DIA 22	38	87089900	18
10023524ABSG	Solis Tractor COOLANT ASSY	305	38200000	18
10023538ACSG	Solis Tractor PIPE (RADIATOR TO COOLANT TANK)	78	73061929	18
10023539AASG	Solis Tractor PIPE (COOLANT TANK TO OUTSIDE)	115	40091100	18
10023560ACSG	Solis Tractor MAGNETIC STRAINER ASSY	1253	84213990	18
10023561AASG	Solis Tractor WIRE CLIP	14	87089900	18
10023563AASG	Solis Tractor ACTUATOR FORK -ADJ	116	87089900	18
10023569AASG	Solis Tractor CLAMP DIA 12.5 MM	23	82054000	18
10023570AASG	Solis Tractor CROWN WHEEL & TAIL PINION SET	7915	87084000	18
10023572AASG	Solis Tractor MOBILE CHARGER SOCKET	198	85361010	18
10023591ABSG	Solis Tractor SPRING RELIEF VALVE	41	73201011	18
10023635ABSG	Solis Tractor BUSH (FOR DIFF. HSG)3 & 4 CYL(SOLIS 3&5	105	84829900	18
10023768CBSG	Solis Tractor RIVET FOR SHIFTER ROD	38	87089900	18
10023793AFSG	Solis Tractor COVER PLATE (G.B.HSG) NEUTRAL SWITCH	2085	87084000	18
10023830AASG	Solis Tractor CLUTCH COVER ASSY.	9498	87089300	18
10023992ABSG	Solis Tractor COVER (FOR BOTTOM WINDOW)	364	87089900	18
10023999ABSG	Solis Tractor SPACER (ROCK SHAFT)	95	73182300	18
10024016ACSG	Solis Tractor DRAIN PLUG ASSEMBLY.	123	87089900	18
10024067AASG	Solis Tractor THRUST WASHER (2 & 3 CYL MODELS)	118	73182300	18
10024072ACSG	Solis Tractor COVER (BRAKE HSG. RIGHT) (OIB)	1664	87083000	18
10024075AASG	Solis Tractor LINK PLAIN (OIB)	44	87083000	18
10024076AASG	Solis Tractor JAW PIN (OIB)	29	73182300	18
10024078AASG	Solis Tractor DISC INTERMEDIATE (OIB)	495	87083000	18
10024079AASG	Solis Tractor DISC FRICTION (OIB)	904	87083000	18
10024080AASG	Solis Tractor SPECIAL BOLT (OIB)	45	73182300	18
10024093AGSG	Solis Tractor DISC ACTUATING (OIB)	968	87083000	18
10024095ACSG	Solis Tractor RUBBER BOOT	252	40161000	18
10024115ABSG	Solis Tractor BRAKE HOUSING (LEFT)(OIB)	4334	87083000	18
10024269AASG	Solis Tractor BANJO BOLT 16.4(19TPI)	45	73182300	18
10024276AASG	Solis Tractor SPRING CLIP (OIB)	11	87081010	18
10024280AASG	Solis Tractor STICKER 4WD	13	39199010	18
10024291AASG	Solis Tractor LINK PIN	11	87089900	18
10024346ACSG	Solis Tractor GASKET FOR BELL HOUSING	50	87081010	18
10024347AASG	Solis Tractor CENTERING GUIDE	17	73182300	18
10024727CBSG	Solis Tractor FUEL PIPE WATER SEPERATOR TO FEED PUMP.	380	87081010	18
10024728ACSG	Solis Tractor PUSH ROD	86	87089900	18
10024780ABSG	Solis Tractor CLAMP (RADIATOR)	10	87089900	18
10024800AASG	Solis Tractor KNOB (FUEL CUT OFF)	23	87089900	18
10024924BASG	Solis Tractor BELL HOUSING	14335	73251000	18
10024952AASG	Solis Tractor PLASTIC CAP	16	40161000	18
10024954ABSG	Solis Tractor SHIM THICKNESS 0.150 MM	18	73182910	18
10024968AFSG	Solis Tractor BATTERY CABLE POSITIVE	1337	85442090	18
10024970ABSG	Solis Tractor DRIVEN GEAR ASSY Z-28	1857	84834000	18
10024996ABSG	Solis Tractor CLOSING CAP	31	40161000	18

10025031ABSG	Solis Tractor MAIN CLUTCH PLATE_L-03028-1065-00	9704	87089300	18
10025032ABSG	Solis Tractor PTO CLUTCH PLATE_L-03028-1066-00	6678	87089300	18
10025063ABSG	Solis Tractor REAR AXLE	13014	87085000	18
10025108ACSG	Solis Tractor BUSH 62 X 72	459	87084000	18
10025118ABSG	Solis Tractor LIFT ROD ASSY.	4712	87089900	18
10025127CASG	Solis Tractor OIL PRESSURE SENSOR (ELECTRICAL)	321	85118000	28
10025128ABSG	Solis Tractor CLUTCH REPAIR KIT FOR DUAL CLUTCH (CA)	4001	87089300	18
10025129AASG	Solis Tractor KIT FOR SHIFTER ROD SOLIS-3 SIDE GEAR	262	87084000	18
10025379ABSG	Solis Tractor BUSH 57 X 67	360	87084000	18
10025399ADSG	Solis Tractor PISTON	1740	87089900	18
10025430ACSG	Solis Tractor CYLINDER Ã~90	4066	87089900	18
10025486ACSG	Solis Tractor PIN FOR STABILIZERS AND LIFT ARMS	190	87089900	18
10025565AASG	Solis Tractor SPECIAL HEX BOLT M12	55	73182300	18
10025595ABSG	Solis Tractor CONNECTING ROD	650	87089900	18
10025600AASG	Solis Tractor GUIDING RING	27	40161000	18
10025604AASG	Solis Tractor RUBBER RING	41	40161000	18
10025605AASG	Solis Tractor GLYDE RING	202	40161000	18
10025844ABSG	Solis Tractor DOG CLUTCH GEAR ASSY.Z-24	1109	87084000	18
10025844ACSG	Solis Tractor DOG CLUTCH GEAR ASSY.Z-24	1379	87084000	18
10025958CASG	Solis Tractor ROCK SHAFT	4101	87084000	18
10026074ADSG	Solis Tractor BULL GEAR(Z-55)	10693	87084000	18
10026079AFSG	Solis Tractor BULL PINION SHAFT-LEFT(Z-12)	6323	87084000	18
10026111ACSG	Solis Tractor GEAR INPUT	2755	87084000	18
10026156AFSG	Solis Tractor BULL PINION SHAFT-RIGHT (Z-12)	7098	87084000	18
10026301ABSG	Solis Tractor STARTING SWITCH	656	85361010	18
10026301BASG	Solis Tractor STARTING SWITCH	799	85361010	18
10026353AASG	Solis Tractor BUSH SINTERED ROCK SHAFT	440	87084000	18
10026370AESG	Solis Tractor SHIFTER LEVER (DIFF.SPEEDS)	489	87084000	18
10026397AASG	Solis Tractor DOG CLUTCH GEAR ASSY. Z-35	1469	87084000	18
10026397ABSG	Solis Tractor DOG CLUTCH GEAR ASSY. Z-35	1809	87084000	18
10026434ABSG	Solis Tractor BREATHER ASSY.	57	87089900	18
10026469AASG	Solis Tractor MOUNTING BRACKET (FENDER SUPPORT BAR)(UN	63	87089900	18
10026680AASG	Solis Tractor CLAMP PLATE	31	82050000	18
10026685AASG	Solis Tractor BRACKET FOR FILTER	228	87089900	18
10026706ABSG	Solis Tractor LIP SEAL (OIL)	67	40161000	18
10026897ADSG	Solis Tractor INLET MANIFOLD ASSY.	961	87089900	18
10026913AASG	Solis Tractor BANJO BOLT DIA 16.4X34 (19TPI)	54	73182300	18
10026923ACSG	Solis Tractor SUCTION PIPE SMALL PUMP	703	87081010	18
10026943AESG	Solis Tractor BRACKET FOR STEERING TANK	327	87089900	18
10026943AFSG	Solis Tractor BRACKET FOR STEERING TANK	343	87089900	18
10026958AASG	Solis Tractor CAP RADIATOR 0.9-PSI	134	87089100	18
10026973ABSG	Solis Tractor PIN (3PT LINK)	131	73182300	18
10027068BBSG	Solis Tractor RUBBER FLAP	99	40082990	18
10027110AESG	Solis Tractor SPIDER KIT SET (10X18)	5945	87085000	18
10027147AASG	Solis Tractor THRUST WASHER	81	73182300	18
10027155ACSG	Solis Tractor GEAR SHIFTER LEVER HI/LOW	799	87084000	18
10027157ACSG	Solis Tractor GEAR SHIFTER LEVER DIFF SPEED	832	87084000	18
10027162ABSG	Solis Tractor PLATE FOR RUBBER BOOT	62	87089900	18
10027167ACSG	Solis Tractor BATTERY CLAMP	40	87089900	18
10027169ACSG	Solis Tractor HAND TOOL KIT	982	82060010	18
10027175ACSG	Solis Tractor COMBINATION SWITCH	802	85361010	18

10027195ADSG	Solis Tractor SPIDER KIT SET (10X18) (DIFF. LOCK)	6441	87085000	18
10027244AASG	Solis Tractor SHIM (0.15)	37	73182300	18
10027245AASG	Solis Tractor SHIM (0.2)	37	73182300	18
10027246AASG	Solis Tractor SHIM (0.4)	54	73182300	18
10027247AASG	Solis Tractor SHIM (0.5)	68	73182300	18
10027313ABSG	Solis Tractor SUCTION PIPE FROM HOSE TO HOSE	435	87081010	18
10027339AFSG	Solis Tractor HYDRAULIC FILTER	877	84213990	18
10027359AASG	Solis Tractor SHIM (0.5)FOR BEVEL GEAR	15	73182300	18
10027389ABSG	Solis Tractor BUSH(Ã~50Ã~65)	121	84829900	18
10027404ABSG	Solis Tractor SHIFTER KNOB (I.P.T.O.)	101	87089900	18
10027411AFSG	Solis Tractor SERVICE STICKER	90	39199010	18
10027437ABSG	Solis Tractor DOG CLUTCH GEAR ASSY Z-34	1788	87084000	18
10027455AASG	Solis Tractor SUCTION PIPE FROM HOSE TO HOSE.	306	87081010	18
10027487ADSG	Solis Tractor SHAFT FOR BEVEL GEAR	365	87084000	18
10027488AASG	Solis Tractor COLLAPSIBLE SPACER	76	87081010	18
10027492AASG	Solis Tractor BUSH	93	87084000	18
10027493ABSG	Solis Tractor COVER	263	87089900	18
10027494ABSG	Solis Tractor THURST WASHER	61	73182300	18
10027495ADSG	Solis Tractor TRIANGULAR WASHER FOR PLANET GEARS	155	73182300	18
10027496AASG	Solis Tractor RING FOR INTERNAL GEAR	34	87089900	18
10027497AASG	Solis Tractor WASHER FOR TAIL PINION	58	73182300	18
10027498ABSG	Solis Tractor WASHER FOR PLANET GEAR	61	73182300	18
10027499ADSG	Solis Tractor DISC SPRING	87	73182300	18
10027504ACSG	Solis Tractor WASHER	79	73182300	18
10027507ADSG	Solis Tractor KING PIN	838	87089900	18
10027511ADSG	Solis Tractor HOSE PIPE	258	40091100	18
10027514AFSG	Solis Tractor BUSH (FRONT AXLE HOUSING)	770	87084000	18
10027536ACSG	Solis Tractor INTERNAL GEAR (FOR PLANET CARRIER)	4815	87084000	18
10027538ACSG	Solis Tractor PLANET GEAR Z=24	1110	87084000	18
10027540ABSG	Solis Tractor THRUST WASHER (FOR SPIDER KIT)	48	73182300	18
10027548AESG	Solis Tractor WHEEL CARRIER (FRONT AXLE 4WD)	1889	87084000	18
10027555AESG	Solis Tractor BUSH (FRONT AXLE 4WD)	86	84829900	18
10027559BASG	Solis Tractor ADOPTER HYDRAULIC FILTER	860	87081010	18
10027561AESG	Solis Tractor BUSH (FOR AXLE HSG.)	629	87084000	18
10027562ADSG	Solis Tractor THURST WASHER	852	73182300	18
10027577ABSG	Solis Tractor DOWEL FOR FRONT & REAR SUPPORT31Q03A03	84	87089900	18
10027599AGSG	Solis Tractor PLANET CARRIER	5098	87089900	18
10027599AHSG	Solis Tractor PLANET CARRIER	4790	87085000	18
10027625AASG	Solis Tractor V-RING (FRONT AXLE 4WD)	67	40161000	18
10027627AFSG	Solis Tractor WHEEL HUB KIT (FRON AXLE 4WD)	4548	87084000	18
10027627AHSG	Solis Tractor WHEEL HUB KIT (FRON AXLE 4WD)	5062	87087000	18
10027637ADSG	Solis Tractor PIN FOR PLANET CARRIER (FRONT AXLE 4WD)	337	84836090	18
10027642AESG	Solis Tractor O-RING Ã~34 X Ã~2.65	17	40161000	18
10027661AASG	Solis Tractor THRUST WASHER LEFT	177	73182300	18
10027662AASG	Solis Tractor THRUST WASHER RIGHT	183	73182300	18
10027663AASG	Solis Tractor THRUST WAHSER	212	73182300	18
10027664AASG	Solis Tractor THRUST WASHER LEFT (DIFF LOCK)	139	73182300	18
10027760AASG	Solis Tractor CLAMP (BIG)	24	87089900	18
10027761AASG	Solis Tractor CLAMP (SMALL)	23	82050000	18
10028305ABSG	Solis Tractor SPACER	28	73182300	18
10028306AASG	Solis Tractor LINK PIN (FOR 3-CYL OIB MODELS)	29	87089900	18

10028335ACSG	Solis Tractor CYLINDRICAL BUSHING	518	87084000	18
10028336ABSG	Solis Tractor BUSH FOR FORK DIFF. SIDE	120	84834000	18
10028340AASG	Solis Tractor BATTERY CABLE NEGATIVE	736	85442090	18
10028428ACSG	Solis Tractor TAIL PINION & CROWN GEAR SET	8360	87084000	18
10028467AASG	Solis Tractor AXLE HUB	1553	87085000	18
10028469ACSG	Solis Tractor SPACER FOR TAIL PINION 3.60 MM	73	87081010	18
10028470ACSG	Solis Tractor SPACER FOR TAIL PINION 3.70 MM	73	87081010	18
10028471ACSG	Solis Tractor SPACER FOR TAIL PINION 3.80 MM	75	87081010	18
10028472ACSG	Solis Tractor SPACER FOR TAIL PINION 3.90 MM	75	87081010	18
10028473ACSG	Solis Tractor SPACER FOR TAIL PINION 4.00MM	76	87081010	18
10028474ACSG	Solis Tractor SPACER FOR TAIL PINION 4.10 MM	76	87081010	18
10028475ACSG	Solis Tractor SPACER FOR TAIL PINION 4.20MM	77	87081010	18
10028476ACSG	Solis Tractor SPACER TAIL PINION 3.50 MM	70	87081010	18
10028489ABSG	Solis Tractor ALUMINIUM TYPE WATER SEPERATOR	715	87081010	18
10028492AASG	Solis Tractor O-RING	59	40161000	18
10028494AESG	Solis Tractor KING PIN ASSY.	1018	87081010	18
10028504AASG	Solis Tractor CRANK DRAFT	119	84830000	18
10028516AASG	Solis Tractor SPECIAL WASHER FOR FRONT AXLE	17	73182300	18
10028524ADSG	Solis Tractor FLEXIBLE PIPE ASSY. (REAR COVER TO BRAKE	641	40091100	18
10028537ACSG	Solis Tractor TIE ROD ASSY. (ADJUSTABLE)	2784	87089900	18
10028543ABSG	Solis Tractor STUD	165	73182300	18
10028544AASG	Solis Tractor HEX SCREW M16X100 FOR SWIVEL HSG.	107	73182300	18
10028546AASG	Solis Tractor O-RING ¥27X¥2.5	14	40161000	18
10028548AFSG	Solis Tractor PLUG M30X2 ASSY.	123	73182300	18
10028583AASG	Solis Tractor HYDRAULIC CYLINDER ASSEMBLY	19137	87089900	18
10028590ACSG	Solis Tractor WHEEL RIM W15L*28 (W/O PAINT)	22150	87087000	18
10028596ACSG	Solis Tractor TIE ROD ASSY	3286	87089900	18
10028635ACSG	Solis Tractor WHEEL RIM W15L*28 (WITH SILVER PAINT)	19337	87087000	18
10028676ADSG	Solis Tractor CLUTCH PLATE ASSEMBLY	6658	87089300	18
10028752AASG	Solis Tractor HOUSING	9319	87089900	18
10028755AASG	Solis Tractor DIA.SPR.DBL.CL.	2401	87089300	18
10028770AASG	Solis Tractor ANGLE BRACKET (LT)	1759	87089900	18
10028771AASG	Solis Tractor ANGLE BRACKET (RT)	1759	87089900	18
10028793ADSG	Solis Tractor FLEXIBLE PIPE REAR COVER TO BRAKE HSG(RH	502	40091100	18
10028794ACSG	Solis Tractor UNIVERSAL JOINT ASSY.(FRONT AXLE 4WD)	28121	87085000	18
10028944ADSG	Solis Tractor RELIEF VALVE ASSY.	349	87089900	18
10028960ADSG	Solis Tractor RELEASE VALVE ASSY.	348	87089900	18
10028988ABSG	Solis Tractor OIL IMMERESD BRAKE ASSY LEFT (4CYL)JMI	17518	87083000	18
10028989ABSG	Solis Tractor OIL IMMERESD BRAKE ASSY RIGHT (4CYL)JMI	17518	87083000	18
10029003BBSG	Solis Tractor ECONOMICAL HYDRAULIC CYLINDER(P.S.)	9422	84121000	18
10029043AESG	Solis Tractor FUEL COCK ASSY.	549	87089900	18
10029088ACSG	Solis Tractor SHIFTER KNOB ASSY.	98	87089900	18
10029136AASG	Solis Tractor GASKET 4CYL TURBO (SK 05336)	17	84841010	18
10029159AASG	Solis Tractor RELAY	273	87081010	18
10029161AASG	Solis Tractor REFLEX REFLECTOR	43	39191000	18
10029269AASG	Solis Tractor POWER STEERING UNIT (80CC)	22880	87089400	18
10029368ABSG	Solis Tractor FUEL PIPES, FUEL TANK TO WATER SEPARATOR	229	40091100	18
10029407ABSG	Solis Tractor WATER SEPARATOR MTG BKT (SHEET METAL)	115	87089900	18
10029416ACSG	Solis Tractor DRIVEN PLATE ASSY. 280	7495	87089300	18
10029523ABSG	Solis Tractor LOCKING WASHER	21	73182300	18
10029559AESG	Solis Tractor WASHER RADIATOR	18	73182300	18

10029618ABSG	Solis Tractor GROMET FOR FLOOR LIGHT	32	40161000	18
10029666ADSG	Solis Tractor ADJUSTABLE STAY BAR ASSY. (RH)	1885	87089900	18
10029671AASG	Solis Tractor LOWER LINK ASSY.	4599	87089900	18
10029687ACSG	Solis Tractor LOCKING WASHER (P.S. CYL.)	14	73182300	18
10029735AASG	Solis Tractor VIBRATION DAMPER	29	40161000	18
10029751ADSG	Solis Tractor O-RING 19.9X 2.7	16	40161000	18
10029764BBSG	Solis Tractor FLEXIBLE PIPE FROM STG. UNIT L TO STG C	799	40091100	18
10029767BASG	Solis Tractor PIPE FROM STG. UNIT L TO HOSE LH	568	73061929	18
10029768BASG	Solis Tractor PIPE FROM STG. UNIT R TO HOSE RH	514	73061929	18
10029772BASG	Solis Tractor FLEXIBLE PIPE FROM STG UNIT TO STG CYL L	679	40091100	18
10029775BBSG	Solis Tractor FLEXIBLE PIPE FROM STG UNIT TO STG CYL R	696	73061929	18
10029795AESG	Solis Tractor STAY BAR MOUNTING BRACKET (LH)	1181	87089900	18
10029796AESG	Solis Tractor STAY BAR MOUNTING BRACKET (RH)	1181	87089900	18
10029815AESG	Solis Tractor ADOPTER QRC OFFSET	308	87081010	18
10029816ABSG	Solis Tractor ADOPTER 3/8' BSP	90	87081010	18
10029825ABSG	Solis Tractor CLAMP ASSY.(FOR POWER STG. PIPES)	72	82050000	18
10029874AASG	Solis Tractor STAR WASHER DIA 6	11	73182300	18
10029875AASG	Solis Tractor STAR WASHER DIA 8	10	73182300	18
10029876AASG	Solis Tractor STAR WASHER DIA 10	14	73182300	18
10029903AASG	Solis Tractor RUBBER FLAP FOR DASHBOARD ANGLE BKT	44	40161000	18
10029904AASG	Solis Tractor RUBBER PAD	18	40161000	18
10029927AASG	Solis Tractor DOUBLE ACTING DCV(BUCHER)	6103	84811000	18
10029941BDSG	Solis Tractor FLEXIBLE PIPE FROM STG. UNIT R TO STG CY	610	40091100	18
10029942BCSG	Solis Tractor FLEXIBLE PIPE FROM STG UNIT L TO STG CYL	695	40091100	18
10029943BDSG	Solis Tractor STARTER SWITCH	653	85361010	18
10029987ABSG	Solis Tractor DOG CLUTCH GEAR ASSY. Z-39	3480	87084000	18
10029988ACSG	Solis Tractor ADOPTER OIB	188	73071190	18
10029998AASG	Solis Tractor CLAMP ASSY.(FOR POWER STG. PIPES)	114	87089900	18
10030005AGSG	Solis Tractor DIFFERENTIAL SIDE GEAR (14T)	1142	87084000	18
10030006AFSG	Solis Tractor DIFFERENTIAL PINION GEAR (10T)	522	87084000	18
10030008ADSG	Solis Tractor DIFFERENTIAL PINION LINER	11	73182300	18
10030009ACSG	Solis Tractor DIFFERENTIAL SIDE GEAR LINER	10	73182300	18
10032508AMSG	Solis Tractor FENDER ASSY LH W/O PAINT	17563	87089900	18
10036003ABSG	Solis Tractor PTO SHAFT	3970	87084000	18
10036082ADSG	Solis Tractor EPOXY BLUE CED PIGMENT PASTE (F1)	889	32091010	18
10036083ADSG	Solis Tractor EPOXY BLUE CED RESIN EMULSION (F2)	375	32091010	18
10036124AASG	Solis Tractor IDLER GEAR Z-33	1705	87084000	18
10036129ABSG	Solis Tractor DRIVEN GEAR ASSY Z -26 (4-WD)	1719	87084000	18
10036141AASG	Solis Tractor PTO GEAR Z-40	1767	87084000	18
10036268ADFG	Solis Tractor FRONT AXLE ASSY. DANA	208617	87089900	18
10036269ABSG	Solis Tractor UNIVERSAL JOINT (FRONT)	2196	87089900	18
10036290ABSG	Solis Tractor COVER 4WD	333	87085000	18
10036432AASG	Solis Tractor PARKING BRAKE MTG BKT	224	87083000	18
10036433ABSG	Solis Tractor PAWL FOR PARKING BRAKE	298	87083000	18
10036455ABSG	Solis Tractor TIE ROD FOR PARKING BRAKE	124	87089900	18
10036483AASG	Solis Tractor ADJUSTABLE PARKING BRAKE ROD	146	87083000	18
10036526ADSG	Solis Tractor DIPSTICK CAP FOR FLOOR	27	87089900	18
10036541ADSG	Solis Tractor HANDLE ASSY PTO (COMPACT TRACTOR)	216	87089900	18
10036546ABSG	Solis Tractor WHEEL BOLT REAR	67	87087000	18
10036626ABSG	Solis Tractor KNOB FOR GROUND/LIVE PTO	119	87089900	18
10036655AASG	Solis Tractor MAINTENANCE FREE BATTERY 80AH	13153	85070000	28

10036682AASG	Solis Tractor RADIATOR MTG BRACKET	555	87089900	18
10036690ABSG	Solis Tractor PROPELLER SHAFT COVER REAR SIDE	1396	84835010	18
10036691ABSG	Solis Tractor PROPELLER SHAFT COVER FRONT SIDE	1099	84835010	18
10036700AASG	Solis Tractor DIRETIONAL CONTROL VALVE (SINGLE ACTING)	4992	84814000	18
10036703AASG	Solis Tractor 90° ORFS ELBOW M12X1.5 & 9/16 UNF	206	87089400	18
10036704AASG	Solis Tractor 135° ORFS ELBO M12X1.5 & 9/16 UNF	241	87089400	18
10036790ABSG	Solis Tractor STAY ROD CLIP (DI)	8	87089900	18
10037028ABSG	Solis Tractor PTO HUB	199	87089900	18
10037032ABSG	Solis Tractor PTO MOUNTING BRACKET	545	87089900	18
10037042AASG	Solis Tractor LEVER ASSY.PTO (CLUTCH ASSY - 10004686AB	1979	87089300	18
10037051ABSG	Solis Tractor SPL BOLT M16	171	73181600	18
10037054AASG	Solis Tractor SHORT COUPLER (WATERPROOF)	63	87089900	18
10037057AASG	Solis Tractor DUMMY CAP SWITCH	11	85361010	18
10037108AASG	Solis Tractor SPLINED BUSH	616	87084000	18
10037164ABSG	Solis Tractor TRUMPET HOUSING (FINISH)	14307	87085000	18
10037198ABSG	Solis Tractor BRACKET	1748	87085000	18
10037199BASG	Solis Tractor GEAR Z-57	1971	87084000	18
10037205BASG	Solis Tractor GEAR Z-18	829	87084000	18
10037218ADSG	Solis Tractor FRONT HOUSING (SUB ASSY.) INFIELDER	2602	87085000	18
10037219ACSG	Solis Tractor REAR HOUSING (SUB ASSY.)	2286	87089900	18
10037233BBSG	Solis Tractor INPUT SHAFT (Z-19) DUAL CLUTCH	2832	87084000	18
10037245AASG	Solis Tractor DOG CLUTH GEAR ASSY Z-40	2654	87084000	18
10037261BBSG	Solis Tractor GEAR SHIFTER ROD 4TH -5TH	435	87089900	18
10037263ABSG	Solis Tractor GEAR SHIFTER ROD 2ND-3RD	445	87084000	18
10037264AASG	Solis Tractor GEAR SHIFTER ROD 1ST	305	87084000	18
10037270AASG	Solis Tractor SPACER LAY SHAFT 1ST GEAR	90	87089900	18
10037308AASG	Solis Tractor FIXED GEAR 3RD(Z-46) (PART)	1901	87084000	18
10037320ACSG	Solis Tractor FIXED GEAR REV Z-23	863	87084000	18
10037332BBSG	Solis Tractor SHIFTER BUSH LOW-REV	339	87084000	18
10037351ABSG	Solis Tractor GEAR SHIFTER ROD HI	379	87084000	18
10037360AASG	Solis Tractor FIXED GEAR 3RD(Z-45)	1802	87084000	18
10037381AASG	Solis Tractor SHIFTER FORK REV-LOW GEAR	575	87089900	18
10037384BBSG	Solis Tractor GEAR SHIFTER ROD REV-LOW	297	87084000	18
10037386AASG	Solis Tractor M5 COLLAR NUT	5	73181500	18
10037387AASG	Solis Tractor M6 COLLAR NUT	6	73181500	18
10037388AASG	Solis Tractor THRUST WAHSER (REV GEAR Z-25)	59	73182300	18
10037389AASG	Solis Tractor SHIFTER KNOB (DIFF. SPEED)	111	87089900	18
10037390AASG	Solis Tractor SHIFTER KNOB (RANGE REV))	99	87089900	18
10037425ABSG	Solis Tractor REV IDLER SHAFT	210	87084000	18
10037427ACSG	Solis Tractor SLEEVE 4TH & 5TH GEAR	647	87084000	18
10037428BDSG	Solis Tractor HUB FOR 4TH & 5TH GEAR	374	87084000	18
10037449AASG	Solis Tractor SPECIAL SCREW	21	87089900	18
10037502ABSG	Solis Tractor PLATE	470	87089900	18
10037524ACSG	Solis Tractor DOG CLUTCH GEAR REV ASSYZ-41	2544	87084000	18
10037525CASG	Solis Tractor BEARING HOUSING REAR	1480	84833000	18
10037553BBSG	Solis Tractor FIXED GEAR 1ST (Z-30) (PART)	1510	87084000	18
10037577AASG	Solis Tractor SHIFTER FORK HI GEAR	570	87089900	18
10037595ABSG	Solis Tractor LAY SHAFT (PART)	2651	87084000	18
10037596BASG	Solis Tractor SPACER FOR LOWER GEAR	106	87089900	18
10037604BASG	Solis Tractor CONNECTING SLEEVE (PART)	501	87084000	18
10037635ABSG	Solis Tractor FEMALE QUICK CONNECT COUPLING-1/2BSP	660	84814000	18

10037688AASG	Solis Tractor DOG CLUTH GEAR ASSY Z-41	2634	87084000	18
10037707ACSG	Solis Tractor OIL SPLASHER FOR 8+2 2WD	87	87084000	18
10037713BBSG	Solis Tractor INPUT SHAFT Z-20 (DC) (PART NO.)	2578	87084000	18
10037729ABSG	Solis Tractor NYLON BUSH	38	84833000	18
10037734ABSG	Solis Tractor SHIFTER HOUSING ASSY	1828	87084000	18
10037778BASG	Solis Tractor INPUT SHAFT Z-21 (DC) (PART NO.)	2611	87084000	18
10037778BCSG	Solis Tractor INPUT SHAFT Z-21 (DC) (PART NO.)	2537	87084000	18
10037805BBSG	Solis Tractor FIXED 1ST GEAR Z-29 (FINISH PART NO.)	1683	87084000	18
10037849ABSG	Solis Tractor DOG CLUTCH GEAR ASSY 2ND (Z-33)	1697	87084000	18
10037939ABSG	Solis Tractor ROCKER LINK ASSY.	1944	87089900	18
10037941ADSG	Solis Tractor THREADED BUSH	142	87084000	18
10038026BBSG	Solis Tractor FIXED 1ST GEAR Z-31 (FINISH PART NO.)	1013	87084000	18
10038041BBSG	Solis Tractor FIXED 1ST GEAR Z-28 (FINISH PART NO.)	1264	87084000	18
10038047AASG	Solis Tractor RUBBER GROMMET ANGLE BRACKET	13	40161000	18
10038059AASG	Solis Tractor PLASTIC INSERT FOR THREAD LOCK	11	39261011	18
10038108AASG	Solis Tractor REAR WHEEL W12X28 (WITH SILVER PT) (IN)	13918	87087000	18
10038142BASG	Solis Tractor HI-LOW LAYSHAFT 10+5 LIVE PTO Z-23 (FINI	2608	87084000	18
10038160BASG	Solis Tractor HI-LOW LAYSHAFT 10+5 LIVE PTO Z-24 (FINI	2610	87084000	18
10038189BASG	Solis Tractor INPUT SHAFT Z-20 (DC) (FINISH NO.)	2451	87084000	18
10038189BBSG	Solis Tractor INPUT SHAFT Z-20 (DC) (FINISH NO.)	2408	87084000	18
10038195BASG	Solis Tractor INPUT SHAFT Z-21 (DC) (FINISH NO.)	2506	87084000	18
10038268CASG	Solis Tractor BUSH FOR NEUTRAL SAFETY SWITCH (LOW-REV	228	87084000	18
10038270CASG	Solis Tractor BUSH FOR NEUTRAL SAFETY SWITCH (HI GEAR	189	87084000	18
10038294ADSG	Solis Tractor FUEL COCK ASSEMBLY	373	87089900	18
10038298ACSG	Solis Tractor HOSE FUEL TANK TO WATER SAPERATOR	385	40092200	18
10038299ACSG	Solis Tractor HOSE FUEL TANK TO WATER SAPERATOR	350	40091100	18
10038349AASG	Solis Tractor SEAL FRAME (FRONT LIGHT)	54	40082990	18
10038463AASG	Solis Tractor B.P SHAFT RIGHT (Z-13) FINISH	5052	87085000	18
10038469AASG	Solis Tractor B.P SHAFT LEFT (Z-13) FINISH	4436	87085000	18
10038492ABSG	Solis Tractor SHIELD PLATE RH (W/O PAINT)	192	87089900	18
10038493ABSG	Solis Tractor SHIELD PLATE LH (W/O PAINT)	362	87089900	18
10038507ACSG	Solis Tractor SHAFT DRAFT	520	87084000	18
10038523ABSG	Solis Tractor FLANGE WITH BUSH	193	84829900	18
10038524ABSG	Solis Tractor FLANGE	101	87089900	18
10038527AASG	Solis Tractor BUSH FOR LIP SEAL	38	87089900	18
10038528AASG	Solis Tractor METALLIC WASHER	107	73182990	18
10038529AASG	Solis Tractor BUSH FOR DRAFT SHAFT	189	84829900	18
10038530AASG	Solis Tractor BRAKE PEDAL SHAFT	1939	87083000	18
10038538AASG	Solis Tractor BRAKE PEDAL SHAFT	924	87083000	18
10038540AASG	Solis Tractor SHAFT & BASIC LEVER ASSY.	721	87084000	18
10038584AASG	Solis Tractor SPIDER KIT (10X16)	2413	87085000	18
10038599ABSG	Solis Tractor DIFF. CAGE ASSY. (10X16)	3275	87085000	18
10038604AASG	Solis Tractor ADJUSTABLE TIE ROD	303	87089900	18
10038619AASG	Solis Tractor DRIVE SHAFT (FINISH NO.)	2728	87084000	18
10038660BASG	Solis Tractor BRAKE HOUSING LEFT (OIB) FINISH	3447	87083000	18
10038671AASG	Solis Tractor GEAR P.T.O Z-55(FINISH NO.)	2874	87084000	18
10038679BASG	Solis Tractor BRAKE HOUSING RIGHT (OIB) FINISH	3447	87083000	18
10038701ABSG	Solis Tractor PIPE FROM DCV HPCO TO REAR COVER HPCO	990	87081010	18
10038702ABSG	Solis Tractor SECONDARY PIPE FROM PUMP TO DCV P	1476	87081010	18
10038703ADSG	Solis Tractor INTERMEDIATE PIPE FROM PUMP TO DCV P	1320	73061929	18
10038704AASG	Solis Tractor PRIMARY PIPE FROM PUMP TO DCV P	1040	87081010	18

10038705ADSG	Solis Tractor SECONDARY PIPE FROM PUMP TO STEERING UNI	959	73061929	18
10038709ACSG	Solis Tractor INTERMEDIATE PIPE FROM PUMP TO DCV P	1413	87084000	18
10038710ABSG	Solis Tractor SECONDARY PIPE FROM PUMP TO DCV P	1370	87081010	18
10038715ABSG	Solis Tractor PRIMARY PIPE FROM PUMP TO STG UNIT	762	73061929	18
10038716ABSG	Solis Tractor SECONDARY PIPE FROM PUMP TO STG UNIT	688	73061929	18
10038720ABSG	Solis Tractor SUCTION PIPE DIFFERENTIAL TO STRAINER	823	87081010	18
10038722ACSG	Solis Tractor SUCTION PIPE FROM FILTER TO HYDRAULIC PU	750	73061929	18
10038724ABSG	Solis Tractor PIPE FROM DCV TO REAR COVER HPCO	1177	87081010	18
10038726AASG	Solis Tractor ADOPTER M24X1.5 - G1/2"	116	87081010	18
10038726ADSG	Solis Tractor ADOPTER M24X1.5 - G1/2"	137	87084000	18
10038727ABSG	Solis Tractor CLAMP ASSY	139	87089900	18
10038729ABSG	Solis Tractor DCV MOUNTING BRACKET ASSY	570	87089900	18
10038732ACSG	Solis Tractor ADOPTER FOR HYDRAULIC FILTER	1042	87089900	18
10038734BASG	Solis Tractor DELIVERY ADOPTER	287	87089900	18
10038736AASG	Solis Tractor CLAMP ASSY	73	87089900	18
10038749ABSG	Solis Tractor SUCTION PIPE FROM STRAINER TO HOSE	462	87081010	18
10038751ABSG	Solis Tractor DCV MOUNTING BRACKET ASSEMBLY	737	87089900	18
10038761ABSG	Solis Tractor DCV LEVER ASSY UNPAINTED	241	87089900	18
10038764AASG	Solis Tractor 1 DOUBLE ACTING DCV	7832	84814000	18
10038774ABSG	Solis Tractor PRIMARY PIPE FROM PUMP TO DCV P	920	73061929	18
10038776AASG	Solis Tractor SUCTION PIPE FROM STRAINER TO HOSE	267	87081010	18
10038804BASG	Solis Tractor SHAFT POSITION	536	87089900	18
10038805BASG	Solis Tractor SHAFT DRAFT	314	87089900	18
10038829ACSG	Solis Tractor PRIMARY PIPE FROM PUMP TO STEERING UNIT	763	73061929	18
10038856AASG	Solis Tractor RADIATOR MOUNTING BRACKET ASSEMBLY Rx	594	87089100	18
10038860AASG	Solis Tractor RUBBER PAD RADIATOR (TOP)	30	40161000	18
10038869ABSG	Solis Tractor WASHER RADIATOR MTG. TOP	23	73182300	18
10038870ABSG	Solis Tractor WASHER RADIATOR MTG. BOTTOM	17	73182300	18
10038876ABSG	Solis Tractor DRIVER SEAT (3 CYL MINOR FACELIFT)	7659	94010000	18
10038878ABSG	Solis Tractor SPACER 3.0mm	72	87089900	18
10038889ABSG	Solis Tractor DCV MOUNTING BRACKET ASSY	425	87089900	18
10038891ABSG	Solis Tractor DCV LEVER ASSY UNPAINTED	209	87089900	18
10038893ABSG	Solis Tractor PIPE FROM DCV TO REAR COVER HPCO	1033	87081010	18
10038894ACSG	Solis Tractor SECONDARY PIPE FROM PUMP TO DCV P	1349	73061929	18
10038895AASG	Solis Tractor ELBOW ADJUSTABLE ADOPTER G1/2 X G3/8	466	87089900	18
10038906ABSG	Solis Tractor RUBBER PAD RADIATOR (BOTTOM)	25	40161000	18
10038916BASG	Solis Tractor BEARING HOUSING FRONT(FINISH.)	590	87085000	18
10039083ABSG	Solis Tractor RELEASE VALVE ASSY.	321	84811000	18
10039084ABSG	Solis Tractor RELIEF VALVE ASSY.	321	84811000	18
10039155AASG	Solis Tractor ROCK SHAFT	5957	87084000	18
10039156ABSG	Solis Tractor RAM CYLINDER ARM	3819	87081010	18
10039157ABSG	Solis Tractor RAM ARM CAM	399	87081010	18
10039159ABSG	Solis Tractor ADOPTER TUBE	182	87089900	18
10039188ABSG	Solis Tractor SPRING CLUTCH ASSY	86	87089300	18
10039221AASG	Solis Tractor BETA PIN DIA 4.5	15	73182300	18
10039233AASG	Solis Tractor HEX FLANGE NUT M10-8.8 SA4GS	13	73181500	18
10039237AASG	Solis Tractor BETA PIN DIA 6	31	73181500	18
10039293AASG	Solis Tractor DOME CAP NUT M10 (IS2687-5S)	15	73181500	18
10039304AASG	Solis Tractor SUPPORT (ACTUATOR)	413	87089900	18
10039341AASG	Solis Tractor WASHER(FOR BRAKE PEDAL SHAFT)	11	73181500	18
10039343AASG	Solis Tractor WASHER	7	73060000	18

10039348AASG	Solis Tractor FOAM SEALING RADIATOR BOTTOM	124	39201099	18
10039371AASG	Solis Tractor WASHER FOR EPA	18	73182990	18
10039401AASG	Solis Tractor SHIELD PLATE RH (BLACK PAINTED)	167	87089900	18
10039438ABSG	Solis Tractor U -FORK	24	87089900	18
10039460ABSG	Solis Tractor CLAMP ASSY	77	82050000	18
10039461AASG	Solis Tractor TUBE ADOPTER M24X1.5	176	87081010	18
10039462AASG	Solis Tractor PIPE FROM DCV T TO REAR COVER TANK	225	87081010	18
10039467ABSG	Solis Tractor STOPPER ASSY.	233	87089900	18
10039471ABSG	Solis Tractor PIPE FROM STEERING UNIT L TO STEERING CY	865	87089900	18
10039472BASG	Solis Tractor PIPE FROM STEERING UNIT R TO STEERING CY	965	73061929	18
10039505ACSG	Solis Tractor LOCK WASHER	12	87089900	18
10039520AASG	Solis Tractor HEX. NUT(BRAKE ADJUSTER) FOR EPA	15	73182300	18
10039601AASG	Solis Tractor SPECIAL WASHER FOR FRONT WEIGHT (FOR EPA	58	73181600	18
10039609AASG	Solis Tractor HEX NUT M18*1.5 (8 REAR AXLE) FOR EPA	47	73182300	18
10039734AASG	Solis Tractor Main tool kit for tractors	53159	82060090	18
10039735AASG	Solis Tractor Puller & Installer tool kit for Tractors	15892	82060090	18
10039736AASG	Solis Tractor Jack kit for Tractors	25836	82060090	18
10039737AASG	Solis Tractor Fitment & Removal Tool kit for SOLIS- SN	18968	82060090	18
10039738AASG	Solis Tractor Mandrel Tool kit for SOLIS- SN Series	23096	82060090	18
10039739AASG	Solis Tractor Jack kit for SOLIS - SN Series Tractors	8084	82060090	18
10039827AASG	Solis Tractor LIFT ARM	3590	87089900	18
10039828AASG	Solis Tractor KIT RELIFE VALVE	1601	87089900	18
10039966AASG	Solis Tractor Gear Box Assy For Infielder	12538	87084000	18
10039968ABSG	Solis Tractor FRONT AXLE ASSY GT26	60781	87085000	18
10040536ACSG	Solis Tractor CAP ASSY. FOR REAR COVER	208	87089900	18
10040640ABSG	Solis Tractor SUB ASSY 2ND GEAR	2300	87084000	18
10040684ABSG	Solis Tractor SHIFTER ROD (RANGE SIDE)	766	87089900	18
10040781AASG	Solis Tractor SPACER IST T.P OF 0.67MM	37	87084000	18
10040782AASG	Solis Tractor SPACER IST T.P OF 0.87MM	37	87084000	18
10040786ABSG	Solis Tractor MITA HYDRAULIC LIFT WITH LIFTOMATIC	71617	87089900	18
10040798ABSG	Solis Tractor INTERMEDIATE SHAFT & BUSH SUB ASSY	5153	87084000	18
10040805AASG	Solis Tractor SUB ASSY 2ND GEAR	1962	87084000	18
10040818AASG	Solis Tractor LOW & MEDIUM GEAR Z56/Z33	2877	87084000	18
10040824AASG	Solis Tractor GEAR Z-55-40/Z55/42	2800	87084000	18
10040830AASG	Solis Tractor GEAR Z46 (LOW DRIVEN)	1939	87084000	18
10040857AASG	Solis Tractor ACTUATOR FORK	73	87089900	18
10040954ABSG	Solis Tractor BEARING HOLDER PLATE (FINISH)	3414	87089900	18
10041055AASG	Solis Tractor BUSH & CONNECTING SHAFT SUB ASSY MST	3220	40169990	18
10041055ABSG	Solis Tractor BUSH AND CONNECTING SHAFT ASSY.	3255	87084000	18
10041069AASG	Solis Tractor FULCRUM RING	47	87089300	18
10041089AASG	Solis Tractor BUSH (FOR PARKING BRAKE)	150	87089900	18
10041101ABSG	Solis Tractor MOUNTING BKT. ASSY. REAR TOW HOOK (LEFT)	1305	87089900	18
10041107ABSG	Solis Tractor MOUNTING BKT. ASSY. REAR TOW HOOK (RIGHT)	1305	87089900	18
10041147ACSG	Solis Tractor SHAFT FRONT PTO 4WD (PAINTED)	4853	87085000	18
10041175AASG	Solis Tractor GEAR PTO Z-64 (FINISH)	3319	40169990	18
10041248AASG	Solis Tractor DRIVE SHAFT	4590	87084000	18
10045022ADSG	Solis Tractor FLOOR MTG BKT ASSY RH	622	87089900	18
10045023ADSG	Solis Tractor FLOOR MTG BKT ASSY LH	630	87089900	18
10045041ACSG	Solis Tractor ACRYLIC SHEET RH	898	39201099	18
10045042ACSG	Solis Tractor ACRYLIC SHEET LH	898	39201099	18
10045067ACSG	Solis Tractor CLUTCH PEDAL ASSY	918	87089300	18

10045075ABSG	Solis Tractor CLUTCH LINKAGE ASSY	993	87089300	18
10045083ABSG	Solis Tractor FRONT MTG BKT ASSY (FOR THROTTLE)	325	87089900	18
10045090ACSG	Solis Tractor BRAKE PEDAL ASSY RIGHT	894	87083000	18
10045091ACSG	Solis Tractor BRAKE PEDAL ASSY LEFT	916	87083000	18
10045091ADSG	Solis Tractor BRAKE PEDAL ASSY LEFT	1008	87089900	28
10045106ACSG	Solis Tractor BRAKE LINKAGE ASSY LH	554	87083000	18
10045107ACSG	Solis Tractor BRAKE LINKAGE ASSY RH	554	87083000	18
10045127ACSG	Solis Tractor BRAKE HUB ASSY LH	380	87083000	18
10045128ADSG	Solis Tractor BRAKE HUB ASSY RH	405	87083000	18
10045137ABSG	Solis Tractor REAR HUB ASSY RH FOR BRAKE	346	87089900	18
10045140ACSG	Solis Tractor REAR HUB ASSY LH FOR BRAKE	203	87089900	18
10045145ACSG	Solis Tractor HUB FOR IPTO LEVER WT	395	87089900	18
10045154ACSG	Solis Tractor INTERMEDIATE HUB FOR IPTO	382	87089900	18
10045160ABSG	Solis Tractor HINGE BKT FOR IPTO LEVER	300	87089900	18
10045168ABSG	Solis Tractor HUB MTG BKT	429	87084000	18
10045179ABSG	Solis Tractor GROMMET RANGE & SPEED LEVER RUBBER BELOW	288	40169310	18
10045182ABSG	Solis Tractor FOOT THROTTLE LUG ASSY	66	87089900	18
10045182ACSG	Solis Tractor FOOT THROTTLE LUG ASSY	70	87089900	18
10045187ADSG	Solis Tractor FRONT WEIGHT (FABRICATION)	7561	87089900	18
10045192ABSG	Solis Tractor STRAP ASSY.	55	87089900	18
10045196BBSG	Solis Tractor CLAMP ASSY	41	87089900	18
10045199ACSG	Solis Tractor FOOT STEP SUPPORT CHANNEL ASSY RH	508	87089900	18
10045200ACSG	Solis Tractor FOOT STEP SUPPORT CHANNEL ASSY LH	508	87089900	18
10045206ACSG	Solis Tractor SHUTTLE LEVER ASSY	212	87089900	18
10045212ABSG	Solis Tractor LUG ASSY FOR SHUTTLE LEVER	164	87084000	18
10045215AGSG	Solis Tractor FLOOR ASSY LH IPTO 3 CYL	228	87089900	18
10045223ABSG	Solis Tractor 4WD ACTUATOR ROD	216	87089900	18
10045223ACSG	Solis Tractor 4WD ACTUATOR ROD	195	87089900	18
10045225BASG	Solis Tractor PRIMARY PIPE PUMP TO BACK END	1757	73061929	18
10045228ACSG	Solis Tractor BRAKE LINKAGE ASSY	239	87083000	18
10045229ACSG	Solis Tractor REAR IPTO LINKAGE ASSY	257	87089900	18
10045230ACSG	Solis Tractor FRONT IPTO LINKAGE ASSY	294	87089900	18
10045243ABSG	Solis Tractor GEAR SHIFTER LEVER	364	87084000	18
10045247BASG	Solis Tractor SUCTION PIPE HOSE TO FILTER HOSE	321	73061929	18
10045249BBSG	Solis Tractor SECONDARY PIPE PUMP TO STEERING UNIT	937	73061929	18
10045250BBSG	Solis Tractor PRIMARY PIPE STEERING UNIT TO STEERING T	685	73061929	18
10045250CASG	Solis Tractor PRIMARY PIPE STEERING UNIT TO STEERING T	271	87089900	18
10045251BASG	Solis Tractor SECONDARY PIPE STEERING UNIT TO STEERI	439	73061929	18
10045252BBSG	Solis Tractor METALLIC PIPE STG UNIT L TO CYL LH	634	73061929	18
10045253BBSG	Solis Tractor METALLIC PIPE STG UNIT R TO CYL RH	663	73061929	18
10045255ABSG	Solis Tractor STRAP MTG PLATE UNPAINTED	74	87089900	18
10045256ABSG	Solis Tractor STRAP MTG PLATE BLACK PAINTED	67	87089900	18
10045257AFSG	Solis Tractor BONNET RESTING PLATE UNPAINTED	1004	87089900	18
10045260ABSG	Solis Tractor SEAT MTG BKT	602	87089900	18
10045261ABSG	Solis Tractor GUIDE PAD FOR IPTO	47	87085000	18
10045262ABSG	Solis Tractor CLAMP ASSY FOR SUCTION PIPE	47	73269099	18
10045266ACSG	Solis Tractor POSITION LEVER ASSY	246	87089900	18
10045267ACSG	Solis Tractor DRAFT LEVER ASSY	244	87089900	18
10045268ABSG	Solis Tractor DRAFT LEVER LINKAGE	82	87089900	18
10045269ABSG	Solis Tractor POSITION LEVER LINKAGE	84	87089900	18
10045270ABSG	Solis Tractor LEVER MTG SHAFT	116	87089900	18

10045271BBSG	Solis Tractor SUCTION PIPE STEERING TANK TO HOSE	341	73061929	18
10045274ABSG	Solis Tractor BRACKET FOR STEERING TANK	229	87089900	18
10045275ABSG	Solis Tractor RANGE LEVER ASSY	364	87089900	18
10045285ADSG	Solis Tractor IPTO SHIFTER LEVER	608	87084000	18
10045286ABSG	Solis Tractor DIFF LOCK ASSY	83	87089900	18
10045286ADSG	Solis Tractor DIFF LOCK ASSY	102	87089900	18
10045287ADSG	Solis Tractor STEERING MTG BKT ASSY	326	87089900	18
10045306ABSG	Solis Tractor TIE ROD FOR SHUTTLE LEVER	447	87089900	18
10045307BBSG	Solis Tractor FLOOR MAT (W/O CREEPER)	5807	39073010	18
10045319ABSG	Solis Tractor Clamp Assembly for delivery pipe	49	73269099	18
10045334AFSG	Solis Tractor FRONT AXLE BRACKET 4 CYL (PS)	35059	87081010	18
10045338ABSG	Solis Tractor LUG ASSY FOR PARKING BRAKE	147	87083000	18
10045342ABSG	Solis Tractor CLUTCH TORSION SPRING	77	73201011	18
10045343ABSG	Solis Tractor Brake tortional spring	77	73201011	18
10045370BCSG	Solis Tractor FLOOR ASSY W/O CREEPER	4536	87089900	18
10045377ABSG	Solis Tractor FRONT REMOVABLE WT 29KG	4607	87081010	18
10045381ABSG	Solis Tractor BRAKE PEDAL SHAFT	876	87083000	18
10045385BASG	Solis Tractor REAR FLOOR ASSY	5991	87089900	18
10045385BDSG	Solis Tractor REAR FLOOR ASSY	7394	87089900	18
10045390ABSG	Solis Tractor TIE ROD (FOOT PEDAL TO AXLE)	46	87089900	18
10045393ADSG	Solis Tractor TIE ROD LINK ASSY	44	87089900	18
10045395ACSG	Solis Tractor SPACER 4MM	12	73181500	18
10045399ABSG	Solis Tractor HAND BRAKE COVER	256	87083000	18
10045439ACSG	Solis Tractor FRONT REMOVABLE WEIGHT 30 KG.	5125	87089900	18
10045441ACSG	Solis Tractor LIFTOMATIC WIRE	252	85440000	18
10045443ABSG	Solis Tractor Fuel pipe fuel tank to water seprator.	626	73061929	18
10045451ACSG	Solis Tractor RADIATOR SEALING PLATE BOTTOM	439	87089100	18
10045453ABSG	Solis Tractor TRIANGULAR PLATE FOR THROTTLE	55	87089900	18
10045455ACSG	Solis Tractor Mtg bkt for fuel cock	38	87089900	18
10045458ADSG	Solis Tractor Bracket fuel tank side holding	47	87089900	18
10045459ABSG	Solis Tractor RUBBER FLAP	80	40169990	18
10045462ABSG	Solis Tractor Hub asy for diff lock	124	87089900	18
10045511AESG	Solis Tractor BONNET RESTING PLATE	765	87089900	18
10045556ACSG	Solis Tractor FLEXIBLE SHAFT ASSY	96	87084000	18
10045560ABSG	Solis Tractor STICKER SERVICE MODEL WITH DRY FILTER	35	39191000	18
10045561ABSG	Solis Tractor STICKER CORRECT METHOD OF USING LIFT	47	39191000	18
10045615ACSG	Solis Tractor EXHAUST ELBOW	1746	87089200	18
10045624ABSG	Solis Tractor SEALING PLATE TOP TIE	40	87089900	18
10045637AESG	Solis Tractor FUEL TANK FRAME ASSEMBLY	5046	87089900	18
10045671ACSG	Solis Tractor BACK PLATE SUPPORT BRACKET	154	87089900	18
10045672ACSG	Solis Tractor POWER STEERING COLUMN	2594	87089900	18
10045673ACSG	Solis Tractor POWER STEERING COLUMN	2580	87089400	18
10045674ADSG	Solis Tractor MOBILE CHARGER SOCKET	191	85365090	18
10045683ACSG	Solis Tractor WIRE FOOT THROTTLE ASSY	292	87081010	18
10045684ADSG	Solis Tractor WIRE HAND THROTTLE ASSY	266	87089900	18
10045744ADSG	Solis Tractor STEERING WHEEL ASSY	1550	87089400	18
10045762ABSG	Solis Tractor BEEDING FOR RADIATOR	63	40082990	18
10045771ABSG	Solis Tractor BONNET BEADING	211	40169990	18
10045772ABSG	Solis Tractor RADIATOR BEADING	95	40169990	18
10045773ADSG	Solis Tractor DASHBOARD LOWER COVER ASSY (DOMESTIC)	372	87089900	18
10045774ACSG	Solis Tractor FUSE BOX COVER	112	85361090	18

10045779ABSG	Solis Tractor RETAINING WASHER DIA 6	6	73182300	18
10045780ABSG	Solis Tractor RETAINING WASHER DIA 10	10	73182300	18
10045785ABSG	Solis Tractor CLAMP ASSY	63	82050000	18
10045786ABSG	Solis Tractor SUCTION PIPE (WITH SUPPORT)	176	87089900	18
10045799ABSG	Solis Tractor HOSE (THERMOSTAT TO RADIATOR)	158	40091100	18
10045804ACSG	Solis Tractor BONNET SIDE SEALING PLATE LH	133	87089900	18
10045807ACSG	Solis Tractor BONNET SIDE SEALING PLATE LH WITH BLUE P	97	87089900	18
10045808ACSG	Solis Tractor BONNET SIDE SEALING PLATE LH	132	87089900	18
10045813ACSG	Solis Tractor LEVER COMBINATION SWITCH	1553	85369030	18
10045825AESG	Solis Tractor WIRE HAND THROTTLE ASSY	273	87089900	18
10045877ABSG	Solis Tractor BONNET LOCK ASSY	392	87089900	18
10045886ABSG	Solis Tractor Cluster Dashboard	1443	87089900	18
10045888AASG	Solis Tractor Cluster decorator LH	154	85122010	18
10045889AASG	Solis Tractor Cluster decorator RH	154	85122010	18
10045891AASG	Solis Tractor Cluster Facia	133	90292090	18
10045894AASG	Solis Tractor Cluster Reset backcover	54	90292090	18
10045916BASG	Solis Tractor SECONADRY PIPE PUMP TO HYD LIFT	1263	73061929	18
10045917BASG	Solis Tractor CLAMP ASSY SUCTION PIPE	83	87089900	18
10045920ADSG	Solis Tractor SUPPORT BRKT LH	17	87089900	18
10045921ADSG	Solis Tractor SUPPORT BRKT RH	17	87089900	18
10045923ABSG	Solis Tractor KNOB ASSY FOR OPERATING SECTOR	33	87089900	18
10045930AASG	Solis Tractor REINFORCEMENT FENDER TOP PANNEL	156	87089900	18
10045933AASG	Solis Tractor SUCTION HOSE	230	40092200	18
10045934ABSG	Solis Tractor HEX SHAFT WITH SLIDER	31	87089900	18
10045935ABSG	Solis Tractor KNOB ASSY	18	87089900	18
10045983ACSG	Solis Tractor FUEL TANK 65 LTR	6401	87089900	18
10045984AESG	Solis Tractor FUEL TANK	5053	87089900	18
10046049AASG	Solis Tractor LIFTOMATIC SWITCH COVER	160	87089900	18
10046069AASG	Solis Tractor STICKER FOR POSITION AND DRAFT INDICATIO	16	39191000	18
10046074ACSG	Solis Tractor EEXHAUST ELBOW FINISH	2005	87089200	18
10046080AASG	Solis Tractor EXHAUST ELBOW FOR 4 CYL WITHOUT UNDERHOO	1188	87089200	18
10046085AASG	Solis Tractor CANOPY MTG REINF	18	87089900	18
10046094AASG	Solis Tractor FLOOR MAT SIDE CHROME STRIP ASSY (LH)	126	39073010	18
10046095AASG	Solis Tractor FLOOR MAT SIDE CHROME STRIP ASSY (RH)	126	39073010	18
10046136AASG	Solis Tractor SPRING FOOT THROTTLE	16	73201011	18
10046137AASG	Solis Tractor SPRING CLUTCH PEDAL	34	73201011	18
10046155ACSG	Solis Tractor FENDER SEAT GAURD ASSEMBLY	1794	87089900	18
10046165AASG	Solis Tractor SOLIS LOGO FRONT	113	83100010	18
10046170AASG	Solis Tractor TIE ROD (DOUBLE)	72	87089900	18
10046173ABSG	Solis Tractor FENDER SEAT	2518	94012000	18
10046193ABSG	Solis Tractor ASSY DASHBOARD MTG BKT LH - MST	38	87089900	18
10046194ABSG	Solis Tractor ASSY DASHBOARD MTG BKT RH - MST	38	87089900	18
10046198BBSG	Solis Tractor TIE ROD THROTTLE LEVER (DUAL CLUTCH)	54	87083000	18
10046205AASG	Solis Tractor CAP FOR PEDAL	9	40161000	18
10046206ABSG	Solis Tractor HAND ACC WIRE MTG BKT	70	87081010	18
10046255ABSG	Solis Tractor FENDER MTG BKT ASSY	12	87089900	18
10046259ACSG	Solis Tractor BRAKE SWITCH MTG BKT ASSY	72	87089900	18
10046261AASG	Solis Tractor PEDAL SUPPORT PLATE LOWER ASSY	27	87089900	18
10046289ACSG	Solis Tractor DASHBOARD FRONT COVER RX (WITHOUT TILTAB	574	87089900	18
10046334AMSG	Solis Tractor DASHBOARD ASSY RX-FACELIFT W/O PAINT	6894	87089900	18
10046340AISG	Solis Tractor DASHBOARD ASSY MST-FACELIFT(BLUE PAINTED	5017	87089900	18

10046359ACSG	Solis Tractor DASHBOARD FRONT COVER RX RED PAINT	783	87089900	18
10046362ABSG	Solis Tractor DASHBOARD FRONT COVER MST W/OUT TIL-RED	335	87089900	18
10046371ACSG	Solis Tractor TOP MESH	273	87089900	18
10046371ADSG	Solis Tractor TOP MESH	255	87089900	18
10046402AASG	Solis Tractor REAR FLOOR COVER PLATE	163	87089900	18
10046445AASG	Solis Tractor COVER ASSY (EXHAUST ELBOW)	272	87089900	18
10046460ABSG	Solis Tractor FLOOR MAT SIDE CHROME STRIP ASSY LH	227	39073010	18
10046460ACSG	Solis Tractor FLOOR MAT SIDE CHROME STRIP ASSY (LH)	241	87089900	18
10046461ABSG	Solis Tractor FLOOR MAT SIDE CHROME STRIP ASSY RH	227	39073010	18
10046461ACSG	Solis Tractor FLOOR MAT SIDE CHROME STRIP ASSY (RH)	241	87089900	18
10046474ABSG	Solis Tractor DCV LEVER	79	87089900	18
10046490AASG	Solis Tractor REAR FLOOR MTG BKT ASSY	116	87089900	18
10046512AASG	Solis Tractor PARKING BRAKE ASSY (MST FACELIFT)	855	87083000	18
10046564ABSG	Solis Tractor STRAP ASSY.	40	87089900	18
10046590ABSG	Solis Tractor PTO LEVER ASSY	557	87089900	18
10046597ADSG	Solis Tractor SHUTTLE LEVER ROD (MST FACELIFT)	616	87089900	18
10046605AASG	Solis Tractor TIE ROD (FIP TO TRIANGULAR PLATE)	370	87089900	18
10046620AASG	Solis Tractor GROMMET FOR SHUTTLE LEVER	15	40169310	18
10046623AASG	Solis Tractor GEAR SHIFTER LEVER	730	87084000	18
10046643ABSG	Solis Tractor FUEL TANK ASSY MST FACELIFT	13464	87089900	18
10046648AASG	Solis Tractor SONALIKA LOGO PLATE (BONNET FRONT MESH)	215	83100010	18
10046673AASG	Solis Tractor Switch for signature light	434	85361010	18
10046702AASG	Solis Tractor STICKER S 7	5	39199010	18
10046751ABSG	Solis Tractor CLUSTER ASSY LOW END	7771	90292020	28
10046755ABSG	Solis Tractor CLUSTER ASSY HIGH END	9603	90292020	28
10046756AASG	Solis Tractor CLUSTER ASSY HIGH END(1800 RPM)	9603	90292020	28
10046836ABSG	Solis Tractor STEERING WHEEL ASSY	1883	87089400	18
10050612ABSG	Solis Tractor SHIFTER KNOB (PTO)	99	87084000	18
10050684ACSG	Solis Tractor FIXED GEAR Z-34 FOR 4WD	689	87084000	18
10050685AESG	Solis Tractor BEARING HOUSING	330	84833000	18
10050688ABSG	Solis Tractor RUBBER SEAL	28	40161000	18
10050689BASG	Solis Tractor PTO INTERMEDIATE SHAFT	1107	87084000	18
10050695ABSG	Solis Tractor INTERMEDIATE SHAFT	951	87084000	18
10050697ACSG	Solis Tractor SLIDING GEAR Z-33 (1ST / REV)	857	87084000	18
10050699AESG	Solis Tractor GEAR SHIFTER HOUSING	1456	87084000	18
10050702AESG	Solis Tractor RUBBER BOOT	87	40161000	18
10050703ABSG	Solis Tractor SHIFTER ROD 1ST / REV	133	87084000	18
10050704ABSG	Solis Tractor SHIFTER ROD 2ND / 3RD	133	87084000	18
10050705AESG	Solis Tractor SHIFTER FORK	462	87084000	18
10050709ACSG	Solis Tractor LOCKING PLATE	92	87089900	18
10050711ADSG	Solis Tractor CONICAL SPRING	34	73201011	18
10050714AFSG	Solis Tractor PIN ASSY HI / LO	281	73182300	18
10050715ADSG	Solis Tractor LOCKING PLATE	39	87089900	18
10050718ABSG	Solis Tractor SPACER BIG (REAR AXLE)	138	87081010	18
10050719ADSG	Solis Tractor G.T BULL GEAR	3088	87084000	18
10050724ABSG	Solis Tractor SLIDING GEAR Z-15 (4WD)	449	87084000	18
10050728ACSG	Solis Tractor WASHER (PTO)	41	73182300	18
10050729ADSG	Solis Tractor PTO FIXED GEAR Z-30	1133	87084000	18
10050731ADSG	Solis Tractor IDLER GEAR Z-16	547	87084000	18
10050734ABSG	Solis Tractor SLEEVE DIFF LOCK	694	87089900	18
10050735ABSG	Solis Tractor SLEEVE	239	87081010	18

10050736ABSG	Solis Tractor SPACER (PTO INTERMEDIATE SHAFT)	46	87081010	18
10050738ACSG	Solis Tractor LOCKING HUB	747	87089900	18
10050749AASG	Solis Tractor SPRING DIFF LOCK	43	73201011	18
10050749ABSG	Solis Tractor SPRING DIFF LOCK	43	73201011	18
10050750ACSG	Solis Tractor LUG DIFF LOCK ASSY	174	73182300	18
10050773ABSG	Solis Tractor WITHDRAWAL NUT	84	73182300	18
10050774ACSG	Solis Tractor LOCKING WASHER	14	73182300	18
10050775ACSG	Solis Tractor RING	271	40161000	18
10050776ACSG	Solis Tractor WASHER (T.P. SHAFT)	44	73182300	18
10050779ABSG	Solis Tractor FIXED GEAR Z-18 (HI GEAR)	550	87084000	18
10050789ABSG	Solis Tractor SPACER BIG (REAR AXLE)	50	87081010	18
10050793AASG	Solis Tractor SHIMS SMALL (T.P. SHAFT)-0.20	8	73182300	18
10050799AASG	Solis Tractor SHIMS BIG (T.P. SHAFT)-0.20	7	73182910	18
10050802ABSG	Solis Tractor IDLER SHAFT	122	87084000	18
10050807ABSG	Solis Tractor WASHER (IDLER SHAFT)	29	73182300	18
10050809ABSG	Solis Tractor BRACKET	177	87085000	18
10050812AKSG	Solis Tractor FORK ASSY 4WD	273	87084000	18
10050812ALSG	Solis Tractor FORK ASSY 4WD	273	87089900	18
10050813AFSG	Solis Tractor DIFF. CAGE	1936	87089900	18
10050821AASG	Solis Tractor LOCKING WASHER (CROWN WHEEL)	12	73182300	18
10050833ABSG	Solis Tractor PINION SHAFT	123	87089900	18
10050840ADSG	Solis Tractor CAGE CARRIER LEFT	530	87085000	18
10050843ACSG	Solis Tractor CAGE CARRIER RIGHT	567	87085000	18
10050848ABSG	Solis Tractor SHIMS 0.15 (FOR CAGE CARRIER)	17	73182910	18
10050849ABSG	Solis Tractor SHIMS 0.20 (FOR CAGE CARRIER)	17	73182910	18
10050851ABSG	Solis Tractor SHIMS 0.50 (FOR CAGE CARRIER)	23	73182910	18
10050852AASG	Solis Tractor LOCKING WASHER	12	73182990	18
10051001ABSG	Solis Tractor T.P.CARRIER	777	73259999	18
10051004CDSG	Solis Tractor Stub Axle Hsg	2309	87085000	18
10051005AFSG	Solis Tractor FRONT AXLE COVER	725	87081010	18
10051009AFSG	Solis Tractor FRONT AXLE	1950	87085000	18
10051010ACSG	Solis Tractor Front Axle Shaft	1184	87085000	18
10051015BASG	Solis Tractor STEERING ARM GUIDE	292	87089400	18
10051018AASG	Solis Tractor Bearing cover	146	87084000	18
10051018ABSG	Solis Tractor BEARING COVER	146	87085000	18
10051026ABSG	Solis Tractor Washer (STEERING ARM GUIDE)	38	73182300	18
10051027AASG	Solis Tractor Stub Axle	750	87085000	18
10051043BASG	Solis Tractor PIVOT PIN ASSY	383	73182300	18
10051045AASG	Solis Tractor DRAG LINK ASSY (RIGHT)	1296	87089900	18
10051046AASG	Solis Tractor THRUST WASHER	50	73182300	18
10051052ABSG	Solis Tractor BEVEL GEAR Z-15	895	87084000	18
10051053ABSG	Solis Tractor Bevel Gear Z-16 (Upper)	918	87084000	18
10051060ABSG	Solis Tractor SPACER SMALL (REAR AXLE)	60	87081010	18
10051064AASG	Solis Tractor Gasket Front Axle	27	84841010	18
10051065AASG	Solis Tractor Gasket (T.P. Carrier)	14	84841010	18
10051069AASG	Solis Tractor Shims (Cage Front Axle)-0.20	12	73182300	18
10051071AASG	Solis Tractor Shims (Cage Front Axle)	15	73182300	18
10051075AASG	Solis Tractor SHIMS (CAGE FRONT AXLE)-0.20	12	73182300	18
10051077AASG	Solis Tractor SHIMS (CAGE FRONT AXLE)-0.50	15	73182300	18
10051092ABSG	Solis Tractor Bevel Gear Z-16 (Lower)	66	87084000	18
10051114ABSG	Solis Tractor ADJUSTABLE TIE ROD (CLUTCH PEDAL)G.T.	360	87089900	18

10051138AASG	Solis Tractor BKT FOR BRAKE & CLUTCH SWITCH MTG.	18	87089300	18
10051143AASG	Solis Tractor FELT RING	8	40161000	18
10051148AASG	Solis Tractor SHIM 0.2MM FOR LAY SHAFT	10	73182300	18
10051150AASG	Solis Tractor SHIMS SMALL (T.P. SHAFT)-0.50	10	73182300	18
10051155AASG	Solis Tractor SHIMS BIG (T.P. SHAFT)-0.50	8	73182300	18
10051160AASG	Solis Tractor REAR TYRE 8*18 6 PLY RATING	12017	40117000	18
10051162AASG	Solis Tractor REAR TUBE 8*18	1510	40139049	18
10051202ABSG	Solis Tractor GASKET FOR GEAR SHIFTER HOUSING	28	84841010	18
10051224ADSG	Solis Tractor UNIVERSAL JOINT ASSY.	2488	73070000	18
10051239ABSG	Solis Tractor WASHER (DIFF. LOCK)	25	73182300	18
10051241AASG	Solis Tractor RUBBER FLAP	47	40091100	18
10051243ABSG	Solis Tractor Gasket for Front Axle Cover	17	84841010	18
10051244AGSG	Solis Tractor Assy trumpet Hsg Front (L)	5891	73251000	18
10051248AASG	Solis Tractor SPRING FOR FOOT THROTTLE	28	73201011	18
10051256ADSG	Solis Tractor Bush (Front Axle Assy.)	107	84833000	18
10051257AJS	Solis Tractor ASSY FRONT AXLE HSG	2546	87085000	18
10051260ABSG	Solis Tractor Bush (Inner bush assy.)	47	84834000	18
10051264ABSG	Solis Tractor DOWEL PIN (10X20)	17	82070000	18
10051270AASG	Solis Tractor BUSH PIN FOR REAR TOE HOOK	113	73182300	18
10051277AASG	Solis Tractor Sterring Arm Cap	18	87089400	18
10051280AASG	Solis Tractor SHIMS BIG (T.P. SHAFT)-.30	8	73182300	18
10051281AASG	Solis Tractor SHIMS SMALL (T.P. SHAFT)-0.30	8	73182300	18
10051282AASG	Solis Tractor Shims (Cage Front Axle)-0.30	12	73182300	18
10051283AASG	Solis Tractor SHIMS (CAGE FRONT AXLE)-0.30	12	73182300	18
10051284AASG	Solis Tractor SHIM 0.3MM FOR LAY SHAFT	7	73182910	18
10051293AGSG	Solis Tractor ASSY STEERING ARM SINGLE	1086	87089400	18
10051309AASG	Solis Tractor SHIM(GEAR Z-15)-0.20	8	73182910	18
10051310AASG	Solis Tractor SHIM(GEAR Z-15)-0.30	7	84830000	18
10051311AASG	Solis Tractor SHIM(GEAR Z-15)-0.50	8	84830000	18
10051312AASG	Solis Tractor SHIM(GEAR Z-16)-0.20	7	87084000	18
10051313AASG	Solis Tractor SHIM(GEAR Z-16)-0.30	10	84830000	18
10051314AASG	Solis Tractor SHIM(GEAR Z-16)-0.50	11	84830000	18
10051315AASG	Solis Tractor SEALING WASHER 6X10	6	73182300	18
10051317AASG	Solis Tractor SEALING WASHER 10X16	7	76160000	18
10051321ABSG	Solis Tractor HYDRAULIC PUMP	5902	84138190	18
10051330ABSG	Solis Tractor BREATHER ASSY	61	87089900	18
10051362AGSG	Solis Tractor CROWN WHEEL & TAIL PINION SET(8X41)	6667	87085000	18
10051363AESG	Solis Tractor CROWN WHEEL & TAIL PINION SET(8X41) F.A.	5989	87084000	18
10051484AASG	Solis Tractor SPACER (IDLER GEAR)	59	87081010	18
10051486AASG	Solis Tractor VIBRATION DAMPER	31	40091100	18
10051486ABSG	Solis Tractor VIBRATION DAMPER	31	40161000	18
10051537AASG	Solis Tractor LIP SEAL RING 12X22X7	45	40161000	18
10051538AASG	Solis Tractor LIP SEAL	72	40161000	18
10051564ABSG	Solis Tractor O RING ¥7.1X ¥1.9	15	40169320	18
10051592AASG	Solis Tractor BACK FLOW FUEL PIPE	270	40091100	18
10051599AASG	Solis Tractor PIPE FOR COOLANT TANK	68	40091100	18
10051600ACSG	Solis Tractor FUEL FEED PUMP ASSY (GT).	1968	84133010	28
10051627AASG	Solis Tractor FUEL FILTER 30N6200400 (STRAINER)	188	84213990	18
10051645ABSG	Solis Tractor RADIATOR BEEDING - GT RH	60	40082990	18
10051645ACSG	Solis Tractor RADIATOR BEEDING - GT RH	60	87089100	18
10051651ADSG	Solis Tractor O RING Å~18.3X Å~2.5	13	40161000	18

10051718AASG	Solis Tractor STUB AXLE WASHER	45	73182300	18
10051787AASG	Solis Tractor DIPSTICK FOR GARDEN TRAC	99	87081010	18
10051815AASG	Solis Tractor FIXED GEAR LOW Z-35	951	87084000	18
10051852ACSG	Solis Tractor O RING ¥89.4X ¥2.0	50	40161000	18
10051888AASG	Solis Tractor RUBBER BOOT FOR CLUTCH HSG.	41	40161000	18
10051927AASG	Solis Tractor SHIM FOR CAGE CARRIER RIGHT 0.15	16	73182910	18
10051928AASG	Solis Tractor SHIM 0.20	17	73182910	18
10051929AASG	Solis Tractor SHIM 0.50	23	73182910	18
10051937AASG	Solis Tractor FUEL PIPE(STRAINER TO FUEL COCK)	90	40091100	18
10051938AASG	Solis Tractor SEALING WASHER 8X12	7	76160000	18
10051985AASG	Solis Tractor SCREW M8X35 8G DIN 931	21	87089900	18
10051988AASG	Solis Tractor SCREW M10X35 UNI5737	40	87089900	18
10051990AASG	Solis Tractor WASHER D=10/20X2,6 ZN	23	73182990	18
10051992AASG	Solis Tractor ARM	1642	87089900	18
10051993AASG	Solis Tractor SEEGER E34 DIN 471	43	87089900	18
10051994AASG	Solis Tractor ENCL. IN SEAL KIT	376	87089900	18
10051995AASG	Solis Tractor SHAFT	2451	87089900	18
10051996AASG	Solis Tractor KIT CRANK	3178	87089900	18
10051998AASG	Solis Tractor ENCL. IN SEAL KIT	117	87089900	18
10051999AASG	Solis Tractor ENCL. IN SEAL KIT	30	87089900	18
10052000AASG	Solis Tractor KIT PISTON	2412	87089900	18
10052001AASG	Solis Tractor ENCL. IN SEAL KIT 900862	678	87089900	18
10052002AASG	Solis Tractor ENCL. IN SEAL KIT	510	87089900	18
10052006AASG	Solis Tractor ENCL. IN SEAL KIT	30	87089900	18
10052048AASG	Solis Tractor GASKET, O/PUMP COVER	150	84099111	28
10052052AASG	Solis Tractor SOLENOID & NUT SET	7147	84099111	28
10052109AASG	Solis Tractor CAP. VALVE STEM	288	84099111	28
10052112AASG	Solis Tractor JOINT, THREE WAY	311	84099111	28
10052150AASG	Solis Tractor GASKET, OIL DRAIN	128	84099111	28
10052162AASG	Solis Tractor GASKET, FUEL RETURN	90	84099111	28
10052163AASG	Solis Tractor GASKET, NOZZLE	90	84099111	28
10052164AASG	Solis Tractor SEAL, VALVE STEM	318	84099111	28
10052190AASG	Solis Tractor STUD	44	84099111	28
10052229AASG	Solis Tractor SWITCH ASSY. THERMO	1226	84099111	28
10052351ACSG	Solis Tractor PULL TO STOP CABLE ASSY	305	87089900	18
10052354ADSG	Solis Tractor KNOB ASSEMBLY (FOR OPERATING SECTOR)	63	87089900	18
10052380ABSG	Solis Tractor SHIFTER PIN FOR 4WD GEAR	36	84099111	28
10052418AASG	Solis Tractor LOCKING SCREW M8X1X10	16	73182300	18
10052428ABSG	Solis Tractor STRAINER CUM PIPE ASSY (GARDEN TRAC)	277	84213990	18
10052452AASG	Solis Tractor DOWEL PIN (6X28) -UNIVERSAL JOINT&PTO FR	23	73182300	18
10052469ABSG	Solis Tractor BRAKE COVER LEFT	647	87083000	18
10052469ACSG	Solis Tractor BRAKE COVER LEFT (FINISH)	654	87083000	18
10052487AHSG	Solis Tractor BRAKE HOUSING LEFT	6473	87083000	18
10052496ABSG	Solis Tractor FUEL FILTER MTG BRKT 24HP	118	87089900	18
10052500AASG	Solis Tractor ACCELERATOR ACTUATING BRKT	58	87089900	18
10052508AESG	Solis Tractor RADIATOR HOSE (RADIATOR TO WATER PUMP)24	356	40091100	18
10052522ABSG	Solis Tractor BRAKE COVER RIGHT	647	87083000	18
10052522ACSG	Solis Tractor BRAKE COVER RIGHT (FINISH)	782	87083000	18
10052530AASG	Solis Tractor GASKET (STRAINER COVER)	14	84841010	18
10052531ADSG	Solis Tractor OIB BRAKE ASSY (JMFT)	3550	87083000	18
10052546AASG	Solis Tractor GASKET INTAKE MANIFOLD 24HP	25	84841010	18

10052580ABSG	Solis Tractor PTO GUARD ASSY	310	87089900	18
10052621ABSG	Solis Tractor BRAKE PEDAL SHAFT 24HP	606	87083000	18
10052624CASG	Solis Tractor BRACKET FOR OIB BRAKE	316	87089900	18
10052662AASG	Solis Tractor DOWEL (8X15)	16	87089900	18
10052678AASG	Solis Tractor ENGINE (MISTUBISHI) S3L2-TDSS3-4202	311246	84080000	28
10052691ACSG	Solis Tractor DRIVEN PLATE ASSY	4408	87089300	18
10052692AASG	Solis Tractor COVER ASSY(sc)	3837	87089900	18
10052693ACSG	Solis Tractor SINGLE CLUTCH ASSY	7458	87089300	18
10052693AESG	Solis Tractor SINGLE CLUTCH ASSY	7255	87089300	18
10052711ACSG	Solis Tractor O-RING DIA 37.82 X DIA 1.78	20	40161000	18
10052712ADSG	Solis Tractor BP SHAFT LEFT FINISH	1376	87084000	18
10052717ADSG	Solis Tractor B.P. SHAFT RIGHT	1170	87084000	18
10052733AASG	Solis Tractor SPRING DOWEL SLEEVE LIGHT	21	73201011	18
10052748AASG	Solis Tractor DIFFERENTIAL CAGE -FRONT AXLE	1939	87085000	18
10052852AASG	Solis Tractor STICKER FOR DIFF LOCK	11	39199010	18
10052862AASG	Solis Tractor COPPER WASHER 8.5*14*1.5 320048000	24	73182990	18
10052882AASG	Solis Tractor FRONT PTO SHAFT	1646	87084000	18
10052908ABSG	Solis Tractor STOPPER FOR C.A. SHAFT	45	87089900	18
10052959BASG	Solis Tractor STEERING CYLINDER	7948	87089400	18
10052960AESG	Solis Tractor STEERING UNIT 40CC	26574	87089400	18
10053039AASG	Solis Tractor CLAMP DIA 16	25	82050000	18
10053068AASG	Solis Tractor PRIORITY VALVE	7956	87081010	18
10053080ACSG	Solis Tractor PIN DIA-20	212	73182300	18
10053083AASG	Solis Tractor WOODRUF KEY	14	87081010	18
10053118ABSG	Solis Tractor BRACKET FOR QRC MOUNTING	143	87089900	18
10053119BBSG	Solis Tractor FLEXIBLE PIPE FROM REAR COVER TO QRC	757	40092200	18
10053120ABSG	Solis Tractor CLAMP ASSY	73	82050000	18
10053125ADSG	Solis Tractor STEERING WHEEL	1017	87087000	18
10053135AESG	Solis Tractor ASSY STEERING ARM DOUBLE	1485	87089400	18
10053155CCSG	Solis Tractor 90° ADJUSTABLE STUD ELBOW 12 X G1/2-A	339	73182300	18
10053156BASG	Solis Tractor 90° ADJUSTABLE STUD ELBOW 10 X G1/4-A	273	73070000	18
10053156CCSG	Solis Tractor 90° ADJUSTABLE STUD ELBOW 10 X G1/4-A	273	73079290	18
10053164ADSG	Solis Tractor FLEXIBLE PIPE FROM STG UNIT L TO CYL LH	1025	40091100	18
10053233BASG	Solis Tractor C.M. GEAR Z-32	896	87084000	18
10053305AESG	Solis Tractor STEERING UNIT MOUNTING BRACKET	655	87089400	18
10053324ABSG	Solis Tractor PRIMARY SUCTION PIPE	498	87081010	18
10053325ABSG	Solis Tractor SECONDARY SUCTION PIPE	386	87081010	18
10053335AASG	Solis Tractor BRAKES SPRING MTG BRACKET	71	87083000	18
10053336ABSG	Solis Tractor CLUTCH SPRING MTG BRACKET	127	87089300	18
10053337BASG	Solis Tractor CLUTCH PADEL ASSY	999	87089300	18
10053343ACSG	Solis Tractor PUSH ROD ASSY FOOT THROTTLE TO MIDDLE LI	55	87089900	18
10053353ACSG	Solis Tractor FOOT THROTTLE ASSY	71	87089900	18
10053353AESG	Solis Tractor FOOT THROTTLE ASSY	86	87089900	18
10053380ABSG	Solis Tractor FLOOR MTG BKT FRONT RH	67	87089900	18
10053381ABSG	Solis Tractor FLOOR MTG BKT FRONT LH	67	87089900	18
10053388ACSG	Solis Tractor CLAMP FOR SUCTION	75	87089900	18
10053400ABSG	Solis Tractor ASSY ACCELERATOR LINK FRONT	62	87089900	18
10053401ADSG	Solis Tractor ADEL RUBBER PAD	65	87142090	18
10053405AFSG	Solis Tractor DIFFERENTIAL LOCK PEDAL ASSY	226	87089900	18
10053406ABSG	Solis Tractor LEVER LUG ASSY	102	87089900	18
10053407ADSG	Solis Tractor ACTUATING LUG ASSY	218	87089900	18

10053408ADSG	Solis Tractor LEVER MOUNTING BRACKET	162	87089900	18
10053409AFSG	Solis Tractor LUG ASSY FOR 4WD LEVER	233	87089900	18
10053412ABSG	Solis Tractor ACTUATOR FORK ASSY.	353	87089900	18
10053412ACSG	Solis Tractor ACTUATOR FORK ASSY.	388	87089900	18
10053421AGSG	Solis Tractor BRAKE HOUSING FINISH	6473	87083000	18
10053427AESG	Solis Tractor BRAKE PEDAL ASSY.(L&R)	1666	87083000	18
10053429AASG	Solis Tractor Dowel (7.7x20)	18	87089900	18
10053438AASG	Solis Tractor HEX. HEAD SCREW M12X1.25X28	19	73182300	18
10053439ACSG	Solis Tractor STICKER 4WD	88	39199010	18
10053448BFSG	Solis Tractor SECONDRY FLEXIBLE PIPE (STEERING UNIT TO	1403	87089900	18
10053449BFSG	Solis Tractor SECONDRY FLEXIBLE PIPE (STEERING UNIT TO	1372	40091100	18
10053458ACSG	Solis Tractor GLOW CONTROL UNIT	2561	85114000	28
10053459AASG	Solis Tractor GASKET FOR EXHAUST	23	87081010	18
10053464AESG	Solis Tractor UNDERHOOD SILENCER	3922	87089200	18
10053465AFSG	Solis Tractor EXHAUST PIPE FOR UNDERHOOD SILENCER	870	87089200	18
10053472AASG	Solis Tractor SLIDING GEAR 2ND & 3RD Z-28 & Z-19	1190	87084000	18
10053482AASG	Solis Tractor FIXED GEAR HI Z-19	634	87084000	18
10053505AASG	Solis Tractor FAN BELT	313	40101110	18
10053509ACSG	Solis Tractor PIN FOR TOP LINK	152	73182300	18
10053511ABSG	Solis Tractor FENDER SIDE FLAP-LH	2100	87089900	18
10053512ABSG	Solis Tractor FENDER SIDE FLAP-RH	2141	87089900	18
10053547AESG	Solis Tractor AIR CLEANER MTG BRACKET	163	87089900	18
10053549ABSG	Solis Tractor AIR CLEANER HOSE	109	40091100	18
10053564ABSG	Solis Tractor SUCTION FLANGE ASSY	267	87089900	18
10053619AASG	Solis Tractor TOP LINK PIN	113	87089900	18
10053640DESG	Solis Tractor ANCHOR CHAIN ASSEMBLY	724	87085000	18
10053648ACSG	Solis Tractor LEVER ASSY HI-LOW	250	87089900	18
10053650AASG	Solis Tractor GUIDE PLATE	124	87089900	18
10053654ACSG	Solis Tractor FAN SPACER DIA 71X11	82	87089900	18
10053655ACSG	Solis Tractor DELIVERY ADOPTER	139	87089900	18
10053656AASG	Solis Tractor CLAMP ASSY (ST. UNIT TO ST. CYLINDER)	37	82050000	18
10053659ACSG	Solis Tractor SHIFTER KNOB (DIFF. SPEED)	116	87084000	18
10053660ABSG	Solis Tractor INLET MANIFOLD UNDERHOOD SILENCER	425	87089200	18
10053661AFSG	Solis Tractor HOUSING COVER	1048	87089900	18
10053664AASG	Solis Tractor GEAR SHIFTER LEVER	316	73260000	18
10053667ADSG	Solis Tractor CONTROLLER TIMER	1695	85361010	18
10053671ACSG	Solis Tractor STICKER FOR HI LOW	14	39199010	18
10053672ADSG	Solis Tractor STIFFNER FOR HOUSING COVER	116	87089900	18
10053690AASG	Solis Tractor KNOB (POSITION LEVER)	49	87089900	18
10053691ACSG	Solis Tractor LOCK COVER POSITION LEVER	82	87089900	18
10053702ADSG	Solis Tractor LATCH FOR PARKING BRAKE	72	87089900	18
10053703ADSG	Solis Tractor PARKING BRAKE LINK	62	87083000	18
10053706AASG	Solis Tractor GASKET (INLET ELBOW)	37	87081010	18
10053714AASG	Solis Tractor RUBBER PAD (FOOT THROTTLE)	37	40161000	18
10053718ABSG	Solis Tractor STICKER FOR PARKING BRAKE	19	39199010	18
10053731AASG	Solis Tractor SPRING (FOR GT 20 4WD)	12	73201011	18
10053739AASG	Solis Tractor BUSH	89	84829900	18
10053742AESG	Solis Tractor MAIN BRACKET AIR CLEANER	149	87089900	18
10053743AASG	Solis Tractor TRUMPET HOUSING FRONT AXLE (R)	4254	73250000	18
10053743BASG	Solis Tractor TRUMPET HOUSING FRONT AXLE (R)	4040	87085000	18
10053750AASG	Solis Tractor PEDAL ROD ASSY	58	87089900	18

10053752AASG	Solis Tractor BONNET BEEDING INNER	44	40082990	18
10053755ACSG	Solis Tractor KNOB FOR HAND ACCELERATOR	49	87089900	18
10053764AASG	Solis Tractor SLIT CORRUGATED-TUBE (CLOGGING SENSOR)	8	39171010	18
10053772BBSG	Solis Tractor METALLIC PIPE (ST UNIT 'R' TO ST CYL RH	298	87089900	18
10053773CBSG	Solis Tractor METALLIC PIPE (ST UNIT 'L' TO ST CYL LH	262	87089900	18
10053774ABSG	Solis Tractor CLAMP FOR STEERING CYL PIPES	73	87089900	18
10053775AASG	Solis Tractor FUEL PIPE (STRAINER TO FEED PUMP)	267	40091100	18
10053776ADSG	Solis Tractor FUEL PIPE (FUEL FEED PUP TO FUEL FILTER	174	87081010	18
10053777AASG	Solis Tractor FUEL FEED PUMP MTG. BKT	69	87089900	18
10053778ABSG	Solis Tractor VIBRATION DAMPER	12	40161000	18
10053788ABSG	Solis Tractor SPRING FOR PARKING BRAKE	17	73201011	18
10053794ADSG	Solis Tractor AIR CLEANER STRAP	92	87089900	28
10053795ABSG	Solis Tractor GROOMET FOR REAR VIEW MIRROR	37	40161000	18
10053796ABSG	Solis Tractor GROMMET BONNET	13	87089900	18
10053797ABSG	Solis Tractor STICKER FOR STARTING CONTROL	13	39199010	18
10053801AESG	Solis Tractor UNIVERSAL JOINT COVER FRONT LEFT	88	87089900	18
10053802AESG	Solis Tractor UNIVERSAL JOINT COVER FRONT RIGHT	94	87089900	18
10053915ABSG	Solis Tractor ACTUATING ROD	42	87089900	18
10053916ACSG	Solis Tractor ACTUATOR FORK LH	55	87089900	18
10053922ABSG	Solis Tractor PIVOT PIN	229	73182300	18
10053990ABSG	Solis Tractor PIN FOR TRAILER HOOK MOUNTING	119	87089900	18
10053993AASG	Solis Tractor DRAW BAR	1531	87089900	18
10054001BASG	Solis Tractor PTO SHIFTER COVER	843	87089900	18
10054020AASG	Solis Tractor TOP LINK ASSEMBLY	1993	87089900	18
10054067BASG	Solis Tractor BRACKET FOR OIB BREAKER RH	294	87089900	18
10054072AASG	Solis Tractor LOWER BONNET BEADING FOR C FLANGE	126	40082990	18
10054076ABSG	Solis Tractor HOSE THERMOSTAT TO RADIATOR	205	40091100	18
10054084AASG	Solis Tractor BATTERY CLAMP ASSY(FOR GT26)	234	87089900	18
10054088AASG	Solis Tractor FLOOR LH MTG BRACKET	36	87089900	18
10054089AASG	Solis Tractor FRONT MTG PLATE RADIATOR	368	87089100	18
10054115AASG	Solis Tractor SLIDING GEAR 4WD Z14	540	87084000	18
10054136AASG	Solis Tractor CLAMP CURVE 2	12	87089900	18
10054141ABSG	Solis Tractor FRONT TOE HOOK	628	87081010	18
10054142ABSG	Solis Tractor RADIATOR SEALING FOAM	116	87089100	18
10054143AASG	Solis Tractor U-STRIP FUEL TANK STOPPER	16	87089900	18
10054213ACSG	Solis Tractor STICKER FOR MAGNETIC STRAINER	14	39199010	18
10054215AASG	Solis Tractor SPACER 50X20X6	60	87089900	18
10054232BBSG	Solis Tractor PTO GEAR (Z-29) (FINISH NO.)	999	87084000	18
10054237ABSG	Solis Tractor PTO SLIDING GEAR (Z-21) (FINISH NO.)	881	87084000	18
10054282AASG	Solis Tractor GASKET STEERING ARM GUIDE	12	84841090	18
10054322ABSG	Solis Tractor RUBBER BEADING	9	40161000	18
10054323ABSG	Solis Tractor RUBBER BEADING	11	40161000	18
10054324AASG	Solis Tractor RUBBER BEADING	34	40161000	18
10054330AASG	Solis Tractor KIT - GEAR SHIFTER SPRING&STEEL BALL S-3	63	87084000	18
10054339AASG	Solis Tractor LIFT ARM PIN	99	73182300	18
10054340ABSG	Solis Tractor HEX NUT M8X1.25 LH-SA4GS	7	73181600	18
10054417AASG	Solis Tractor KNOB PLASTIC	11	87089900	18
10054482AASG	Solis Tractor OPERATING SECTOR BUSH	31	87089900	18
10054485AASG	Solis Tractor FRONT RIM ASSY 24HP-4X12(SILVER)	2500	87087000	18
10054532ABSG	Solis Tractor MTG BKT FOR UNDERHOOD SILENCER	33	87089200	18
10054535AASG	Solis Tractor SPACER FOR STRAINER	54	87089900	18

10054564AASG	Solis Tractor SHIFTER KNOB (4-WD)	67	87089900	18
10054632ABSG	Solis Tractor REGISTRATION PLATE (W/O PAINT)	212	83100010	18
10054658AASG	Solis Tractor PTO LAY SHAFT	1492	87084000	18
10054672AASG	Solis Tractor BEARING SET. CON-ROD_30A19-10020	7268	84099111	28
10054673AASG	Solis Tractor BEARING SET. CON-ROD_30A19-10030	6432	84099111	28
10054675AASG	Solis Tractor GUIDE, EXHAUST VALVE_31A01-02500	208	84099111	28
10054676AASG	Solis Tractor GUIDE, INLET VALVE_31A01-02800	208	84099111	28
10054678AASG	Solis Tractor CASE. OIL SEAL_31A07-11601	1201	84099111	28
10054679AASG	Solis Tractor RING SET, PISTON_31A17-00010	5647	84099111	28
10054723AASG	Solis Tractor BEARING SET. CON-ROD_30A19-00040	3143	84099111	28
10054724AASG	Solis Tractor BEARING SET. CON-ROD_30A19-10010	4662	84099111	28
10054727AASG	Solis Tractor GASKET,TIE-ROD COVER_30A63-00101	159	84099111	28
10054728AASG	Solis Tractor GASKET, WATER PUMP_30H45-00101	146	84099111	28
10054744AASG	Solis Tractor HOSE ASSY,AIR VENT	827	84099111	28
10054758AASG	Solis Tractor VALVE, INLET_31A04-1040.	2481	84099111	28
10054759AASG	Solis Tractor VALVE, EXHAUST_31A04-10500	2041	84099111	28
10054764AASG	Solis Tractor ROD, PUSH_31A05-01300	246	84099111	28
10054766AASG	Solis Tractor SEAL. OIL_31A07-02300	1300	84099111	18
10054767AASG	Solis Tractor BUSHING, CAMSHAFT_31A07-03100	1103	84099111	28
10054770AASG	Solis Tractor GASKETAIL SEAL CASE	264	84099111	28
10054771AASG	Solis Tractor GASKET, FRONT PLATE_31A07-11901	698	84099111	28
10054772AASG	Solis Tractor SEAL. SIDE_31A07-12200	285	84099111	28
10054773AASG	Solis Tractor BEARING SET, MAIN_31A09-01010	7796	84099111	28
10054774AASG	Solis Tractor BEARING SET, MAIN_31A09-01020	6916	84099111	28
10054775AASG	Solis Tractor BEARING SET. MAIN_31A09-01030	7602	84099111	28
10054779AASG	Solis Tractor GASKET, GEAR CASE_31A11-11200	1403	84099111	28
10054782AASG	Solis Tractor PISTON_31A17-09100	7067	84099111	28
10054783AASG	Solis Tractor PISTON	8787	84099111	28
10054784AASG	Solis Tractor PIN, PISTON_31A17-10602	1215	84099111	28
10054794AASG	Solis Tractor PACKING, BODY	637	84099111	28
10054798AASG	Solis Tractor PULLEY, WATER PUMP_31A45-20700	1459	84099111	28
10054802AASG	Solis Tractor GASKET,THERMO CASE_31A46-10101	36	84099111	28
10054816AASG	Solis Tractor GASKET. GOVERNOR CASE_31A63-12201	80	84099111	28
10054824AASG	Solis Tractor SWITCH, OIL PRESSURE_31A90-10300	1361	84099111	28
10054825AASG	Solis Tractor GASKET, CYLINDER HEAD_31B01-23200	4725	84099111	28
10054827AASG	Solis Tractor GASKET. ROCKER COVER_31B04-13201	1174	84099111	28
10054830AASG	Solis Tractor ROD ASSY, CONNECTING_31B19-01023	4657	84099111	28
10054833AASG	Solis Tractor COVER ASSY, INLET_31B30-00040	2872	84099111	28
10054834AASG	Solis Tractor GASKET, INLET COVER_31B30-00800	548	84099111	28
10054836AASG	Solis Tractor GASKET, EXHAUST_31B32-01200	815	84099111	28
10054839AASG	Solis Tractor CASE ASSY,GOVERNOR	52096	84099111	28
10054846AASG	Solis Tractor VALVE ASSY, RELIEF_32A36-05012	2718	84099111	28
10054847AASG	Solis Tractor PLUG, GLOW_32A66-03100	1928	84099111	28
10054852AASG	Solis Tractor GASKET_34340-00700	318	84099111	28
10054878AASG	Solis Tractor BOLT_F1035-08020	44	84099111	28
10054895AASG	Solis Tractor SEAL,OIL_MD008762	411	84099111	28
10054896AASG	Solis Tractor CAP. OIL FILLER_MD008784	620	84099111	28
10054900AASG	Solis Tractor PLUG, DRAIN_MD050316	320	84099111	28
10054906AASG	Solis Tractor BOLT	18	84099111	28
10054910AASG	Solis Tractor BOLT	54	87089900	18
10054936AASG	Solis Tractor GASKET_MF660036	53	84099111	28

10054964AASG	Solis Tractor GASKET, WATER PUMP	160	40169340	18
10055032AASG	Solis Tractor SHIM 0.2 (PTO OUT PUT SHAFT ASSY)	10	73182300	18
10055033AASG	Solis Tractor SHIM 0.3 (PTO OUT PUT SHAFT ASSY)	10	73182300	18
10055034AASG	Solis Tractor SPACER (PTO OUT PUT SHAFT AASY)	44	87081010	18
10055047AASG	Solis Tractor RUBBER GROOMET	5	40169310	18
10055053ACSG	Solis Tractor STICKER FOR MAGNETIC STRAINER	13	39199010	18
10055079ABSG	Solis Tractor CASSETTE SEAL TCEN0056(35X56X13)GT FA P	589	40161000	18
10055080AASG	Solis Tractor SEAL TREA00450N7MMR GT FA PADDY	420	40161000	18
10055128AASG	Solis Tractor MAINTENANCE FREE BATTERY 12V, 65AH & 540	11371	87089900	18
10055214AASG	Solis Tractor FRONT AXLE COVER	549	87089900	18
10055220BDSG	Solis Tractor SLEEVE T.P SHAFT (PADDY)	128	87084000	18
10055222ABSG	Solis Tractor BREATHER (PADDY AXLE)	70	87089900	18
10055223AASG	Solis Tractor BUSH FOR PADDY FRONT AXLE	104	84833000	18
10055224ABSG	Solis Tractor TP CARRIER HOUSING	819	87089900	18
10055225BCSG	Solis Tractor STUB AXLE HOUSING PADDY SPL	2450	87081010	18
10055248BBSG	Solis Tractor ASSY FRONT AXLE HSG	2276	87085000	18
10055268AASG	Solis Tractor THREADED PIN M8X1.25X20	9	73182400	18
10055313ABSG	Solis Tractor PTO END COVER	1157	87089900	18
10055316BASG	Solis Tractor PTO SHAFT	1074	87084000	18
10055321ABSG	Solis Tractor SHAFT FOR 4WD	621	87084000	18
10055384AESG	Solis Tractor BEARING HOUSING	2556	87083000	18
10055388AASG	Solis Tractor BALL BEARING(25X62X12) 1838001	359	84822011	18
10055389ACSG	Solis Tractor CASSETTE SEAL TCWN00061(45X65X12) (PADDY	635	40161000	18
10055390ABSG	Solis Tractor RUBBER BUTTON	18	40161000	18
10055391ACSG	Solis Tractor OIL SEAL (25X40X10)	63	40161000	18
10055483AASG	Solis Tractor TAPER THREAD CONICAL HEAD GREASE NIPPLE	16	87081010	18
10055489AASG	Solis Tractor HEX SHAFT (FOR TIPPING TRAILER)	35	87089900	18
10055498ACSG	Solis Tractor FRONT THRESH GUARD SOLIS 26 (W/O PAINT)	668	87089900	18
10055548ABSG	Solis Tractor INTERMEDIATE PIPE FROM STG UNIT T TO TA	390	73061929	18
10055566AASG	Solis Tractor FLEXIBLE PIPE FROM STG UNIT T TO REAR C	589	40091100	18
10055569ABSG	Solis Tractor FLEXIBLE PIPE FROM PRIORITY VALVE CF TO	746	40091100	18
10055662AASG	Solis Tractor STICKER PTO	19	39191000	18
10055796AASG	Solis Tractor SECONDARY PIPE FROM PRIORITY VALVE L	165	87089900	18
10055864AASG	Solis Tractor ADOPTER FOR TANK LINE	89	87081010	18
10055865ACSG	Solis Tractor SECONDARY PIPE FOR STG TANK LINE	182	73061929	18
10055870BBSG	Solis Tractor INTERMEDIATE PIPE FROM STG TANK TO DIFFE	382	73061929	18
10055911AASG	Solis Tractor Primary Element Dry Air Cleaner 5 Inch(P	869	84213990	18
10055931AASG	Solis Tractor CLUTCH SAFETY SWITCH	414	85361010	18
10055940ABSG	Solis Tractor HOSE	42	40091100	18
10055984AASG	Solis Tractor BUSH	69	87089900	18
10056096AESG	Solis Tractor FLOOR ASSY LH	1544	87089900	18
10056131AASG	Solis Tractor REFLEX REFLECTOR (RED)	39	39191000	18
10056149AASG	Solis Tractor RUBBER BEEDING	34	40082990	18
10056151ACSG	Solis Tractor LEVER ASSY PTO	356	87089900	18
10056153ABSG	Solis Tractor PARKING BRAKE LEVER	218	87089900	18
10056158ACSG	Solis Tractor HAND ACCELERATOR ASSY.	289	87089900	18
10056162AASG	Solis Tractor STICKER FOR PTO INSTRUCTION	54	39199010	18
10056203AASG	Solis Tractor FUEL TANK STRAP MOUNTING BRACKT	167	87089900	18
10056240ABSG	Solis Tractor REAR AXLE (FINISH)	4426	87085000	18
10056240BBSG	Solis Tractor REAR AXLE	3234	87085000	18
10056338AASG	Solis Tractor RUBBER BUTTON	17	40161000	18

10056466AASG	Solis Tractor FIXED GEAR FOR 4WD (FINISH)	802	87084000	18
10056470AASG	Solis Tractor REAR TYRE 8.3-20	12975	40117000	18
10056471AASG	Solis Tractor TRACTOR FRONT TYRE 6-12 4 PR	6031	40117000	18
10056472AASG	Solis Tractor REAR TUBE 8.3-20 TR-218A	1522	40139049	18
10056473AASG	Solis Tractor FRONT TUBE 6.00-12 TR-15	653	40139049	18
10056483AASG	Solis Tractor REAR WHEELASSY-W7X20(ADUSTATYPE-SILVER P	6660	87087000	18
10056487AASG	Solis Tractor PLUG 440010000	117	87089900	18
10056488AASG	Solis Tractor O RING 360121000	35	40169320	18
10056491AASG	Solis Tractor O RING 360103000	27	87089900	18
10056595ABSG	Solis Tractor CLUSTER ASSEMBLY WITH CHROME RING BEZEL	4995	87089900	28
10056636AASG	Solis Tractor PTO GEAR Z-30 (FINISH)	849	87084000	18
10056640AASG	Solis Tractor CM GEAR Z-31 (FINISH)	685	87084000	18
10056655AASG	Solis Tractor LAY SHAFT (FINISH)	3215	87084000	18
10056661AASG	Solis Tractor FIXED GEAR 3rd Z-30 (FINISH)	737	87084000	18
10056671AASG	Solis Tractor FIXED GEAR LOW Z-33	985	87084000	18
10056676ABSG	Solis Tractor SLIDING GEAR HI-LOW Z-18/Z-34	1335	87084000	18
10056682ABSG	Solis Tractor PIN ASSY. PTO	237	73182300	18
10056683ABSG	Solis Tractor PTO SLIDING GEAR (FINISH)	1466	87084000	18
10056691AASG	Solis Tractor LOCKING PLATE (FOR 2 SPEED)	131	87089900	18
10056694AASG	Solis Tractor SLIDING GEAR 2nd & 3rd Z-25/Z-21	1194	87084000	18
10056704ADSG	Solis Tractor TRANSMISSION HOUSING (FINISH)	21612	87085000	18
10056760AASG	Solis Tractor PLOUGH LAMP	1222	85122010	18
10056880ABSG	Solis Tractor BRAKE TIE ROD ASSY	212	87083000	18
10056881ABSG	Solis Tractor BRACKET FOR CLUTCH SAFETY SWITCH	34	87089900	18
10056925AASG	Solis Tractor 4WD HANDLE MTG BRACKET W/O PAINT	88	87089900	18
10056926AASG	Solis Tractor CONNECTING ROD FOR 4WD LEVER ASSY	94	87089900	18
10056926ABSG	Solis Tractor CONNECTING ROD FOR 4WD LEVER ASSY	78	87089900	18
10056927AASG	Solis Tractor PIN (3 POINT LINK)	75	87089900	18
10056934AASG	Solis Tractor PIN (3 POINT LINK)	80	87089900	18
10056954AASG	Solis Tractor BRACKET FOR 4WD LEVER W/O PAINT	118	87089900	18
10057294AASG	Solis Tractor SLIDING GEAR 2ND/3RD Z-25/Z-18	1453	87084000	18
10057307AASG	Solis Tractor FIXED GEAR 3RD Z-32	925	84834000	18
10057316AASG	Solis Tractor LAY SHAFT Z-19/Z-26/Z-17	3162	84831099	18
10057339AASG	Solis Tractor 500 KG MITA PCDC LIFT	35998	87089900	18
10057373ABSG	Solis Tractor SLIDING GEAR HI-LOW Z-32/Z-16 (FINISH)	1306	87084000	18
10057413ACSG	Solis Tractor ACTUATOR FORK RH	80	87081010	18
10057418BBSG	Solis Tractor POSITION LEVER ASSY UNPAINTED	313	87089900	18
10057420BCSG	Solis Tractor DRAFT LEVER ASSY UNPAINTED	302	87089900	18
10057452AHSG	Solis Tractor FUEL TANK FRAME ASSY	3249	87089900	18
10057465ACSG	Solis Tractor DASHBOARD PANEL CHROME RH	86	87089900	18
10057466ACSG	Solis Tractor DASHBOARD PANEL CHROME LH	86	87089900	18
10057507ADSG	Solis Tractor CENTER COVER DASHBOARD	177	87089900	18
10057508AGSG	Solis Tractor DASHBOARD LOWER	1011	87089900	18
10057513AFSG	Solis Tractor FUEL TANK ASSY	6834	87089900	18
10057518ACSG	Solis Tractor STRAP	58	73182300	18
10057532ABSG	Solis Tractor FUEL TANK NECK GROMMET	106	40161000	18
10057533ABSG	Solis Tractor GAS SPRING ASSEMBLY	1094	73201011	18
10057546ABSG	Solis Tractor BONNET TOP SEALING FOAM	236	94012000	18
10057565ACSG	Solis Tractor BEADING FOR CLADDING	429	40161000	18
10057566AGSG	Solis Tractor CLUSTER PANEL G.T.	934	87089900	18
10057569ADSG	Solis Tractor BONNET BEEDING LOWER	141	40161000	18

10057598ABSG	Solis Tractor SECONDARY PIPE FROM PV TO REAR COVER	593	73061929	18
10057601AASG	Solis Tractor FENDER SUPPORT BAR ASSY	1763	87089900	18
10057603ABSG	Solis Tractor DRIVER SEAT	6270	94010000	18
10057614AASG	Solis Tractor BRACKET TOP LINK HOLDER	209	87081010	18
10057709ABSG	Solis Tractor FUEL TANK RESTING RUBBER PAD	39	40161000	18
10057710ABSG	Solis Tractor FUEL TANK RESTING RUBBER PAD	67	40161000	18
10057716AASG	Solis Tractor Friction Disc	367	87089300	18
10057717AASG	Solis Tractor Intermediate Steel Plate	195	87084000	18
10057721ACSG	Solis Tractor SEALING PLATE BACK W/O PAINT	242	87089900	18
10057721ADSG	Solis Tractor SEALING PLATE BACK W/O PAINT	185	87089900	18
10057723AASG	Solis Tractor TANK UNIT	429	87089900	18
10057774AASG	Solis Tractor 60A SLOW BLOW FUSE	104	87081010	18
10057933AASG	Solis Tractor MANIFOLD,EXHAUST__31N3200100	7446	84099990	28
10058414AASG	Solis Tractor MST60 HP(12+12)SYNCHRO 2WD	355687	87085000	18
10065018ABSG	Solis Tractor WASHER FOR PLANET GEAR	85	73181500	18
10065019ABSG	Solis Tractor WASHER FOR SUN GEAR	76	73182300	18
10065020ADSG	Solis Tractor ROD FOR CROSS	419	87084000	18
10065021ABSG	Solis Tractor FLANGE	198	73182300	18
10065022AASG	Solis Tractor RING FOR CAGE	100	73182300	18
10065025ABSG	Solis Tractor DOWEL (DIFF LOCK)	55	87089900	18
10065026AASG	Solis Tractor SPRING FOR CAGE	12	73201011	18
10065027AASG	Solis Tractor DOWEL PIN	26	73182300	18
10065028ADSG	Solis Tractor SLEEVE FOR DIFF LOCK	1441	87084000	18
10065035ABSG	Solis Tractor SLEEVE FOR LOW	1080	73182300	18
10065054ABSG	Solis Tractor WASHER FOR DUAL PTO	72	73182300	18
10065055ABSG	Solis Tractor SUPPORT TRB (PTO)	350	87089900	18
10065064ABSG	Solis Tractor SPACER 1ST FOR LAY SHAFT	155	87081010	18
10065065ACSG	Solis Tractor COPPER WASHER	159	87081010	18
10065067ACSG	Solis Tractor SYNCHRO CONE FOR 1/2/3/4	470	87089900	18
10065068AESG	Solis Tractor HUB FOR 1ST-2ND GEAR	1625	87084000	18
10065069AISG	Solis Tractor BUSH FOR GEAR 1ST	545	87084000	18
10065070ADSG	Solis Tractor HUB FOR 3RD-4TH GEAR	1598	87084000	18
10065071AFSG	Solis Tractor BUSH FOR 2ND/3RD GEAR	710	87084000	18
10065075ADSG	Solis Tractor INTERNAL GEAR Z-73	5770	87084000	18
10065078AFSG	Solis Tractor STRUT (1/2/3/4/SHUTTLE)	45	87085000	18
10065079AGSG	Solis Tractor BALL FOR SYNCHRO HUB	32	87081010	18
10065080AESG	Solis Tractor SLEEVE FOR HUB(1ST/2ND/3RD/4TH SHUTTLE)	1173	87084000	18
10065081ABSG	Solis Tractor SPACER 1ST FOR TAIL PINION	111	73182300	18
10065082ADSG	Solis Tractor LOCKING NUT FOR TAIL PINION	231	73182300	18
10065084AASG	Solis Tractor SPACER 2ND FOR TAIL PINION SHAFT	92	87081010	18
10065085ACSG	Solis Tractor SLEEVE HI-MED & DUAL PTO	1202	87084000	18
10065086ADSG	Solis Tractor HUB FOR TAIL PINION	721	87084000	18
10065091ABSG	Solis Tractor SUPPORT TRB	346	87089900	18
10065096ABSG	Solis Tractor SYNCHRONIZER FOR SHUTTLE	1868	87089900	18
10065098ADSG	Solis Tractor HUB FOR SHUTTLE	1583	87084000	18
10065121ABSG	Solis Tractor SEALING WASHER	19	73182990	18
10065122AESG	Solis Tractor SHIFTER ROD LOW	445	87084000	18
10065124ACSG	Solis Tractor SHIFTER BUSH 1ST-2ND & LOW	382	87084000	18
10065124ADSG	Solis Tractor SHIFTER BUSH 1ST-2ND & LOW	382	87084000	18
10065124AFSG	Solis Tractor SHIFTER BUSH FOR 1ST, 2ND & LOW	338	87084000	18
10065127AESG	Solis Tractor SHIFTER FORK LOW	758	87084000	18

10065128AASG	Solis Tractor SCREW M12*1.75*16	27	73182300	18
10065129AFSG	Solis Tractor LOCKING SCREW FOR FORK	37	73182300	18
10065144ACSG	Solis Tractor SHIM 0.3 MM (HI-LOW INTERMEDIATE SHAFT)	11	73182910	18
10065144ADSG	Solis Tractor SHIM 0.3 MM (HI-LOW INTERME WE04	9	73182200	18
10065145AESG	Solis Tractor SHIM 0.5	11	73182200	18
10065156AGSG	Solis Tractor BRAKE HOUSING	3407	87083000	18
10065175AASG	Solis Tractor SEALING PLUG FOR SHIFTER HOUSING	18	73182300	18
10065188AASG	Solis Tractor CAP (FOR TRANSMISSION HSG.)	16	84841090	18
10065190ACSG	Solis Tractor WASHER FOR LOCKING SCREW	21	73182300	18
10065196ABSG	Solis Tractor SPRING FOR STEEL BALL	15	73201011	18
10065198ADSG	Solis Tractor SHIFTER FORK FOR SHUTTLE	1105	87084000	18
10065200ACSG	Solis Tractor BUSH FOR SHUTTLE ASSY	319	84829900	18
10065201AFSG	Solis Tractor GEAR SHIFTER ROD FOR SHUTTLE	400	87084000	18
10065203AESG	Solis Tractor LEVER ASSY FOR SHUTTLE	272	87089900	18
10065204ABSG	Solis Tractor SEALING WASHER	19	73182990	18
10065207AFSG	Solis Tractor FORK FOR PTO	1115	87084000	18
10065209ADSG	Solis Tractor SHITER ROD PTO	288	87089900	18
10065217AASG	Solis Tractor RING	45	73182300	18
10065268ACSG	Solis Tractor SHIM 0.1 MM (HI-LOW INTERMEDIATE SHAFT)	9	73182910	18
10065268ADSG	Solis Tractor SHIM 0.1 MM (HI-LOW INTE WE04	6	73182200	18
10065422AASG	Solis Tractor SPRING FOR HUB	12	73201011	18
10065458ACSG	Solis Tractor SHIM (0.3) INPUT SHAFT	11	73182910	18
10065605AASG	Solis Tractor DOWEL FOR CROWN WHEEL	34	87089900	18
10065631ABSG	Solis Tractor BUSH FOR CONNECTING SHAFT PTO	71	84836090	18
10065640ABSG	Solis Tractor SPACER INPUT SHAFT	48	87081010	18
10065726BBSG	Solis Tractor O- RING ¥117.5X¥3	21	40169320	18
10066099ACSG	Solis Tractor SHIM (0.1) INPUT SHAFT	11	73182910	18
10066108ABSG	Solis Tractor O RING Ã~14X Ã~1.78	14	40169320	18
10066121ACSG	Solis Tractor SHIM 0.15 MM	11	73182910	18
10066122ACSG	Solis Tractor SHIM 0.3 MM	12	73182910	18
10066183ABSG	Solis Tractor CLUTCH Ã~280 (DOUBLE CLUTCH)	25637	87089300	18
10066303ACSG	Solis Tractor SHIM 75X50X0.15	10	73182910	18
10066312ACSG	Solis Tractor SHIM 1MM FOR BEARING 6210	20	73182300	18
10066312ADSG	Solis Tractor SHIM 1MM FOR BEARING WE01	14	87089900	18
10066377ABSG	Solis Tractor REAR GUARD 90 HP	969	87089900	18
10066387ABSG	Solis Tractor FRONT GUARD	1199	87081010	18
10066390ABSG	Solis Tractor SHIM 0.5MM	11	73182910	18
10066617AASG	Solis Tractor RUBBER PAD FENDER SUPPORT BAR(WT-75 W/O	53	40169310	18
10066625AASG	Solis Tractor NEUTRAL SAFETY SWITCH	445	85361010	18
10066657ABSG	Solis Tractor SHIFTER SLEEVE HI-MED	647	87084000	18
10066703ABSG	Solis Tractor WET BRAKE ASSY	10115	87083000	18
10066717ACSG	Solis Tractor TRB HOLDER 60 75 90 HP	2080	87085000	18
10066723AASG	Solis Tractor SPIDER KIT SET (10X18) FOR MST	6516	87085000	18
10066733AASG	Solis Tractor PIN FOR ACCELATOR	21	73182300	18
10066747BFSG	Solis Tractor CLUTCH HOUSING ASSY.	41782	87089300	18
10066802AASG	Solis Tractor GEAR Z-52	3621	87084000	18
10066809ABSG	Solis Tractor IDLER GEAR Z-22	1255	87084000	18
10066810BBSG	Solis Tractor IDLER SHAFT	405	87084000	18
10066834AASG	Solis Tractor STICKER FOR REVERSE PTO	7	39191000	18
10066896ABSG	Solis Tractor REAR AXLE	10280	87084000	18
10066928ABSG	Solis Tractor LAY SHAFT Z-33(OPTION 1 HELIX)	4033	87084000	18

10067075ACSG	Solis Tractor STARTER MOTOR & HYD PUMP COVER BKT 4CYL	99	87089900	18
10067515AASG	Solis Tractor DOWEL	19	87089900	18
10067660AASG	Solis Tractor BONDED SEAL FOR 3/4# BSP	43	40161000	18
10067702BBSG	Solis Tractor Flexible Pipe from DCV to QRC1	1297	87089900	18
10067748AASG	Solis Tractor BRACKET FOR LIFTOMATIC CABLE ASSY (LINK	33	87089900	18
10067783ABSG	Solis Tractor LIGHT FOR REGISTRATION PLATE	323	85122010	18
10067785AASG	Solis Tractor NEUTRAL SAFETY SWITH	538	85361010	18
10067792AASG	Solis Tractor RUBBER BEADING	14	40082990	18
10067839ABSG	Solis Tractor GROMMET FOR REGISTRATION LIGHT	16	40161000	18
10067936AASG	Solis Tractor BANJO BOLT (M18X1.5)	62	73182300	18
10067945AASG	Solis Tractor CROSS SLOTTED TRUSS HEAD SCREW M6X25	8	73182300	18
10067946AASG	Solis Tractor CROSS SLOTTED TRUSS HEAD SCREW M8X25	22	73182300	18
10067947AASG	Solis Tractor SROSS SLOTTED TRUSS HEAD SCREW M6X16	10	73182300	18
10067951AASG	Solis Tractor CROSS SLOTTED CHESE HEAD SCREW M6*16	36	73182300	18
10067980ABSG	Solis Tractor DRAIN LINE HOSE FOR 16 OD	64	40092200	18
10068051AASG	Solis Tractor HAZARD WARNING SWITCH	1222	85361010	18
10068285AASG	Solis Tractor ORFS CONNECTION M22x1.5 / 1 3/16-12 UNF	314	73079290	18
10068289AASG	Solis Tractor SPECIAL HEX SCREW M10X50	24	73182300	18
10068582ABSG	Solis Tractor FRONT REMOVABLE WEIGHT 30 KG	6296	87081010	18
10068583ABSG	Solis Tractor FRONT REMOVABLE WEIGHT 25 KG	5248	87081010	18
10069146ABSG	Solis Tractor PTO SHAFT	3095	87084000	18
10069268AASG	Solis Tractor O RING ¥22.5X¥3.4	14	40161000	18
10069269ABSG	Solis Tractor O RING ¥5.77X¥1.95	12	40161000	18
10069389ACSG	Solis Tractor INPUT GEAR Z-45	1386	87084000	18
10069431AASG	Solis Tractor METALLIC SPACER DIA 9x DIA20x28	49	87081010	18
10069431ACSG	Solis Tractor METALLIC SPACER DIA 9XDIA20X28	46	87089900	18
10069434ABSG	Solis Tractor HI-LO INTERMEDIATE SHAFT Z-25	3075	87084000	18
10069435ABSG	Solis Tractor GEAR 4WD Z-61	2052	87084000	18
10069436ABSG	Solis Tractor GEAR TAIL PINION Z-56	2021	87084000	18
10069535ABSG	Solis Tractor SUB ASSY1STGEAR	3095	87084000	18
10069556ABSG	Solis Tractor DRAW BAR	2815	87089900	18
10069563AASG	Solis Tractor SPRING SEAT (OPERATING SECTOR)	21	73201011	18
10069564AASG	Solis Tractor SPRING SMALL (OPERATING SECTOR)	10	73201011	18
10069565AASG	Solis Tractor SPRING LARGE (OPERATING SECTOR)	11	73201011	18
10069566AASG	Solis Tractor NYLON WASHER	5	73182300	18
10069590AASG	Solis Tractor SPACER	9	73181500	18
10069710ACSG	Solis Tractor CROWN WHEEL & TAIL PINION SET (13X46)	11111	87084000	18
10069726ABSG	Solis Tractor SHIFTER ROD (SPEED SIDE)	847	87089900	18
10070073AASG	Solis Tractor BONNET HING PIN	38	87089900	18
10070082AFSG	Solis Tractor BONNET LOCK	696	87089900	18
10070111ABSG	Solis Tractor MIRROR ASSY. (RIGHT)	406	70091090	18
10070162AASG	Solis Tractor STRAP	82	73182300	18
10070203AASG	Solis Tractor ANGLE BRACKET FOR DASHBOARD	112	87089900	18
10070256ABSG	Solis Tractor BONNET BEEDING	222	40082990	18
10070279AASG	Solis Tractor FLEXIBLE CLAMP	13	87081010	18
10070308ABSG	Solis Tractor SPECIAL WASHER FOR FRONT WEIGHT	61	73182300	18
10070310ABSG	Solis Tractor BEEDING FOR RADIATOR SEALING PLATE SIDE	81	40082990	18
10070313AASG	Solis Tractor SEALING PLATE TOP TIE	60	87089900	18
10070355BASG	Solis Tractor FRONT AXLE BEAM	23985	87081010	18
10070355DBSG	Solis Tractor FRONT AXLE BEAM	23985	87089900	18
10070388AESG	Solis Tractor BRACKET FOR COOLANT TANK (RIGHT)	73	87089900	18

10070389ACSG	Solis Tractor BRACKET FOR COOLANT TANK (LEFT)	70	87089100	18
10070427ABSG	Solis Tractor STICKER FOR STEEP SLOPE	42	39199010	18
10070428ACSG	Solis Tractor STICKER FOR TYRE PRESSURE	80	39199010	18
10070428ADSG	Solis Tractor STICKER FOR TYRE PRESSURE	50	39199010	18
10070429ABSG	Solis Tractor STICKER FOR DRY AIR-CLEANER	41	39199010	18
10070469AASG	Solis Tractor SPACER FOR LOCK PIN BKT.	37	87081010	18
10070477ACSG	Solis Tractor RADIATOR MTG. PLATE	486	87089100	18
10070537AASG	Solis Tractor GROMMET FOR STAY ROD	11	40161000	18
10070545ACSG	Solis Tractor HOSE PIPE FOR CAP (NON-TURBO)	501	40091100	18
10070546ACSG	Solis Tractor CAP (SMALL)	78	87089900	18
10070547ABSG	Solis Tractor CAP (BIG)	65	87081010	18
10070597AESG	Solis Tractor DATA PLATE	80	73182300	18
10070597AGSG	Solis Tractor DATA PLATE FOR SONALIKA RX	71	83100010	18
10070668AASG	Solis Tractor XENOY/PC+PBT(BLACK)	0	39079900	18
10070750AHSG	Solis Tractor STARTER MOTOR COVER (BLACK COLOR)	160	87089900	18
10070751ADSG	Solis Tractor MOUNTING STRIP FOR STARTER MOTOR COVER	97	87089900	18
10070766BASG	Solis Tractor FRONT AXLE BEAM ECO CYL.	17722	87085000	18
10070768AASG	Solis Tractor SPACER CYLINDER	27	87081010	18
10070775AASG	Solis Tractor RUBBER PAD FOR SPACER	38	87081010	18
10070775ABSG	Solis Tractor RUBBER PAD FOR SPACER	32	40161000	18
10070776ABSG	Solis Tractor LOCKING PIN	103	73182300	18
10070785ADSG	Solis Tractor INSTRUCTION STICKER FOR SET OF 7	94	39199010	18
10070787AASG	Solis Tractor CIRCLIP 20X1.75XH IS: 3075 (PART 1)	19	73182300	18
10070794BBSG	Solis Tractor KING PIN STUB AXLE LEFT	4018	87089900	18
10070831BBSG	Solis Tractor KING PIN STUB AXLE RIGHT	4018	87089900	18
10070843BASG	Solis Tractor STAY ROD BOTTOM MTG. BKT	35	87089900	18
10070846BASG	Solis Tractor STAY ROD (4 CYL)	84	87089900	18
10070854ACSG	Solis Tractor BKT. FOR COOLANT TANK (RT) 4 CYL	67	87089900	18
10070893AASG	Solis Tractor LOCKING BLOCK FOR KING PIN	424	87089900	18
10070894AFSG	Solis Tractor FUEL TANK CAP (DOUBLE LOCK) HOMOLOGATION	377	87089900	18
10070905AASG	Solis Tractor STEERING ARM LEFT	1135	87089400	18
10070953AASG	Solis Tractor HOSE (INTAKE MANIFOLD TO SUCTION PIPE)	930	40091100	18
10071016ACSG	Solis Tractor FUEL TANK CAP	191	87089900	18
10071020ACSG	Solis Tractor KEY SET ASSY WITHOUT KEY	237	83012000	18
10071239ADSG	Solis Tractor ADJUSTABLE GROMMET	18	40169310	18
10071287ABSG	Solis Tractor PIVOT PIN (Ã~34.9)	1153	73182300	18
10071288AESG	Solis Tractor PTO LEVER ASSY .	741	87089900	18
10071321AASG	Solis Tractor T-COUPLING	153	87084000	18
10071355AASG	Solis Tractor 10 AMP BLADE TYPE FUSE	6	85443000	18
10071356AASG	Solis Tractor 15 AMP BLADE TYPE FUSE	6	85443000	18
10071357AASG	Solis Tractor 20 AMP BLADE TYPE FUSE	6	85443000	18
10071358AASG	Solis Tractor FUSES FOR FARMER KIT	85	85361010	18
10071450AASG	Solis Tractor V-BELT BX-47	371	40101110	18
10071450ABSG	Solis Tractor V-BELT BX-47	399	40101110	18
10071451AFSG	Solis Tractor FRONT WEIGHT (FABRICATION)	8899	87081010	18
10071455ACSG	Solis Tractor FOAM RADIATOR SEALING	100	87089100	18
10071460ACSG	Solis Tractor FOAM SEALING PLATE REAR	91	39073010	18
10071538AASG	Solis Tractor WASHER FOR STAY ROD	7	40161000	18
10071579AASG	Solis Tractor 7 PIN SOCKET ASSY WITH GROMMET	227	87081010	18
10071581AASG	Solis Tractor PIVOT PIN (Ã~40)	1548	73182300	18
10071610AASG	Solis Tractor BONNET BEEDING	136	40082990	18

10071614AASG	Solis Tractor FOAM SEALING PLATE BOTTOM (RH)	80	39201099	18
10071615AASG	Solis Tractor FOAM SEALING PLATE BOTTOM (LH)	80	39201099	18
10071617AASG	Solis Tractor GROOMET (FRONT AXLE BKT)	42	40161000	18
10071626BASG	Solis Tractor STEERING ARM LEFT(POTATO SPL)	830	87089400	18
10071632AASG	Solis Tractor FOAM TOP RADIATOR SEALING	98	87089100	18
10071690AASG	Solis Tractor PROTECTION PLUG FOR M8	8	73182300	18
10071691AASG	Solis Tractor PROTECTION PLUG FOR M10	10	73182300	18
10071692AASG	Solis Tractor PROTECTION PLUG FOR M12	8	73182300	18
10071705AASG	Solis Tractor PLASTIC PROTECTION PLUG	5	87089900	18
10071908ADSG	Solis Tractor FRONT AXLE BKT FINISH	21370	87081010	18
10071933AASG	Solis Tractor STRAP ASSY.	46	39261011	18
10071944AASG	Solis Tractor GROOMET FOR FRONT & REAR LIGHT	16	40161000	18
10075013ABSG	Solis Tractor O RING 24.75X2.25	17	40161000	18
10079042ABSG	Solis Tractor TRIANGULAR PLATE SUPPORT	30	87089900	18
10079047ADSG	Solis Tractor ASSY FOOT STEP RH	2003	87089900	18
10079069AESG	Solis Tractor Floor Mounting Bracket -Front Side (RH)	852	87089900	18
10079074ACSG	Solis Tractor Liftomatic Mounting Plate	76	87089900	18
10079116ACSG	Solis Tractor ASSEMBLY CLUTCH PEDAL LEVER	846	87089300	18
10079121ABSG	Solis Tractor ASSEMBLY DIFF. LOCK PLATE	195	87089900	18
10079123ABSG	Solis Tractor PADDLE ASSY (DIFF LOCK)	753	87089900	18
10079125AESG	Solis Tractor ASSEMBLY DIFF. LOCK PEDAL	102	87089900	18
10079227ABSG	Solis Tractor Rubber Pad Accelerator	125	40169310	18
10079237ABSG	Solis Tractor FENDER DGNL RR SUPRT REINFRMNT	47	87089900	18
10079241ABSG	Solis Tractor FENDER TOP PANEL BRKT COVER	14	87089900	18
10079242ACSG	Solis Tractor FENDER CENTRE SUPRT BRKT	75	87089900	18
10079243ABSG	Solis Tractor FENDER TOP PANEL SUPRT BRKT	82	87089900	18
10079263ABSG	Solis Tractor STIFFENER SEAT	13	87089900	18
10079287ABSG	Solis Tractor FENDER CARRY OVER BASE PLATE NON ROPS	949	87089900	18
10079313AFSG	Solis Tractor 4 CYL WITH OIB (WITH INDEPENDENT PARKING	2128	87083000	18
10079315AFSG	Solis Tractor 3 CYL WITH OIB (WITHOUT INDEPENDENT PARK	2556	87089900	18
10079318ADSG	Solis Tractor ASSEMBLY PEDAL SUPPORT PLATE	129	87089900	18
10079324ADSG	Solis Tractor TRIANGULAR PLATE	93	87089900	18
10079325ABSG	Solis Tractor TIE ROD (THROTTLE LEVER)	57	87089900	18
10079327ABSG	Solis Tractor ASSY ACCELERATOR SHAFT	107	87089900	18
10079330ACSG	Solis Tractor Foot Accelerator Pad	208	87089900	18
10079330ADSG	Solis Tractor FOOT ACCELERATOR PAD	208	87089900	18
10079335ACSG	Solis Tractor ASSY THROTTLE LOWER SUPPORT BRACKET	211	87081010	18
10079380ACSG	Solis Tractor STEERING COLUMN BELLOW	251	40161000	18
10079381ADSG	Solis Tractor STEERING COLUMN COVER MTG BRKT ASSY	237	87089400	18
10079385ACSG	Solis Tractor DRAFT & POSITION CONTROL LEVER COVER	208	87089900	18
10079388ACSG	Solis Tractor GEAR SHIFTER LEVER COVER (LH)	130	87084000	18
10079389ACSG	Solis Tractor GEAR SHIFTER LEVER COVER (RH)	135	87084000	18
10079392ABSG	Solis Tractor METER PLATE SCREW CAP	12	76169990	18
10079392ACSG	Solis Tractor METER PLATE SCREW CAP	12	87089900	18
10079412ABSG	Solis Tractor FOOT PEDAL SPRING	20	87089900	18
10079418ABSG	Solis Tractor ASSY BALL JOINT ACTUATOR	323	87089900	18
10079424ACSG	Solis Tractor BALL JOINT CONNECTOR	43	87089900	18
10079425ACSG	Solis Tractor Foot Pad Pin	44	73182400	18
10079439ACSG	Solis Tractor HINGE CROSS MEMBER	311	87089900	18
10079443ACSG	Solis Tractor RADIATOR CROSS MEMBER TOP	283	87089900	18
10079482ADSG	Solis Tractor STRAP ASSY. (55 LT TANK)	71	87089900	18

10079593ABSG	Solis Tractor ASSY HAND ACC BASE PLATE	89	87089900	18
10079596ABSG	Solis Tractor BONNET LOCK HANDLE	145	87089900	18
10079596ACSG	Solis Tractor GRAB HANDLE BONNET ASSY	144	87089900	18
10079597ACSG	Solis Tractor BONNET LOCK - PUSH KNOB	47	87089900	18
10079678AESG	Solis Tractor STEERING COLUMN MTG BKT	115	87089400	18
10079682ABSG	Solis Tractor STEERING COLUMN FIXING BKT	34	87089400	18
10079699AFSG	Solis Tractor ASSY HAND ACC LEVER AND BRKT	195	87089900	18
10079750AESG	Solis Tractor FRONT AXLE BKT 3CYL (POWER STEERING)	33700	87081010	18
10079750AFSG	Solis Tractor FRONT AXLE BKT 3CYL	34205	87081010	18
10079780ABSG	Solis Tractor ASSY BONNET GUIDE PIN LH	53	73182300	18
10079781ABSG	Solis Tractor ASSY BONNET GUIDE PIN RH	51	87089900	18
10080008ABSG	Solis Tractor WASHER FOR PTO LEVER	10	73182300	18
10080009AASG	Solis Tractor PIN FOR PTO LEVER	87	87089900	18
10080010AASG	Solis Tractor SPACER	21	87081010	18
10080022ABSG	Solis Tractor PIN FOR SHUTTLE LEVER	37	73182300	18
10080030ACSG	Solis Tractor BRACKET FOR DIFF. LOCK PEDAL	554	87089900	18
10080035ABSG	Solis Tractor STICKER DRAFT & POSITION INDICATION	38	39199010	18
10080036ABSG	Solis Tractor BUSH SHAFT LOWER LINK	80	87089900	18
10080037ACSG	Solis Tractor PLATE TIE ROD	140	87089900	18
10080040AHSG	Solis Tractor SHAFT LOWER LINK	1165	87089900	18
10080043ABSG	Solis Tractor PIN SUPPORT PLATE	124	73182300	18
10080047BASG	Solis Tractor PIN	119	73182300	18
10080048ACSG	Solis Tractor TIE ROD ASSY RH(WITH HANDLE)	3344	87089900	18
10080049ACSG	Solis Tractor TIE ROD ASSY LH	2458	87089900	18
10080050ABSG	Solis Tractor TOP LINK ASSY	3935	87089900	18
10080051AASG	Solis Tractor LOWER LINK ASSY	6281	87089900	18
10080052AASG	Solis Tractor SPACER FOR LEVERS	12	87081010	18
10080057ABSG	Solis Tractor WASHER FOR SHUTTLE LEVER	25	73182300	18
10080067ABSG	Solis Tractor SPACER FOR DIFF. LOCK	12	84820000	18
10080080AISG	Solis Tractor ADJUSTABLE TIE ROD FOR PARKING BRAKE	223	87083000	18
10080085ABSG	Solis Tractor SHIFTER KNOB (DIFF SPEEDS)	149	87084000	18
10080086ABSG	Solis Tractor SHIFTER KNOB (RANGE)	123	87084000	18
10080283AESG	Solis Tractor KNOB POSITION LEVER	66	87089900	18
10080284AESG	Solis Tractor KNOB DRAFT LEVER	72	87089900	18
10080288AESG	Solis Tractor SUPPORT PLATE ASSY LH	2539	87089900	18
10080289AESG	Solis Tractor SUPPORT PLATE ASSY. RH	2539	87089900	18
10080295ACSG	Solis Tractor ACTUATOR FORK	67	87089900	18
10080304ABSG	Solis Tractor PIN	26	73182300	18
10080431AASG	Solis Tractor DOUBLE CLUTCH ASSY.	38583	87089300	18
10080432AASG	Solis Tractor DRIVEN PLATE ASSY. PTO	6409	87089300	18
10080433AASG	Solis Tractor DRIVEN PLATE ASSY.	8807	87089300	18
10080652AASG	Solis Tractor ES BOLT WITH SECURING COLLAR 8X16	67	73182300	18
10080657AASG	Solis Tractor FORK HEAD 8X32	228	87089900	18
10080658AASG	Solis Tractor TIE ROD	69	87089900	18
10080723BASG	Solis Tractor MOUNTING BKT. ASSY. REAR TOE HOOK (RIGHT	2392	87089900	18
10080724BASG	Solis Tractor MOUNTING BKT. ASSY. REAR TOE HOOK (LEFT	2392	87089900	18
10080818BBSG	Solis Tractor REAR TOE HOOK	7614	87089900	18
10080818BCSG	Solis Tractor REAR TOE HOOK [GO10702A]	5836	87089900	18
10080820ACSG	Solis Tractor SLEEVE FOR FRONT PTO SHAFT	785	87084000	18
10080871ABSG	Solis Tractor RUBBER PAD	323	40161000	18
10080874AASG	Solis Tractor LINK PIN (BRAKE SIDE FOR WORLD TRACK)	36	73182300	18

10080875BESG	Solis Tractor VERTICAL MUFFLER ASSY.	4962	87089200	18
10080900AASG	Solis Tractor SOCKET HEAD SCREW	87	73182300	18
10080934ABSG	Solis Tractor ADOPTER M16X1.5-G 1/2A	77	87089900	18
10080935ABSG	Solis Tractor ADOPTER M14X1.5-G 1/2 A	77	87081010	18
10080937AESG	Solis Tractor O-RING DIA 41.5 X DIA 1.8	14	40161000	18
10080939ABSG	Solis Tractor FLEXIBLE PIPE FROM DCV TO REAR COVER	913	40091100	18
10080939ACSG	Solis Tractor FLEXIBLE PIPE FROM DCV TO REAR COVER	483	40091100	18
10080961AASG	Solis Tractor AIR CLEANER HOSE PIPE CONNECTOR	265	40091100	18
10080973AASG	Solis Tractor CLAMP ASSY.	69	82050000	18
10080978AESG	Solis Tractor BACK FLOW FUEL PIPE (FIP TO THERMOSTARTE	424	40091100	18
10080984AASG	Solis Tractor CLOSING FLANGA	1485	87089900	18
10080997AASG	Solis Tractor CYLINDER M60 WITH PLUG	6189	87089900	18
10080998AASG	Solis Tractor SPECIAL WASHER	10	87089900	18
10080999AASG	Solis Tractor OR D=15.54X2.62 SH90	113	87089900	18
10081001AASG	Solis Tractor ALSELE 95/110X12.5	701	87089900	18
10081002AASG	Solis Tractor PISTON	2101	87089900	18
10081003AASG	Solis Tractor OR 6212 D=53.34X5.34 SH70/80	98	87089900	18
10081010AASG	Solis Tractor BALSELE 55/70X8-10	159	87089900	18
10081015AASG	Solis Tractor WASHER	24	87089900	18
10081018AASG	Solis Tractor SEEGER RS 7 DIN 6799	8	87089900	18
10081023AASG	Solis Tractor PIN D6X35UNI 6873	23	87089900	18
10081032AASG	Solis Tractor ROLLER	72	87089900	18
10081034AASG	Solis Tractor SEEGER RS 6 DIN 6799	8	87089900	18
10081049AASG	Solis Tractor PLATE	110	87089900	18
10081050AASG	Solis Tractor LEVER	139	87089900	18
10081051AASG	Solis Tractor ROLLER	318	87089900	18
10081052AASG	Solis Tractor FLANGE	533	87089900	18
10081053AASG	Solis Tractor TIE ROD	344	87089900	18
10081054AASG	Solis Tractor SPRING COVER	899	87089900	18
10081055AASG	Solis Tractor SUPPORT	2926	87089900	18
10081056AASG	Solis Tractor TIE ROD	138	87089900	18
10081058AASG	Solis Tractor NUT M10-8G	26	87089900	18
10081059AASG	Solis Tractor NUT M16X1.5 DIN982	78	87089900	18
10081060AASG	Solis Tractor LOCKERD8.1 DIN 7980	6	87089900	18
10081061AASG	Solis Tractor WASHER	67	87089900	18
10081063AASG	Solis Tractor PIN	911	87089900	18
10081064AASG	Solis Tractor COVER	2516	87089900	18
10081066AASG	Solis Tractor OR 4093 D23AX3,53 SH 70/80	22	87089900	18
10081067AASG	Solis Tractor ELASTIC FIN D6X35 DIN 1481	15	87089900	18
10081068AASG	Solis Tractor BUSH D8/20X19	61	87089900	18
10081070AASG	Solis Tractor FITTING M10X1	44	87089900	18
10081071AASG	Solis Tractor WASHER 16,15/24,8X0,5-ZN	6	87089900	18
10081077AASG	Solis Tractor SCREW TCEI M8X30 U59318G ZN	25	87089900	18
10081079AASG	Solis Tractor SCREW TCEI M6X40 U5931 8G ZN	34	87089900	18
10081080AASG	Solis Tractor SPRING	19	87089900	18
10081083AASG	Solis Tractor FRICTION	25	87089900	18
10081084AASG	Solis Tractor CLUTCH HUB	250	87089900	18
10081088AASG	Solis Tractor DISTRIBUTOR	14493	87089900	18
10081110AASG	Solis Tractor SCREW M6X16 DIN 912-8G	14	87089900	18
10081129AASG	Solis Tractor PIN D4X19,8	11	87089900	18
10081167AASG	Solis Tractor SNAP RING D30	34	87081010	18

10081170AASG	Solis Tractor O.RING	25	40161000	18
10081258AASG	Solis Tractor BEARING	531	84821020	18
10081295AASG	Solis Tractor PIN D 12X30	56	73182300	18
10081484AASG	Solis Tractor NUT M.12	13	73182300	18
10081499AASG	Solis Tractor GREASER NIPPLE M6X1	50	87081010	18
10081507AASG	Solis Tractor BOLT M 12X33	157	73182300	18
10081511AASG	Solis Tractor BUSHING	84	84829900	18
10081585AASG	Solis Tractor BOLT M8X20	25	73182300	18
10081597AASG	Solis Tractor VIBRATION DAMPER	37	40161000	18
10081597ABSG	Solis Tractor VIBRATION DAMPER	32	40161000	18
10081598AASG	Solis Tractor VIBRATION DAMPER	40	40161000	18
10081598ABSG	Solis Tractor VIBRATION DAMPER	33	40161000	18
10081605AASG	Solis Tractor CROSS SLOTTED TRUSS HEAD SCREW M6X40	12	73182300	18
10081635ACSG	Solis Tractor STICKER FOR PTO RPM	9	39199010	18
10081637ABSG	Solis Tractor BEEDING	47	40082990	18
10081652ABSG	Solis Tractor KNOB ASSY.	28	87089900	18
10081659AASG	Solis Tractor CONNECTING BUSH	18	84829900	18
10081718AASG	Solis Tractor ANGLE JOINT & FORK HEAD ASSY	2108	87089900	18
10081719AASG	Solis Tractor YOKE SUB ASSY	2155	84820000	18
10081768AGSG	Solis Tractor BACK PLATE ASSY.	720	87089900	18
10081845AASG	Solis Tractor BEEDING LT	395	40082990	18
10081846AASG	Solis Tractor BEEDING RT	395	40082990	18
10081850AASG	Solis Tractor SOCKET HEAD CAP SCREW M6X25	16	73182300	18
10081875ABSG	Solis Tractor ADOPTER 18X1.5	81	87081010	18
10081882AASG	Solis Tractor PUSH PIN	11	73182300	18
10081882ABSG	Solis Tractor PUSH PIN	11	87089900	18
10081938AASG	Solis Tractor WING NUT M8	32	73182300	18
10081946AESG	Solis Tractor STEERING WHEEL FOR W.T. HI TECH	1745	87089400	18
10081998AASG	Solis Tractor LEVER KIT (MAIN)	2897	87089900	18
10081999AASG	Solis Tractor LEVER KIT (PTO)	3328	87089900	18
10082001AASG	Solis Tractor PRESSURE PLATE FOR PTO CLUTCH	1995	87089300	18
10082002AASG	Solis Tractor PRESSURE PLATE FOR MAIN CLUTCH	3738	87089300	18
10082556AASG	Solis Tractor REAR WHEEL RIM ASSY. (W15L X 28)(UNPAINT	25336	87089900	18
10082557AASG	Solis Tractor REAR WHEEL RIM ASSY. (W15L X 28) (SILVER	20728	87087000	18
10082677BCSG	Solis Tractor HYDRAULIC HOSE(RIGID PIPE RO LH STG CYL)	492	40092200	18
10082678BCSG	Solis Tractor HYDRAULIC HOSE(RIGID PIPE TO RH STG CYL)	799	40091100	18
10082724ABSG	Solis Tractor CLAMP(FOR WIRE HARNESS OF W.T.)	65	87089900	18
10082752AASG	Solis Tractor PIN FOR TOP LINK	240	73182300	18
10082752ABSG	Solis Tractor PIN FOR TOP LINK	212	73181500	18
10082764ABSG	Solis Tractor SQUARE HEAD PIN	34	87089900	18
10082780BBSG	Solis Tractor FRONT MUDGUARD FRAME ASSY RH	1747	87089900	18
10082781BBSG	Solis Tractor FRONT MUDGUARD FRAME ASSY LH	1747	87089900	18
10082782BBSG	Solis Tractor BASE FRAME ASSY.FRONT MUDGUARD RH	1192	87089900	18
10082783BBSG	Solis Tractor BASE FRAME ASSY. FRONT MUDGUARD LH	1283	87089900	18
10082784AFSG	Solis Tractor UNDERHOOD SILENCER FOR SOLIS 60	5917	87089200	18
10082814AASG	Solis Tractor MITA LIFTOMATIC SWITCH ASSY	1175	87081010	18
10082821ABSG	Solis Tractor SPACER	41	87089900	18
10082866ACSG	Solis Tractor REGISTRATION PLATE	487	83100010	18
10082899CASG	Solis Tractor BASE ASSY	1653	87089900	18
10082901ABSG	Solis Tractor SLOTTED PLATE	86	87089900	18
10082903ABSG	Solis Tractor STOPPER PLATE	75	87089900	18

10082913ABSG	Solis Tractor TORSIONAL SPRING LH	241	73201011	18
10082914ABSG	Solis Tractor TORSIONAL SPRING RH	241	73201011	18
10083026AASG	Solis Tractor RUBBER PAD	10	40161000	18
10083043ABSG	Solis Tractor Slotted Cheese Head Screw M5X30 SA4GS	5	73181600	18
10083044AASG	Solis Tractor Head Gasket for Exhaust Elbow 2-Mtg.	34	84841010	18
10083082AASG	Solis Tractor FLANGE BEARING 4WD LEVER	158	84830000	18
10083094AASG	Solis Tractor FORK FOR SERVICE BRAKE	296	87083000	18
10083095AASG	Solis Tractor ES BOLT (FOR10X20 FORK HEAD) WITH SECURI	88	73182300	18
10083111ABSG	Solis Tractor 4WD LEVER MTG	89	87089900	18
10083153BCSG	Solis Tractor FRONT MUDGAURD	3571	87081010	18
10083183AASG	Solis Tractor STICKER FOR QRC	13	39199010	18
10083246ACSG	Solis Tractor UNIVERSAL JOINT	2270	87089900	18
10083505ABSG	Solis Tractor INLET HOSE(RADIATOR TO THERMOSTAT)	128	40091100	18
10083512AASG	Solis Tractor HOSE (RADIATOR TO WATER PUMP)	306	40091100	18
10083522ADSG	Solis Tractor BEEDING FOR RADIATOR	181	40082990	18
10083528ABSG	Solis Tractor SONALIKA PLATE	124	87081010	18
10084026AASG	Solis Tractor BEADING(SEALING PLATE)	70	40082990	18
10084442AASG	Solis Tractor BEEDING FOR RADIATOR	103	40082990	18
10084523AASG	Solis Tractor Spring Cotter Sleeve(Dia 6X30) DIN-148	26	87081010	18
10084536AASG	Solis Tractor STICKER FOR PARKING BRAKE	13	39199010	18
10084541AASG	Solis Tractor STICKER FOR IPTO	16	39199010	18
10084544AASG	Solis Tractor TRANSPORT AND DRAFT SENSITIVITY STICKER	41	39199010	18
10084547AASG	Solis Tractor WARNING STICKER FOR USE OF TRACTOR	108	39199010	18
10084550AASG	Solis Tractor WARNING STICKER FOR CLUTCH	72	39199010	18
10084558AASG	Solis Tractor KNOB FOR 540/540E LEVER	70	87089900	18
10084595ABSG	Solis Tractor SNAP RING FOR SHAFT DIA 42	14	73182300	18
10084652AASG	Solis Tractor STICKER FOR DIFF LOCK	34	39199010	18
10084652ABSG	Solis Tractor STICKER FOR DIFF LOCK	34	39199010	18
10084957AASG	Solis Tractor Washer For Levers	6	73182990	18
10084957ABSG	Solis Tractor WASHER FOR LEVERS	11	73182300	18
10085073ABSG	Solis Tractor Suction Hose (Filter To Pump)	127	40091100	18
10085073ACSG	Solis Tractor SUCTION HOSE (FILTER TO PUMP)	116	40091100	18
10085116AASG	Solis Tractor OPERATING COVER	641	87089900	18
10085118AASG	Solis Tractor KNOB (DRAFT LEVER)	30	87089900	18
10085120ACSG	Solis Tractor KNOB ASSY	54	87089900	18
10085144AASG	Solis Tractor HEX BOLT M18X2.5X60 10.9 SA2JS	71	73182300	18
10085154ACSG	Solis Tractor STICKER FOR DRAFT & POSITION INDICATION	108	39199010	18
10085186AASG	Solis Tractor SPECIAL SQUARE NECK SECREW M8X20	19	73182300	18
10085315ABSG	Solis Tractor HOSE CONNECTOR TO INTAKE MANIFOLD	298	40091100	18
10085339ABSG	Solis Tractor HEX BOLT M18X2.5X90	99	73181600	18
10085366AASG	Solis Tractor CAP FOR FENDER	8	87089900	18
10085395AASG	Solis Tractor SPECIAL PLUG G1/2 -A WITH M10 MONUTING	149	87089900	18
10085420AASG	Solis Tractor NUT	27	87089900	18
10085438ABSG	Solis Tractor SPACER (DIA 8.5XDIA 15X3)	15	73182300	18
10085450ABSG	Solis Tractor LOCK PIN MTG. BKT.	311	87089900	18
10085467AASG	Solis Tractor BUSH	65	84829900	18
10085487ABSG	Solis Tractor O-RING DIA 7.5* DIA 2	13	40161000	18
10085492ABSG	Solis Tractor PLAIN WASHER A6.4	2	73182100	18
10085510AASG	Solis Tractor BEADING FOR RADIATOR TOP	69	40082990	18
10085521AASG	Solis Tractor SPECIAL BOLT SHUTTLE LEVER(M14X40 SA2JS	119	73182300	18
10085521ABSG	Solis Tractor SPECIAL BOLT FOR SHUTTLE LEVER (M14X40)	110	73181500	18

10085543ABSG	Solis Tractor GROMMET FOR ROPS HARNESS (UPPER)	17	87140000	28
10085543ACSG	Solis Tractor GROMMET FOR ROPS HARNESS (UPPER)	13	40169990	18
10085553ABSG	Solis Tractor GROMMET	15	40161000	18
10085556AASG	Solis Tractor SPECIAL SCREW FOR IPTO LEVER(M8X48 SA2JS	12	73181500	18
10085562AASG	Solis Tractor TENSION SPRING FOR IPTO	13	73201011	18
10085563AASG	Solis Tractor COMPRESSION SPRING FOR IPTO	13	73201011	18
10085580AASG	Solis Tractor GRUB SCREW M6X1	10	73182300	18
10085889AASG	Solis Tractor RUBBER BEADING	15	40161000	18
10086022ACSG	Solis Tractor BEADING FOR RADIATOR SEALING PLATE (TOP	21	40161000	18
10086042ABSG	Solis Tractor Cover for foot throttle	37	40169990	18
10086145AASG	Solis Tractor RUBBER PAD FOR FENDER SUPPORT BAR	10	40161000	18
10086196ABSG	Solis Tractor STOPPER PIN	77	87089900	18
10086197ABSG	Solis Tractor DUST CAP	50	87089900	18
10086284ABSG	Solis Tractor TIE ROD FOR BRAKE (BRAKE SIDE)	398	87083000	18
10086293AASG	Solis Tractor HEXAGONAL SOCKET COUNTER SUNK SCREW M6	11	73181500	18
10086301AASG	Solis Tractor GASKET (FOR MUDGUARD CAP)	13	68129922	18
10086303ABSG	Solis Tractor COVER ASSEMBLY FOR EXHAUST ELBOW	485	87089200	18
10086303ACSG	Solis Tractor COVER ASSEMBLY FOR EXHAUST ELBOW	430	87089900	18
10086407ABSG	Solis Tractor ROD FOR FRONT WEIGHT	209	87089900	18
10086408ABSG	Solis Tractor ROD FOR FRONT WEIGHT	258	87089900	18
10086423ACSG	Solis Tractor PIN FOR STABILIZER AND LIFT ARMS	207	73181500	18
10086546ABSG	Solis Tractor ADJUSTABLE STAY BAR ASSEMBLY	4814	87089900	18
10086578AASG	Solis Tractor STICKER FOR 24 SPEEDS	50	39199010	18
10086630AASG	Solis Tractor KNOB ASSY (FOR LIFTOMATIC SWITCH)	66	87089900	18
10086632ABSG	Solis Tractor COVER FOR LIFTOMATIC SWITCH	137	87089900	18
10086648AASG	Solis Tractor KNOB DCV LEVER	154	87089900	18
10086649ABSG	Solis Tractor HAND ACC. KNOB ASSY	138	87089900	18
10086655ABSG	Solis Tractor KNOB FR LEVER	77	87089900	18
10086695AASG	Solis Tractor STICKER PTO DISENGAGE	10	39191000	18
10086705AASG	Solis Tractor STICKER FOR TOP LINK MOUNTING INSTRUCTIO	26	39199010	18
10086791AASG	Solis Tractor TANK UNIT (ROHS COMPLIANCE)	414	87089900	18
10086920AASG	Solis Tractor RUBBERIZED SEALING WASHER M14	34	40161000	18
10087140ABSG	Solis Tractor MTG PLATE FOR PTO	66	87089900	18
10087464ACSG	Solis Tractor PROPELLER SHAFT ASSY	11863	87084000	18
10087902AASG	Solis Tractor BEATA PIN	17	73182300	18
10087916AASG	Solis Tractor LINCH PIN	20	87089900	18
10087923AASG	Solis Tractor LINCH PIN ASSY.(1#7)	17	87089900	18
10090006AESG	Solis Tractor GEAR PTO 540E Z-71	2963	87084000	18
10090045AASG	Solis Tractor Spacer - 1 for lay shaft	234	73182910	18
10090069CASG	Solis Tractor Shaft Idler PTO	611	87089900	18
10090104ACSG	Solis Tractor SHIFTER BUSH HIGH	394	87089900	18
10090109AASG	Solis Tractor SHIFTER KNOB (RANGE)	110	87089900	18
10090110BCSG	Solis Tractor BUSH REVERSE PINION	509	87084000	18
10090111BCSG	Solis Tractor BUSH FORWARD PINION	449	87084000	18
10090126ABSG	Solis Tractor Gear PTO 540 Z-77	3213	87084000	18
10090126ACSG	Solis Tractor GEAR PTO 540 Z-77	3127	87084000	18
10090131ACSG	Solis Tractor FORK	468	87089900	18
10090135BASG	Solis Tractor Bush shifter PTO	263	87089900	18
10090136ABSG	Solis Tractor Gear shifter rod for shuttle	391	87084000	18
10090144AASG	Solis Tractor PTO shaft	3418	87084000	18
10090154ABSG	Solis Tractor COUPLING PTO SHAFT	501	87084000	18

10090155AFSG	Solis Tractor SHIFTER FORK LOW MEDIUM	678	87089900	18
10090177BASG	Solis Tractor PTO LEVER ASSY	248	87089900	18
10090180ABSG	Solis Tractor Plain cover	890	87085000	18
10090185ABSG	Solis Tractor HUB PTO	610	87089900	18
10090224CASG	Solis Tractor Shaft reverse idler	574	87089900	18
10090231BBSG	Solis Tractor GEAR IDLER PTO Z-26 / Z-34	1897	87084000	18
10090257AGSG	Solis Tractor CROWN WHEEL & TAIL PINION (12*38)	12262	87084000	18
10090258BBSG	Solis Tractor Bush 4th wheel (collar shift)	424	87089900	18
10090258BCSG	Solis Tractor Bush 4th wheel (collar shift)	479	87084000	18
10090264BBSG	Solis Tractor Bush low wheel	473	87089900	18
10090266BBSG	Solis Tractor Connecting shaft	2817	87084000	18
10090291BBSG	Solis Tractor Gear shifter rods 3rd & 4th	333	87084000	18
10090291BCSG	Solis Tractor GEAR SHIFTER RODS 3RD & 4TH	311	87084000	18
10090293ABSG	Solis Tractor Gear shifter rod PTO	328	87084000	18
10090295AASG	Solis Tractor Spacer - 2 for lay shaft	224	73182910	18
10090296AASG	Solis Tractor Spacer - 4 for lay shaft	171	73182910	18
10090341BASG	Solis Tractor Sleeve high gear	567	87084000	18
10090347ABSG	Solis Tractor Cover (for bottom window)	850	87085000	18
10090361BASG	Solis Tractor Hub Hi-gear	894	87084000	18
10090367BESG	Solis Tractor INPUT SHAFT, DUAL CLUTCH	2786	87084000	18
10090426BESG	Solis Tractor INPUT SHAFT, DOUBLE CLUTCH	2870	87084000	18
10090452BDSG	Solis Tractor BUSH PTO 540E WHEEL	503	87084000	18
10090472ACSG	Solis Tractor SHIFTER FORK HIGH	653	87089900	18
10090630BCSG	Solis Tractor BUSH FOR PTO IDLER SHAFT	244	870899	18
10090637BASG	Solis Tractor Gear shifter rods low medium	319	87084000	18
10090637BBSG	Solis Tractor GEAR SHIFTER RODS LOW MEDIUM	360	87084000	18
10090639BDSG	Solis Tractor GEAR SHIFTER ROD HI	316	87084000	18
10090652BASG	Solis Tractor Hub for shuttle	1392	87084000	18
10090713BBSG	Solis Tractor GEAR REVERSE PINION	1338	87084000	18
10090732ADSG	Solis Tractor Gear reverse wheel Z-59	1583	84834000	18
10090750ABSG	Solis Tractor Shuttle small lever sub assy	213	87089900	18
10090752AASG	Solis Tractor Spacer for connecting shaft	54	87084000	18
10090754AASG	Solis Tractor Copper washer M14	10	73182300	18
10090757BASG	Solis Tractor Lay Shaft Sub Assy With Bush	3089	87084000	18
10090778AHSG	Solis Tractor DIFFERENTIAL HOUSING WITHOUT DIFF LOCK	59244	87085000	18
10090785ACSG	Solis Tractor DIFFERENTIAL HSG (WITH DIFF LOCK)	62193	87085000	18
10090806BASG	Solis Tractor Spacer	680	73182910	18
10090813AASG	Solis Tractor Pin For Neutral Safety Switch	18	87089900	18
10090847AASG	Solis Tractor Graded Spacer for Pinion Shaft 3.15	42	87089900	18
10090847ABSG	Solis Tractor Graded Spacer for Pinion Shaft 3.15	44	87089900	18
10090848ABSG	Solis Tractor Graded Spacer for Pinion Shaft 3.30	44	87089900	18
10090849ABSG	Solis Tractor Graded Spacer for Pinion Shaft 3.45	45	87089900	18
10090862AASG	Solis Tractor Graded Spacer for Pinion Shaft 3.60	46	87089900	18
10090862ABSG	Solis Tractor Graded Spacer for Pinion Shaft 3.60	46	87089900	18
10090863AASG	Solis Tractor Graded Spacer for Pinion Shaft 3.75	47	87089900	18
10090863ABSG	Solis Tractor Graded Spacer for Pinion Shaft 3.75	47	87089900	18
10090864ABSG	Solis Tractor Graded Spacer for Pinion Shaft 3.90	48	87089900	18
10090865ACSG	Solis Tractor HUB LOW-MED	749	87084000	18
10090900AASG	Solis Tractor SPECIAL SCREW	49	73181190	18
10090961ABSG	Solis Tractor GEAR 4TH PINION Z-64	1671	84834000	18
10091033CBSG	Solis Tractor INTERMEDIATE SHAFT Z-32 FOR CM	4555	87084000	18

10091129BCSG	Solis Tractor GEAR BOX HOUSING	34083	84833000	18
10091132AASG	Solis Tractor COVER PLATE	1767	87085000	18
10091146ACSG	Solis Tractor GEAR 1ST PINION Z-32	1105	87084000	18
10091175ABSG	Solis Tractor GEAR 3RD WHEEL Z-47	1492	87084000	18
10091186ABSG	Solis Tractor GEAR FORWARD PINION Z-41	1489	87084000	18
10091192BASG	Solis Tractor MEDIUM GEAR WHEEL Z-38	2148	87084000	18
10091209CBSG	Solis Tractor LAY SHAFT RANGE Z-26/39/76	6194	87084000	18
10091221ACSG	Solis Tractor GEAR 4TH WHEEL Z-40 FOR CM	1409	87084000	18
10091232AASG	Solis Tractor GEAR 2ND WHEEL Z-59 FOR CM	1696	87084000	18
10091243ABSG	Solis Tractor GEAR 2ND/3RD PINION Z-46/57	2144	87084000	18
10091258AASG	Solis Tractor GEAR FORWARD WHEEL Z-62	1764	84834000	18
10091356AASG	Solis Tractor CAP FOR GEAR BOX HOUSING	14	87084000	18
10093612ABSG	Solis Tractor FRONT TOE PIN	712	87089900	18
10093767AASG	Solis Tractor 1SA IDA DCV WITH DETENT OPTION	14893	84811000	18
10093784AASG	Solis Tractor PIPE CLAMP FOR DIA 6	17	73261990	18
10093906AASG	Solis Tractor MICRO RELAY WITH BRACKET	167	85361010	18
10094058AASG	Solis Tractor C CLIP M6	20	73181500	18
10094099AASG	Solis Tractor PIPE CLAMP FOR DIA 16	24	73260000	18
10094728AASG	Solis Tractor BEEDING FOR RADIATOR SEALING	141	40082990	18
10094809AASG	Solis Tractor LINCH PIN ASSY (FOR EPA)	27	87089900	18
10095121AASG	Solis Tractor BASE PLATE ASSY	1069	87089900	18
10095604AASG	Solis Tractor SWITCH FOR HAZARD WARNING	601	85361090	18
10095604ABSG	Solis Tractor SWITCH FOR HAZARD WARNING	555	85361090	18
10096266ABSG	Solis Tractor SPACER SMALL REAR AXLE	70	87089900	18
10096382AASG	Solis Tractor SHIM BP SHAFT 0.1	21	73182300	18
10096383AASG	Solis Tractor SHIM BP SHAFT 0.2	6	73182300	18
10096384AASG	Solis Tractor SHIM BP SHAFT 0.5	7	73182300	18
10096428AASG	Solis Tractor Dowel ~6x18	11	87089900	18
10098601AASG	Solis Tractor LIGHT FOR REGISTRATION PLATE	444	85122020	18
105425-01690S	Solis Tractor PLUG, DRAIN M16	269	73181500	18
11000271AASG	Solis Tractor Bush for clutch & brake pedal	115	87083000	18
11000448AASG	Solis Tractor Radiator cowl (plastic)	260	87089100	18
11000456AASG	Solis Tractor PRESSURE PLATE FOR PTO CLUTCH	1749	87089300	18
11000457AASG	Solis Tractor PRESSURE PLATE FOR MAIN CLUTCH	2335	87089300	18
11000459AASG	Solis Tractor FULCRUM RING	34	87089300	18
11000519AASG	Solis Tractor PIN FOR ADJUSTABLE STAY BAR	165	73182300	18
11000579AASG	Solis Tractor SST CARRARO TRANSMISSION	45341	87085000	18
11000611AASG	Solis Tractor SOLIS WATERLESS SHINER	227	34051000	18
11000620AASG	Solis Tractor PRESSURE PLATE FOR MAIN CLUTCH	2266	87089300	18
11000627AASG	Solis Tractor Eng. Overhaul KIT_4105 NG Series	23517	84099941	28
11000628AASG	Solis Tractor PISTON RING SET (Ø73) FM_ GARDEN TRACK	608	84099111	28
11000638AASG	Solis Tractor ENGINE KIT FOR 4105NG & 4105NU SERIES	25217	84099941	28
11000640AASG	Solis Tractor PAINT SOLIS RED BOTTEL 300G SPRAY CAN	445	84213990	18
11000645AASG	Solis Tractor PAINT GOLDEN MET BOTTEL 300G SPRAY CAN	508	32082090	18
11000650AASG	Solis Tractor SOLIS DD GREY BOTTLE 300G SPRAY	523	32082090	18
11000660AASG	Solis Tractor DANA 4WD front axle SPECIAL TOOL KIT	22437	87081010	18
11000663AASG	Solis Tractor Seal Kit of ECO. HYD CYL.(PS)1002900	359	40169330	18
11000667AASG	Solis Tractor DRIVEN PLATE ASSY_L-03028-0H31-01	4632	87081010	18
11000668AASG	Solis Tractor DRIVEN PLATE ASSY_L-03028-0H30-01	9099	87081010	18
11000678AASG	Solis Tractor Spherical Bushing and Cap(Kit)	699	87089900	18
11000687AASG	Solis Tractor Liner Piston Kit (Ø105) P Type	5177	84099199	28

11000692AASG	Solis Tractor Valve guide Special service tool YANMAR	961	82060010	18
1133208074SG	Solis Tractor DIESEL CONSUMPTION MEASURING KIT CAP-5L	12795	82060090	18
119005-35170S	Solis Tractor FILTER, OIL D80X100	824	84212300	18
119130-44740S	Solis Tractor FAN, COOLING D=410	4641	84149090	18
119609-32040S	Solis Tractor O-RING, P16	110	40169320	18
119751-77210S	Solis Tractor ALTERNATOR, 12V-40A	50358	85114000	28
119761-39450S	Solis Tractor SWITCH, HYDRAULIC	786	85365090	18
119761-44901S	Solis Tractor SWITCH, TEMPERATURE	3712	85365090	18
119802-25101S	Solis Tractor GEAR ASSY, IDLE	12060	84834000	18
119802-25901S	Solis Tractor GEAR, PUMP	12858	84834000	18
119802-51690S	Solis Tractor O-RING, 1016	295	40169390	18
119803-11340S	Solis Tractor SEAL, VALVE STEM	310	40169390	18
119803-25050S	Solis Tractor SHAFT, IDLE GEAR	4641	84834000	18
119860-34810S	Solis Tractor GUIDE, DIPSTICK	2237	87089900	18
119934-01800S	Solis Tractor SEAL, OIL	946	40169390	18
120130-11860S	Solis Tractor GUIDE, VALVE	1742	84099990	28
120130-22301S	Solis Tractor PIN, PISTON	4495	84099990	28
121400-11340S	Solis Tractor SEAL, VALVE STEM	376	40169390	18
121520-34810S	Solis Tractor GUIDE, DIPSTICK	454	84099990	28
121550-23200S	Solis Tractor BOLT, CONNECTING ROD	426	73181500	18
121850-49550S	Solis Tractor GASKET, THERMOSTAT	136	48230000	18
121850-49811S	Solis Tractor THERMOSTAT, 71C	2654	84819090	18
121850-51960S	Solis Tractor O-RING, FUEL PUMP	150	40169390	18
121850-77021S	Solis Tractor GASKET, AIR HEATER	483	40169340	18
123900-25060S	Solis Tractor SHAFT, IDLE GEAR	2919	87089900	18
123907-11601S	Solis Tractor SEAL, PIPE	997	40169390	18
124160-01751S	Solis Tractor CAP, FILLER	508	39269099	18
124160-11340S	Solis Tractor SEAL, VALVE STEM	321	40169390	18
124460-11340S	Solis Tractor SEAL, VALVE STEM	376	40169390	18
124465-44950S	Solis Tractor GASKET, 16	122	74152100	18
124550-77030-4S	Solis Tractor COVER, TERMINAL B	29	40161000	18
124756-77040-3S	Solis Tractor COVER, TERMINAL A	23	40161000	18
129001-02931S	Solis Tractor METAL ASSY, MAIN	3582	84833000	18
129005-03080S	Solis Tractor HOSE ASSY, BREATHER	1727	40091100	18
129005-11100S	Solis Tractor VALVE, INTAKE	2466	84099990	28
129005-22080S	Solis Tractor PISTON ASSY	14925	84099990	28
129005-22500S	Solis Tractor RING SET, PISTON	4495	84099990	28
129005-22900S	Solis Tractor PISTON ASSY, 0.25 OS	15504	84099990	28
129005-22950S	Solis Tractor RING SET, PISTON .25	5363	84099990	28
129008-01520S	Solis Tractor FLANGE, GEAR CASE	23412	84834000	18
129008-51390S	Solis Tractor VALVE ASSY, DELIVERY	7319	84099990	28
129008-53200S	Solis Tractor VALVE ASSY, INJECTION	7391	84099990	28
129054-42320S	Solis Tractor O-RING	150	40169320	18
129100-11112S	Solis Tractor VALVE, EXHAUST	2466	84099990	28
129100-23910S	Solis Tractor METAL, PISTON PIN	547	84833000	18
129150-01881S	Solis Tractor GASKET, PUMP COVER	188	40169390	18
129150-02450S	Solis Tractor METAL, THRUST	1316	84833000	18
129150-02871S	Solis Tractor METAL ASSY, MAIN .25	2123	84833000	18
129150-02931S	Solis Tractor METAL ASSY, THRUST	1063	84833000	18
129150-02941S	Solis Tractor METAL ASSY, 0.25 OS	1327	84833000	18
129150-11810S	Solis Tractor GUIDE, VALVE	1091	84099990	28

129150-14101S	Solis Tractor GEAR, CAMSHAFT	6761	84834000	18
129150-14200S	Solis Tractor TAPPET	1091	84099990	28
129150-14400S	Solis Tractor ROD, PUSH L=178	467	84099990	28
129150-23601S	Solis Tractor METAL ASSY, CRANK PIN	1858	84833000	18
129150-23611S	Solis Tractor METAL, CRANK PIN .25	2255	84833000	18
129150-26000S	Solis Tractor DRIVE ASSY, PUMP	19416	84830000	28
129150-32020S	Solis Tractor GASKET, PUMP	122	48230000	18
129150-35042S	Solis Tractor GASKET, INLET PIPE	122	40169390	18
129150-42059S	Solis Tractor GASKET	1727	84841010	18
129150-42319S	Solis Tractor GASKET, FLANGE	361	84841010	18
129150-49811S	Solis Tractor GASKET, WATER PUMP	150	84841010	18
129150-77511S	Solis Tractor GASKET, AIR HEATER	150	40169390	18
129155-49801S	Solis Tractor THERMOSTAT, 71C	2389	84841010	18
129155-51280S	Solis Tractor O-RING, S6	97	40169320	18
129202-22300S	Solis Tractor PIN, PISTON D26 L70	2321	84099990	28
129407-01340S	Solis Tractor GASKET, HEAD	7821	84841090	18
129407-12110S	Solis Tractor GASKET, MANIFOLD	508	84841090	18
129407-32001S	Solis Tractor PUMP ASSY, OIL	18981	84133010	28
129407-77010S	Solis Tractor STARTOR (R A 1.4	58510	85114000	28
129411-13100S	Solis Tractor MANIFOLD, EXHAUST	18224	84841090	18
129423-77730S	Solis Tractor REGULATOR ASSY	24568	85437099	18
129436-44740S	Solis Tractor FAN, COOLING D=410	3184	84145990	18
129457-28000S	Solis Tractor BALANCER ASSY	84046	84839000	18
129457-28011S	Solis Tractor CASE ASSY, BALANCER	39214	84839000	18
129457-34800S	Solis Tractor DIPSTICK, OIL	1461	90170000	18
129486-42050S	Solis Tractor GASKET, WATER PUMP	310	84841010	18
129509-51390S	Solis Tractor VALVE ASSY, DELIVERY	6695	84839000	18
129550-01702S	Solis Tractor OIL PAN	28179	87089900	18
129550-13110S	Solis Tractor GASKET, MANIFOLD	361	84841090	18
129550-35090S	Solis Tractor PIPE ASSY, OIL INLET	2031	84099990	28
129601-11241S	Solis Tractor SHAFT ASSY, ROCKER	29722	84839000	18
129601-11251S	Solis Tractor SHAFT, ROCKER ARM	7245	84099990	28
129601-11310S	Solis Tractor GASKET, BONNET	2255	40169390	18
129601-59810S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129601-59820S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129601-59830S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129601-59840S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129602-12101S	Solis Tractor MANIFOLD, INTAKE	24618	84099990	28
129604-11700S	Solis Tractor HEAD ASSY, CYLINDER	120639	84839000	18
129604-77821S	Solis Tractor CONNECTOR, GLOW PLUG	1727	85369090	18
129623-21650S	Solis Tractor V-PULLEY, CRANKSHAFT	11796	84835090	18
129630-77900S	Solis Tractor SOLENOID, STOP	10604	85050000	18
129636-59561S	Solis Tractor PIPE ASSY, RETURN	2321	84099990	28
129636-59661S	Solis Tractor PIPE, FUEL RETURN	1742	84099990	28
129648-01780S	Solis Tractor SEAL, OIL	3978	40169390	18
129652-11350S	Solis Tractor BONNET ASSY, HEAD	23322	84839000	18
129652-21010S	Solis Tractor CRANKSHAFT ASSY	92123	84839000	18
129659-13521S	Solis Tractor SILENCER	33692	84090000	28
129659-21530S	Solis Tractor FLYWHEEL ASSY	81226	84839000	18
129659-42061S	Solis Tractor PUMP ASSY, CW	55992	84133090	28
129671-42280S	Solis Tractor V-BELT, A45.5	10667	84213990	18

129795-49551S	Solis Tractor GASKET, COVER	178	84841010	18
129900-13200S	Solis Tractor MANIFOLD, EXHAUST	18224	84841090	18
129900-13251S	Solis Tractor GASKET, MANIFOLD	665	84841090	18
129900-14110S	Solis Tractor GEAR, CAMSHAFT	20675	87089900	18
129900-23001S	Solis Tractor ROD ASSY, CONNECTING	21826	73181600	18
129900-23200S	Solis Tractor BOLT, CONNECTING ROD	178	73181600	18
129900-23911S	Solis Tractor METAL, PISTON PIN	1171	84833000	18
129900-26020S	Solis Tractor GEAR ASSY, PUMP	6099	84834000	18
129900-42061S	Solis Tractor GASKET, WATER PUMP	188	84841010	18
129900-42170S	Solis Tractor GASKET, PUMP COVER	681	84841010	18
129900-49560S	Solis Tractor GASKET, COVER	334	40169390	18
129900-77040S	Solis Tractor STARTOR (1 2 V 2.3 KW	68580	85114000	28
129906-01350S	Solis Tractor GASKET, HEAD	7821	84841010	18
129906-22050S	Solis Tractor RING SET, PISTON	5541	84099113	28
129906-51580S	Solis Tractor GASKET, BARREL PLUG	217	84841010	18
129906-53000S	Solis Tractor VALVE ASSY, INJECTION	7391	84099990	28
129907-11100S	Solis Tractor VALVES	2466	84099990	28
129907-11110S	Solis Tractor VALVE, EXHAUST	2321	84099990	28
129907-11250S	Solis Tractor SHAFT, ROCKER ARM	24941	84099990	28
129907-11700S	Solis Tractor HEAD ASSY, CYLINDER	135718	84839000	18
129907-11800S	Solis Tractor GUIDE, VALVE	1016	84099990	28
129907-12100-9S	Solis Tractor MANIFOLD, INTAKE	23905	84841090	18
129907-12110S	Solis Tractor GASKET, MANIFOLD	1171	84841090	18
129907-14400S	Solis Tractor ROD, PUSH	583	84099990	28
129907-21650S	Solis Tractor V-PULLEY, CRANKSHAFT	10073	84835090	18
129907-25900S	Solis Tractor GEAR, PUMP	12858	87089900	18
129907-39061S	Solis Tractor PIPE ASSY, OIL	3045	84099990	28
129907-59140S	Solis Tractor PIPE ASSY, RETURN	6377	84099990	28
129907-59810S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129907-59820S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129907-59830S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129907-59840S	Solis Tractor PIPE ASSY, INJECTION	3045	84099990	28
129908-14590S	Solis Tractor CAMSHAFT ASSY	22154	84839000	18
129916-01790S	Solis Tractor SEAL, D115/95XT11	3712	40169390	18
129916-01800S	Solis Tractor SEAL, OIL	1461	40169390	18
129916-22950S	Solis Tractor RING SET, PISTON .25	6156	84099113	28
129927-02340S	Solis Tractor BEARING ASSY, MAIN US	3846	84833000	18
129927-02930S	Solis Tractor BEARING ASSY, THRUST	1116	84833000	18
129927-02940S	Solis Tractor BEARING, THRUST 0.25 OS	1461	84833000	18
129927-23600S	Solis Tractor BEARING ASSY, PIN	3582	84833000	18
129927-23610S	Solis Tractor BEARING ASSY, PIN US	2785	84833000	18
129927-25110S	Solis Tractor GEAR ASSY, IDLE	11398	87089900	18
129927-25920S	Solis Tractor BUSH, IDLE GEAR	747	87089900	18
129927-44900S	Solis Tractor SENSOR, TEMPERATURE	3050	90251990	18
129930-13201S	Solis Tractor GASKET, SILENCER	759	84841010	18
129930-39050S	Solis Tractor PIPE, HO PUMP	1004	84099990	28
129933-11310S	Solis Tractor GASKET, BONNET	2191	40169390	18
129936-01500S	Solis Tractor CASE, GEAR	26449	87089900	18
129942-21000S	Solis Tractor CRANKSHAFT ASSY	95412	84839000	18
129956-01731S	Solis Tractor OIL PAN	40401	87089900	18
129956-28030S	Solis Tractor BALANCER ASSY	145133	84839000	18

129956-28040S	Solis Tractor CASE ASSY, BALANCER	145133	84839000	18
129956-32001S	Solis Tractor PUMP ASSY, OIL	16518	84133090	28
129962-11300S	Solis Tractor BONNET ASSY	26119	84839000	18
129962-21501S	Solis Tractor FLYWHEEL ASSY.	88607	84839000	18
129962-22090S	Solis Tractor PISTON ASSY	15109	84839000	18
129962-22910S	Solis Tractor PISTON ASSY	17802	84839000	18
129962-34810S	Solis Tractor DIPSTICK, LUB.OIL	3314	90170000	18
129962-42120S	Solis Tractor PUMP ASSY, CW HIGH	41964	84133090	28
129968-01640S	Solis Tractor CASE ASSY, OIL SEAL	12619	84839000	18
129968-13580S	Solis Tractor SILENCER	35730	84090000	28
129968-21620S	Solis Tractor GEAR, RING	4508	40169390	18
129C26-01890S	Solis Tractor GASKET, PUMP	178	84841010	18
158552-51151S	Solis Tractor FLANGE, CAMSHAFT	3184	84831099	18
158552-51571S	Solis Tractor GASKET, BARREL PLUG	244	74152100	18
158552-51600S	Solis Tractor GASKET, HEAD	1288	84849000	18
158552-52100S	Solis Tractor PUMP ASSY, FUEL FEED	15360	84133090	28
158552-52311S	Solis Tractor O-RING, FEED PUMP	188	40169390	18
158552-52400S	Solis Tractor O-RING, 4E S42	136	40169390	18
158552-52500S	Solis Tractor O-RING, PUMP INNER	321	40169390	18
158552-61900S	Solis Tractor O-RING	83	40169390	18
158553-51680S	Solis Tractor GASKET, TIMER	122	74152100	18
158553-61050S	Solis Tractor GASKET, CASE	466	40169390	18
158553-61070S	Solis Tractor GASKET, CASE	217	40169390	18
158560-51600S	Solis Tractor GASKET, HEAD	1250	84841010	18
158560-61050S	Solis Tractor GASKET, CASE	466	40169390	18
158560-61071S	Solis Tractor GASKET, CASE	217	40169390	18
158563-51150S	Solis Tractor FLANGE	5468	73070000	18
158563-51281S	Solis Tractor O-RING, 4D S6	178	40169390	18
172B06-11520S	Solis Tractor AIR CLEANER ELEMENT (SECONDARY)	0	84219900	18
192180-31850-2S	Solis Tractor WASHER, DIFF PINION	14	73181500	18
194065-34170-4S	Solis Tractor WASHER, 16	17	73181500	18
194145-27450-6S	Solis Tractor SPRING	15	73202000	18
194150-25530-3S	Solis Tractor WASHER, 20X43X2.5	37	73181500	18
194151-36670-4S	Solis Tractor PLUG, PF02	18	40161000	18
194170-51210-2S	Solis Tractor GROMMET, 25	15	73202000	18
194180-12471-2S	Solis Tractor NUT,CASTLE	23	73181600	18
194250-25520-0S	Solis Tractor SPACER, 35X45X2	15	87089900	18
194250-46470-0S	Solis Tractor SHIM, 0.2	2	87081010	18
194251-13910-0S	Solis Tractor SHIM	13	87089900	18
194251-13920-0S	Solis Tractor SHIM	8	87089900	18
194251-13930-0S	Solis Tractor SHIM	6	87089900	18
194279-14220-4S	Solis Tractor WASHER, 14	28	73181600	18
194279-14220S	Solis Tractor WASHER, 14	27	40161000	18
194301-12730-3S	Solis Tractor SHIM, 30X45X0.1	3	87089900	18
194312-25470-1S	Solis Tractor SPACER, 30X40X2	16	87089900	18
194312-27770-5S	Solis Tractor JOINT, 2-WAY	38	87081010	18
194312-27780-4S	Solis Tractor PIN	31	87089900	18
194312-46630-2S	Solis Tractor HOLDER, VALVE	105	87089900	18
194440-51620-1S	Solis Tractor CLAMP, B	25	87089900	18
194446-62310-2S	Solis Tractor CAP, RUBBER 8	7	40161000	18
194450-11190-2S	Solis Tractor CAP, 15.0	8	40161000	18

194450-48830-4S	Solis Tractor CLAMP,	17	87089900	18
194464-45920-3S	Solis Tractor PLUG, 3/4-16UNF	52	87089900	18
194464-45930-0S	Solis Tractor PACKING, 8-1	4	40161000	18
194555-46300-4S	Solis Tractor VALVE, STOP	83	87089900	18
194555-51210-2S	Solis Tractor GROMMET, 35	14	40161000	18
194555-65130-1S	Solis Tractor CUSHION	6	40161000	18
194640-25860-2S	Solis Tractor WASHER, 30X50X3	46	73181500	18
194640-34130-2S	Solis Tractor WASHER, 13X64X9	112	73181500	18
194680-27540-2S	Solis Tractor SPRING, HORK LOCK	15	73202000	18
194697-62560-1S	Solis Tractor CAP, HOLE	11	87089900	18
194740-00160-3S	Solis Tractor WASHER, CONICAL 10	6	73181500	18
194850-49290-2S	Solis Tractor O-RING, 6-1	13	73060000	18
197810-83220-4S	Solis Tractor GROMMET, 18	15	40161000	18
197830-85490-1S	Solis Tractor PLUG, RUBBER 15	8	40161000	18
198071-24340-1S	Solis Tractor COLLAR, 13X17X14	29	87089900	18
198071-24350-1S	Solis Tractor PLATE, OIL SIGHT	10	87089900	18
198071-27860-3S	Solis Tractor PIN, 4X35	18	73181500	18
198071-37510-2S	Solis Tractor COVER, PEDAL HEAD	61	87081010	18
198071-58810-2S	Solis Tractor GROMMET, 8	10	40161000	18
198072-60590-3S	Solis Tractor BOLT, M6X20	10	73181500	18
198119-27150-0S	Solis Tractor COLLAR, SHIFT ARM A	13	87089900	18
198133-64400-3S	Solis Tractor GROMMET,	16	40161000	18
198163-65950-2S	Solis Tractor LABEL, SEATBELT	8	39191000	18
198165-04380-4S	Solis Tractor RUBBER, 100X25X3	25	40161000	18
198200-14210-1S	Solis Tractor RING, HALF TIMBER	29	73182910	18
198200-22470-1S	Solis Tractor HINGE, LEVER	12	87089900	18
198200-34190-3S	Solis Tractor NUT, 14	31	73181600	18
198212-24360-4S	Solis Tractor PLATE, CENTER	1107	87081010	18
198212-25210-2S	Solis Tractor SHAFT, MAIN	1631	87084000	18
198212-26580-2S	Solis Tractor PIPE, HYD.OIL	52	87089900	18
198212-26590-3S	Solis Tractor PIPE, LUB.OIL	55	87089900	18
198212-27280-1S	Solis Tractor PLATE, FORK LOCK	41	87089900	18
198212-27521-3S	Solis Tractor ARM, RANGE SHIFT	133	87081010	18
198212-34150-1S	Solis Tractor WASHER, REAR AXLE	49	73181500	18
198220-26910-2S	Solis Tractor SPRING	12	73202000	18
198220-37900-4S	Solis Tractor PIN, 8X24	30	87089900	18
198220-62150-5S	Solis Tractor WASHER	29	40161000	18
198220-63340-5S	Solis Tractor SPRING, FRICTION	15	73202000	18
198230-61960-4S	Solis Tractor SPRING, RETURN	14	73202000	18
198240-24120S	Solis Tractor BOLT, M16X45	65	73181600	18
198240-24690-4S	Solis Tractor FILLER, OIL	329	87081010	18
198240-25930-2S	Solis Tractor WASHER, THRUST 17X32	68	73181500	18
198240-62451-3S	Solis Tractor RUBBER,	70	40161000	18
198255-24460-1S	Solis Tractor PLATE, OIL SEAL	49	87081010	18
198290-26860-4S	Solis Tractor COVER, PTO SHAFT	29	87089900	18
198310-27370-2S	Solis Tractor JOINT, TWO-WAY	38	87081010	18
198360-31530-1S	Solis Tractor LINER, SIDE GEAR	42	87084000	18
198448-28430-2S	Solis Tractor BOLT, JOINT 14	46	73181500	18
198475-22520-4S	Solis Tractor SPRING, RETURN	46	73202000	18
198475-22530-2S	Solis Tractor PLATE, LINK	23	87089900	18
198475-37690-3S	Solis Tractor SPRING, LOCK	25	73202000	18

198535-24120-2S	Solis Tractor NUT, M16	30	73181600	18
198535-52110-4S	Solis Tractor FUSE, 5A	11	85443000	18
198535-52120-4S	Solis Tractor FUSE, 10A	12	85443000	18
198535-52130-4S	Solis Tractor FUSE, 15A	12	85443000	18
198535-52140-4S	Solis Tractor FUSE, 20A	12	85443000	18
1A7030-52810-3S	Solis Tractor FUSE, 40A	122	85443000	18
1A7090-25930-0S	Solis Tractor RING 45	22	73181500	18
1A7130-37990-2S	Solis Tractor BOLT, REAMER 8X55	20	73181500	18
1A7130-48110-2S	Solis Tractor CLAMP, PIPE	29	87089900	18
1A7140-13300-2S	Solis Tractor SHAFT, PROPELLER	2209	87084000	18
1A7180-01050-3S	Solis Tractor RUBBER, RADIATOR	48	40161000	18
1A7180-04180-2S	Solis Tractor SCREW, 5X14	10	73181500	18
1A7180-13150-0S	Solis Tractor COLLAR,	72	73060000	18
1A7180-13250-0S	Solis Tractor COLLAR, DIFFERENTIAL	756	87089900	18
1A7180-13260-0S	Solis Tractor SHIM, A DIFFERENTIAL	14	87089900	18
1A7180-13270-0S	Solis Tractor SHIM, B DIFFERENTIAL	18	87089900	18
1A7180-13380-0S	Solis Tractor COLLAR, 58X62X4.8	92	87089900	18
1A7180-13400-0S	Solis Tractor COLLAR, 58X62X5.0	92	87089900	18
1A7180-13410-0S	Solis Tractor COLLAR, 58X62X5.1	92	87089900	18
1A7180-13560-1S	Solis Tractor SHAFT, L FRONT 1ST	1720	87084000	18
1A7180-13570-1S	Solis Tractor SHAFT, R FRONT 1ST	1222	87084000	18
1A7180-13830-1S	Solis Tractor PINION, FAINAL 11	2053	87084000	18
1A7180-13840-3S	Solis Tractor GEAR, FAINAL 49	13763	87084000	18
1A7180-36240-1S	Solis Tractor WASHER, THRUST	14	73181500	18
1A7180-43280-0S	Solis Tractor PISTON ASSY,	3242	84818090	18
1A7180-43290-2S	Solis Tractor PISTON	1159	87081010	18
1A7180-43410-3S	Solis Tractor ROD, PISTON	692	87084000	18
1A7335-71240-3S	Solis Tractor PIN,	116	87089900	18
1A7347-51140-0S	Solis Tractor DIODE, 3A	224	85443000	18
1A7500-72160-2S	Solis Tractor WASHER, 16	16	73181500	18
1A7590-51570-1S	Solis Tractor ROD, BATTERY CLAMP	46	87081010	18
1A7601-32310-2S	Solis Tractor CARRIER, DIFF.	1835	87089900	18
1A7640-15710-2S	Solis Tractor BUSHING, TILT	19	40169990	18
1A7640-43450-0S	Solis Tractor PLUG, CHECK VALVE	62	87084000	18
1A7640-44230-3S	Solis Tractor WASHER, 65X82X2	86	73181500	18
1A7640-44240-3S	Solis Tractor SEAL PLATE	24	87089900	18
1A7781-65300-0S	Solis Tractor LABEL, WARNING ESCAPE	14	39191000	18
1A7781-65320-0S	Solis Tractor LABEL, PROHIBITION EX	16	39191000	18
1A7815-32810-0S	Solis Tractor BREATHER, GREASE	32	27101974	18
1A7870-24910-2S	Solis Tractor CAP, OIL	26	83090000	0
1A7874-65360-4S	Solis Tractor LABEL, BRAKE COUPLIN	5	39191000	18
1A7880-71550-2S	Solis Tractor SPRING	69	73202000	18
1A8042-46430-0S	Solis Tractor PLUG, VALVE	84	87084000	18
1A8042-47640-2S	Solis Tractor BUSH	107	87089900	18
1A8060-46470-2S	Solis Tractor SHIM, 0.5	2	87081010	18
1A8060-48270-0S	Solis Tractor JOINT, BYPASS	586	87089900	18
1A8060-48300-0S	Solis Tractor BOLT, PIPE JOINT 1/2	83	73181500	18
1A8060-65590-1S	Solis Tractor LABEL, DIFFERENTIAL	3	39191000	18
1A8060-65780-1S	Solis Tractor LABEL, STG WHEEL	30	39191000	18
1A8061-51930-1S	Solis Tractor CONNECTOR, 7282-7062	53	85443000	18
1A8061-65110-0S	Solis Tractor LABEL, SAFETY SHIELD	5	39191000	18

1A8061-65130-0S	Solis Tractor LABEL, SAFETY HYD	5	39191000	18
1A8061-65140-0S	Solis Tractor LABEL, SAFETY HOT	5	39191000	18
1A8061-65150-0S	Solis Tractor LABEL, SAFETY FLYING	2	39191000	18
1A8115-00650-2S	Solis Tractor TANK ASSY, SUB	194	87089900	18
1A8115-01160-0S	Solis Tractor RUBBER,	8	40161000	18
1A8115-01190-1S	Solis Tractor KNOB, THROTTLE LEVER	26	87089900	18
1A8115-22700-2S	Solis Tractor TURNBUCKLE, M10	48	87081010	18
1A8115-27030-1S	Solis Tractor COLLAR, 8X14X5.3	19	73181500	18
1A8115-27240-2S	Solis Tractor SPRING, RETURN	19	73181500	18
1A8115-47810-1S	Solis Tractor KNOB, BLACK	32	87089900	18
1A8240-05170S	Solis Tractor VALVE UNLOADER	1706	84213990	18
1A8240-15720-0S	Solis Tractor COLLAR, 17.3X10X22	21	87089900	18
1A8240-15730-0S	Solis Tractor WASHER, 10.5X44X2.3	42	73181500	18
1A8240-22240-2S	Solis Tractor SPRING, CLUTCH	80	73202000	18
1A8240-37600-1S	Solis Tractor ROD KIT, BRAKE F	185	87089900	18
1A8240-37610-0S	Solis Tractor ROD ASSY, BRAKE	108	87081010	18
1A8240-37650-0S	Solis Tractor LEVER, PARK LOCK UNPAINTED	214	87089900	18
1A8250-46640-0S	Solis Tractor KNOB, STOP VALVE	26	87089900	18
1A8250-65580-0S	Solis Tractor LABEL, STOP VALVE	4	39191000	18
1A8252-00350-0S	Solis Tractor HOSE, BREATHER	69	40090000	18
1A8252-00610-2S	Solis Tractor SEAL, 5X13X20	3	39204900	18
1A8252-00650-0S	Solis Tractor GUIDE ASSY, SCREEN UNPAINTED	102	87089900	18
1A8252-00700-2QWS	Solis Tractor SCREEN ASSY, RADI	566	87089900	18
1A8252-00700-2S	Solis Tractor SCREEN ASSY, RADI UNPAINTED	472	87089900	18
1A8252-00750-3QWS	Solis Tractor SCREEN ASSY, LOWER	431	87089900	18
1A8252-00750-3S	Solis Tractor SCREEN ASSY, LOWER UNPAINTED	376	87089900	18
1A8252-00820-1S	Solis Tractor CW-T, B	440	84099941	28
1A8252-00850-2S	Solis Tractor STOPPER, SUB TANK	10	87089900	18
1A8252-01100-0S	Solis Tractor LEVER UNIT, ACCEL.	263	87089900	18
1A8252-01110-0S	Solis Tractor LEVER,ACCEL	150	87089900	18
1A8252-01150-0S	Solis Tractor STAY,ACCEL LEVER	75	87089900	18
1A8252-01200-0S	Solis Tractor WIRE, HAND ACCEL	290	87089400	18
1A8252-01210-0S	Solis Tractor WIRE, FOOT ACCEL	319	87089900	18
1A8252-01250-2S	Solis Tractor SUPPORT, LEVER	13	87089900	18
1A8252-01310-2S	Solis Tractor ACCEL UNIT, FOOT	189	87089900	18
1A8252-01660-0S	Solis Tractor PLATE,BATTERY SIDE R UNPAINTED	69	87089900	18
1A8252-03200-0S	Solis Tractor PIPE ASSY, EXHAUST	764	87089400	18
1A8252-04010-1S	Solis Tractor KEY, FO CAP	44	83012000	18
1A8252-04020-2S	Solis Tractor CAP ASSY, FUEL TANK	182	87089900	18
1A8252-04200-0S	Solis Tractor PUMP, FUEL FEED	1409	84131990	28
1A8252-04250-2S	Solis Tractor BRACKET ASSY, TANK UNPAINTED	403	87089900	18
1A8252-04270-0S	Solis Tractor STAY ASSY, BAND UNPAINTED	54	87089900	18
1A8252-04311-1S	Solis Tractor TANK ASSY	5997	87089900	18
1A8252-04350-0S	Solis Tractor BRACKET ASSY, PUMP UNPAINTED	157	87089900	18
1A8252-04380-1S	Solis Tractor CUSHION, RUBBER	193	40161000	18
1A8252-04500-0S	Solis Tractor STAY, FUEL HOSE	39	87089900	18
1A8252-04520-0S	Solis Tractor PROTECTOR ASSY,FILTE UNPAINTED	160	87089900	18
1A8252-04600-1S	Solis Tractor HOSE,FO FILTER-PUMP	63	40091100	18
1A8252-04630-1S	Solis Tractor BAND ASSY, FO TANK UNPAINTED	90	87089900	18
1A8252-04670-1S	Solis Tractor RUBBER, SUPPORT	223	40161000	18
1A8252-04681-1S	Solis Tractor COVER, TANK UNPAINTED	651	87089900	18

1A8252-04700-0S	Solis Tractor STAY ASSY, COVER L UNPAINTED	72	87089900	18
1A8252-04710-0S	Solis Tractor STAY ASSY, COVER R UNPAINTED	72	87089900	18
1A8252-04800-2S	Solis Tractor STRAINER, FUEL	120	84213990	18
1A8252-04850-0S	Solis Tractor PIN, FLAT HEAD 8X50	25	87089900	18
1A8252-04860-1S	Solis Tractor WASHER	16	73181500	18
1A8252-04870-1S	Solis Tractor RUBBER, WASHER	18	40161000	18
1A8252-04880-1S	Solis Tractor COLLAR	18	87081010	18
1A8252-04900-0S	Solis Tractor STAY ASSY, CLAMP	134	87089900	18
1A8252-05200-1S	Solis Tractor COVER ASSY, STARTER UNPAINTED	249	87089900	18
1A8252-05250-0S	Solis Tractor STAY, AIR FLOW L	117	87089900	18
1A8252-05300-0S	Solis Tractor STAY ASSY, SHUTTER	69	87089900	18
1A8252-05350-0S	Solis Tractor STAY, AIR FLOW R	247	87089900	18
1A8252-05400-0S	Solis Tractor RUBBER, AIR FLOW L	144	40161000	18
1A8252-05410-0S	Solis Tractor RUBBER, AIR FLOW R	73	40161000	18
1A8252-05450-0S	Solis Tractor STAY, HARNESS STARTER	102	87089900	18
1A8252-06120-1S	Solis Tractor HOSE, AIR INTAKE OUT	528	40091100	18
1A8252-06200-0S	Solis Tractor BRACKET, AIR CLEANER UNPAINTED	55	87089900	18
1A8252-11101-4S	Solis Tractor BRACKET ASSY, F AXLE	17002	87081010	18
1A8252-11350-0S	Solis Tractor SHIM, A FAB	12	87089900	18
1A8252-11360-0S	Solis Tractor SHIM, B FAB	11	87089900	18
1A8252-11370-0S	Solis Tractor SHIM, C FAB	8	87089900	18
1A8252-11510-0S	Solis Tractor SUPPORT, FRONT AXLE F	1632	87081010	18
1A8252-11710-0S	Solis Tractor SUPPORT, FRONT AXLE R	1791	87089900	18
1A8252-12280-1FG	Solis Tractor NUT, M22X1.5	32	73181600	18
1A8252-12280-1S	Solis Tractor NUT, M22X1.5	32	73181600	18
1A8252-12290-1FG	Solis Tractor NUT, M22X1.5 L	35	73181600	18
1A8252-12290-1S	Solis Tractor NUT, M22X1.5 L	35	73181600	18
1A8252-12301-1FG	Solis Tractor TIE-ROD ASSY, L	2397	87089900	18
1A8252-12301-1S	Solis Tractor TIE-ROD ASSY, L	2397	87089900	18
1A8252-12341-3FG	Solis Tractor COVER, DUST	74	87089900	18
1A8252-12341-3S	Solis Tractor COVER, DUST	74	87089900	18
1A8252-12401-1FG	Solis Tractor TIE-ROD ASSY, R	2397	87084000	18
1A8252-12401-1S	Solis Tractor TIE-ROD ASSY, R	2397	87084000	18
1A8252-13100-0S	Solis Tractor GEAR ASSY, RING	3343	87084000	18
1A8252-13200-0FG	Solis Tractor HOUSING ASSY, DIFF	4949	87084000	18
1A8252-13200-0S	Solis Tractor HOUSING ASSY, DIFF	4949	87084000	18
1A8252-13210-0FG	Solis Tractor HOUSING, DIFF.	1843	87089900	18
1A8252-13210-0S	Solis Tractor HOUSING, DIFF.	1843	87089900	18
1A8252-13230-0S	Solis Tractor PINION, DIFFERENTIAL	345	87084000	18
1A8252-13240-0S	Solis Tractor WASHER, DIFF. PINION	21	73181500	18
1A8252-13250-1S	Solis Tractor GEAR, DIFFERENTIAL	715	87084000	18
1A8252-13260-0S	Solis Tractor WASHER, DIFF. GEAR	41	73182100	18
1A8252-13270-1S	Solis Tractor SHAFT, DIFF. PINION	213	87089900	18
1A8252-13390-1S	Solis Tractor COLLAR, 58X62X4.9	68	73181500	18
1A8252-13420-1S	Solis Tractor COLLAR, 58X62 X5.2	68	73181500	18
1A8252-13520-0S	Solis Tractor PINION, 1ST SHAFT 12	1722	87084000	18
1A8252-13640-0S	Solis Tractor PLUG, 20 DIPSTICK	30	40161000	18
1A8252-13670-0S	Solis Tractor SPACER, SEAL DRIVE	266	87089900	18
1A8252-13710-2S	Solis Tractor CASE, FRONT GEAR L	6267	87081010	18
1A8252-13720-2S	Solis Tractor CASE, FRONT GEAR R	6267	87084000	18
1A8252-13760-1S	Solis Tractor GEARBOX, FRONT L	6409	87081010	18

1A8252-13770-1S	Solis Tractor GEARBOX, FRONT R	6409	87081010	18
1A8252-13820-1S	Solis Tractor GEAR, 2ND SHAFT 15	1861	87084000	18
1A8252-13870-0S	Solis Tractor SHAFT, FRONT 2ND	893	87084000	18
1A8252-13910-1S	Solis Tractor BOLT, M10X30	18	73181500	18
1A8252-14100-2S	Solis Tractor SPINDLE, FRONT	3115	87084000	18
1A8252-14140-0S	Solis Tractor WHEEL ASSY, W6X18	5985	87081010	18
1A8252-14140-0TRS	Solis Tractor WHEEL ASSY, W6X18	5824	87089900	18
1A8252-14250-1S	Solis Tractor BOLT, STUD M14X31	58	73182910	18
1A8252-14310-0S	Solis Tractor TIRE ASSY, 8-18-6	12278	40117000	18
1A8252-14610-1QVS	Solis Tractor COVER, SHAFT FRONT	420	87089900	18
1A8252-14610-1S	Solis Tractor COVER, SHAFT FRONT UNPAINTED	342	87081010	18
1A8252-14650-2S	Solis Tractor BOOT, SHAFT	52	40169990	18
1A8252-14690-1S	Solis Tractor COLLAR, O-RING	41	73060000	18
1A8252-14710-1QVS	Solis Tractor COVER ASSY, SHAFT	481	87089900	18
1A8252-14710-1S	Solis Tractor COVER ASSY, SHAFT UNPAINTED	336	87081010	18
1A8252-15200-2S	Solis Tractor COVER, STEERING	33	40161000	18
1A8252-15450-0S	Solis Tractor SHAFT, STEERING	1282	84821020	18
1A8252-15500-1S	Solis Tractor WASHER, MOUNT	24	87089900	18
1A8252-15602-1S	Solis Tractor COLUMN UNIT, STEERING	4983	87089400	18
1A8252-17101-1FG	Solis Tractor CYLINDER ASSY, PST	17648	87089900	28
1A8252-17101-1S	Solis Tractor CYLINDER ASSY, PST	17648	87089900	28
1A8252-17120-2FG	Solis Tractor CYLINDER PST	16479	87089400	18
1A8252-17120-2S	Solis Tractor CYLINDER PST	16479	87089400	18
1A8252-17300-1S	Solis Tractor ELBOW ASSY, 3/8-3/8	285	87084000	18
1A8252-17350-0S	Solis Tractor CONNECTOR, G3/8-3/8	74	87081010	18
1A8252-17450-1FG	Solis Tractor BOLT, M12X38	47	73181600	18
1A8252-17450-1S	Solis Tractor BOLT, M12X38	47	73181600	18
1A8252-17460-1FG	Solis Tractor BOLT, REAMER M12X46	79	73181500	18
1A8252-17460-1S	Solis Tractor BOLT, REAMER M12X46	79	73181500	18
1A8252-17820-2S	Solis Tractor HOSE ASSY, 3/8-930	907	40091100	18
1A8252-17880-2S	Solis Tractor HOSE ASSY, 1/4-1510	1096	40091100	18
1A8252-17900-0S	Solis Tractor GUARD, PST CYLINDER	298	87081010	18
1A8252-17970-1S	Solis Tractor CLIP, 18	19	87089900	18
1A8252-21160-0S	Solis Tractor SHEET, 2ND RELIEF	45	87089900	18
1A8252-21180-1S	Solis Tractor COVER, HOUSING UNPAINTED	36	87089900	18
1A8252-21250-2S	Solis Tractor FLANGE	774	87085000	18
1A8252-21280-0S	Solis Tractor BOLT, 12X80	50	73181500	18
1A8252-21320-0S	Solis Tractor BOLT, 12X90	45	73181500	18
1A8252-21350-0S	Solis Tractor BOLT, STUD M12X220	107	73181500	18
1A8252-21500-0S	Solis Tractor CLUTCH KIT, SINGLE	6486	87089400	18
1A8252-21510-0S	Solis Tractor DISK, CLUTCH	3252	87089400	18
1A8252-21520-0S	Solis Tractor COVER, CLUTCH	4921	84822090	18
1A8252-22040-0S	Solis Tractor BEARING, RELEASE	1027	87089400	18
1A8252-22110-1S	Solis Tractor SHAFT, INPUT	894	87084000	18
1A8252-22200-1S	Solis Tractor SLEEVE, RELEASE	654	87085000	18
1A8252-22250-0S	Solis Tractor ARM, CLUTCH	459	87081010	18
1A8252-22280-0S	Solis Tractor YOKE, RELEASE	569	87081010	18
1A8252-22381-1S	Solis Tractor PEDAL ASSY, CLUTCH UNPAINTED	1095	87089900	18
1A8252-22481-1S	Solis Tractor LEVER, PEDAL LOCK	22	87089900	18
1A8252-22500-1S	Solis Tractor ROD UNIT, CLUTCH	335	87081010	18
1A8252-22520-2S	Solis Tractor ROD ASSY, SCREW R	162	73181500	18

1A8252-22660-1S	Solis Tractor ROD ASSY, SCREW L	127	73181500	18
1A8252-24120-1S	Solis Tractor NUT, FLANGE M16	28	73181600	18
1A8252-24240-1S	Solis Tractor COVER, REAR	2095	87084000	18
1A8252-24260-1S	Solis Tractor PLUG, 9/16-18	36	73181500	18
1A8252-24310-0S	Solis Tractor BOLT, STUD M8X90	36	84090000	18
1A8252-24320-0S	Solis Tractor BOLT, STUD M16X50	77	84090000	18
1A8252-24330-0S	Solis Tractor BOLT, STUD M12X45	32	73181500	18
1A8252-24340-0S	Solis Tractor BOLT, STUD M12X50	27	73060000	18
1A8252-24600-0S	Solis Tractor PLUG, G1/2	39	73181600	18
1A8252-24660-0S	Solis Tractor ADAPTER,G1/2-1/2	102	87089900	18
1A8252-24701-1S	Solis Tractor COVER, FRONT	1928	87085000	18
1A8252-24710-0S	Solis Tractor PLATE	7	87089900	18
1A8252-24730-0S	Solis Tractor RETAINER, BEARING	1851	87081010	18
1A8252-25130-1S	Solis Tractor SHAFT, PTO DRIVE	1098	87084000	18
1A8252-25150-0S	Solis Tractor COUPLING, 13X16/32	240	87084000	18
1A8252-25240-1S	Solis Tractor GEAR, MAIN 31	612	87084000	18
1A8252-25250-1S	Solis Tractor GEAR, MAIN 34	791	87084000	18
1A8252-25260-0S	Solis Tractor GEAR ,MAIN 19	404	87084000	18
1A8252-25410-1S	Solis Tractor GEAR, MAIN 27	1160	87084000	18
1A8252-25430-1S	Solis Tractor GEAR, MAIN 36	1233	87084000	18
1A8252-25450-0S	Solis Tractor GEAR, MAIN 43	1417	87084000	18
1A8252-25540-0S	Solis Tractor WASHER, 20X38X4.5	32	73181500	18
1A8252-25560-1S	Solis Tractor COLLAR, 35X49X62	282	87089900	18
1A8252-25750-1S	Solis Tractor GEAR, 34R DRIVEN	749	87084000	18
1A8252-25760-1S	Solis Tractor GEAR, 37F DRIVEN	704	87084000	18
1A8252-25890-1S	Solis Tractor SHIFTER	364	87084000	18
1A8252-25910-1S	Solis Tractor GEAR, REVERSE 33	1428	87089900	18
1A8252-25920-1S	Solis Tractor GEAR ASSY, REVERSE36	1870	87084000	18
1A8252-25930-1S	Solis Tractor COLLAR, SPLINE	464	87084000	18
1A8252-25950-0S	Solis Tractor SHAFT, REVERSE IDLE	666	87081010	18
1A8252-25960-2S	Solis Tractor SHAFT, DRIVE REV	1932	87084000	18
1A8252-25970-1S	Solis Tractor PLATE, KEEP	10	87089900	18
1A8252-25980-1S	Solis Tractor GEAR, REVERSE IDLE	491	87084000	18
1A8252-25990-0S	Solis Tractor SHAFT, DRIVEN	709	87084000	18
1A8252-26050-1S	Solis Tractor COUPLING	273	87084000	18
1A8252-26130-1S	Solis Tractor COUPLING	325	87084000	18
1A8252-26150-1S	Solis Tractor SHAFT, PINION PTO 16	1113	87084000	18
1A8252-26160-1S	Solis Tractor PINION, PTO 15	453	87084000	18
1A8252-26310-1S	Solis Tractor SHAFT, PTO	1490	87084000	18
1A8252-26330-0S	Solis Tractor SPACER, 30X40X10	73	87081010	18
1A8252-26360-1S	Solis Tractor COLLAR, SPLINE	542	87084000	18
1A8252-26370-1S	Solis Tractor SHIFTER, PTO	615	87084000	18
1A8252-26380-0S	Solis Tractor COLLAR, 35X43X16	47	87089900	18
1A8252-26420-0S	Solis Tractor COLLAR, 23	81	73060000	18
1A8252-26451-1S	Solis Tractor BOLT, M10 STOPPER	20	73181500	18
1A8252-26520-2S	Solis Tractor GEAR, PTO 72	2306	87084000	18
1A8252-26530-2S	Solis Tractor GEAR, PTO 49	1867	87084000	18
1A8252-26560-1S	Solis Tractor LEVER, PTO	114	87081010	18
1A8252-26600-2S	Solis Tractor KNOB, PTO	41	87089900	18
1A8252-26850-1S	Solis Tractor SPRING, 2ND RELIEF	11	73202000	18
1A8252-27020-0S	Solis Tractor ARM, SHIFT REVERSER	187	87081010	18

1A8252-27070-1S	Solis Tractor FORK, SHIFT REVERSER	739	87081010	18
1A8252-27160-1S	Solis Tractor SHAFT, MAIN SHIFT	532	87081010	18
1A8252-27180-1S	Solis Tractor SHAFT, FORK REVERSER	222	87084000	18
1A8252-27200-1S	Solis Tractor KNOB ASSY, MAIN SHIFT	92	87089900	18
1A8252-27210-1S	Solis Tractor KNOB ASSY, SUB SHIFT	92	87089900	18
1A8252-27220-1S	Solis Tractor KNOB ASSY, 4WD SHIFT	92	87089900	18
1A8252-27250-2S	Solis Tractor SHAFT, FORK 1-2	419	87081010	18
1A8252-27260-1S	Solis Tractor SHAFT, FORK 3-4	336	87084000	18
1A8252-27330-0S	Solis Tractor SHIFTER, MAIN SHIFT	280	87081010	18
1A8252-27370-1S	Solis Tractor FORK, MAIN SHIFT 3-4	674	87089900	18
1A8252-27380-1S	Solis Tractor FORK, MAIN SHIFT 1-R	674	87081010	18
1A8252-27391-1S	Solis Tractor PLATE, SLIDE	111	87089900	18
1A8252-27400-0S	Solis Tractor ARM, SHIFT MAIN	185	87081010	18
1A8252-27440-1S	Solis Tractor SPRING	11	84090000	18
1A8252-27470-1S	Solis Tractor HOLDER, SHIFT ARM	243	87081010	18
1A8252-27500-1S	Solis Tractor FORK, RANGE SHIFT	535	73202000	18
1A8252-27550-0S	Solis Tractor LEVER ASSY, MAIN	356	87089400	18
1A8252-27601-1S	Solis Tractor LEVER ASSY, RANGE UNPAINTED	265	87081010	18
1A8252-27650-1S	Solis Tractor SHAFT, FORK RANGE	216	87081010	18
1A8252-27800-0S	Solis Tractor ARM, CHANGE REVERSER	137	87081010	18
1A8252-27880-2S	Solis Tractor SHAFT, FORK PTO.	158	87081010	18
1A8252-27950-1S	Solis Tractor FORK, SHIFT PTO	559	87081010	18
1A8252-28220-0S	Solis Tractor PINION, DRIVE 31	585	87084000	18
1A8252-28230-0S	Solis Tractor GEAR, FRONT DRIVE 46	1096	87084000	18
1A8252-28300-1S	Solis Tractor LEVER ASSY, 4WD UNPAINTED	377	87081010	18
1A8252-28340-1S	Solis Tractor SHAFT, CONNECTING	1405	87084000	18
1A8252-31400-0S	Solis Tractor GEAR ASSY, RING	6100	87084000	18
1A8252-31500-0S	Solis Tractor CASE ASSY, DIFF	8050	87084000	18
1A8252-31510-1S	Solis Tractor GEAR, DIFF. SIDE	1028	87084000	18
1A8252-31520-1S	Solis Tractor GEAR, DIFFERENTIAL	1111	87084000	18
1A8252-31531-1S	Solis Tractor BOLT FLANGE, M10X19.5	15	73181600	18
1A8252-31820-0S	Solis Tractor SHAFT, DIFF. PINION	307	87084000	18
1A8252-31860-1S	Solis Tractor PINION, DIFFERENTIAL	428	87084000	18
1A8252-32110-1S	Solis Tractor CASE, DIFF.	3194	87084000	18
1A8252-32650-0S	Solis Tractor PLATE	166	87089900	18
1A8252-33090-2S	Solis Tractor FORK, DIFF. LOCK	1033	87081010	18
1A8252-33130-0S	Solis Tractor SHAFT, DIFF LOCK	248	87081010	18
1A8252-33151-1S	Solis Tractor PEDAL ASSY, DIFF. UNPAINTED	461	87089900	18
1A8252-33190-1S	Solis Tractor SPRING, DIFF. LOCK	68	73202000	18
1A8252-33410-1S	Solis Tractor PINION, FINAL L	1270	87084000	18
1A8252-33420-1S	Solis Tractor PINION, FINAL R	1474	87084000	18
1A8252-33540-1S	Solis Tractor PINION, PLANETARY	1403	87084000	18
1A8252-33550-0S	Solis Tractor SHAFT, PLANETARY	237	87081010	18
1A8252-33560-1S	Solis Tractor NEEDLE, 4.5X39.8	10	84821020	18
1A8252-33570-1S	Solis Tractor CARRIER, PLANETARY	2627	87081010	18
1A8252-33580-1S	Solis Tractor WASHER, THRUST	14	73181500	18
1A8252-33610-1S	Solis Tractor GEAR, INTERNAL	5555	87084000	18
1A8252-33650-0S	Solis Tractor PIN, PARALLEL 12X42	21	73060000	18
1A8252-34110-1S	Solis Tractor SHAFT, REAR AXLE	8746	87081010	18
1A8252-34120-1S	Solis Tractor COLLAR, 60X80X6	145	87084000	18
1A8252-34630-0S	Solis Tractor TIRE ASSY, 13.6-28	38877	40117000	18

1A8252-34750-0S	Solis Tractor WHEEL ASSY, W12X28 UNPAINTED	14149	84210000	18
1A8252-34750-OTRS	Solis Tractor WHEEL ASSY, W12X28	12817	87089900	18
1A8252-35340-1S	Solis Tractor WASHER, 16.2X38X4	27	73181500	18
1A8252-35350-2S	Solis Tractor ARM ASSY, BRAKE	246	87081010	18
1A8252-35360-1S	Solis Tractor BOLT, M16X60 L	73	74150000	18
1A8252-36250-2S	Solis Tractor LEVER ASSY, CAM L	698	87089900	18
1A8252-36260-2S	Solis Tractor LEVER ASSY, CAM R	698	87089900	18
1A8252-36350-0S	Solis Tractor DISK, FRICTION 226	848	87083000	18
1A8252-37301-1S	Solis Tractor PEDAL ASSY, BRAKE L UNPAINTED	746	87089900	18
1A8252-37411-1S	Solis Tractor PEDAL ASSY, BRAKE R UNPAINTED	1329	87089900	18
1A8252-37470-1S	Solis Tractor ROD ASSY, BRAKE	351	73182100	18
1A8252-37520-1S	Solis Tractor CONNECTOR, UNPAINTED	33	87089900	18
1A8252-37550-0S	Solis Tractor SHAFT, BRAKE	595	87081010	18
1A8252-42280-2S	Solis Tractor PIPE, BREATHER	143	87084000	18
1A8252-43231-1S	Solis Tractor HEAD, CYLINDER	1625	87089900	18
1A8252-44110-0S	Solis Tractor CRANK, LIFT	2458	73181500	18
1A8252-44211-1S	Solis Tractor SHAFT, LIFT	2547	87084000	18
1A8252-44250-1S	Solis Tractor SLEEVE, LIFT SHAFT	576	73070000	18
1A8252-44410-0S	Solis Tractor ARM, LIFT	2507	87081010	18
1A8252-44510-0S	Solis Tractor PLATE ASSY, LIFT ARM	180	87089900	18
1A8252-44540-0S	Solis Tractor PLATE, LIFT ARM R	146	87089900	18
1A8252-46380-1S	Solis Tractor SPRING, CHECK	7	73202000	18
1A8252-46620-0S	Solis Tractor BOLT, STOP	163	73181500	18
1A8252-47100-0S	Solis Tractor PLATE, LOCK	10	87089900	18
1A8252-47110-0S	Solis Tractor PLATE, LOCK	12	87089900	18
1A8252-47151-1S	Solis Tractor KNOB	18	39260000	18
1A8252-47160-0S	Solis Tractor PLATE	34	87089900	18
1A8252-47170-0S	Solis Tractor BOLT, STUD	81	73181500	18
1A8252-47200-1S	Solis Tractor ROD, PC	77	87081010	18
1A8252-47230-0S	Solis Tractor ROD, DC	51	87089900	18
1A8252-47260-1S	Solis Tractor PIN, FEEDBACK HINGE	59	87089900	18
1A8252-47291-1S	Solis Tractor LEVER UNIT, POSITION UNPAINTED	368	87089900	18
1A8252-47340-1S	Solis Tractor LEVER UNIT, DRAFT UNPAINTED	315	87089900	18
1A8252-47480-0S	Solis Tractor KNOB, BLACK	11	87089900	18
1A8252-47490-1S	Solis Tractor PLATE, CONTROL	229	87085000	18
1A8252-47600-1S	Solis Tractor BRACKET ASSY, LEVER UNPAINTED	414	87089900	18
1A8252-47631-1S	Solis Tractor BRACKET ASSY, LEV D UNPAINTED	101	87089900	18
1A8252-47650-1S	Solis Tractor SHAFT ASSY	115	87081010	18
1A8252-47710-0S	Solis Tractor SUPPORT, HINGE	2406	87089900	18
1A8252-47730-0S	Solis Tractor HINGE, TOPLINK	2011	87085000	18
1A8252-47741-1S	Solis Tractor CAP, 26	23	40169990	18
1A8252-47860-0S	Solis Tractor PIN, FLAT HEAD	55	87089900	18
1A8252-47880-0S	Solis Tractor BOLT, M16X80	76	87089900	18
1A8252-47900-0S	Solis Tractor BAR, TORSION	665	87085000	18
1A8252-47950-1S	Solis Tractor NIPPLE, GREASE	11	87089900	18
1A8252-47960-2S	Solis Tractor SPRING, D-FB ROD	16	73202000	18
1A8252-48001-1S	Solis Tractor PIPE ASSY, LP FRONT	511	87089900	18
1A8252-48051-3S	Solis Tractor PIPE ASSY, LP REAR	459	87089900	18
1A8252-48120-0S	Solis Tractor COLLAR, O-RING	30	87089900	18
1A8252-48140-1S	Solis Tractor FLANGE, PIPE PST	180	87085000	18
1A8252-48150-1S	Solis Tractor FLANGE, PIPE LIFT	214	87081010	18

1A8252-48160-2S	Solis Tractor FLANGE ASSY	344	87089900	18
1A8252-48300-1S	Solis Tractor ELBOW ASSY, 1/2-3/8	374	87084000	18
1A8252-48340-1S	Solis Tractor HOSE	258	40090000	18
1A8252-48350-0S	Solis Tractor CONNECTOR, G3/8-1/4	73	87081010	18
1A8252-48380-1S	Solis Tractor ELBOW ASSY, 3/8-3/8	400	73070000	18
1A8252-48450-0S	Solis Tractor BRACKET ASSY, FILTER	161	87089900	18
1A8252-48481-4S	Solis Tractor HOSE, LP	420	40090000	18
1A8252-48540-1S	Solis Tractor PIPE ASSY, LP	770	87089900	18
1A8252-48570-1S	Solis Tractor PIPE ASSY, PTO LUB	132	87089900	18
1A8252-48670-0S	Solis Tractor BRACKET ASSY, CLAMP	25	87089900	18
1A8252-48720-0S	Solis Tractor HOLDER,RELIEF	179	87081010	18
1A8252-48800-2S	Solis Tractor PIPE ASSY, FRONT	435	87089900	18
1A8252-48850-1S	Solis Tractor PIPE ASSY, REAR	422	87089900	18
1A8252-48900-1S	Solis Tractor O-RING	3	73181500	18
1A8252-49010-1S	Solis Tractor ROD, CONTROL	76	87081010	18
1A8252-49040-1S	Solis Tractor PIN, CONTROL	34	87084000	18
1A8252-49050-1S	Solis Tractor LINK,P CONTROL	38	87089900	18
1A8252-49061-1S	Solis Tractor LINK,D CONTROL	62	87089900	18
1A8252-49070-1S	Solis Tractor COLLAR	16	87084000	18
1A8252-49100-1S	Solis Tractor LINK ASSY, P LEVER	95	87089900	18
1A8252-49140-0S	Solis Tractor SHAFT, P LEVER	157	87089900	18
1A8252-49150-0S	Solis Tractor ARM ASSY, P LEVER	122	87081010	18
1A8252-49250-0S	Solis Tractor ARM ASSY, P-FB	116	87081010	18
1A8252-49290-2S	Solis Tractor ROD, P-FB	76	87081010	18
1A8252-49300-1S	Solis Tractor LINK ASSY, D LEVER	353	87089900	18
1A8252-49350-0S	Solis Tractor ARM ASSY, D LEVER	94	87089900	18
1A8252-49401-1S	Solis Tractor LINK ASSY, D-FB	315	87084000	18
1A8252-49450-0S	Solis Tractor ARM ASSY, D-FB	88	87089900	18
1A8252-49491-1S	Solis Tractor PIN, DRAFT FEEDBACK	53	87089900	18
1A8252-49500-0S	Solis Tractor ARM UNIT, D-FB	250	87089900	18
1A8252-49550-0S	Solis Tractor BOLT, STEPPED M12	64	87089900	18
1A8252-49560-0S	Solis Tractor PLATE, D-FB	16	87089900	18
1A8252-49600-1S	Solis Tractor LINK ASSY, P-FB	266	87089900	18
1A8252-49610-0S	Solis Tractor BUSH, FLANGE	82	84840000	18
1A8252-49640-1S	Solis Tractor PLATE CANCEL	17	87081010	18
1A8252-49670-2S	Solis Tractor ROD ASSY, D-FB	152	87089900	18
1A8252-49750-0S	Solis Tractor SUPPORT UNIT, TANK	828	87089900	18
1A8252-49790-0S	Solis Tractor ROD ASSY, LIMIT	124	87089900	18
1A8252-49800-0S	Solis Tractor ROD	51	87089900	18
1A8252-49810-0S	Solis Tractor ROD, L	57	87089900	18
1A8252-49830-0S	Solis Tractor SHAFT ASSY, LIMIT	190	87089900	18
1A8252-49860-0S	Solis Tractor ARM ASSY, LIMIT	75	87089900	18
1A8252-49931-1S	Solis Tractor LINK ASSY, LIMIT	70	87089900	18
1A8252-49960-0S	Solis Tractor TURNBUCKLE, M10	60	87089900	18
1A8252-51101-1S	Solis Tractor HARNESS ASSY	13758	85443000	18
1A8252-51120-0S	Solis Tractor HARNESS,STARTER	155	85443000	18
1A8252-51310-1S	Solis Tractor HARNESS, HEAD LAMP	1456	87089400	18
1A8252-51400-0S	Solis Tractor CABLE,+BATTERY	1214	85443000	18
1A8252-51450-0S	Solis Tractor CABLE,BATTERY	420	85443000	18
1A8252-51550-0S	Solis Tractor GUIDE, BATTERY UNPAINTED	141	87089900	18
1A8252-51670-0S	Solis Tractor CLIP, M8 HOLE	35	85443000	18

1A8252-51870-1S	Solis Tractor HARNESS,FENDER FRONT	376	85443000	18
1A8252-51881-1S	Solis Tractor HARNESS, FENDER REAR	717	85443000	18
1A8252-51930-1S	Solis Tractor CONNECTOR, 6180-2181	22	85443000	18
1A8252-51940-1S	Solis Tractor CONNECTOR, 6187-2171	30	85443000	18
1A8252-51960-1S	Solis Tractor HARNESS, ILL OFF	92	85443000	18
1A8252-52140-0S	Solis Tractor SWITCH, COMBINATION	659	85367000	18
1A8252-52180-0S	Solis Tractor HARNESS, COUPLER	141	84210000	18
1A8252-52250-0S	Solis Tractor STAY ASSY, T-COUPLER	77	87089900	18
1A8252-53200-2S	Solis Tractor HEADLAMP ASSY, L LHT	5701	85122010	18
1A8252-53210-0S	Solis Tractor LAMP UNIT, LOW LHT	2270	85443000	18
1A8252-53250-0S	Solis Tractor LAMP UNIT, HIGH	2270	85443000	18
1A8252-53300-2S	Solis Tractor HEADLAMP ASSY, R LHT	6652	85122010	18
1A8252-53430-0S	Solis Tractor STAY ASSY, LAMP CL	34	87089900	18
1A8252-53440-0S	Solis Tractor STAY ASSY, LAMP CR	34	87089900	18
1A8252-54100-1S	Solis Tractor LAMP ASSY, WORK	934	85122010	18
1A8252-55660-0S	Solis Tractor VALVE, 2ND RELIEF	35	87081010	18
1A8252-56090-0S	Solis Tractor LABEL, METER	1	39191000	18
1A8252-57150-0S	Solis Tractor HORN ASSY	328	85122010	18
1A8252-58010-0S	Solis Tractor SUPPORT,HARNESS	12	87089900	18
1A8252-58210-0S	Solis Tractor STAY, HARNESS R	20	87089900	18
1A8252-58250-0S	Solis Tractor STAY ASSY, HARNESS R	14	87089900	18
1A8252-58550-1S	Solis Tractor STAY ASSY,FUSE BOX	85	87089900	18
1A8252-58600-0S	Solis Tractor STAY, BONNET HARNESS UNPAINTED	10	87089900	18
1A8252-59060-1S	Solis Tractor WASHER, LARGE 6	1	87089900	18
1A8252-60100-0S	Solis Tractor FRAME ASSY,FRONT UNPAINTED	2243	87089900	18
1A8252-60290-0S	Solis Tractor STOPPER, BATTERY UNPAINTED	84	87081010	18
1A8252-60500-0S	Solis Tractor FRAME, REAR	214	87089900	18
1A8252-60800-1S	Solis Tractor FRAME, CONNECT UNPAINTED	846	87089900	18
1A8252-60951-1S	Solis Tractor HINGE ASSY, BONNET UNPAINTED	1044	87089900	18
1A8252-61050-0S	Solis Tractor FRAME ASSY, BONNET UNPAINTED	378	87089900	18
1A8252-61130-0S	Solis Tractor BONNET ASSY, LOWER L UNPAINTED	2208	87089900	18
1A8252-61140-0S	Solis Tractor BONNET ASSY, LOWER R UNPAINTED	2209	87089900	18
1A8252-61250-0S	Solis Tractor COVER, BONNET	982	87089900	18
1A8252-61350-1S	Solis Tractor SPRING, BONNET	30	73202000	18
1A8252-61360-0S	Solis Tractor DAMPER, GAS 700	1522	87088000	28
1A8252-61412-1S	Solis Tractor FRAME ASSY,PEDAL UNPAINTED	3505	87089900	18
1A8252-61500-1S	Solis Tractor DASHBOARD YANMAR	1666	84210000	18
1A8252-61510-0S	Solis Tractor PANEL,DASHBOARD L UNPAINTED	182	39260000	18
1A8252-61520-0S	Solis Tractor PANEL,DASHBOARD R UNPAINTED	182	39260000	18
1A8252-61550-0S	Solis Tractor STAY,COVER DASHBOARD	153	87089900	18
1A8252-61700-2S	Solis Tractor PLATE ASSY, SHIELD	1854	87089900	18
1A8252-61750-1S	Solis Tractor COVER, COLUMN F	389	73060000	18
1A8252-61770-0S	Solis Tractor GUIDE, HOSE	28	87089900	18
1A8252-61810-2S	Solis Tractor GROMMET, FUSE BOX	36	40161000	18
1A8252-61830-0S	Solis Tractor ROD	10	87089900	18
1A8252-61850-0S	Solis Tractor COVER, SIDE R UNPAINTED	508	87089900	18
1A8252-61880-0S	Solis Tractor SCREW, TAPPING 5X16	5	73181500	18
1A8252-61911-1S	Solis Tractor FRAME, GRILLE	597	87089900	18
1A8252-61930-0S	Solis Tractor SCREEN, GRILLE UNPAINTED	661	87089900	18
1A8252-61940-1S	Solis Tractor GROMMET,60	3	40169310	18
1A8252-61960-0S	Solis Tractor EMBLEM, FY M	162	87089400	0

1A8252-61970-1S	Solis Tractor WIRE ASSY, BONNET	145	87089900	18
1A8252-62350-1S	Solis Tractor MAT, FLOOR	3515	40161000	18
1A8252-62400-0S	Solis Tractor GROMMET, FENDER	13	84840000	18
1A8252-62510-0S	Solis Tractor FLOOR ASSY, L UNPAINTED	792	87089900	18
1A8252-62520-0S	Solis Tractor FLOOR ASSY, R UNPAINTED	786	87089900	18
1A8252-62560-0S	Solis Tractor FLOOR ASSY, C UNPAINTED	959	87089900	18
1A8252-62800-0S	Solis Tractor STEP ASSY, SUB UNPAINTED	433	87089900	18
1A8252-62850-0S	Solis Tractor GUIDE, LEVER L UNPAINTED	205	87089900	18
1A8252-62880-1S	Solis Tractor GUIDE, LEVER R	532	87089900	18
1A8252-62950-1S	Solis Tractor BOLT, M8X16	11	73181500	18
1A8252-62960-1S	Solis Tractor PLATE, SPACER UNPAINTED	1023	73181500	18
1A8252-62990-1S	Solis Tractor PLATE, FENDER	23	87089900	18
1A8252-63101-2S	Solis Tractor SEAT ASSY	13280	94010000	18
1A8252-64101-1S	Solis Tractor MIRROR ASSY,REARVIEW	679	70091010	18
1A8252-64200-0S	Solis Tractor GROMMET,26	19	40161000	18
1A8252-64351-1S	Solis Tractor STAY ASSY, MIRROR R UNPAINTED	345	87089900	18
1A8252-64810-1S	Solis Tractor TOOLBOX	459	87089400	18
1A8252-64840-0S	Solis Tractor STAY ASSY,TOOLBOX	685	87089900	18
1A8252-65060-0S	Solis Tractor LABEL, MODEL YM342A	9	39191000	18
1A8252-65120-1S	Solis Tractor LABEL, SAFETY COVER	4	39191000	18
1A8252-65190-1S	Solis Tractor LABEL, FUSE BOX	6	39191000	18
1A8252-65400-1S	Solis Tractor LABEL, WARNING	4	39191000	18
1A8252-65422-1S	Solis Tractor LABEL, PTO	8	39199010	18
1A8252-65500-0S	Solis Tractor LABEL, SPEED	25	39191000	18
1A8252-65511-1S	Solis Tractor LABEL, P.D CONTROL	14	39191000	18
1A8252-65530-1S	Solis Tractor LABEL, PARKING	3	39191000	18
1A8252-65540-1S	Solis Tractor LABEL, ACCELERATOR	2	39191000	18
1A8252-65690-1S	Solis Tractor LABEL, KEY SWITCH	4	39199010	18
1A8252-65700-0S	Solis Tractor BRACKET ASSY, SMV UNPAINTED	134	87089900	18
1A8252-65760-1S	Solis Tractor MARK, YANMAR L	899	87089900	28
1A8252-65770-1S	Solis Tractor MARK, YANMAR R	899	87089900	28
1A8252-65850-0S	Solis Tractor LABEL, FUSE S/B	2	39191000	18
1A8252-65910-1S	Solis Tractor RIVET	2	76161000	18
1A8252-65960-1S	Solis Tractor LABEL, MODEL ORIG	14	39191000	18
1A8252-66200-0S	Solis Tractor ARM UNIT, HOOD LOCK	136	87081010	18
1A8252-66210-0S	Solis Tractor ARM ASSY, HOOD LOCK	88	73181500	18
1A8252-66280-0S	Solis Tractor PLATE, LINK	24	87089900	18
1A8252-66300-0S	Solis Tractor ROD ASSY, HOOD LOCK	86	87089900	18
1A8252-66451-1S	Solis Tractor COVER ASSY, DUST UNPAINTED	401	87089900	18
1A8252-66610-2S	Solis Tractor FRAME ASSY, FRONT L UNPAINTED	1334	87089900	18
1A8252-66620-2S	Solis Tractor FRAME ASSY, FRONT R UNPAINTED	1259	87089900	18
1A8252-66630-0S	Solis Tractor PLATE, BASE FRONT	137	87089900	18
1A8252-66640-0S	Solis Tractor PLATE, FRONT	343	87089900	18
1A8252-66650-0S	Solis Tractor PLATE, BASE REAR L	89	87089900	18
1A8252-66660-0S	Solis Tractor PLATE, BASE REAR R	108	87089900	18
1A8252-66851-1S	Solis Tractor BRACKET ASSY, FENDER	1976	87081010	18
1A8252-67101-1S	Solis Tractor STAY, SIDE COVER L UNPAINTED	239	87089900	18
1A8252-67150-0S	Solis Tractor STAY ASSY,SIDE COVER UNPAINTED	350	87089900	18
1A8252-67370-0S	Solis Tractor LEVER ASSY, REVERSE	207	87084000	18
1A8252-67410-1S	Solis Tractor BRACKET ASSY	433	87089900	18
1A8252-67430-1S	Solis Tractor ARM ASSY	249	73181500	18

1A8252-67520-1S	Solis Tractor ROD	223	87081010	18
1A8252-67600-1S	Solis Tractor KNOB, REVERSER LEVER	70	39260000	18
1A8252-69350-1S	Solis Tractor SHAFT	90	87084000	18
1A8252-71110-0QUS	Solis Tractor LINK ASSY, TOP	2931	87089900	18
1A8252-71110-0S	Solis Tractor LINK ASSY, TOP UNPAINTED	2544	87089900	18
1A8252-71240-0S	Solis Tractor PIN ASSY, TOP LINK	238	87089900	18
1A8252-72100-0QUS	Solis Tractor LINK ASSY, LIFT R	2636	87089900	18
1A8252-72100-0S	Solis Tractor LINK ASSY, LIFT R UNPAINTED	1909	87089900	18
1A8252-72180-1S	Solis Tractor SNAP PIN 10-16	9	73202000	18
1A8252-72310-0QUS	Solis Tractor LINK ASSY, LIFT L	1698	87089900	18
1A8252-72310-0S	Solis Tractor LINK ASSY, LIFT L UNPAINTED	1236	87089900	18
1A8252-72400-0S	Solis Tractor PIN, LIFT ARM	197	87089900	18
1A8252-72550-1S	Solis Tractor PIN, LIFT YOKE	149	87081010	18
1A8252-73010-0S	Solis Tractor LINK KIT, LOWER&CHAIN	8235	87089900	18
1A8252-73180-3S	Solis Tractor PIN, LOWER LINK	720	87089900	18
1A8252-73300-0S	Solis Tractor LINK ASSY, LOWER UNPAINTED	4549	87089900	18
1A8252-74200-2S	Solis Tractor STABILIZER ASSY	3408	87089900	18
1A8252-74430-0S	Solis Tractor PIN ASSY	220	87089900	18
1A8252-75651-1S	Solis Tractor BOLT, M14X28	63	73181600	18
1A8252-75710-1S	Solis Tractor PIN ASSY, 33.5X157	452	87089900	18
1A8252-75800-0S	Solis Tractor HITCH ASSY, LADDAR UNPAINTED	2389	87089900	18
1A8252-75850-1S	Solis Tractor PIN ASSY, 20X282	262	87089900	18
1A8252-75902-1S	Solis Tractor HITCH ASSY TRAILER UNPAINTED	7434	87089900	18
1A8252-85311-2QWS	Solis Tractor PLATE ASSY, BASE L	1172	87089900	18
1A8252-85311-2S	Solis Tractor PLATE ASSY, BASE L UNPAINTED	1515	87089900	18
1A8252-85321-2QWS	Solis Tractor PLATE ASSY, BASE R	1172	87089900	18
1A8252-85321-2S	Solis Tractor PLATE ASSY, BASE R UNPAINTED	1515	87089900	18
1A8252-85460-1S	Solis Tractor FRAME ASSY, UPPER UNPAINTED	7833	87089900	18
1A8252-85511-1S	Solis Tractor FRAME ASSY, LOWER LH UNPAINTED	6999	87089900	18
1A8252-85521-1S	Solis Tractor FRAME ASSY, LOWER RH UNPAINTED	7176	87089900	18
1A8252-95500-1S	Solis Tractor OIL, ENGINE 10W30 CJ4	0	27101972	18
1A8253-25230-1S	Solis Tractor GEAR, MAIN 21	442	87084000	18
1A8253-25420-1S	Solis Tractor GEAR, MAIN 40	1684	87084000	18
1A8256-01330-0S	Solis Tractor SPRING, ACCELERATOR	9	73201011	18
1A8256-01611-1S	Solis Tractor PLATE ASSY, BATTERY UNPAINTED	937	87081010	18
1A8256-15610-0S	Solis Tractor COLUMN ASSY, STEERING	3552	84213990	18
1A8256-17840-1S	Solis Tractor HOSE ASSY, 3/8-1700	1472	40091100	18
1A8256-17870-1S	Solis Tractor HOSE ASSY, 1/4-1230	971	87089900	18
1A8256-26950-0S	Solis Tractor COLLAR	12	87089900	18
1A8256-27840-0S	Solis Tractor ARM, SHIFT PTO	188	87089900	18
1A8256-48260-1S	Solis Tractor HOSE ASSY, 3/8-625	812	87089900	18
1A8256-48400-0S	Solis Tractor ELBOW ASSY, 1/2-1/2	400	73072200	18
1A8256-48580-1S	Solis Tractor CONNECTOR, G1/2	149	87089900	18
1A8256-48590-0S	Solis Tractor CONNECTOR, G1/2	226	87089900	18
1A8256-61760-0S	Solis Tractor COVER, COLUMN R YANMAR	672	87089900	18
1A8256-67200-1S	Solis Tractor BRACKET ASSY, SEAT R UNPAINTED	818	87081010	18
1A8262-25520-0S	Solis Tractor GEAR, COUNTER 19	637	87084000	18
1A8262-25530-0S	Solis Tractor GEAR, COUNTER 41	910	87084000	18
1A8262-25630-0S	Solis Tractor GEAR, REDUCTION 29	770	87084000	18
1A8262-25640-0S	Solis Tractor GEAR, REDUCTION 19	1538	87084000	18
1A8262-26150-0S	Solis Tractor SHAFT, PINION PTO 17	1128	87084000	18

1A8262-26520-0S	Solis Tractor GEAR, PTO 61	1816	87084000	18
1A8262-41100-0S	Solis Tractor PUMP ASSY 13/7	12344	84133030	28
1A8262-51101-1S	Solis Tractor HARNESS ASSY	16985	85443000	18
1A8262-65060-0S	Solis Tractor LABEL, MODEL YM348A	9	39191000	18
1A8262-65500-0S	Solis Tractor LABEL, SPEED	26	39191000	18
1A8263-00200-0S	Solis Tractor HOOK ASSY, WIRE ACCEL	25	87089900	18
1A8263-00250-0S	Solis Tractor SUPPORT, ACCEL WIRE	47	87089900	18
1A8263-00820-1S	Solis Tractor CW-T, B	353	40169990	18
1A8263-03201-1S	Solis Tractor PIPE ASSY, EXHAUST	846	87089900	18
1A8263-06120-1S	Solis Tractor HOSE, AIR INTAKE OUT	600	40091100	18
1A8263-13300-2S	Solis Tractor SHAFT, PROPELLER	2171	87084000	18
1A8263-14610-1QVS	Solis Tractor COVER, SHAFT FRONT	447	87089900	18
1A8263-17880-2S	Solis Tractor HOSE ASSY, 1/4-1600	1152	40091100	18
1A8263-21510-1S	Solis Tractor DISK, CLUTCH	3244	87089300	18
1A8263-21520-1S	Solis Tractor COVER, CLUTCH	4961	87089300	18
1A8263-22040-1S	Solis Tractor BEARING, RELEASE	569	84822090	18
1A8263-22110-1S	Solis Tractor SHAFT, INPUT	920	87084000	18
1A8263-22280-1S	Solis Tractor YOKE, RELEASE	607	87089900	18
1A8263-25530-1S	Solis Tractor GEAR, COUNTER 41	1116	87084000	18
1A8263-25640-1S	Solis Tractor GEAR, REDUCTION 16	1525	87084000	18
1A8263-26160-1S	Solis Tractor PINION, PTO 19	512	87084000	18
1A8263-26530-2S	Solis Tractor GEAR, PTO 53	1867	87084000	18
1A8266-17820-1S	Solis Tractor HOSE ASSY, 3/8-765	803	87089900	18
1A8266-17870-1S	Solis Tractor HOSE ASSY, 1/4-1290	1000	87089900	18
1A8266-25520-1S	Solis Tractor GEAR, COUNTER 23	627	87084000	18
1A8266-25630-1S	Solis Tractor GEAR, REDUCTION 29	685	87084000	18
1A8275-13760-0S	Solis Tractor BOLT, 10X28	12	73060000	18
1A8275-24160-2S	Solis Tractor PLUG ASSY	48	87081010	18
1A8275-25420-0S	Solis Tractor SHAFT, DRIVEN	1859	87084000	18
1A8275-27480-0S	Solis Tractor SHAFT, RANGE SHIFT	234	87084000	18
1A8275-28110-0S	Solis Tractor SHAFT, FRONT DRIVE	1403	87084000	18
1A8275-28120-1S	Solis Tractor COLLAR, 25	133	87089900	18
1A8275-28240-1S	Solis Tractor SLIDER, 4WD	561	87084000	18
1A8275-28290-0S	Solis Tractor SHAFT, MFWD	234	87084000	18
1A8275-28350-1S	Solis Tractor ARM, FRONT SHIFT	204	87081010	18
1A8275-33490-1S	Solis Tractor WASHER, 9	10	73060000	18
1A8275-48050-2S	Solis Tractor SPRING, CHECK	11	73202000	18
1A8275-51670-1S	Solis Tractor CLIP, M8 HOLE	19	73181500	18
1A8292-47410-1S	Solis Tractor ADJUSTER	54	87081010	18
1A8292-47490S	Solis Tractor PLATE, FRICTION	406	87083000	18
1A8292-47870-0S	Solis Tractor PIN, LOCK	85	87089900	18
1A8292-47940-0S	Solis Tractor SPRING, RETURN	32	73201011	18
1A8296-27170-1S	Solis Tractor NUT, STEPPED 12	38	73181500	18
1A8296-27241-1S	Solis Tractor COLLAR, 12X18X8.8	15	87089900	18
1A8296-35350-1S	Solis Tractor COLLAR,	91	87089900	18
1A8296-36370-0S	Solis Tractor SPRING, RETURN	14	73202000	18
1A8296-47360-0S	Solis Tractor PLATE, KEEP	6	87089900	18
1A8296-47380-1S	Solis Tractor SPRING, DISK	14	73202000	18
1A8310-01400-1S	Solis Tractor RUBBER, FOOT ACCELE	23	40169990	18
1A8310-25610-0S	Solis Tractor WASHER, 30	20	73060000	18
1A8310-62160-0S	Solis Tractor MOUNT ASSY, FENDAR	20	87089900	18

1A8310-65310-1S	Solis Tractor LABEL,SAFETY OPRATIO	20	39191000	18
1A8330-65930-0S	Solis Tractor LABEL, WARNING FIRE	3	39191000	18
1A8330-71130-0S	Solis Tractor PIN ASSY	36	87089900	18
1A8400-28520-0S	Solis Tractor KNOB,ORANGE	14	87089900	18
1A8400-51880-0S	Solis Tractor CLIP, HARNESS	90	85443000	18
1A8470-00810-1S	Solis Tractor CW-T, A	260	40169990	18
1A8470-00830-1S	Solis Tractor CAP,RADIATOR DRAIN	50	40169990	18
1A8470-00910-0S	Solis Tractor URETHANE	58	39204900	18
1A8470-00920-0S	Solis Tractor URETHANE	33	39204900	18
1A8470-01511-2S	Solis Tractor SHROUD, 500X48T	550	73060000	18
1A8470-01561-1S	Solis Tractor GROMMET, HOSE	22	40161000	18
1A8470-01651-1S	Solis Tractor PLATE,BATTERY SIDE L UNPAINTED	70	87089900	18
1A8470-06110-1S	Solis Tractor HOSE, AIR INTAKE IN	271	87089900	18
1A8470-06401-1S	Solis Tractor RUBBER, INTAKE HOSE	12	40090000	18
1A8470-11540-0S	Solis Tractor WASHER, THRUST 65X4	86	73181500	18
1A8470-11590-0S	Solis Tractor WASHER, 67X80X1.6	52	73181500	18
1A8470-13160-1S	Solis Tractor BEARING, 32007	630	84822090	18
1A8470-14141-3S	Solis Tractor CASE, FRONT BEARING	2950	87089900	18
1A8470-60300-0S	Solis Tractor FRAME,CONNECT F UNPAINTED	70	73089090	18
1A8470-61104-6S	Solis Tractor BONNET ASSY, UPPER	5861	87081010	18
1A8470-61220-0S	Solis Tractor LOCK,BONNET	24	87085000	18
1A8470-61240-0S	Solis Tractor SHAFT, FULCRUM	59	87089900	18
1A8470-61301-2S	Solis Tractor LOCK ASSY, BONNET	191	87089900	18
1A8470-61401-2S	Solis Tractor COVER, SIDE L	724	87089900	18
1A8470-61690-0S	Solis Tractor WEATHER-STRIP	327	40161000	18
1A8470-61920-1S	Solis Tractor INSULATOR, UPPER	595	87082900	28
1A8470-61940-1S	Solis Tractor INSULATOR, LOWER	560	87082900	28
1A8470-61950-0S	Solis Tractor URETHANE,HOOD UPPER	69	39204900	18
1A8470-65590-1S	Solis Tractor MARK, TOP	213	87082900	28
1A8480-00810-1S	Solis Tractor CW-T, A	265	40169990	18
1A8480-06110-2S	Solis Tractor HOSE, AIR INTAKE IN	305	87089900	18
1C6053-32020-10S	Solis Tractor WASHER, 8.5X20X3.2	13	73181500	18
1C6720-47621-2S	Solis Tractor BOLT, 6X44	27	73181500	18
1E3080-47660-3S	Solis Tractor SCREW, NUT 6 L	2	73181600	18
1E4760-43090SG	Solis Tractor LINK BALL BL8D	360	84821030	18
1E6460-63240-3S	Solis Tractor NUT,M8 L	3	73181600	18
1E8540-83220-2S	Solis Tractor FUSE 60A,SLOW BLOW	114	85443000	18
1E8970-84820-0S	Solis Tractor PULLER. FUSE	21	85443000	18
1E9265-84300-2S	Solis Tractor CLIP,BAND	12	87089900	18
200000109ASG	Solis Tractor COTTER SLEEVE Ø8*36(DIN:7346)HEAVY	28	87089900	18
200000120ASG	Solis Tractor O RING Æ~ 25.2 X Æ~2.5	12	40161000	18
200000133ASG	Solis Tractor TAPPING SCREW M5X20 SA2NS	9	73182300	18
200000141ASG	Solis Tractor CROSS SLOTTED TRUSS HEAD SCREW M6X16	6	73182300	18
200000150ASG	Solis Tractor SPLIT PIN DIA 5*40	6	87081010	18
200000306ASG	Solis Tractor O-RING ¦#50.47X ¦#2.62	19	40169320	18
200000363ASG	Solis Tractor HEX HEAD SCREW M10X1.5X65	18	73181600	18
200000373ASG	Solis Tractor SPRING TYPE STRAIGHT PIN DIN -1481 8X65	23	73201011	18
200000373BSG	Solis Tractor SPRING TYPE STRAIGHT PIN DIN -1481 8X65	20	73201011	18
200000375ASG	Solis Tractor M/C WASHER B10	5	73181500	18
200000382ASG	Solis Tractor HEX HEAD SCREW M8X1.25X30 8.8 SA4NS	11	73181110	18
200000418ASG	Solis Tractor HEX HEAD SCREW M8X1.25X55 8.8 SA4GS	13	73181110	18

200000419ASG	Solis Tractor HEX HEAD SCREW M20X2.5X80 10.9 SA4GS	97	73181110	18
200000430ASG	Solis Tractor HEX. HEAD SCREW M8X1.25X20 8.8 SA4GS	8	73181600	18
200000463ASG	Solis Tractor SPL. HEX HEAD SCREW M10X1.5X30 8.8 SA4GS	16	73181110	18
200000482ASG	Solis Tractor HEX SCREW M8X45 SA4GS	14	73181500	18
200000559ASG	Solis Tractor STUD M10*1.5*37	16	73181500	18
200000602ASG	Solis Tractor HEX. HEAD SCREW M12X1.75X20 SA4GS	16	73182300	18
20000100AASG	Solis Tractor M/CD WASHER 10.5*21*2	8	73182300	18
200001837CSG	Solis Tractor PL. HEX FLANGE BOLT M10*1.5*175	86	73181600	18
200001839ASG	Solis Tractor HEX BOLT M12X1.5X90 8.8 SA2JS	37	73181600	18
200001840ASG	Solis Tractor HEX NYLOC NUT M12X1.5 8 SA2JS	11	73181600	18
200002228ASG	Solis Tractor HEX SCREW M16X2X25 8.8 SA4GS	30	73181600	18
200002271ASG	Solis Tractor HEX BOLT M6X1X45 8.8 SA4GS	7	73181600	18
200002982ASG	Solis Tractor DGB BEARING 6010 (50X80X16)	491	84821090	18
200002989ASG	Solis Tractor TRB 32009 X (45X75X20)	654	84822090	18
200002991ASG	Solis Tractor DGB BEARING 6009 (45X75X16)	380	84821090	18
200002999ASG	Solis Tractor SEAL CASSETTE FRONT AXLE COVER (60X84X14	3408	40169330	18
200003005BSG	Solis Tractor BOLT LOCKING M14X1.5 (SPECIAL)	97	73181600	18
200003005CSG	Solis Tractor BOLT LOCKING M14X1.5 (SPECIAL)	107	73181500	18
200003094ASG	Solis Tractor HEX FLANGE SCREW M8X1.25X30 8.8 SA4GS	12	73181600	18
200003096ASG	Solis Tractor BOLT STOPPER ROUND HEAD M12*1.75-40 (GRA	30	73181600	18
200003097ASG	Solis Tractor O-RING INPUT PINION HOUSING (89X2)	34	40169320	18
200003103ASG	Solis Tractor O-RING INPUT SEAL HOUSING BOLTED (62X2.5	27	40169320	18
200003132ASG	Solis Tractor CYL ROLLER BEARING NUP 208	968	84825011	18
200003172ASG	Solis Tractor SPL. HEX FLANGE BOLT M12*1.75*193	106	73181600	18
200003527ASG	Solis Tractor Cotter pin6x46 Heavy Duty (DIN 1481)	14	73201011	18
200003539ASG	Solis Tractor OIL FILLING PLUG	58	87089900	18
200003657ASG	Solis Tractor HEX LOCK NUT M8 X 1.25 (GRADE-8) SA3NS	5	73181600	18
200003680ASG	Solis Tractor INNER BUSH ASSY.	1155	87089900	18
200003753ASG	Solis Tractor INNER BUSH ASSY (SINGLE CLUTCH)	858	87084000	18
200003754ASG	Solis Tractor INNER BUSH ASSY (SINGLE CLUTCH)	821	87084000	18
20000375ACSG	Solis Tractor OIL SEAL (F4D 50X72X8)	332	40161000	18
200003923ASG	Solis Tractor CASSETTE SEAL 60X82X16	1406	73181600	18
200004622ASG	Solis Tractor COMPOUND COTTER PIN ¥6X30	25	87089900	18
200005331ASG	Solis Tractor CYLINDRICAL PIN Ø8M6X24	9	87089900	18
20001014AASG	Solis Tractor LOCK PIN	23	87089900	18
20001089AASG	Solis Tractor HEX. HEAD SCREW M8 X 1.25-25 8-8 SA2JS	15	73182300	18
20001096ABSG	Solis Tractor Hex. head screw M8 x 1.25 x 20 8-8 SA4JS	14	73182300	18
20001174AASG	Solis Tractor CLAMP-10/10	70	87089900	18
20001175AASG	Solis Tractor CLAMP-12/12	68	82050000	18
20001508AFSG	Solis Tractor CLOGGING SENSOR	433	85443000	18
20001568ABS	Solis Tractor CONCENTRATE COOLING LIQUID	0	38200000	18
20001568ABSG	Solis Tractor CONCENTRATE COOLING LIQUID	307	38119000	18
20001668AASG	Solis Tractor FLAT WASHER N5-10 SA2JS	6	73182300	18
20001670ABSG	Solis Tractor FLAT WASHER N8-22	6	73181500	18
20001714AASG	Solis Tractor TAPPER ROLLER BEARING 40*80*19.75	673	84822090	18
20001714ABSG	Solis Tractor TAPPER ROLLER BEARING 40*80*19.75	564	84822090	18
20002015ACSG	Solis Tractor HEX. HEAD SCREW M10 X 1.5 X 25 8-8 SA4JS	14	73182300	18
20002016AASG	Solis Tractor Hex. head screw M10 x 1.5 x 30 8-8 SA2JS	14	73182300	18
20002016ABSG	Solis Tractor HEX. HEAD SCREW M10 X 1.5 X 30 8-8 SA2JS	17	73182300	18
20002017ACSG	Solis Tractor HEX. SCREW M10 X 40	16	73182300	18
20002059AASG	Solis Tractor HEX HEAD SCREW M8X1.25X16 8-8 SA2JS	12	73182300	18

20002111AASG	Solis Tractor TAPER ROLLER BEARING 35*62*18	701	84822090	18
20002197AASG	Solis Tractor LIP SEAL RING 57*72*11	133	40161000	18
20002198AASG	Solis Tractor SEALING RING FOR ROCK SHAFT	124	40161000	18
20002253AASG	Solis Tractor STRAINER-160 MICRONS	450	84213990	18
20002396ABSG	Solis Tractor SWITCH FOR BRAKES-NORMALLY CLOSED	319	85361010	18
20002461AASG	Solis Tractor BEATA PIN	27	87089900	18
20002542AASG	Solis Tractor THRUST BEARING 51208 (40*68*19)	449	84833000	18
20002543AASG	Solis Tractor OIL SEAL 64*80.2*8-4B-080064	62	40161000	18
20002549AASG	Solis Tractor CIRCLIP 25*1.2N,IS:3075 [PART-1]	8	73182300	18
20002582AASG	Solis Tractor STICKER - AIR CLEANER PAPER ELEMENT INSI	6	39191000	18
20002616ACSG	Solis Tractor O-RING (DIA 8.92 X DIA1.83)	15	40161000	18
20002735AASG	Solis Tractor TAPPER ROLLER BEARING(482/472)69.85*120	1054	84822090	18
20002805AASG	Solis Tractor OIL SEAL (35*50.2*7)	46	40161000	18
20002815AASG	Solis Tractor OIL SEAL 4D(095075)	79	40161000	18
20002826AASG	Solis Tractor OIL SEAL (40*58.2*10)	57	40161000	18
20002827AASG	Solis Tractor SLOTTED CHEESE HEAD SCREW(M4*20)	9	73182300	18
20002828AASG	Solis Tractor Punched Washer 4.5 x 9 x 0.8	6	73182300	18
20002874ADSG	Solis Tractor O-RING (FOR RAM CYLINDER,R.V.HSG.,RELEAS	14	40161000	18
20002877ACSG	Solis Tractor O-RING (FOR POSITION CRANK & RV SPOOL)	11	40161000	18
20002879ADSG	Solis Tractor O-RING (FOR SEAL CARRIER)	65	40161000	18
20002882ABSG	Solis Tractor O-RING (FOR RESPONSE VALVE)	21	40169320	18
20002883ACSG	Solis Tractor O-RING (FOR ADOPTER)	16	40161000	18
20002886ABSG	Solis Tractor O-RING (FOR TUBE ASSY)	27	40161000	18
20002891ABSG	Solis Tractor O-RING (FOR ADOPTER)	18	40169320	18
20002896AASG	Solis Tractor HEX SCREW FLANGE M8X 1.25-45 8.8 SA2JS	12	73182300	18
20002896ACSG	Solis Tractor HEX SCREW FLANGE M8X 1.25X45 8.8 SA4GS	12	73181600	18
20002910AASG	Solis Tractor BALL BEARING 6204	186	84821090	18
20002912AASG	Solis Tractor CYD. PIN DIA6 R5 X 20 IS:6689	16	87089900	18
20002915AASG	Solis Tractor WASHER(RAM CYLINDER) 10.6*2*16	17	73182300	18
20002938AASG	Solis Tractor INTERNAL CIRCClip B 47	20	73182300	18
20002939AASG	Solis Tractor OIL SEAL (4WD 056035)	72	40161000	18
20002960ACSG	Solis Tractor O-RING (FOR DIFF LOCK)	15	40161000	18
20003094ACSG	Solis Tractor HEX BOLT M10*1.5*70 8-8 SA2JS	25	73182300	18
20003126ABSG	Solis Tractor O-RING FOR CRANK POSITIONDIA 27.5* DIA 2	16	40161000	18
20003127AASG	Solis Tractor SPRING PIN (HEAVY DUTY)6X36	12	73182300	18
20003127ABSG	Solis Tractor SPRING PIN (HEAVY DUTY) 6*36	12	73201011	18
20003130AASG	Solis Tractor SPRING COTTER SLEEVE (SPRING PIN) DIA4*3	11	73201011	18
20003187ABSG	Solis Tractor WOODRUFF KEY FOR BRAKE PEDAL SHAFT	32	87083000	18
20003188AASG	Solis Tractor SLOTTED CHEESE HEAD SCREWS M5*40	8	73182300	18
20003190AASG	Solis Tractor EXTERNAL CIRCLIP A-47	23	73182300	18
20003209ABSG	Solis Tractor HEX BOLT M14*2*75 8-8 SA3NS	55	73182300	18
20003222ABSG	Solis Tractor HEX BOLT M10*1.5*80 8-8 SA3NS	31	73182300	18
20003223ABSG	Solis Tractor HEX. BOLT M10*1.5*90	37	73182300	18
20003225ABSG	Solis Tractor HEX. BOLT M12*1.75*45	26	73182300	18
20003227ABSG	Solis Tractor HEX. BOLT M12*1.75*60	28	73182300	18
20003228ABSG	Solis Tractor HEX. BOLT M12*1.75*70	32	73182300	18
20003230AASG	Solis Tractor HEX BOLT M10*1.5*40 8-8 SA3NS	20	73182300	18
20003231ABSG	Solis Tractor HEX. BOLT M10*100	32	73182300	18
20003233ACSG	Solis Tractor HEX. BOLT M14*2*60	41	73181600	18
20003235ABSG	Solis Tractor HEX SCREW M10X20	16	73182300	18
20003238AASG	Solis Tractor HEX SCREW M10X35 8-8 SA3NS	16	73182300	18

20003238ABSG	Solis Tractor HEX. SCREW M10X35	19	73182300	18
20003239ABSG	Solis Tractor HEX. SCREW M10X40	16	73182300	18
20003240AASG	Solis Tractor HEX SCREW M12X1.5X28 8-8 SA3NS	20	73182300	18
20003241ABSG	Solis Tractor HEX SCREW M12*1.75*20	18	73182300	18
20003243ABSG	Solis Tractor Hex screw M12x1.75x30 8-8 SA2NS	19	73182300	18
20003244ABSG	Solis Tractor Hex screw M12x1.75x35 8-8 SA3NS	23	73182300	18
20003245AASG	Solis Tractor HEX SCREW M12X1.75X40 8-8 SA3NS	25	73182300	18
20003245ACSG	Solis Tractor HEX. SCREW M12X1.75X40 -8.8 SA4GS	25	73182300	18
20003246ABSG	Solis Tractor HEX SCREW M14*30	27	73182300	18
20003258ABSG	Solis Tractor BEARING 32206	612	84821090	18
20003285ABSG	Solis Tractor MMX SCREW M8X1.25X30 8-8 SA2JS	15	73182300	18
20003299AASG	Solis Tractor SLOTTED COUNTERSUNK HD SCR W M4X15 4.8 SA2	4	73182300	18
20003304AASG	Solis Tractor EXTERNAL CIRCLIP A-47(HEAVY DUTY) 2.5MM	29	73182300	18
20003341AASG	Solis Tractor SINGLE TAPERED ROLLER BEARING 32208	720	84822090	18
20003353AASG	Solis Tractor HEX NUT M5-8 SA3NS	7	73182300	18
20003354ABSG	Solis Tractor HEX NUT M6 -8 SA2JS	8	73182300	18
20003355ABSG	Solis Tractor HEX NUT M8X1.25 -8 SA2JS	10	73182300	18
20003355ADSG	Solis Tractor HEX NUT M8X1.25 -8 SA4JS	8	73182300	18
20003357ABSG	Solis Tractor M10 -8 SA2JS	14	73182300	18
20003357ADSG	Solis Tractor HEX NUT M10 -8 SA4JS	14	73182300	18
20003357AFSG	Solis Tractor HEX NUT M10 -8 SA4GS	14	73181500	18
20003358AESG	Solis Tractor HEX NUT M12X1.75 -8 SA4GS	16	73181500	18
20003359AASG	Solis Tractor HEX NUT M12X1.5 -8 SA3NS	19	73182300	18
20003359ACSG	Solis Tractor HEX NUT M12X1.5 -8 SA4GS	16	73181500	18
20003361AASG	Solis Tractor EX NUT M14X2 -8 SA3NS	20	73182300	18
20003362ADSG	Solis Tractor HEX NUT M16X2 -8 SA4JS	29	73182300	18
20003365AASG	Solis Tractor HEX NUT M16X1.5 -8 SA2GS	29	73182300	18
20003372ABSG	Solis Tractor HEX LOCK NUT M16 SA2JS	19	73182300	18
20003374ABSG	Solis Tractor HEX NYLOCK NUT M 5	6	73181500	18
20003377ADSG	Solis Tractor HEX NYLOC NUT M10 8 SA4GS	10	73181600	18
20003378ACSG	Solis Tractor HEX NYLOC NUT M 12 SA4GS	17	73181600	18
20003389ABSG	Solis Tractor PLAIN WASHER A 6.4 IS:5370 STEEL	4	73182300	18
20003390ABSG	Solis Tractor PLAIN WASHER A 10.5 IS:5370 STEEL	9	73182300	18
20003460ABSG	Solis Tractor CONICAL HEAD GRESE NIPPLE B M8X1 IS:4009	20	73182300	18
20003468AASG	Solis Tractor BEARING 6206 NTN	289	84822011	18
20003477AASG	Solis Tractor BEARING 6304	226	84821020	18
20003477ABSG	Solis Tractor BEARING 6304	226	84821020	18
20003491ABSG	Solis Tractor HEX BOLT M10*1.5*55 8-8 SA2JS	22	73182300	18
20003491ADSG	Solis Tractor HEX BOLT M10*1.5*55 8-8 SA4GS	27	73181600	18
20003511AASG	Solis Tractor WORM DRIVE HOSE CLAMP A22 IS:4762	17	73261910	18
20003513ABSG	Solis Tractor MUD BLOCK (50X80X10.5)	443	87089900	18
20003515AASG	Solis Tractor HEX FLANGE SCREW M10*1.5*25-8.8 SA2JS	25	73182300	18
20003635AASG	Solis Tractor STEEL BALL DIA 25 (IS:2898 -1976, GR 24)	62	84820000	18
20003646ABSG	Solis Tractor HEX BOLT M8*1*30 8-8 SA4GS	9	73181110	18
20003653ABSG	Solis Tractor PUNCHED WASHER A (20) IS:2016 STEEL	8	73182990	18
20003659AASG	Solis Tractor HOSE WORM CLAMP 38X50 IS:4762	18	73261910	18
20003659ABSG	Solis Tractor HOSE WORM CLAMP 38X50 IS:4762	21	73261910	18
20003662AASG	Solis Tractor HOSE WORM CLAMP DIA 70 IS:4762	20	73182300	18
20003670ACSG	Solis Tractor SPRING WASHER B-8 TYPE-A IS:3063-1972	5	73201011	18
20003672ABSG	Solis Tractor SPRING WASHER B-12 TYPE-A IS:3063-1972	10	73182300	18
20003674ABSG	Solis Tractor SPRING WASHER B-16 TYPE-A IS:3063-1972	15	73182300	18

20003676ABSG	Solis Tractor PLIT PIN DIA 2*25	4	73182990	18
20003677ABSG	Solis Tractor SPLIT PIN DIA 3.2*25	5	73061929	18
20003704AASG	Solis Tractor NEEDLE CAGE V162116D	314	84829120	18
20003717AASG	Solis Tractor HEX. HEAD SCREW M8 X 1.25 - 50 8-8 SA2JS	17	73182300	18
20003737ADSG	Solis Tractor O-RING Ã~12.42XÃ~1.78	11	40161000	18
20003749ACSG	Solis Tractor SLOTTED FLAT HD TAPPING SCREW ST 6.3, L1	21	73182300	18
20003758AASG	Solis Tractor HOSE WORM CLAMP (DIA 84) I.S.4762	22	40091100	18
20003761AASG	Solis Tractor TAPPER ROLLER BEARING 3982/3920	974	84822090	18
20003766AASG	Solis Tractor EXTERNAL CIRCLIP A-26	14	73182300	18
20003769AASG	Solis Tractor Ball Bearing 6002-2Z 15*32*9	210	84821090	18
20003771AASG	Solis Tractor HEX CAP SCREW M20 X 1.5 X 45	112	73182300	18
20003780AASG	Solis Tractor HEX LOCK NUT M8 X 1 (GRADE-8) SA3NS	7	73182300	18
20003790AASG	Solis Tractor EXTERNAL CIPCLIP TYPE -E DIA 6 X 0.7 IS	8	73182300	18
20003804AASG	Solis Tractor SPRING COTTER SLEEVE 5X22	12	40161000	18
20003806AASG	Solis Tractor EXTERNAL CIRCLIP A-15	9	73182300	18
20003808AASG	Solis Tractor CSK ScrewHex SKT M8*20 Dacromet ISO10642	33	73182300	18
20003810AASG	Solis Tractor SPRING COTTER SLEEVE DIA 8 X 45	21	73182300	18
20003811AASG	Solis Tractor BEARING (SKF) 33205 (2DE)	576	84828000	18
20003813AASG	Solis Tractor EXTERNAL CIRCLIP TYPE E Ã~9X1.1 IS -307	11	73182300	18
20003818AASG	Solis Tractor CIRCLIP 34 X 1.5N (IS:3075, PART -1)	14	73182300	18
20003843AASG	Solis Tractor BALL BEARING 6008 2RS	459	84821020	18
20003851ABSG	Solis Tractor SCREW M6X1X12 -12.9	17	73182300	18
20003856AASG	Solis Tractor CIRCLIP A-30 HEAVY DUTY (FOR LAY SHAFT)	1953	73182300	18
20003859AASG	Solis Tractor BALL BEARING 6008 NR	477	84821090	18
20003862ABSG	Solis Tractor CYLINDRICAL ROLLER BEARING NU210E	1201	84825011	18
20003865AASG	Solis Tractor TRB 31310 M	1548	84829119	18
20003867AASG	Solis Tractor CYL ROLLER BEARING NJ 208	1174	84820000	18
20003870AASG	Solis Tractor TRB 32011X	925	84822090	18
20003870ABSG	Solis Tractor TRB 32011X	763	84822090	18
20003876ABSG	Solis Tractor DOWEL PIN LEVER HSG Ã~6H8X12 IS2393393	18	73182300	18
20003879AASG	Solis Tractor STEEL BALL DIA 9.5	8	84829119	18
20003880AASG	Solis Tractor BALL BEARING 6308 C3	771	84821020	18
20003883ABSG	Solis Tractor OIL SEAL 40X72X7 (BAUD2SL) BEARING HSG	262	40161000	18
20003884AASG	Solis Tractor OIL SEAL 20*30*7	192	40161000	18
20003896AASG	Solis Tractor BANJO BOLT M18x1.5 IS:3174-1974	37	73181600	18
20003908ABSG	Solis Tractor OIL SEAL 24X35X7	169	40161000	18
20003922AASG	Solis Tractor PHILLIPS CROSS RECESSED CHEESE HEAD MACH	17	73182300	18
20003923ABSG	Solis Tractor PHILLIPS CROSS RECESSED CHEESE HEAD MACH	15	73182300	18
20003925AASG	Solis Tractor HEX SCREW M16X1.5X35 10.9-SA2JS	47	73182300	18
20003926AASG	Solis Tractor EXTERNAL CIRCLIP A45 (HEAVY DUTY)	31	73182300	18
20003928AASG	Solis Tractor STUD TYPE-B M14X2X33 IS:1862-75,P-10.9	40	73182300	18
20003931AASG	Solis Tractor CROSS SLOTTED TRUSS HEAD SCREW M6	9	73182300	18
20003932AASG	Solis Tractor CROSS SLOTTED TRUSS HEAD SCREW M8(CONTRO	15	73182300	18
20003974ABSG	Solis Tractor PLAIN WASHER A 6.4 IS:5370 STEEL	5	73181600	18
20003978ACSG	Solis Tractor HOSE WORM CLAMPS	27	73269099	18
20003982AASG	Solis Tractor SPECIAL HEX SCREW M16X1.5 -SA2JS	50	73182300	18
20003987AASG	Solis Tractor HEX SCREW M16X2X38 GRADE 12.9	52	73182300	18
20003988ABSG	Solis Tractor OIL SEAL - 43347	54	40161000	18
20003991AASG	Solis Tractor HEX BOLT M10X1.6X40	21	73182300	18
20003992ACSG	Solis Tractor HEX BOLT M12X1.75X35	21	73182300	18
20003994ABSG	Solis Tractor HEX. BOLT M12X1.75X90	42	73182300	18

20003995AASG	Solis Tractor HEX HEAD SCREW M20*2.5*70 10.9 SA2JS	120	73182300	18
20003996ABSG	Solis Tractor HEX BOLT M10X1.5X95 10.9 SA3NS	42	73182300	18
20003997ACSG	Solis Tractor HEX. BOLT M10X1.5X55	23	73182300	18
20003998AASG	Solis Tractor CIRCLIP B-80 (HEAVY SERIES)	105	73182300	18
20004002AASG	Solis Tractor OIL SEAL (12M) 40X60X18.5	136	40161000	18
20004002ABSG	Solis Tractor OIL SEAL (12M) 40X60X18.5	136	40161000	18
20004004AASG	Solis Tractor HOSE WORM CLAMP DIA 68 IS-4762	25	73269099	18
20004008AASG	Solis Tractor NEEDLE BUSH	170	84824000	18
20004015AASG	Solis Tractor SOCKET FLAT HEAD SCREW DIN 7991-M8X20-10	33	73182300	18
20004020AASG	Solis Tractor SPRING PIN(HEAVY DUTY)DIN-1481 D6X40	27	73201011	18
20004023AASG	Solis Tractor BEARING JL819349/JL819310	1520	84821020	18
20004025AASG	Solis Tractor BEARING 30307 BV	1005	84821020	18
20004025ABSG	Solis Tractor BEARING 30307 BV	617	84825011	18
20004029AASG	Solis Tractor GREASE NIPPLE M6X1	13	87081010	18
20004031AASG	Solis Tractor HEXAGON SOCKET PIPE PLUG(M24X1.5), DIN90	92	73182300	18
20004034AASG	Solis Tractor SEAL(130X160X14)	3623	40161000	18
20004035AASG	Solis Tractor NEEDLE BEARING (25.6X4)	10	84824000	18
20004036ABSG	Solis Tractor SEAL(45X60X10)	267	40161000	18
20004038AASG	Solis Tractor SEAL(32X44X10)	225	40161000	18
20004039AASG	Solis Tractor SEAL(33X50X9)	240	40161000	18
20004047AASG	Solis Tractor SOCKET SET SCREW,ISO 4026-M4X8L	11	73182300	18
20004048AASG	Solis Tractor SPRING PIN ISO 8752, DIA 4X18L	13	73201011	18
20004049AASG	Solis Tractor HOSE WORM CLAMP DIA 52	21	73269099	18
20004049ABSG	Solis Tractor HOSE WORM CLAMP DIA 52	23	73261910	18
20004051AASG	Solis Tractor SOCKET HEAD CAP SCREW M6X10	49	73182300	18
20004065ABSG	Solis Tractor CLUTCH RELEASE BEARING (306445CLLU)	920	84822011	18
20004067ABSG	Solis Tractor HEX. BOLT M10*1.5*120	46	73182300	18
20004091ABSG	Solis Tractor PUNCHED WASHER A 22	9	73181600	18
20004092AASG	Solis Tractor HEX NYLOC NUT M 20	58	73182300	18
20004096AASG	Solis Tractor OIL SEAL 4B090065 (65X90.3X10)	450	40161000	18
20004098AASG	Solis Tractor TR BEARING 32013X(65X100X23)	1312	84822011	18
20004110AASG	Solis Tractor SOCK. HEAD SCREW M14X2X50	50	73182300	18
20004111ABSG	Solis Tractor CYLINDRICAL ROLLER BRG. NUP204EP	633	84825011	18
20004113AASG	Solis Tractor INTERNAL CIRCLIP B-52	17	73182300	18
20004114AASG	Solis Tractor INTERNAL CIRCLIP B-55	18	73182300	18
20004119ABSG	Solis Tractor BALL BEARING (6205)	235	84821020	18
20004120AASG	Solis Tractor TR BEARING (32205)	373	84822011	18
20004120ABSG	Solis Tractor TR BEARING (32205)	373	84822011	18
20004121ABSG	Solis Tractor TR BEARING 32006	635	84822011	18
20004122ABSG	Solis Tractor BALL BEARING 63/22	250	84821020	18
20004123ABSG	Solis Tractor BRG. 62/28	467	84821011	18
20004124AASG	Solis Tractor BALL BEARING (6011)	608	84821090	18
20004125ABSG	Solis Tractor BALL BEARING 63/28	545	84821020	18
20004126ABSG	Solis Tractor Oil Seal Type 3B(54X42.7X8)	170	40161000	18
20004127ABSG	Solis Tractor Oil Seal 4B 053037 (super seal)	63	40161000	18
20004127ACSG	Solis Tractor Oil Seal 4D 053037 (super seal)	63	40161000	18
20004128ACSG	Solis Tractor Oil Seal 4B 047035 (super seal)	51	40161000	18
20004133AASG	Solis Tractor M/CD WASHER DIA 26 *DIA 44*4	17	73182300	18
20004133ABSG	Solis Tractor 3/CD WASHER DIA 26 *DIA 44*4	15	73182990	18
20004134AASG	Solis Tractor EXTERNAL CIRCLIP A - 25	16	73182300	18
20004135AASG	Solis Tractor HEX SCREW M12X1.25X15	38	73182300	18

20004136AASG	Solis Tractor HEX HEAD BOLT M8X1.25X55	21	73182300	18
20004139AASG	Solis Tractor HEX HEAD BOLT M10X1.5X75	46	73182300	18
20004141ACSG	Solis Tractor O-RING Ã~10.6 X Ã~2.3	10	40161000	18
20004142ADSG	Solis Tractor O-RING Ã~18 X Ã~2.0	14	40169320	18
20004143AASG	Solis Tractor O-RING ¥09.6 X ¥2.3	11	40161000	18
20004143ACSG	Solis Tractor O-RING Ã~09.6 X Ã~2.3	14	40161000	18
20004144ACSG	Solis Tractor O-RING Ã~15.6 X Ã~2.3	15	40169320	18
20004145ABSG	Solis Tractor NEEDLE CAGE BEARING (31X25X17)	195	84824000	18
20004146AASG	Solis Tractor SPRING COTTER SLEEVE(DIA 5X32)	9	73182300	18
20004147ABSG	Solis Tractor NEEDLE CAGE BEARING (24X18X12)	92	84824000	18
20004150AASG	Solis Tractor Spring Cotter Sleeve(Dia 6X28)	12	73182300	18
20004151AASG	Solis Tractor EXTERNAL CIRCLIP E-15	12	73182300	18
20004154ABSG	Solis Tractor HEX SCREW M12X1.25X25	34	73182300	18
20004158AASG	Solis Tractor External Circlip A-29	15	73182300	18
20004159AASG	Solis Tractor SPRING PIN DIA 8X36 (HEAVY DUTY) BN-876	11	73201011	18
20004161ABSG	Solis Tractor SEAL 32*50*14	330	40161000	18
20004162AASG	Solis Tractor SPRING PIN DIA 8X36 (LIGHT DUTY)IS:5988	28	73201011	18
20004171AASG	Solis Tractor HOSE WORM CLAMP DIA IS:4762	20	73182300	18
20004176ACSG	Solis Tractor HEX. BOLT M12*1.75*110	55	73182300	18
20004177AASG	Solis Tractor OIL SEAL 40X60X15	288	40161000	18
20004192AASG	Solis Tractor HEX SCREW M12X1.75X40 SA3NS	16	73182300	18
20004193AASG	Solis Tractor HEX BOLT M16X2X75 10.9 SA3NS	67	73182300	18
20004204AASG	Solis Tractor HEX SCREW M8X45	17	73182300	18
20004204ABSG	Solis Tractor HEX SCREW M8X45 SA4JS	11	73181600	18
20004205AASG	Solis Tractor HEX SCREW M8X70	19	73182300	18
20004244AASG	Solis Tractor ANABOND-666	5	35069999	18
20004245ABSG	Solis Tractor LIQUID GASKET ANAEROBIC 2 LOC574/ANA613E	30	35069999	18
20004248AASG	Solis Tractor LOCTITE-542	25	35069999	18
20004249AASG	Solis Tractor SILICON SEALANT-1080	7	32141000	18
20004250AASG	Solis Tractor LOCTITE-401	32	35069999	18
20004251AASG	Solis Tractor HEX NYLOCK NUT M16*1.5	22	73182300	18
20004256AASG	Solis Tractor SEALING WASHER 8X12	6	73182990	18
20004263AASG	Solis Tractor EXTERNAL CIRCLIP A IS 3075-1965 D-42 P-I	19	73182300	18
20004265AASG	Solis Tractor SOCKET HEAD CAP SCREW M6*18, 8-8 SA2JS	16	73182300	18
20004274AASG	Solis Tractor NTERNAL CIRCLIP B-58 IS:3075	25	73182300	18
20004275AASG	Solis Tractor INTERNAL CIRCLIP B-68 IS:3075	50	73182300	18
20004276AASG	Solis Tractor EXTERNAL CIRCLIP A-28 IS:3075	17	73182300	18
20004296AASG	Solis Tractor COTTER SLEEVE Ã~6*36(DIN:7346)LIGHT	13	73182300	18
20004297ABSG	Solis Tractor BALL BEARING 6001 ZZ	182	84821090	18
20004298ABSG	Solis Tractor CASTLE NUT M16X1.5 SA4GS	53	73181600	18
20004304AASG	Solis Tractor PUNCHED WASHER A14 IS:2016	11	73182300	18
20004309AASG	Solis Tractor EXTERNAL CIRCLIP E-8	8	73182300	18
20004313AASG	Solis Tractor COTTER SLEEVE Ã~5*26(DIN:7346)LIGHT	10	73182300	18
20004324AASG	Solis Tractor EXTERNAL CIRCLIP A-25 (HEAVY DUTY) IS:307	20	73182300	18
20004325AASG	Solis Tractor HEX FLANGE SCREW M12*1.75*25-8.8 SA2JS	19	73181600	18
20004328AASG	Solis Tractor EXTERNAL CIRCLIP H 35X2.5 IS:3075	23	73182300	18
20004333AASG	Solis Tractor TAPPER ROLLER BEARING 30304	362	84822011	18
20004335AASG	Solis Tractor BALL DIA 8.731 GRADE 40 (IS:2898)	8	84821090	18
20004338AASG	Solis Tractor HOSE WORM CLAMP 32X45 IS:4762	16	73269099	18
20004339AASG	Solis Tractor NEEDLE CAGE 40X45X27	454	84829119	18
20004351AASG	Solis Tractor EXTERNAL CIRCLIP 40X2.5 H IS:3075	25	73182300	18

20004355ABSG	Solis Tractor SNAP RING FOR SHAFT DIA 32 (DIN 7993	23	87081010	18
20004356AASG	Solis Tractor HEX SCREW M8X1.25X12 8.8 SA3NS	21	73182300	18
20004359AASG	Solis Tractor OIL SEAL 114X135X13	773	40161000	18
20004362AASG	Solis Tractor HEX SCREW M10X20 8.8 (SA2JS)	15	73182300	18
20004368ACSG	Solis Tractor BALL BEARING LS10	399	84821090	18
20004376AASG	Solis Tractor HEX BOLT M12X1.75X 50 (10.9 GRADE)	28	73182300	18
20004377AASG	Solis Tractor SOCKET HEAD CAP SCREW M5X35 8-8 SA2JS	12	73182300	18
20004381AASG	Solis Tractor SOCKET HEAD SCREW M8X1.25X20 -8.8 (SA2JS	8	73182300	18
20004382AASG	Solis Tractor SPLIT PIN DIA 2X16	4	73181500	18
20004407AASG	Solis Tractor SPL. HEX HEAD SCREW M10X1.5X30 8.8 SA2JS	14	73182300	18
20004420AAS	Solis Tractor ROTRA MULTI THT	0	27101974	18
20004420AASG	Solis Tractor ROTRA MULTI THT	0	27101974	18
20004440AASG	Solis Tractor HEX SCREW M6X10 8.8 SA2JS	7	73182300	18
20004449ABSG	Solis Tractor BALL BEARING 6307	432	84821090	18
20004466AASG	Solis Tractor LOCTITE 587	13	35069999	18
20004485AASG	Solis Tractor HEX FLANGE SCREW M10X1.5X45 8.8 SA2JS	25	73182300	18
20004488AASG	Solis Tractor OIL SEAL TSL11	728	40161000	18
20004496AASG	Solis Tractor HEX FLANGE NUT M10 -8.8 SA2JS	15	73182300	18
20004498AASG	Solis Tractor SOCKET HEAD CAP SCREW M10X55	19	73182300	18
20004503AASG	Solis Tractor HEX LOCK NUT M16X1.5 SA2JS	11	73182300	18
20004508ABSG	Solis Tractor HEX SCREW M16X2X60 - 8.8-SA4GS	55	73181600	18
20004516AASG	Solis Tractor BALL BEARING 6208 2RS1	757	84821020	18
20004524AASG	Solis Tractor EXTERNAL CIRCLIP A- 18	19	73182300	18
20004529ABSG	Solis Tractor CLUTCH RELEASE BEARING CR1002	1257	84829900	18
20004532AASG	Solis Tractor HEX NUT M14X2 -8 SA2JS	14	73182300	18
20004556AASG	Solis Tractor TR REAR 14.9-28 12PR BKT FARM2000 TT	40354	40117000	18
20004557AASG	Solis Tractor TR REAR 14.9-28 TR-218A TUBE	3918	40117000	18
20004564AASG	Solis Tractor HEX HEAD SCREW M6X30	10	73182300	18
20004566ABSG	Solis Tractor CLUTCH RELEASE BEARING TG 1956/1 GT4WD	805	84822011	18
20004578AASG	Solis Tractor HEX HEAD SCREW M10X1.5X45 8.8 SA2JS	16	73182300	18
20004582AASG	Solis Tractor HEX HEAD SCREW M10X1.25X30 8.8 SA2JS	13	73182300	18
20004583AASG	Solis Tractor EXTERNAL CIRCLIP 28 (IS:3075 P-I HEAVY	27	73182300	18
20004587ACSG	Solis Tractor HEX.SCREW M14X2X40	35	73182300	18
20004592ABSG	Solis Tractor SOCKET HEAD CAP BOLT M10X130 12.9 SA3NS	51	73181600	18
20004608AASG	Solis Tractor HOSE WORM CLAMP 14X20 IS:4762	44	40091100	18
20004609AASG	Solis Tractor EXT. CIRCLIP A34 (H)	23	73182300	18
20004653AASG	Solis Tractor CASTLE NUT	57	73182300	18
20004654AASG	Solis Tractor Hex Flange Screw M12X1.75X35 Grade 12.9	19	73181600	18
20004658AASG	Solis Tractor USS PHILIPS M/C SCREW(M8X20)	14	73182300	18
20004659AASG	Solis Tractor TRUSS PHILIPS M/C SCREW(M5X20)	11	73182300	18
20004819AASG	Solis Tractor HOSE WORM CLAMP 5/8"	35	40091100	18
20004820AASG	Solis Tractor LOCTITE 270	23	35069999	18
20004823AASG	Solis Tractor HOSE WORM CLAMP DIA 30 IS:4762	19	40091100	18
20004823ABSG	Solis Tractor HOSE WORM CLAMP DIA 30 IS:4762	18	73182300	18
20004834AASG	Solis Tractor CROSS SLOTTED HEAD SCREW	26	73181500	18
20004859ABSG	Solis Tractor SOCKET SET SCREW M4*16	14	73182300	18
20004866AASG	Solis Tractor CROSS SLOTTED TRUSS HEAD SCREW M6X12	6	73181500	18
20004868AASG	Solis Tractor INTERNAL CIRCLIP B-110	62	73182910	18
20004870AASG	Solis Tractor TRB 32014X NBC	1438	84822090	18
20004872AASG	Solis Tractor OIL SEAL (70X85X8)	73	40161000	18
20004879AASG	Solis Tractor Needle bush 28*35*16	275	87089900	18

20004881AASG	Solis Tractor CRB (NUP212ECML) (110X60X22)	1790	84829900	18
20004883ABSG	Solis Tractor NEEDLE CAGE NW 223020	246	84829120	18
20004904ABSG	Solis Tractor SOCKET HEAD SCREW M8X1.25X25 SA4NS	15	73181500	18
20004911AASG	Solis Tractor Bolt spring retention screw M12*1.75*36	28	73201011	18
20004913AASG	Solis Tractor EXTERNAL CIRCLIP A-60 (HEAVY DUTY)	43	73182910	18
20004915ABSG	Solis Tractor HEX NYLOC NUT M6 8	10	73182300	18
20004917ABSG	Solis Tractor HEX NYLOC NUT M8*1.25 8	10	73182300	18
20004935ABSG	Solis Tractor PLAIN WASHER DIA 8.4 *DIA 17*1.6	7	73182300	18
20004936ACSG	Solis Tractor SPRING WASHER B-20 JIS B 1251 NO.2 20S	9	73061929	18
20004940ABSG	Solis Tractor M/C WASHER DIA 13 *DIA 24*2.5	9	73182300	18
20004941AASG	Solis Tractor M/C WASHER DIA 6.4 *DIA 12.4*1.6	4	73181500	18
20004943ACSG	Solis Tractor SPRING WASHER B-18 TYPE-A IS:3063-1972	8	73182300	18
20004948AASG	Solis Tractor Bolt spring retension PTO M14	30	73201011	18
20004949AASG	Solis Tractor Spring (Gear shifter rod)	12	73201011	18
20004950AASG	Solis Tractor SPRINGCOTER SLEVE~6*46ISO:13337LIGHT	15	73201011	18
20004951ABSG	Solis Tractor BALL BEARING 6304/22	258	84821020	18
20004952AASG	Solis Tractor Bearing NJ 210	1154	84821020	18
20004959AASG	Solis Tractor Ext. Circlip A-32 Heavy Duty	17	73182910	18
20004976AASG	Solis Tractor ANGULAR CONTACT CLUTCH RELEASE ASSY.	5908	84821020	18
20004977AASG	Solis Tractor HEX HEAD SCREW M8X1.25X25 8-8 SA4NS	8	73181110	18
20004978AASG	Solis Tractor HEX FLANGE SCREW M8X25-8.8 SA4NS	9	73182300	18
20004980AASG	Solis Tractor HEX NYLOC NUT M8 8 SA4NS	7	73181600	18
20004981AASG	Solis Tractor HEX NYLOC NUT M12 8 SA4NS	11	73182300	18
20004982AASG	Solis Tractor PUNCHED WASHER A 9 IS:2016 STEEL	4	73182990	18
20004983AASG	Solis Tractor PUNCHED WASHER A 14 IS:2016 STEEL	5	73181600	18
20004984AASG	Solis Tractor PUNCHED WASHER A 6.6 IS:2016 STEEL	5	73182300	18
20004985AASG	Solis Tractor HEX NYLOC NUT M6 8 SA4NS	6	73181500	18
20004987AASG	Solis Tractor HEX NYLOCK NUT M18*1.5 10 SA2JS	45	73182300	18
20004988AASG	Solis Tractor HEX FLANGE SCREW M6X55-8.8 SA2JS	8	73182300	18
20004991AASG	Solis Tractor WHEEL TYRE FRONT	15325	40117000	18
20004993ABSG	Solis Tractor SPRING WASHER B-12TYPE-A IS:3063-1972	8	73182300	18
20004994ABSG	Solis Tractor SPRING WASHER B-16 TYPE-A IS:3063-1972	11	73182300	18
20005002ABSG	Solis Tractor SOCKET HEAD CAP SCREW M6*25	7	73182300	18
20005003ABSG	Solis Tractor BENJO BOLT M14*1.5*26 SA4GS	29	73182300	18
20005005ABSG	Solis Tractor PUNCHED WASHER A 18 IS:2016 STEEL	10	73182300	18
20005026ABSG	Solis Tractor TAPER ROLLER BEARING (TX-32005X)	461	84822011	18
20005027ABSG	Solis Tractor RUBBER SEAL	56	40161000	18
20005030AASG	Solis Tractor SPRING COTTER SLEEVE 6X36 HEAVY DUTY DIN	17	73182300	18
20005032AASG	Solis Tractor SPRING COTTER SLEEVE 6X30 HEAVY DUTY DIN	16	73182300	18
20005032ABSG	Solis Tractor SPRING COTTER SLEEVE 6X30 HEAVY DUTY DIN	16	73201011	18
20005033AASG	Solis Tractor M/C WASHER 21X 3X37	14	73182300	18
20005036ABSG	Solis Tractor M/C WASHER DIA 15 *DIA 27*2.5	7	73181600	18
20005044ABSG	Solis Tractor NUT FOR WHEEL - FLAT	80	73182300	18
20005047AASG	Solis Tractor HEX NUT M18*1.5	28	73182300	18
20005052AASG	Solis Tractor NEEDLE BEARING JL - 108	78	84824000	18
20005053AASG	Solis Tractor BALL BEARING 6211	667	84822011	18
20005054AASG	Solis Tractor BALL BEARING 6207	370	84821020	18
20005055AASG	Solis Tractor BALL BEARING 6209	433	84821020	18
20005057ABSG	Solis Tractor SPL BENJO BOLT M14*1.5*M10*1*26	25	73181500	18
20005058ABSG	Solis Tractor BENJO BOLT M12*1.5	18	73181600	18
20005060AASG	Solis Tractor BALL BEARING 6208	376	84821020	18

20005064AASG	Solis Tractor Needle Bush (28x36x16)	311	84824000	18
20005065AASG	Solis Tractor SOCKET HEAD CAP SCREW M8X1.25X35	15	73182300	18
20005065ABSG	Solis Tractor SOCKET HEAD CAP SCREW M8X1.25X35 SA4GS	11	73181600	18
20005095AASG	Solis Tractor TAPPER ROLLER BEARING 32309	1077	84822011	18
20005102AASG	Solis Tractor TAPPER ROLLER BRG 32211	771	84822090	18
20005103AASG	Solis Tractor TAPPER ROLLER BEARING 3982 / 3920	1174	84822011	18
20005113AASG	Solis Tractor TRUSS PHILIPS M/S SCREW (M6X15)	6	73181110	18
20005117AASG	Solis Tractor HEX SCREW M6X35 8-8 SA3NS	9	73182300	18
20005123AASG	Solis Tractor HEX FLANGE SCREW M10X1.5X35-8.8 SA4NS	15	73181600	18
20005135AASG	Solis Tractor PHILLIPS CROSS RECESSED CHEESE HEAD SCRE	5	73181600	18
20005163ABSG	Solis Tractor SOCKET HEAD CAP SCREW M8X40 10.9 SA2JS	17	73181500	18
20005178AASG	Solis Tractor HEX. SCREW M14X1.5X30 10.9 SA4JS	29	73181600	18
20005196AASG	Solis Tractor INTERNAL CIRCLIP B-30 NORMAL TYPE	10	73181500	18
20005201AASG	Solis Tractor HEX. SCREW M8*1.25*35 8.8 SA2NS	9	73182300	18
20005203AASG	Solis Tractor NEEDLE ROLLER BEARING B50X55X30	299	84824000	18
20005204ABSG	Solis Tractor EXTERNAL CIRCLIP E-5 IS:3075 (PART-3)	7	73182300	18
20005212AASG	Solis Tractor Needle Roller Bearing NW26x40x26	469	84824000	18
20005215AASG	Solis Tractor Needle Roller Bearing B55X60X24.3	322	84824000	18
20005217AASG	Solis Tractor CIRCLIP A-22X1.75XH IS:3075	19	73182300	18
20005254AASG	Solis Tractor NRB 45X52X36	597	84824000	18
20005284AASG	Solis Tractor ANABOND 666T	5	35069999	18
20005287AASG	Solis Tractor LOCTITE GASKET DRESSING COMPOUND 98D	12	35069999	18
20005325AASG	Solis Tractor INTERNAL CIRCLIP B 120 (NOMAL DUTY)	97	73181500	18
20005326AASG	Solis Tractor DGBB 6213	904	84821011	18
20005329AASG	Solis Tractor TRUSS PHILIPS M/S SCREW (M5X20) SA4GS	8	73181110	18
20005330ABSG	Solis Tractor CASTLE NUT M20X1.5 IS:2232	50	73181500	18
20005338AASG	Solis Tractor HEX SCREW M12X1.75X35-10.9 SA3NS	20	73182300	18
20005342AASG	Solis Tractor SPECIAL BOLT M18X1.5 - 10.9	110	73182300	18
20005351AASG	Solis Tractor HEX NYLOC NUT M18X1.5 - 10 SA4GS	46	73182300	18
20005366AASG	Solis Tractor HEX HEAD SCREW M20X2.5X80 10.9 SA2JS	103	73182300	18
20005367ABSG	Solis Tractor O-RING Ã~7.65XÃ~1.78	11	40161000	18
20005372AASG	Solis Tractor STUD M8X1.25-25 10.9 SA2JS	15	73181600	18
20005372ABSG	Solis Tractor STUD M8X1.25-30 10.9 SA2JS	15	73181600	18
20005390AASG	Solis Tractor O-RING DIA 16.3X2	12	40169320	18
20005396AASG	Solis Tractor HEX NUT M12X1.5 -8 SA4NS	9	73181600	18
20005397ABSG	Solis Tractor O-RING Ã~7.5XÃ~2	10	40161000	18
20005412ABSG	Solis Tractor O-RING ¥9.5X¥2	10	40161000	18
20005415AASG	Solis Tractor STEEL BALL DIA 22.225	32	84821030	18
20005417ABSG	Solis Tractor O-RING Ã~12XÃ~2	15	40161000	18
20005449AASG	Solis Tractor SPLIT PIN DIA 4*40	7	73182300	18
20005452AASG	Solis Tractor HEX BOLT M18X2.5X80 10.9 SA4GS	80	73182300	18
20005454AASG	Solis Tractor HEX BOLT M16X2X80 8.8 SA4GS	75	73181500	18
20005456AASG	Solis Tractor PUNCHED WASHER A(16) IS:2016 STEEL	8	87083000	18
20005463AASG	Solis Tractor HEX LOCK NUT M16 SA4GS	12	73182300	18
20005465AASG	Solis Tractor HEX HEAD SCREW M20*2.5*70 10.9 SA4GS	95	73181500	18
20005467AASG	Solis Tractor HEX SCREW M16X2X50 8.8 SA4GS	42	73181500	18
20005470AASG	Solis Tractor HEX SCREW M8X70 8.8 SA4GS	13	73182300	18
20005491AASG	Solis Tractor HEX NUT M6 -8 SA4GS	7	73182300	18
20005493AASG	Solis Tractor HEX NUT M16X2 -8 SA4GS	19	73181500	18
20005496AASG	Solis Tractor HEX HEAD SCREW M6X1X14 8.8 SA4GS	3	73182300	18
20005504AASG	Solis Tractor HEX NUT M8X1.25 -8 SA4GS	8	73182300	18

20005512AASG	Solis Tractor PUNCHED WASHER A14 IS:2016	10	73182300	18
20005513AASG	Solis Tractor HEX NUT M16X1.5 -8 SA4GS	20	73182300	18
20005516AASG	Solis Tractor SPRING WASHER B-6 TYPE A IS:3067-1972	7	73182300	18
20005517AASG	Solis Tractor SPRING WASHER B-8 TYPE A IS:3067-1972	7	73182300	18
20005518AASG	Solis Tractor SPRING WASHER B-10 TYPE A IS:3067-1972	7	73182300	18
20005520AASG	Solis Tractor SPRING WASHER B-14 TYPE A IS:3067-1972	7	73182300	18
20005522AASG	Solis Tractor SPRING WASHER B-18 TYPE A IS:3067-1972	8	73181600	18
20005526AASG	Solis Tractor SPLIT PIN DIA 2*25	7	73182300	18
20005527AASG	Solis Tractor SPLIT PIN DIA 1.6*20	6	73182300	18
20005528AASG	Solis Tractor SPLIT PIN DIA 3.2*25	4	73182300	18
20005534AASG	Solis Tractor SLOTTED CHEASE HEAD SCREW M5*15	8	73182300	18
20005536AASG	Solis Tractor SLOTTED CHEASE HEAD SCREW M5*40	8	73182300	18
20005537AASG	Solis Tractor SLOTTED CHEASE HEAD SCREW M5*12	8	73182300	18
20005538AASG	Solis Tractor SLOTTED CHEASE HEAD SCREW M5*25	6	73182300	18
20005539AASG	Solis Tractor HEX FLANGE SCREW M8*1.25*20 -8.8 SA4GS	12	73182300	18
20005540AASG	Solis Tractor HEX FLANGE SCREW M10*1.5*25 -8.8 SA4GS	14	73182300	18
20005541AASG	Solis Tractor HEX FLANGE SCREW M6*1*20 -8.8 SA4GS	10	73182300	18
20005542AASG	Solis Tractor HEX FLANGE SCREW M6*1*16 -8.8 SA4GS	10	73182300	18
20005543AASG	Solis Tractor HEX FLANGE SCREW M8*1.25*25 -8.8 SA4GS	8	73182300	18
20005544AASG	Solis Tractor HEX BOLT M10X1.5X40 SA4GS	15	73182300	18
20005547AASG	Solis Tractor HEX BOLT ,M16*2*175 10.9 SA4GS	108	73182300	18
20005548AASG	Solis Tractor HEX BOLT M8X1.25-45 -8.8 SA4GS	14	73182300	18
20005553AASG	Solis Tractor HEX HEAD SCREW M10X1.5X25 SA4GS	15	73182300	18
20005557AASG	Solis Tractor HEX SCREW M12X1.25X25 SA4GS	25	73182300	18
20005559AASG	Solis Tractor HEX HEAD SCREW M8X1.25X16 -8.8 SA4GS	8	73182300	18
20005562AASG	Solis Tractor HEX HEAD SCREW M10X1.5X30 -8.8 SA4GS	16	73182300	18
20005563AASG	Solis Tractor HEX SCREW M8X1.25X30 -8.8 SA4GS	12	73182300	18
20005564AASG	Solis Tractor HEX HEAD SCREW M8X1.25-25 -8.8 SA4GS	11	73182300	18
20005567AASG	Solis Tractor HEX SCREW M8X1.25X35 8.8 SA4GS	12	73182300	18
20005568AASG	Solis Tractor HEX SCREW M6X30 SA4GS	9	73182300	18
20005569AASG	Solis Tractor HEX SCREW M6X1X20	7	73182300	18
20005570AASG	Solis Tractor HEX SCREW M6X25	6	73182300	18
20005573AASG	Solis Tractor HEX SCREW M6X10	7	73182300	18
20005579AASG	Solis Tractor HEX LOCK NUT M12 SA4GS	10	73182300	18
20005585AASG	Solis Tractor HEX HEAD SCREW M10X20 8.8 SA4GS	14	73181600	18
20005589AASG	Solis Tractor HEX HEAD SCREW M5X16_8.8 SA4GS	6	73181110	18
20005598AASG	Solis Tractor HEX HEAD BOLT M8X65_8.8 SA4GS	14	73182300	18
20005611AASG	Solis Tractor PUNCHED WASHER M10	6	73181110	18
20005624AASG	Solis Tractor M/CD WASHER B8	6	73182300	18
20005625AASG	Solis Tractor M/CD WASHER 10.5*21*2	8	73182300	18
20005628AASG	Solis Tractor BENJO BOLT M18X1.5 IS:3174-1974	45	73182300	18
20005630AASG	Solis Tractor WHEEL BOLT FRONT	45	73182300	18
20005635AASG	Solis Tractor SOCKET HEAD CAP SCREW M4X8 8.8-SA4GS	8	73182300	18
20005636AASG	Solis Tractor HEX. FLANGED SCREW M8X1.25X15	10	73182300	18
20005651AASG	Solis Tractor OIL SEAL 40x62x8	259	40161000	18
20005653AASG	Solis Tractor BALL BEARING 6007	267	84821030	18
20005658AASG	Solis Tractor HEX, HEAD SCREW M8 X 1.25 - 50 SA2JS	12	73182300	18
20005671AASG	Solis Tractor EXTERNAL CIRCLIP A-14	10	73182300	18
20005679AASG	Solis Tractor PUNCHED WASHER A(20) IS:2016 STEEL	9	73182990	18
20005682AASG	Solis Tractor HEX SCREW M12X1.75X25 -10.9 SA4GS	18	73182300	18
20005753AASG	Solis Tractor SPECIAL HEX HEAD SCREW M8X1X30/M8X1.25X1	51	73182300	18

20005754AASG	Solis Tractor HEX SCREW M12x1.75x45 -10.9 SA3NS	28	73182300	18
20005759AASG	Solis Tractor SOCKET HEAD CAP SCREW M10X1.5X25 8.8 SA2	17	73182300	18
20005759ABSG	Solis Tractor SOCKET HEAD CAP SCREWM10X1.5X25 10.9SA4G	14	73182300	18
20005765AASG	Solis Tractor WASHER A 6.4 IS:5370 STEEL (FOR EPA)	6	73182300	18
200401038ASG	Solis Tractor MAIN BRG. KIT Ø76 4CYL_10PCS (STD) CU	1216	84834000	18
200403078ASG	Solis Tractor B-End Liner Set Ø64 (4Cyl_8pcs) Std._Cu	898	84831099	18
200415030ASG	Solis Tractor ENGINE GASKET KIT 4105FLT_Overhaul	775	84099941	28
200415031BSG	Solis Tractor ENG. OVERHAUL KIT_4105FLT (P TYPE)	25170	84099941	28
203001010BSG	Solis Tractor ENGINE GASKETS KIT. 3 CYL. (OVERHAUL)	418	84841090	18
203001034ASG	Solis Tractor Main Brg. Kit Ø76 3cyl_8pcs (STD) cu	1206	84834000	18
203003035ASG	Solis Tractor PISTON SET ASSY. (Ø102F) `P' FM/Menon	2843	84099111	28
203003074ASG	Solis Tractor Big-End Liner Set Ø64(3Cyl.)6pcs Std._Cu	673	84834000	18
203015033ASG	Solis Tractor OVERHAUL KIT_3100 `P' LW (MOLYCOATED)	16830	84099941	28
203015034ASG	Solis Tractor Eng. Overhaul KIT_3102 (P-type)	16500	84099941	28
203015035ASG	Solis Tractor Eng. Overhaul KIT_3105 (P type)	21753	84099941	28
203401042ASG	Solis Tractor Thrust Bearing Kit (Std) Cu_110/118st	355	87081010	18
203403045CSG	Solis Tractor PISTON RING SET-102F_FM/Menon	893	84099111	28
203403060ASG	Solis Tractor PISTON RING SET Assy. (Ø100-L/W) FM	808	84099111	28
203403065ASG	Solis Tractor PISTON SET ASSY`P'(Ø100) L/W_Molycoated	2553	84099111	28
203405001ASG	Solis Tractor ENGINE VALVE KIT (DIA 100)	521	84099111	28
203405002ASG	Solis Tractor ENGINE VALVE KIT (DIA 105)	497	84099111	28
21000015AASG	Solis Tractor PIN 6X40 (024409)	24	73182300	18
21000116AASG	Solis Tractor SCREW M6X10	26	73182300	18
21000215AASG	Solis Tractor DIAPHRAGM SPRING	1785	87089300	18
22117-080001S	Solis Tractor WASHER, 8	4	73181500	18
22117-100001S	Solis Tractor WASHER, 10	5	73060000	18
22117-140001S	Solis Tractor WASHER, 14	8	73181500	18
22137-060001S	Solis Tractor WASHER, 6	6	73181500	18
22137-080001S	Solis Tractor WASHER, 8	8	73181500	18
22137-100001S	Solis Tractor WASHER, 10	11	73181500	18
22137-120001S	Solis Tractor WASHER, 12	21	73182990	18
22137-160001S	Solis Tractor WASHER, 16	17	73181600	18
22137-200001S	Solis Tractor WASHER, 20	19	73181500	18
22157-080000S	Solis Tractor WASHER, 8	13	73182990	18
22157-100000S	Solis Tractor WASHER, 10	6	73181500	18
22190-080002S	Solis Tractor WASHER, SEAL 8	110	40161000	18
22217-080000S	Solis Tractor WASHER, 8	2	73181500	18
22217-100000S	Solis Tractor WASHER, 10	3	73181500	18
22217-120000S	Solis Tractor WASHER, 12	4	73181500	18
22217-140000S	Solis Tractor WASHER, 14	58	73181500	18
22217-160000S	Solis Tractor WASHER, 16	7	73181500	18
22217-180000S	Solis Tractor WASHER, 18	58	73181500	18
22242-000200S	Solis Tractor RING, 20	6	73182910	18
22242-000220S	Solis Tractor RING, 22	5	73181500	18
22242-000290S	Solis Tractor RING, 29	10	73181500	18
22242-000300S	Solis Tractor RING, 30	12	73182910	18
22242-000320S	Solis Tractor RING, 32	12	73182910	18
22242-000340S	Solis Tractor RING, 34	11	73181500	18
22242-000500S	Solis Tractor RING, 50	17	73181500	18
22252-000190S	Solis Tractor RING, 19	3	73181500	18
22252-000220S	Solis Tractor RING, 22	5	73181500	18

22252-000260S	Solis Tractor RING, 26	45	73182990	18
22252-000300S	Solis Tractor RING, 30	83	40169390	18
22252-000370S	Solis Tractor RING, 37	9	73182910	18
22252-000450S	Solis Tractor RING, 45	8	73181500	18
22252-000550S	Solis Tractor RING, 55	13	73181500	18
22252-000620S	Solis Tractor RING, 62	20	73182910	18
22252-000850S	Solis Tractor RING, 85	38	73181500	18
22252-000900S	Solis Tractor RING, 90	42	73181500	18
22252-000950S	Solis Tractor RING, 95	51	73181500	18
22262-000320S	Solis Tractor RING, 32	8	73181500	18
22272-000070S	Solis Tractor RING, 7	2	73181500	18
22272-000080S	Solis Tractor RING, 8	2	73181500	18
22272-000120S	Solis Tractor RING, 12	5	73181500	18
22272-000150S	Solis Tractor RING, 15	7	73181500	18
22292-000340S	Solis Tractor RING, 34	22	73181500	18
22312-080180S	Solis Tractor PIN, 8 X 18	10	73181500	18
22312-100180S	Solis Tractor PIN, 10 X 18	11	73181500	18
22351-035036S	Solis Tractor PIN, 3.5AX 36	6	87081010	18
22351-040012S	Solis Tractor PIN, 4.0AX 12	5	73181500	18
22351-050025S	Solis Tractor PIN, 5.0AX 25	7	73181500	18
22351-050040S	Solis Tractor PIN, 5.0AX 40	7	73060000	18
22351-050050S	Solis Tractor PIN, 5.0AX 50	7	87089900	18
22351-060016S	Solis Tractor PIN, 6.0AX 16	7	87089900	18
22351-060025S	Solis Tractor PIN, 6.0AX 25	8	87089900	18
22351-060032S	Solis Tractor PIN, 6.0AX 32	10	87089900	18
22351-060036S	Solis Tractor PIN, 6.0AX 36	11	87089900	18
22351-060040S	Solis Tractor PIN, 6.0AX 40	11	87089900	18
22351-060050S	Solis Tractor PIN, 6.0AX 50	16	87089900	18
22351-080018S	Solis Tractor PIN, 8.0AX 18	11	87089900	18
22351-080032S	Solis Tractor PIN, 8.0AX 32	11	87089900	18
22351-080040S	Solis Tractor PIN, 8.0AX 40	12	87089900	18
22351-080050S	Solis Tractor PIN, 8.0AX 50	19	73060000	18
22372-080000S	Solis Tractor PIN, 8	11	87089900	18
22372-100000S	Solis Tractor PIN, 10	17	87089900	18
22372-160000S	Solis Tractor PIN, 16	17	73181500	18
22417-160160S	Solis Tractor PIN, 1.6 X 16	1	73181500	18
22417-160180S	Solis Tractor PIN, 1.6 X 18	1	73181500	18
22417-200100S	Solis Tractor PIN, 2.0 X 10	1	73181500	18
22417-200200S	Solis Tractor PIN, 2.0 X 20	1	73181500	18
22417-250300S	Solis Tractor PIN, 2.5 X 30	1	73181500	18
22417-300250S	Solis Tractor PIN, 3.0 X 25	1	73181500	18
22417-320250S	Solis Tractor PIN, 3.2 X 25	1	73181500	18
22417-400400S	Solis Tractor PIN, 4.0 X 40	2	73181500	18
22487-060100S	Solis Tractor PIN, 6 X 10	7	73181500	18
22487-080100S	Solis Tractor PIN, 8 X 10	12	73181500	18
22487-080120S	Solis Tractor PIN, 8 X 12	8	73181500	18
22487-080350S	Solis Tractor PIN, 8 X 35	18	87089900	18
22487-080450S	Solis Tractor PIN, 8 X 45	14	73181500	18
22487-100240S	Solis Tractor PIN, 10 X 24	34	87089900	18
22697-480641S	Solis Tractor RIVET, 4.8 X 6.4	8	76161000	18
23000-035000S	Solis Tractor CLAMP, HOSE 35	59	73181500	18

23000-048000S	Solis Tractor CLAMP, HOSE 48	90	73269099	18
23000-060000S	Solis Tractor CLAMP, HOSE 60	68	73181500	18
23000-070000S	Solis Tractor CLAMP, HOSE 70	81	73269099	18
23000-080000S	Solis Tractor CLAMP, HOSE 80	83	73269099	18
23414-150000S	Solis Tractor GASKET, 15 X 1.0	5	40161000	18
23491-140002S	Solis Tractor PLUG, 14	72	40161000	18
23857-150000S	Solis Tractor BOLT, JOINT 15	93	73181500	18
23871-020000S	Solis Tractor PLUG, R02	17	87089900	18
23887-100002S	Solis Tractor PLUG, 10	29	73181500	18
23887-160002S	Solis Tractor PLUG, 16	150	40161000	18
23887-200002S	Solis Tractor PLUG, 20	54	73181500	18
23980-730300S	Solis Tractor HOSE, 7.3 X 300	49	40091100	18
23980-730380S	Solis Tractor HOSE, 7.3 X 380	75	40091100	18
23980-730500S	Solis Tractor HOSE, 7.3 X 500	107	40091100	18
23980-731750S	Solis Tractor HOSE, 7.3 X 1750	279	40091100	18
24161-303520S	Solis Tractor NEEDLE, 303520	166	84822090	18
24161-404517S	Solis Tractor NEEDLE, 404517	201	84821020	18
24163-305200S	Solis Tractor RING, INNER 303520	224	40161000	18
24165-000402S	Solis Tractor RING, 40	19	73181500	18
24165-000452S	Solis Tractor RING, 45	21	73181500	18
24190-080001S	Solis Tractor BALL, 1/4	1	87085000	18
24190-100001S	Solis Tractor BALL, 5/16	2	84821020	18
24190-130003S	Solis Tractor BALL, 13/32	3	84821020	18
24190-160001S	Solis Tractor BALL, 1/2	5	84821020	18
24190-180001S	Solis Tractor BALL, 9/16	10	84821020	18
24311-000070S	Solis Tractor PACKING, P 7.0	70	40169390	18
24311-000090S	Solis Tractor PACKING, P 9.0	3	84840000	18
24311-000120S	Solis Tractor PACKING, P 12.0	70	40169390	18
24311-000140S	Solis Tractor PACKING, P 14.0	70	40169390	18
24311-000150S	Solis Tractor PACKING, P 15.0	4	40161000	18
24311-000180S	Solis Tractor PACKING, P 18.0	4	40161000	18
24311-000200S	Solis Tractor PACKING, P 20.0	83	40161000	18
24311-000220S	Solis Tractor PACKING, P 22.0	5	40161000	18
24311-000320S	Solis Tractor PACKING, P 32.0	110	40161000	18
24311-000500S	Solis Tractor PACKING, P 50.0	8	40161000	18
24311-000700S	Solis Tractor PACKING, P 70.0	13	40161000	18
24311-000800S	Solis Tractor PACKING, P 80.0	13	40161000	18
24311-000850S	Solis Tractor PACKING, P 85.0	13	84840000	18
24315-000140S	Solis Tractor PACKING, P 14.0	5	40161000	18
24315-000150S	Solis Tractor PACKING, P 15.0	4	40161000	18
24315-000180S	Solis Tractor PACKING, P 18.0	6	40161000	18
24315-000200S	Solis Tractor PACKING, P 20.0	5	40161000	18
24315-000280S	Solis Tractor PACKING, P 28.0	6	84090000	18
24321-000300S	Solis Tractor PACKING, G 30.0	10	84840000	18
24321-000450S	Solis Tractor PACKING, G 45.0	9	40169990	18
24321-000500S	Solis Tractor PACKING, G 50.0	15	40169990	18
24321-000650S	Solis Tractor PACKING, G 65.0	13	40161000	18
24321-000750S	Solis Tractor PACKING, G 75.0	14	84849000	18
24321-000850S	Solis Tractor PACKING, G 85.0	188	40169990	18
24321-001300S	Solis Tractor PACKING, G130.0	23	40169990	18
24321-002300S	Solis Tractor PACKING, G230.0	42	40169990	18

24325-000800S	Solis Tractor PACKING, G 80.0	13	40161000	18
24341-000080S	Solis Tractor PACKING, S 8.0	3	40161000	18
24341-000240S	Solis Tractor O-RING, 1AS24.0	97	40161000	18
24341-000250S	Solis Tractor PACKING, S 25.0	11	40161000	18
24341-000315S	Solis Tractor PACKING, S 31.5	13	40169990	18
24351-240300S	Solis Tractor PACKING, 24030	11	84840000	18
24356-190180S	Solis Tractor O-RING, 4D19018	269	40169390	18
24356-190200S	Solis Tractor O-RING, 4D19020	310	40169390	18
24550-010150S	Solis Tractor BEARING, 10 X 15	32	84090000	18
24550-012060S	Solis Tractor BEARING, 12 X 6	27	84210000	18
24550-015120S	Solis Tractor BEARING, 15 X 12	43	84821020	18
24550-016100S	Solis Tractor BEARING, 16 X 10	47	84840000	18
24550-022200S	Solis Tractor BEARING, 22 X 20	127	87089900	18
24550-025200S	Solis Tractor BEARING, 25 X 20	128	84821020	18
24550-030120S	Solis Tractor BEARING, 30 X 12	198	84828000	18
25152-004100S	Solis Tractor V-BELT, A41	1593	40100000	18
26106-060102S	Solis Tractor BOLT, 6 X 10	58	73181500	18
26106-060122S	Solis Tractor BOLT, 6 X 12	50	73181500	18
26106-060162S	Solis Tractor BOLT, 6 X 16	58	73181500	18
26106-060202S	Solis Tractor BOLT, 6 X 20	58	73181500	18
26106-060252S	Solis Tractor BOLT, 6 X 25	58	73181500	18
26106-060402S	Solis Tractor BOLT, 6 X 40	70	73181500	18
26106-060452S	Solis Tractor BOLT, 6 X 45	12	73181500	18
26106-080162S	Solis Tractor BOLT, 8 X 16	58	73181500	18
26106-080202S	Solis Tractor BOLT, 8 X 20	66	73181500	18
26106-080252S	Solis Tractor BOLT, 8 X 25	70	73181500	18
26106-080302S	Solis Tractor BOLT, 8 X 30	70	73181500	18
26106-080352S	Solis Tractor BOLT, 8 X 35	70	73181500	18
26106-080354S	Solis Tractor BOLT, 8 X 35	8	73181500	18
26106-080402S	Solis Tractor BOLT, 8 X 40	70	73181500	18
26106-080452S	Solis Tractor BOLT, 8 X 45	70	73181500	18
26106-080552S	Solis Tractor BOLT, 8 X 55	83	73181500	18
26106-080702S	Solis Tractor BOLT, 8 X 70	83	73181500	18
26106-080802S	Solis Tractor BOLT, 8 X 80	83	73181500	18
26106-081002S	Solis Tractor BOLT, 8 X 100	97	73181500	18
26106-100122S	Solis Tractor BOLT, 10 X 12	13	73181500	18
26106-100202S	Solis Tractor BOLT, 10 X 20	83	73181500	18
26106-100252S	Solis Tractor BOLT, 10 X 25	13	73181500	18
26106-100302S	Solis Tractor BOLT, 10 X 30	14	73181500	18
26106-100402S	Solis Tractor BOLT, 10 X 40	17	73181500	18
26106-120252S	Solis Tractor BOLT, 12 X 25	97	73181500	18
26106-120302S	Solis Tractor BOLT, 12 X 30	21	73181500	18
26106-120402S	Solis Tractor BOLT, 12 X 40	24	73181500	18
26106-120404S	Solis Tractor BOLT, 12 X 40	24	87081010	18
26106-120502S	Solis Tractor BOLT, 12 X 50	29	73181500	18
26106-120602S	Solis Tractor BOLT, 12 X 60	45	73181500	18
26106-120652S	Solis Tractor BOLT, 12 X 65	34	73181500	18
26106-120852S	Solis Tractor BOLT, 12 X 85	40	73181500	18
26111-060122S	Solis Tractor BOLT, 6 X 12	3	73181500	18
26111-100202S	Solis Tractor BOLT, 10 X 20	15	73181500	18
26116-060404S	Solis Tractor BOLT, 6 X 40	5	73181500	18

26116-081004S	Solis Tractor BOLT, 8 X 100	18	73181500	18
26116-081302S	Solis Tractor BOLT, 8 X 130	22	73181500	18
26116-100552S	Solis Tractor BOLT, 10 X 55	21	73181500	18
26116-140352S	Solis Tractor BOLT, 14 X 35	46	73181500	18
26116-160302S	Solis Tractor BOLT, 16 X 30	36	73181500	18
26116-160352S	Solis Tractor BOLT, 16 X 35	39	73181500	18
26116-160402S	Solis Tractor BOLT, 16 X 40	46	73181500	18
26116-160602S	Solis Tractor BOLT, 16 X 60	49	73181500	18
26116-160604S	Solis Tractor BOLT, 16 X 60	47	73181500	18
26116-180702S	Solis Tractor BOLT, 18 X 70	81	73181500	18
26161-060162S	Solis Tractor BOLT, WELD 6 X 16	4	87089900	18
26161-080162S	Solis Tractor BOLT, WELD 8 X 16	4	73181500	18
26216-080162S	Solis Tractor STUD,BOLT 8 X 16	6	73181500	18
26216-120402S	Solis Tractor STUD,BOLT 12 X 40	19	87081010	18
26331-060002S	Solis Tractor NUT, WELD 6	2	73181600	18
26331-080002S	Solis Tractor NUT, WELD 8	3	73181600	18
26366-060002S	Solis Tractor NUT, 6	58	73181600	18
26366-080002S	Solis Tractor NUT, 8	5	73181600	18
26366-100002S	Solis Tractor NUT, 10	7	73181600	18
26450-080122S	Solis Tractor BOLT, 8 X 12	5	73181500	18
26450-080252S	Solis Tractor BOLT, 8 X 25	7	73181500	18
26450-080402S	Solis Tractor BOLT, 8 X 40	10	87081010	18
26551-050122S	Solis Tractor SCREW, 5 X 12	3	73181500	18
26557-050352S	Solis Tractor SCREW, 5 X 35	7	73181500	18
26557-060202S	Solis Tractor SCREW, 6 X 20	6	73181500	18
26706-100002S	Solis Tractor NUT, 10	6	73181600	18
26711-060002S	Solis Tractor NUT, 6	2	73181600	18
26711-080002S	Solis Tractor NUT, 8	3	73181600	18
26716-080002S	Solis Tractor NUT, 8	4	73181600	18
26716-100002S	Solis Tractor NUT, 10	6	73181600	18
26716-120002S	Solis Tractor NUT, 12	10	73181600	18
26716-160002S	Solis Tractor NUT, 16	19	73181600	18
26716-180002S	Solis Tractor NUT, 18	29	73181600	18
26717-080002S	Solis Tractor NUT, 8	4	73181600	18
26756-060002S	Solis Tractor NUT, 6	2	73181600	18
26776-120002S	Solis Tractor NUT, 12	7	73181600	18
26893-000600S	Solis Tractor NUT, 6	3	73181600	18
27260-170000S	Solis Tractor CAP, SEALING 17	12	40161000	18
27260-350000S	Solis Tractor CAP, SEALING 35	20	40161000	18
27310-070001S	Solis Tractor COTTER, 7	321	73182400	18
27310-080001S	Solis Tractor COTTER, 8	321	73182400	18
29311-163000S	Solis Tractor GROMMET, 16.0 X 3	7	40161000	18
29622-140001S	Solis Tractor BAND, 140	7	39260000	18
29622-250001S	Solis Tractor BAND, 250	13	39269099	18
300000297BSG	Solis Tractor BEVEL GEAR Z-27	1059	87084000	18
300000300BSG	Solis Tractor BEVEL GEAR LOWER Z-16	1031	87084000	18
300000301ASG	Solis Tractor BEVEL GEAR Z-15	1070	87084000	18
300000302BSG	Solis Tractor BEVEL GEAR UPPER Z-16	49	87084000	18
300000484BSG	Solis Tractor DASHBOARD ASSY WITH RED PAINT	3950	87089900	18
300000484CSG	Solis Tractor DASHBOARD ASSY WITH RED PAINT	1800	87089900	18
300000624ASG	Solis Tractor TRACTOR KEY SOLIS TEXT	85	83017000	18

300000635ASG	Solis Tractor BATTERY STRIP	47	87089900	18
300001139ASG	Solis Tractor MECHANICAL STEERING WHEEL CAP SOLIS TEXT	23	87089400	18
300001220ASG	Solis Tractor POWER STEERING COLUMN	2153	87089400	18
300001693ASG	Solis Tractor CLUSTER ASSY.	15076	87089900	18
300001709ASG	Solis Tractor CRYSTAL	272	87089900	18
300001711ASG	Solis Tractor HOUSING	207	94012000	18
300001716ASG	Solis Tractor FACIA	146	94012000	18
300001720ASG	Solis Tractor FUEL GAUGE ASSEMBLY	210	87089900	18
300001723ASG	Solis Tractor TEMPRATURE GAUGE ASSEMBLY	203	87089900	18
300001726ASG	Solis Tractor BACK COVER	131	94012000	18
300002031CSG	Solis Tractor EXHAUST MANIFOLD 3CYL. (GT-STAGE V)	655	84099111	28
300002031DSG	Solis Tractor Exhaust Manifold 3cyl. (GT-stage V)	785	84099941	28
300002094ASG	Solis Tractor ENGINE LIFTING BRACKET (REAR)	33	87089900	18
300002220ASG	Solis Tractor CAP(FOR DIFF. LOCK HOLE)	12	87089900	18
300002692ASG	Solis Tractor REAR COVER CASTING	9963	87089900	18
300002694BSG	Solis Tractor REAR COVER OIB WITH DCV BACK END	27076	87085000	18
300002723ASG	Solis Tractor TIE ROD	85	87084000	18
300002725ASG	Solis Tractor PIN	49	73182300	18
300002729ASG	Solis Tractor LOWER LINK ASSY	1614	87081010	18
300002729BSG	Solis Tractor LOWER LINK ASSY	2331	87089900	18
300002731BSG	Solis Tractor ANCHOR CHAIN ASSY	893	87089900	18
300002733ASG	Solis Tractor SLEEVE FOR LOWER LINK ASSY	158	87081010	18
300002734ASG	Solis Tractor SPECIAL WASHER FOR LOWER LINK	35	73182200	18
300002735ASG	Solis Tractor SPECIAL WASHER FOR LOWER LINK	77	87081010	18
300003054BSG	Solis Tractor CLAMP ASSY. (FOR POWER STG. PIPES)	41	87089900	18
300003122ASG	Solis Tractor SOCKET HEAD SCREW M8X1.25 SA4GS	8	73182300	18
300003569ASG	Solis Tractor SPACER FOR REVERSE IDLER	52	87089900	18
300003596BSG	Solis Tractor BUSH FOR PTO IDLER GEAR	121	87089900	18
300003643ASG	Solis Tractor SHIM (0.15)	14	73182910	18
300003644ASG	Solis Tractor SHIM (0.20)	15	73182910	18
300003645ASG	Solis Tractor SHIM (0.30)	15	73182910	18
300003841ASG	Solis Tractor RETAINING WASHER DIA 10	10	73182300	18
300004074DSG	Solis Tractor SIDE MTG BKT ASSY- RH	576	87089900	18
300004075ASG	Solis Tractor SIDE MTG BRACKET ASSY LH	538	87081010	18
300004075DSG	Solis Tractor SIDE MTG BKT ASSY- LH	576	87089900	18
300004302ASG	Solis Tractor ADJUSTABLE LIFT ROD ASSY	977	87089900	18
300004382ASG	Solis Tractor PIPE(EGR to W.pump INLET_mwp)4cyl NA-MST	116	73061929	18
300004383ASG	Solis Tractor PIPE(W.pump OUTLET to EGR_mwp)4cy NA-MST	108	73061929	18
300004467ASG	Solis Tractor ROD FOR 4WD	258	87089900	18
300004473ASG	Solis Tractor DROP BOX (4WD)	5280	87085000	18
300004526ASG	Solis Tractor INPUT SHAFT Z-24 (FINISH)	1617	84831099	18
300004535ESG	Solis Tractor INPUT CONNECTING SHAFT Z-15 (FINISH)	1752	87084000	18
300004547BSG	Solis Tractor CLUSTER GEAR (FINISH)	1416	87084000	18
300004558ASG	Solis Tractor HUB (FINISH)	439	87084000	18
300004558BSG	Solis Tractor HUB (FINISH)	408	87084000	18
300004564BSG	Solis Tractor DOG GEAR ASSY	1073	87084000	18
300004573BSG	Solis Tractor SHIFTER ROD	180	87089900	18
300004573CSG	Solis Tractor SHIFTER ROD	123	87089900	18
300004579ASG	Solis Tractor SHIFTER FORK (FINISH)	375	87089900	18
300004579BSG	Solis Tractor SHIFTER FORK (FINISH)	453	87089900	18
300004584ASG	Solis Tractor INNER BUSH ASSY	399	87089900	18

300004588BSG	Solis Tractor CA Fork (FINISH)	624	87089900	18
300004590ASG	Solis Tractor OIL SEAL COVER	134	40161000	18
300004595ASG	Solis Tractor LOCKING STRIP	10	87089900	18
300004596BSG	Solis Tractor WINDOW SIDE COVER	246	87089900	18
300004619ASG	Solis Tractor FORK FOR 4WD	662	87089900	18
300004793BSG	Solis Tractor BUSH FOR DOG GEAR	96	87089900	18
300004796ASG	Solis Tractor UNIVERSAL JOINT COVER REAR ASSY (12+4)	243	87089900	18
300004799BSG	Solis Tractor ACTUATING LUG ASSY	145	87089900	18
300004820ASG	Solis Tractor CA SHAFT ASSY (GT-12+4)	374	87089300	18
300005423BSG	Solis Tractor ANGLE BRACKET ASSEMBLY LH	989	87089900	18
300005424BSG	Solis Tractor ANGLE BRACKET ASSEMBLY RH	1118	87089900	18
300005430BSG	Solis Tractor CLUSTER ASSY. WITH SILVER COWL (FOR 8+2	5455	90292020	18
300005708ASG	Solis Tractor PIN FOR TOP LINK	127	87081010	18
300005855ASG	Solis Tractor BULB T10 (WEDGE BASED)	42	94012000	18
300005857ASG	Solis Tractor INNER SEALING RING	50	94012000	18
300005871ASG	Solis Tractor WIRING HARNESS INSTRUMENT CLUSTER	448	85446090	18
300005985ASG	Solis Tractor BUSH 2WD	459	87089900	18
300005987BSG	Solis Tractor GEAR LOW WHEEL Z-66	2657	87084000	18
300006080ASG	Solis Tractor SUCTION PIPE FROM DIFFERENTIAL TO STRAIN	815	73061929	18
300006098ASG	Solis Tractor LOW BAKE PU DD GREY TOP COAT	517	32082090	18
300006178ASG	Solis Tractor CIRCLIP A-40 HEAVY DUTY	23	73182910	18
300006202BSG	Solis Tractor FOOT STEP ASSY	1384	87089900	18
300006235ASG	Solis Tractor TIE ROD FOR FOOT THROTTLE ASSY	70	87089900	18
300006235BSG	Solis Tractor TIE ROD FOR FOOT THROTTLE ASSY	64	87089900	18
300006238ASG	Solis Tractor STICKER (24 SPEEDS)	23	39191000	18
300006407BSG	Solis Tractor REAR FLOOR ASSY LH	595	87089900	18
300006408BSG	Solis Tractor REAR FLOOR ASSY RH	600	87089900	18
300006688ASG	Solis Tractor BKT ASSY FENDER SUPPORT BAR MOUNTING LH	44	87089900	18
300006693ASG	Solis Tractor BKT ASSY FENDER SUPPORT BAR MOUNTING RH	44	87089900	18
300006896BSG	Solis Tractor RADIATOR SEALING PLATE W/O PAINT FOR RX	1532	87089900	18
300007052ASG	Solis Tractor RADIATOR SEALING PLATE TOP ASSY W/O PAIN	545	87089100	18
300007326ASG	Solis Tractor FOAM RADIATOR SEALING	81	39201099	18
300007351ASG	Solis Tractor F.I.P Assy 3105NH_49@2000(F002 A2Z)A44	24249	84133010	28
300007359CSG	Solis Tractor THERMOSTAT HOUSING (GT-STAGE V)	307	84099111	28
300007376BSG	Solis Tractor FLY-WHEEL (GT-22/POWER PLUS)	3045	84835090	18
300007383ASG	Solis Tractor CLUSTER ASSY (FOR 8+2 TRANSMISSION)	7770	90261090	18
300007383BSG	Solis Tractor CLUSTER ASSY (FOR 8+2 TRANSMISSION)	8616	90292020	18
300007383CSG	Solis Tractor CLUSTER ASSY (FOR 8+2 TRANSMISSION)	8074	87089900	28
300007388ASG	Solis Tractor LOCK PIN MTG. BKT.	281	87089900	18
300007533BSG	Solis Tractor FOOT THROTTLE ASSY	98	87089900	18
300007776ASG	Solis Tractor PLUG DIA 10	12	87089900	18
300008055ASG	Solis Tractor SHIFTER KNOB (P.T.O)	97	87089900	18
300008064ASG	Solis Tractor BRAKE PEDAL LH LEVER (W/O INDEPENDENT BR	0	870810	18
300008158BSG	Solis Tractor CYL. HEAD ASSY_IW-NA_Ã~105 (Magna-2.5sw)	6554	84099941	28
300008158CSG	Solis Tractor CYL. HEAD ASSY IW NA Ø105 (MAGNA 2.5SW)	5941	84099941	28
300008206ASG	Solis Tractor CLUTCH SWITCH MOUNTING BRACKET	52	87089900	18
300008207ASG	Solis Tractor BRAKE SWITCH MOUNTING BRACKET	75	87089900	18
300008263CSG	Solis Tractor PROPELLER SHAFT ASSY	11955	87084000	18
300008458ASG	Solis Tractor FUEL PIPE (Single Filter to FIP) CT	171	73061929	18
300008459ASG	Solis Tractor FUEL PIPE (F. Pump To Single Filter) CT	185	73061929	18
300008463ASG	Solis Tractor MTG BKT FOR ACTUATOR LINK	161	87089900	18

300008500ASG	Solis Tractor PIPE FROM DIFFERENTIAL TO GEAR BOX	200	87089900	18
300008500BSG	Solis Tractor PIPE FROM DIFFERENTIAL TO GEAR BOX	261	73061929	18
300008597BSG	Solis Tractor RADIATOR SEALING BEADING GT-20	119	40082990	18
300008747BSG	Solis Tractor EXHAUST ELBOW FINISH 4 CYL	1382	87089200	18
300008749BSG	Solis Tractor EXHAUST ELBOW FINISH 3 CYL	1418	87089200	18
300008799ASG	Solis Tractor ROLLER POSITION	79	87089900	18
300008858BSG	Solis Tractor BUSH	122	39046100	18
300008910BSG	Solis Tractor GUIDING RING	24	87089900	18
300008911BSG	Solis Tractor GLYDE RING	153	40161000	18
300008912BSG	Solis Tractor RUBBER RING	31	40169100	18
300009105ASG	Solis Tractor BUSH	33	87089900	18
300009170ASG	Solis Tractor BRAKE PEDAL SHAFT FOR OIB BRAKES	898	87083000	18
300009177BSG	Solis Tractor SENSOR SPRING	414	73201011	18
300009183ASG	Solis Tractor BRACKET_F.Filter (3 cyl.-CT)	220	87089900	18
300009407BSG	Solis Tractor BONNET HINGE ASSY W/O PAINT	374	87089900	18
300009487ASG	Solis Tractor LEVER ASSEMBLY TRANSMISSION 12+4	125	87084000	18
300009551BSG	Solis Tractor GROMMET	23	40169310	18
300009568ASG	Solis Tractor HINGE GROMMET LH	45	40161000	18
300009569ASG	Solis Tractor HINGE GROMMET RH	44	40161000	18
300009574ASG	Solis Tractor BKT ASSY FOR HAND ACCELATOR GUIDE	132	87081010	18
300009615ASG	Solis Tractor SHIELD PLATE RH (W/O PAINT)	172	87089900	18
300009615BSG	Solis Tractor SHIELD PLATE RH ASSY W/O PAINT	207	87089900	18
300009620ASG	Solis Tractor BUSH LEVER MOUNTING	24	87089900	18
300009848CSG	Solis Tractor FRONT COVER	798	87085000	18
300010419ASG	Solis Tractor BUSH	119	87089900	18
300010465BSG	Solis Tractor AXLE ASSY	355	87089900	18
300010567ASG	Solis Tractor BATTERY STRAP MTG PLATE	137	87089900	18
300010746ASG	Solis Tractor HOSE	27	40092200	18
300010859ASG	Solis Tractor MOUNTING STRIP ASSY	125	87089900	18
300010860ASG	Solis Tractor BASE PLATE ASSY	108	87089900	18
300011057BSG	Solis Tractor GUIDE BUSH	88	87089900	18
300011084ASG	Solis Tractor WASHER FIBRE	42	73181600	18
300011161ASG	Solis Tractor FRONT WHEEL 5.5FX16(SILVER PAINTED)	4764	87087000	18
300011191ASG	Solis Tractor STICKER FOR MAGNETIC STRAINER	11	39191000	18
300011268BSG	Solis Tractor TIE ROD ASSEMBLY 12+4 (WITHOUT PAINT)	80	87089900	18
300011270BSG	Solis Tractor LEVER ASSEMBLY 12+4 (WITHOUT PAINT)	285	87089900	18
300011902ASG	Solis Tractor F.I.P ASSY-3105NM_47@1900(F002 A2Z)A56	26703	84133010	28
300012033ASG	Solis Tractor TIMING GEAR-F.I.P (7Â° HDM+ SERIES)	1109	84834000	18
300012074ASG	Solis Tractor CLAMP ASSY	67	87089900	18
300012189ASG	Solis Tractor SPACER FOR INTERMEDIATE SHAFT	37	87089900	18
300012204ASG	Solis Tractor CLAMP ASSY	63	73269099	18
300012205ASG	Solis Tractor CLAMP ASSY	44	73269099	18
300012755BSG	Solis Tractor BATTERY HOLDING CLAMP	27	87089900	18
300021585BSG	Solis Tractor BONNET RESTING PLATE ASSEMBLY (UNPAINTED)	668	87089900	18
300021896DSG	Solis Tractor CLUTCH HOUSING GT 12+4 IN HOUSE ENGINE	10923	87089300	18
300021897CSG	Solis Tractor CLUTCH HOUSING GT 6+2 IN HOUSE ENGINE	10425	87089300	18
300021970ASG	Solis Tractor CYLINDRICAL BEARING NUP205E	679	84825011	18
300022133BSG	Solis Tractor FOOT STEP ASSY LH	2003	87089900	18
300022214ASG	Solis Tractor CLAMP ASSY	73	73269099	18
300022240BSG	Solis Tractor PIPE FROM STEERING UNIT L TO STEERING CYL	533	87089900	18
300022241BSG	Solis Tractor PIPE FROM STEERING UNIT R TO STEERING CYL	548	87089900	18

300022254ASG	Solis Tractor GRAB HANDLE BONNET ASSY	155	87089900	18
300022276BSG	Solis Tractor PUSH KNOB ASSY BONNET LOCK	44	87089900	18
300022362ASG	Solis Tractor C.A.SHAFT ASSY (PTO)	623	87089900	18
300022570ASG	Solis Tractor BUSH (NYLON - 6)	11	87085000	18
300022591ASG	Solis Tractor SPACER DIA 72X10	72	73181500	18
300022733ASG	Solis Tractor PULL TO STOP CABLE	334	87089900	18
300022761ASG	Solis Tractor CURVE CLAMP FOR 25.4 OD METALIC PIPE	19	87089900	18
300023195BSG	Solis Tractor DASHBOARD HANDEL LH	94	87089900	18
300023207ASG	Solis Tractor DASHBOARD HANDEL RH	73	87089900	18
300023333ASG	Solis Tractor HYD.PUMP ASSY-22.5cc(G3/4" DELIVERY PORT	5992	84138190	18
300023365CSG	Solis Tractor STIFNER DASHBOARD HANDEL LH	51	87089900	18
300023368CSG	Solis Tractor STIFNER DASHBOARD HANDEL RH	39	87089900	18
300023546DSG	Solis Tractor BONNET ASSY 4-CYL WITH TOP MESH WITH TC_	25207	87089900	18
300024063BSG	Solis Tractor PEDAL MTG BRACKET ASSY	4592	87089900	18
300024063CSG	Solis Tractor PEDAL MTG BRACKET [GO10901A	6556	87089900	18
300024063DSG	Solis Tractor PEDAL MTG BKT ASSY	15680	73181900	18
300024092ASG	Solis Tractor CLAMP WIRING HARNESS	69	87089900	18
300024168BSG	Solis Tractor SLIDING TOW HOOK ASSY- GT	2595	87089900	18
300024198ASG	Solis Tractor REGISTRATION PLATE ASSY	438	83100010	18
300024327ASG	Solis Tractor MOUNTING BKT FOR REFLECTOR-RT	67	87089900	18
300024438ASG	Solis Tractor FRONT REMOVABLE WEIGHT 29 KG (SOLIS)	6086	87089900	18
300025291CSG	Solis Tractor SPECIAL PIN	17	87089900	18
300025298ASG	Solis Tractor CLUSTER ASSY	4995	90292020	28
300025801ASG	Solis Tractor CAGE ASSY (WITHOUT DIFF LOCK)	5204	87085000	18
300025832CSG	Solis Tractor HEAD LAMP ASSY RX FACELIFT STAGE IV LH	9579	85122010	18
300025833CSG	Solis Tractor HEAD LAMP ASSY RX FACELIFT STAGE IV RH	9579	85122010	18
300025960BSG	Solis Tractor FLOOR ASSY RH	1560	87089900	18
300026149ASG	Solis Tractor DRAW BAR	3152	87089900	18
300026199BSG	Solis Tractor FENDER SUPPORT BAR GT (UN PAINTED)	229	87089900	18
300026199CSG	Solis Tractor FENDER SUPPORT BAR GT	214	87089900	18
300026220CSG	Solis Tractor FLOOR MAT	1692	39073010	18
300026380ASG	Solis Tractor SPRING	10	73201011	18
300026651ASG	Solis Tractor PIN	212	87081010	18
300027523ASG	Solis Tractor BONNET SIDE SEALING PLATERH(W/O PAINT)	150	87089900	18
300027609BSG	Solis Tractor 4WD LINK ROD (FACELIFT)	102	87089900	18
300027774ASG	Solis Tractor RUBBER FLAP	47	40161000	18
300028006ASG	Solis Tractor PLOUGH LAMP	788	87089900	18
300028488ASG	Solis Tractor SPECIAL BOLT (FOR 4WD LEVER)	42	73182300	18
300028644ASG	Solis Tractor HEX. HEAD BOLT M8 X 1.25-20 8-8 SA4GS	10	73181110	18
300028650ASG	Solis Tractor SLOTTED CHEESE HD SCREW M4*15	4	73181110	18
300028708BSG	Solis Tractor BREATHER ASSY	103	87089900	18
300028829ASG	Solis Tractor SPRING GRAB HANDLE BONNET	8	73201011	18
300028832ASG	Solis Tractor SLEEVE BIG FOR IST & REV GEAR	577	87084000	18
300029084ASG	Solis Tractor SHIFTER KNOB (P.T.O)	107	87089900	18
300029084BSG	Solis Tractor SHIFTER KNOB (P.T.O)	108	87089900	18
300029240ASG	Solis Tractor HEX BOLT M18X2.5X60 10.9 SA4GS	74	73182300	18
300029260ASG	Solis Tractor BONNET SIDE SEALING PLATERH(RED PAINT)	181	87089900	18
300029262ASG	Solis Tractor BONNET SIDE SEALING PLATE LH(W/O PAINT)	168	87089900	18
300029264ASG	Solis Tractor BONNET SIDE SEALING PLATE LH(RED PAINT)	181	87089900	18
300029488ASG	Solis Tractor PRIMARY PIPE FROM PUMP TO DCV P	828	73061929	18
300029496ASG	Solis Tractor SUCTION PIPE FROM STRAINER TO HOSE	210	87089900	18

300029524ASG	Solis Tractor PRIMARY PIPE FROM PUMP TO DCV P	634	73061929	18
300029610ASG	Solis Tractor FLOOR MTG CHANNEL FRONT LH ASSY	172	87089900	18
300029611BSG	Solis Tractor FLOOR MTG CHANNEL FRONT RH ASSY	173	87089900	18
300029612ASG	Solis Tractor FLOOR MTG CHANNEL REAR LH ASSY	153	87089900	18
300029613BSG	Solis Tractor FLOOR MTG CHANNEL REAR RH ASSY	153	87089900	18
300029928ASG	Solis Tractor RTUG GASKET	134	35069999	18
300030125ASG	Solis Tractor HAND ACCEL RATOR GROMMET	33	40161000	18
300030448ASG	Solis Tractor FLAT WASHER N8-22 SA4GS	5	73182990	18
300031043ASG	Solis Tractor STIFFNER ROD	30	87089900	18
300031073ASG	Solis Tractor SPECIAL BOLT(M12)	38	73181500	18
300031136ASG	Solis Tractor HEX BOLT M16X2X65 8.8 SA4NS	61	73182300	18
300031384CSG	Solis Tractor HANDLE FOR PARKING BRAKE	64	87089900	18
300031472ASG	Solis Tractor Crank Shaft 3cyl. INTG.-FL (MICRO ALLOY)	20765	84831092	18
300031473ASG	Solis Tractor Crank Shaft 4cyl. INTG.-FL (MICRO ALLOY)	24674	84831092	18
300031485ASG	Solis Tractor REAR VIEW MIRROR ASSY RH	617	70091090	18
300031732ASG	Solis Tractor PRIMER SURFACE 3CIB W/W	843	32081090	0
300031807ASG	Solis Tractor SPLIT PIN DIA 2*16	4	73181500	18
300031864ASG	Solis Tractor FORK FOR PARKING BRAKE	224	87084000	18
300031924ASG	Solis Tractor HAND TOOL KIT	738	82060090	18
300031951ASG	Solis Tractor IDLER GEAR (FINISH NO.)	1537	87084000	18
300031951BSG	Solis Tractor IDLER GEAR (FINISH NO.)	1717	87084000	18
300032116BSG	Solis Tractor HARNESS ASSY.	8834	85443000	18
300032118BSG	Solis Tractor HARNESS ASSY.	9235	85443000	18
300032118CSG	Solis Tractor HARNESS ASSEMBLY	10084	85443000	18
300032120BSG	Solis Tractor HARNESS ASSY.	7487	85443000	18
300032120CSG	Solis Tractor HARNESS ASSEMBLY	10554	85443000	18
300032148BSG	Solis Tractor SHIFTER LEVER ASSY	581	87089900	18
300032324BSG	Solis Tractor FRONT MESH ASSY BLACK PAINT	902	87089900	18
300032540ASG	Solis Tractor REAR VIEW MIRROR ASSY RH	375	70091090	18
300032568ASG	Solis Tractor FLASHER UNIT ASSEMBLY	597	85361010	18
300032668ASG	Solis Tractor GAS SPRING SUPPORT ASSY	154	87089900	18
300032712ASG	Solis Tractor WASHER	4	73181600	18
300032779ASG	Solis Tractor STEPER PIN DIA 8 BONNET LOCK	25	87089900	18
300032938ASG	Solis Tractor FLEXIBLE HOSE RUBBER (0.520 M) LEFT SIDE	214	40092200	18
300032938BSG	Solis Tractor Flexible Hose Pipe-0.46m (Left side)	259	40091100	18
300032941BSG	Solis Tractor BREATHER PIPE ASSY.I (LEFT SIDE)	54	87089900	18
300032948ASG	Solis Tractor FLEXIBLE PIPE RUBBER (0.432 M)RIGHT SIDE	226	40092200	18
300032948BSG	Solis Tractor FLEXIBLE HOSE PIPE (0.432 M)RIGHT SIDE	200	40091100	18
300033452BSG	Solis Tractor BREATHER PIPE ASSY.II (RIGHT SIDE)	61	87089900	18
300033515CSG	Solis Tractor FENDER LEFT (SKY BLUE PAINT)	14772	87089900	18
300033531ASG	Solis Tractor STRAP ASSY (4 CYL FUEL TANK)	46	87089900	18
300033666ASG	Solis Tractor COVER PLATE FOR PTO CONVERTER	44	87089900	18
300033687CSG	Solis Tractor GAS SPRING MTG BKT	832	87089900	18
300033707ESG	Solis Tractor HARNESS ASSEMBLY	8572	85446090	18
300033711BSG	Solis Tractor TAIL LIGHT LH	1832	85122020	18
300033712BSG	Solis Tractor TAIL LIGHT RH	1832	85122020	18
300033713BSG	Solis Tractor FRONT LIGHT LH	1401	85122020	18
300033714BSG	Solis Tractor FRONT LIGHT RH	1277	85120000	18
300033833ASG	Solis Tractor SOCKET HEAD SCREW	7	73181110	18
300033900ASG	Solis Tractor GROMMET RADIATOR SEALING PLATE	47	40161000	18
300033923ASG	Solis Tractor GAS SPRING 3 CYL	1072	87089900	18

300033924ASG	Solis Tractor GAS SPRING 4 CYL	1127	87089900	18
300034000ASG	Solis Tractor STEERING COLUMN COVER UPPER	111	87089900	18
300034001ASG	Solis Tractor STEERING COLUMN COVER LOWER	115	87089900	18
300034020ASG	Solis Tractor HOSE PIPE (DCV T TO REAR COVER TANK)	81	40091100	18
300034077BSG	Solis Tractor SWITCH ACTUATING PIN	45	73182300	18
300034287ASG	Solis Tractor ES BOLT WITH SECURING COLLAR 8X32	48	87084000	18
300034317ASG	Solis Tractor BONNET LOCK INTERMEDIATE LINK STAGE IV	60	87089900	18
300034503ASG	Solis Tractor SUCTION STRAINER (3 CYL) 4x4	336	84219900	18
300034503BSG	Solis Tractor SUCTION STRAINER (3CYL) 4x4	278	84213990	18
300034520ASG	Solis Tractor CLUTCH PEDAL SPRING MTG BKT ASSY	114	87089300	18
300034826CSG	Solis Tractor PC DC COVER	305	87089900	18
300034852ASG	Solis Tractor FOOT STEP SUPPORT CHANNEL ASSY LH	508	87089900	18
300034852BSG	Solis Tractor FOOT STEP SUPPORT CHANNEL ASSY LH	602	87089900	18
300034905ASG	Solis Tractor FUEL CUT OFF ROD 4 CYL	77	73201011	18
300034906ASG	Solis Tractor FUEL CUT OFF ROD 3 CYL	84	73201011	18
300035076ASG	Solis Tractor PTO LEVER ASSY.	680	87089900	18
300035335ASG	Solis Tractor OVERFLOW FUEL PIPE (INJECTOR TO T-JOINT)	72	73061929	18
300035368CSG	Solis Tractor RADIATOR SEALING PLATE ASSEMBLY	2885	87089100	18
300035741CSG	Solis Tractor SPACER (ROCK SHAFT)	128	87089900	18
300035916ASG	Solis Tractor GROMMET ASSY FOR MAIN GEAR SHIFTER LEVER	491	87089900	18
300036375ASG	Solis Tractor BONNET LOCK PLATE ASSY (RX FACELIFT WITH	99	87089900	18
300036378ASG	Solis Tractor CAGE ASSY. WITH DIFF LOCK	4688	87085000	18
300036519BSG	Solis Tractor FRONT LAMP LH	3071	85122010	18
300036520BSG	Solis Tractor FRONT LAMP RH	3071	85122010	18
300036521BSG	Solis Tractor TAIL LAMP LH	3071	85122010	18
300036522BSG	Solis Tractor TAIL LAMP RH	3071	85122010	18
300037038ASG	Solis Tractor FRONT TRASH GUARD (W/O PAINT)	390	87089900	18
300037090BSG	Solis Tractor BONNET LOCK ROD	38	87089900	18
300037297ASG	Solis Tractor LOCK MTG BRACKET	237	87089900	18
300037406ASG	Solis Tractor RUBBER BEEDING	19	40161000	18
300037478ASG	Solis Tractor RADIATOR MTG BKT RH	279	87089900	18
300037479ASG	Solis Tractor RADIATOR MTG BKT LH	268	87089900	18
300037498ASG	Solis Tractor F.I.P ASSY-4105NU_58hp@2100(F002 A3Z)F62	30896	84133010	28
300037512BSG	Solis Tractor FRONT AXLE BRACKET FOR SOLIS-28	8270	87089900	18
300037709ASG	Solis Tractor STICKER 52 POWER AND HIGH TORQUE AT 2000	44	39199010	18
300037851ASG	Solis Tractor FRICTION DISC BRAKE	407	87083000	18
300037852ASG	Solis Tractor STEEL DISC BRAKE	198	87083000	18
300037907ASG	Solis Tractor M8 COLLAR NUT	8	73181600	18
300037996ASG	Solis Tractor RUBBER PAD	183	40169310	18
300038024ASG	Solis Tractor SIGNATURE LIGHT SWITCH	397	85361010	18
300038267CSG	Solis Tractor 4 CYL FENDER ASSY NON ROPS LH RX TC_MAG	13670	87089900	18
300038267HSG	Solis Tractor 4 CYL FENDER ASSY NON ROPS LH RX TC_MAG	19539	87089900	18
300038273CSG	Solis Tractor 4 CYL FENDER ASSY NON ROPS RH RX TC_MAG	14289	87089900	18
300038273HSG	Solis Tractor 4 CYL FENDER ASSY NON ROPS RH RX TC_MAG	20262	87089900	18
300038325ESG	Solis Tractor 4 CYL FENDER ASSY NON ROPS LH MST TC_M	9320	87089900	18
300038331ESG	Solis Tractor 4 CYL FENDER ASSY NON ROPS RH MST TC_M	9334	87089900	18
300038584ASG	Solis Tractor PIPE FOR LUBRICATION	171	73061929	18
300038600ASG	Solis Tractor CLAMP FOR LUBRICATION	16	87089900	18
300039238ASG	Solis Tractor RUBBER WASHER FOR SIDE CHROME	6	40169310	18
300039441ASG	Solis Tractor GRUB SCREW M12X1.5X15	24	73181500	18
300039906ASG	Solis Tractor PRIMARY PIPE ASSY FROM STEERING UNIT L T	509	73061929	18

300039955ASG	Solis Tractor PRIMARY PIPE ASSY FROM STEERING UNIT R T	493	73061929	18
300039995ASG	Solis Tractor SEC PIPE FROM STEERING UNIT L TO STEERIN	574	73061929	18
300040375BSG	Solis Tractor HYDRAULIC CYLINDER-ECONOMICAL	6670	87089900	18
300040376BSG	Solis Tractor CLAMP ASSY	76	87089900	18
300040559ASG	Solis Tractor CA GUIDE SINGLE CLUTCH	770	87084000	18
300040848ASG	Solis Tractor SLEEVE REV REV. PTO (FINISH)	814	87084000	18
300040875ASG	Solis Tractor CONNECTING SHAFT 10+5	2173	87084000	18
300041169ASG	Solis Tractor STEERING UNIT 60CC	22634	87089400	18
300041199ASG	Solis Tractor INPUT SHAFT Z-19	2911	84831099	18
300041199BSG	Solis Tractor INPUT SHAFT Z-19 FINISH NO	2482	87089900	18
300041205ASG	Solis Tractor INPUT SHAFT Z-20	2274	87084000	18
300041367ASG	Solis Tractor BADGE GT 28	160	39199010	18
300041414ASG	Solis Tractor FIXED GEAR 2ND Z-36	1104	87084000	18
300041415ASG	Solis Tractor FIXED GEAR 2ND Z-37	1515	87084000	18
300041416ASG	Solis Tractor FIXED GEAR 2ND Z-38	1197	87084000	18
300041421ASG	Solis Tractor HOLLOW DOWEL (16X10)	27	73181500	18
300041488ASG	Solis Tractor STEERING BELLOW	149	87089900	18
300041606ASG	Solis Tractor DRIVEN PLATE DIA 310 (WITH 15.75 TORSION	10486	87089300	18
300041675ASG	Solis Tractor SPECIAL VIBRATION DAMPER FOR PIPE OD 12	25	40169100	18
300041680ASG	Solis Tractor CLUTCH PEDAL ASSY	836	87089900	18
300041806ASG	Solis Tractor Shifter Fork 1st/Rev. (Finish)	559	87089900	18
300041811ASG	Solis Tractor Shifter Fork 2nd/3rd (Finish)	559	87089900	18
300041816BSG	Solis Tractor Gear Shifter Rod (1st/ Rev) (Finish)	276	87084000	18
300041818BSG	Solis Tractor Gear Shifter Rod (2nd/ 3rd) (Finish)	276	87084000	18
300042288ASG	Solis Tractor LOCKING PIN	32	87089900	18
300042420BSG	Solis Tractor GASKET FOR EXHAUST	43	84841090	18
300042432ASG	Solis Tractor CLAMP ASSY	39	87089900	18
300042569ASG	Solis Tractor BENJO BOLT 1/2 INCH BSP	93	73181500	18
300043091CSG	Solis Tractor TUBE AND SIDE COVER ASSY (FOR OPERATING	1087	87089900	18
300043305CSG	Solis Tractor KNOB ASSY	34	84822090	18
300043375ASG	Solis Tractor CLUTCH PEDAL LOCK (UNPAINTED)	27	87089300	18
300043425CSG	Solis Tractor POSITION LEVER	130	87089900	18
300043426CSG	Solis Tractor DRAFT LEVER	176	87089900	18
300043872CSG	Solis Tractor STICKER FOR PC DC INDICATION	31	39191000	18
300044293ASG	Solis Tractor BATTERY CABLE POSITIVE	999	85442090	18
300044931ASG	Solis Tractor BUSH FOR INTERMEDIATE SHAFT	66	87089900	18
300044936ASG	Solis Tractor BUSH FOR SWIVEL HOUSING	191	87089900	18
300045332BSG	Solis Tractor CLUSTER ASSY.(12+12 TRANSMISSION(PTO 100	7615	90292090	18
300045425ASG	Solis Tractor RADIATOR SEALING PLATE BOTTOM	373	87089100	18
300045970ASG	Solis Tractor TOP LEVER HAND ACCELERATOR (POWDER COATI	128	87089900	18
300046155ASG	Solis Tractor CAGE ASSY.	4912	87085000	18
300046160ASG	Solis Tractor SWIVEL HOUSING ASSY. LEFT	11234	87089900	18
300046160BSG	Solis Tractor SWIVEL HOUSING ASSY. (LEFT)	9323	87085000	18
300046162ASG	Solis Tractor SWIVEL SUB ASSY.(RIGHT)	9416	87085000	18
300046162BSG	Solis Tractor SWIVEL HOUSING ASSY. (RIGHT)	9448	87085000	18
300046167ASG	Solis Tractor AXLE HOUSING & BUSH SUB ASSY	37147	87089900	18
300046639ASG	Solis Tractor SEALING PLUG	31	87089900	18
300046701ASG	Solis Tractor PTO SHAFT	1941	87084000	18
300046713ASG	Solis Tractor SPACER BIG	478	73181500	18
300046714ASG	Solis Tractor SPACER SMALL	231	73181500	18
300046836ASG	Solis Tractor RUBBER FLAP 495MM	75	40169310	18

300047466ASG	Solis Tractor PTO SHIFTER ROD	449	87089900	18
300047484ASG	Solis Tractor FORK	762	87084000	18
300047579ASG	Solis Tractor EXHAUST PIPE ASSY	873	87089200	18
300048549ASG	Solis Tractor OUTER RUBBER PAD LH	0	40169340	18
300048879BSG	Solis Tractor POSITION PLATE	103	87089900	18
300049166ASG	Solis Tractor IDLER GEAR Z-31 (FINISH)	1687	87084000	18
300049639ASG	Solis Tractor CRANK CASE with B/CAP (3cyl.-NA) CE_IW	62804	84099941	28
300049685ASG	Solis Tractor AIR CLEANER CONNECTOR	178	40091100	18
300050614ASG	Solis Tractor EGR COOLER ASSY. (37 TUBES) 9KW	7577	84099990	28
300050674ASG	Solis Tractor LIP SEAL ¥42X¥55X8	63	40169390	18
300050675ASG	Solis Tractor BUSH ¦#42X¦#51	254	87089900	18
300050893ASG	Solis Tractor FLY WHEEL	4016	84834000	18
300051497ASG	Solis Tractor GROMMET SHUTTLE LEVER	31	40161000	18
300051804ASG	Solis Tractor SPACER (ROCK SHAFT)	41	39261011	18
300051954BSG	Solis Tractor TUBE ADOPTER ASSY 1/2 INCH BSP	98	87089900	18
300052076ASG	Solis Tractor ROD (GT-SIDE SHIFT) (FINISH)	688	87089900	18
300052716BSG	Solis Tractor HOUSING, REAR AXLE CASTING	5683	73251000	18
300052960DSG	Solis Tractor BRACKET FOR SPRING GUIDE	433	87089900	18
300052999CSG	Solis Tractor REAR FLOOR SUPPORT BRACKET	25	87089900	18
300053002ASG	Solis Tractor CONTROL VALVE	8203	84814000	18
300053551BSG	Solis Tractor PIN FOR ROCKER LINK	122	73182400	18
300053670ASG	Solis Tractor TYRE (6.5X16)	8382	40117000	18
300053671ASG	Solis Tractor TUBE (6.5X16)	712	40139049	18
300053762BSG	Solis Tractor TRUMPET HOUSING (FINISH)	11745	87081010	18
300053818BSG	Solis Tractor GASKET FOR TUBE ASSEMBLY	12	84841010	18
300054044ASG	Solis Tractor Housing - Assy Includes Item 1B	45690	87089900	18
300054096ASG	Solis Tractor Plug - Drain	55	87085000	18
300054098ASG	Solis Tractor Wheel End Assembly (LH) NOT SHOWN	58196	87089900	18
300054100ASG	Solis Tractor Assy - Wheel End (RH) SHOWN	58796	87089900	18
300054102ASG	Solis Tractor Axle Shaft (LH)	4215	87085000	18
300054103ASG	Solis Tractor Axle Shaft (RH)	4156	87085000	18
300054104ASG	Solis Tractor Washer	46	87085000	18
300054105ASG	Solis Tractor Capscrew - Hex Head	173	87085000	18
300054106ASG	Solis Tractor Assy - Carrier	50605	87085000	18
300054107ASG	Solis Tractor Capscrew - Hex Head	106	87085000	18
300054108ASG	Solis Tractor Assy - Dipstick	220	87089900	18
300054109ASG	Solis Tractor O-ring - Dipstick	31	87085000	18
300054110ASG	Solis Tractor Assy - Tie Rod - See SEV-0976	8812	87081010	18
300054111ASG	Solis Tractor Plate - Thrust	191	87085000	18
300054112ASG	Solis Tractor Front V-Ring Kit	1122	87089900	18
300054114ASG	Solis Tractor Trunnion Assy - Front	10884	87089900	18
300054115ASG	Solis Tractor Fitting - Grease	37	87085000	18
300054117ASG	Solis Tractor Bolt - Hex	96	87085000	18
300054135ASG	Solis Tractor Bushing	784	87085000	18
300054136ASG	Solis Tractor Nut - Hex	42	87085000	18
300054141ASG	Solis Tractor Nut - Castle	106	87085000	18
300054142ASG	Solis Tractor Washer	138	87085000	18
300054143ASG	Solis Tractor Pin - Cotter	14	87085000	18
300054144ASG	Solis Tractor Inverted Rear V- Ring Kit	1162	87089900	18
300054146ASG	Solis Tractor Trunnion Assy - Rear	14801	87089900	18
300054150ASG	Solis Tractor Bushing - Rear	1090	87085000	18

300054152ASG	Solis Tractor Washer - Thrust	681	87085000	18
300054155ASG	Solis Tractor Rear V Ring Kit	1202	87089900	18
300054167ASG	Solis Tractor Carrier Housing	17451	87085000	18
300054168ASG	Solis Tractor Kit - Differential Bearing	2998	87089900	18
300054169ASG	Solis Tractor Cup - Bearing	722	87089900	18
300054171ASG	Solis Tractor Cone - Bearing	1441	87089900	18
300054172ASG	Solis Tractor Shim Kit	1963	87089900	18
300054174ASG	Solis Tractor Pinion Bearing Kit & Seal N.I	13818	87089900	18
300054175ASG	Solis Tractor Cup - Bearing	1005	87089900	18
300054179ASG	Solis Tractor Cone - Bearing	1815	87089900	18
300054181ASG	Solis Tractor Shim Kit	355	87089900	18
300054183ASG	Solis Tractor Assy - Diff Case	7093	87085000	18
300054185ASG	Solis Tractor Set - Ring & Pinion	19609	87085000	18
300054187ASG	Solis Tractor Screw - Drive Gear	74	87085000	18
300054188ASG	Solis Tractor Spacer - Pinion Bearing	554	87085000	18
300054189ASG	Solis Tractor Shim Kit	1957	87089900	18
300054190ASG	Solis Tractor Cup - Bearing	1755	87089900	18
300054192ASG	Solis Tractor Cone - Bearing	3500	87089900	18
300054193ASG	Solis Tractor Seal Kit - N.I.	1853	87089900	18
300054194ASG	Solis Tractor Spacer	328	87085000	18
300054195ASG	Solis Tractor O-ring	18	87085000	18
300054196ASG	Solis Tractor Seal - Oil	877	87085000	18
300054198ASG	Solis Tractor Slinger	61	87085000	18
300054200ASG	Solis Tractor Nut - Pinion	523	87085000	18
300054203ASG	Solis Tractor Shoulder N.S.S.	13136	87085000	18
300054204ASG	Solis Tractor Snap Ring	225	87085000	18
300054209ASG	Solis Tractor Shim	1476	87089900	18
300054210ASG	Solis Tractor Bearing	1990	87085000	18
300054211ASG	Solis Tractor Bearing	2437	87085000	18
300054212ASG	Solis Tractor Gear (12T) N.S.S.	4149	87089900	18
300054213ASG	Solis Tractor Gear (15T) N.S.S.	4159	87089900	18
300054214ASG	Solis Tractor Bearing - Cone	4894	87085000	18
300054215ASG	Solis Tractor Seal - Face	3513	87085000	18
300054217ASG	Solis Tractor Knuckle - Sub Assy (LH)	17466	87089900	18
300054218ASG	Solis Tractor Knuckle - (LH) N.S.S	15530	87089900	18
300054219ASG	Solis Tractor Bearing - Cup	1238	87085000	18
300054221ASG	Solis Tractor Plug - Welch	40	87085000	18
300054222ASG	Solis Tractor Cup - Bearing, Tapered Roller	603	87085000	18
300054223ASG	Solis Tractor Bearing Cone	1394	87085000	18
300054226ASG	Solis Tractor Star - Lockwasher	210	87085000	18
300054228ASG	Solis Tractor Spanner - Nut	955	87085000	18
300054232ASG	Solis Tractor Shaft - Axle	6632	87085000	18
300054233ASG	Solis Tractor Snap Ring	76	87085000	18
300054234ASG	Solis Tractor Roller Bearing	3102	87085000	18
300054236ASG	Solis Tractor Cover - Sub Assy	10271	87089900	18
300054238ASG	Solis Tractor Cover N.S.S	8469	87085000	18
300054242ASG	Solis Tractor Cups - Inner & Outer	878	87085000	18
300054244ASG	Solis Tractor O-ring	269	87085000	18
300054245ASG	Solis Tractor Cone - Inner & Outer	1811	87085000	18
300054248ASG	Solis Tractor Output Shaft	7713	87085000	18
300054249ASG	Solis Tractor Bevel Gear (41T) N.S.S	20364	87089900	18

300054251ASG	Solis Tractor Shim	2181	87089900	18
300054254ASG	Solis Tractor Plate - Retainer	322	87085000	18
300054257ASG	Solis Tractor Nut - Output shaft	276	87085000	18
300054259ASG	Solis Tractor Bolt - Hex	87	87085000	18
300054260ASG	Solis Tractor Snap Ring	111	87085000	18
300054261ASG	Solis Tractor Spacer	540	87085000	18
300054262ASG	Solis Tractor Shim	4152	87089900	18
300054263ASG	Solis Tractor Gear - Bevel N.S.S.	2775	87089900	18
300054264ASG	Solis Tractor Plug - Welch	431	87085000	18
300054265ASG	Solis Tractor Gear Shoulder Kit	4319	87089900	18
300054266ASG	Solis Tractor Gear Output Kit	14336	87089900	18
300054267ASG	Solis Tractor Screw Hex	182	87089900	18
300054494ASG	Solis Tractor Cylinder - Steer - See SEV-0969	22583	87081010	18
300054504ASG	Solis Tractor Knuckle - Sub Assy (RH)	15412	87089900	18
300054506ASG	Solis Tractor KNUCKLE - (RH) N.S.S	16523	87089900	18
300054507ASG	Solis Tractor Boot Kit	951	87081010	18
300054510ASG	Solis Tractor Piston	1342	87081010	18
300054511ASG	Solis Tractor Rod Assembly	19895	87081010	18
300054512ASG	Solis Tractor Head	3060	87081010	18
300054513ASG	Solis Tractor Seal Kit	2616	87081010	18
300054514ASG	Solis Tractor Assy - Socket (RH)	3809	87081010	18
300054515ASG	Solis Tractor Assy - Socket (LH)	3809	87081010	18
300054517ASG	Solis Tractor Jam Nut (RH)	226	87081010	18
300054518ASG	Solis Tractor Jam Nut (LH)	226	87081010	18
300054519ASG	Solis Tractor Castle Nut	374	87081010	18
300054520ASG	Solis Tractor Cotter Pin	14	87081010	18
300054521ASG	Solis Tractor Boot Seal	149	87081010	18
300055390ASG	Solis Tractor SEALING PLUG	28	87089900	18
300055461ASG	Solis Tractor FLOOR MAT (RX FACELIFT)	4941	39073010	18
300055480ASG	Solis Tractor GEAR SHIFTER COVER LH	177	87089900	18
300055525ASG	Solis Tractor GEAR SHIFTER COVER RH	186	87089900	18
300055628ASG	Solis Tractor CRANK CASE w/Brg.CAP (3cyl.-NA) CE-NT	52443	84099941	28
300055630BSG	Solis Tractor CRANK CASE ASSY.(3CYL.-NA_IW) CE-NT M16	50981	87089900	18
300055774ASG	Solis Tractor CLUTCH HOUSING (FINISH)	15223	87089300	18
300055820ASG	Solis Tractor CLUTCH HOUSING ASSY.	11109	87089300	18
300056003ASG	Solis Tractor REAR PLATE (Mistubishi Engine)	1964	87089900	18
300056116ASG	Solis Tractor Fender Flap RH	3097	87089900	18
300056309ASG	Solis Tractor FENDER FLAP LH	3097	40082990	18
300056326ASG	Solis Tractor PUSH ROD AXLE ASSY TO FIP (4CYL REGULAR	73	87089900	18
300056340ASG	Solis Tractor PUSH ROD AXLE ASSY TO FIP (3CYL REGULAR	67	87089900	18
300056958BSG	Solis Tractor CYLINDER LINER L.S.	1467	84099990	28
300057091CSG	Solis Tractor CONNECTING ROD	463	87089900	18
300057128BSG	Solis Tractor RAM ARM	2418	87089900	18
300057172BSG	Solis Tractor ROCK SHAFT	3119	87084000	18
300057285ASG	Solis Tractor FRONT WHEEL RIM W7x20 (SILVER PAINTED)	7404	87087000	18
300058513ASG	Solis Tractor REAR WHEEL RIM W13*28 SILVER PAINTED	14378	87087000	18
300059497ASG	Solis Tractor ADOPTER	128	73071190	18
300060663BSG	Solis Tractor SENSOR SPRING	92	73201011	18
300060679ASG	Solis Tractor PUNCHED WASHER M8 (Trivalent)	21	73182990	18
300060684BSG	Solis Tractor GASKET - CYL. HEAD (L.S.)	260	84841090	18
300060792DSG	Solis Tractor CYLINDER ¥76 FINISH	1686	87089900	18

300060803BSG	Solis Tractor CON ROD ASSY	1826	84099199	28
300060959BSG	Solis Tractor COVER (BRAKE HSG LEFT)	1286	87083000	18
300061478BSG	Solis Tractor SPACER FOR ROCKER LINK	60	87089900	18
300062337ASG	Solis Tractor TOP LEVER HAND ACCELERATOR	129	87084000	18
300062347ASG	Solis Tractor TOP LEVER HAND ACCELERATOR (BLACK POWDER	138	87084000	18
300062357ASG	Solis Tractor BELLOW SHIFFTER LEVER	106	40169990	18
300062357BSG	Solis Tractor BELLOW SHIFFTER LEVER	92	87089900	18
300062385ASG	Solis Tractor STICKER SPEED CHART MST SAME SPEED REVER	39	39191000	18
300062772DSG	Solis Tractor CLUTCH PEDAL ASSY	1101	87089900	18
300062919BSG	Solis Tractor KNOB ASSY FRONT LEVER	73	87089900	18
300063291CSG	Solis Tractor LEVER SIDE SHIFT	534	87084000	18
300063804GSG	Solis Tractor 3 CYL FENDER ASSY NON ROPS STAGE IV RH W	10602	87089900	18
300063825ASG	Solis Tractor SHAFT FRONT PTO 4WD ASSY. W/O IPTO 8+2(D	3988	87084000	18
300063872ASG	Solis Tractor PRIMARY DELIEVERY PIPE FROM PRIORITY VAL	378	73061929	18
300064222CSG	Solis Tractor RANGE LEVER ASSY	425	87084000	18
300064782ASG	Solis Tractor ADOPTER M14X1.5 & 3/8BSP	82	87089900	18
300064827ASG	Solis Tractor SHAFT FRONT PTO 4WD ASSY. WITH I-PTO	3555	87084000	18
300066054CSG	Solis Tractor SIDE CENTRE PANEL LH3 CYL	367	87089900	18
300066056CSG	Solis Tractor SIDE CENTRE PANEL RH3 CYL	367	87089900	18
300066305ASG	Solis Tractor M/C WASHER DIA 16.5X26X3	8	73182300	18
300066476ASG	Solis Tractor GRAB HANDLE	94	87089900	18
300066552BSG	Solis Tractor RING TOP	312	84099113	28
300066559BSG	Solis Tractor RING_2ND	93	84099113	28
300066564ASG	Solis Tractor PISTON OIL RING_¥107 (LS)	397	84099113	28
300066672ASG	Solis Tractor PRIMARY PIPE FROM PUMP TO PRIORITY VALVE	346	73061929	18
300066707ASG	Solis Tractor PRIMARY PIPE FROM PRIORITY VALVE 'CF' TO	263	87089900	18
300066713ASG	Solis Tractor PRIORITY VALVE MOUNTING BRACKET	134	87089900	18
300066713BSG	Solis Tractor PRIORITY VALVE MOUNTING BRACKET	163	87089900	18
300066861ASG	Solis Tractor FLEXIBLE PIPE FROM PRIORITY VALVE L TO S	602	40091100	18
300066939ASG	Solis Tractor BONNET ASSY GT 3 CYL RED PAINT	11775	87089900	18
300066939CSG	Solis Tractor BONNET ASSY GT 3 CYL RED PAINT	17982	87081010	18
300068762BSG	Solis Tractor INTERMEDIATE SHAFT Z-24 (FINISH NO.)	4130	87084000	18
300068767BSG	Solis Tractor HUB HI GEAR	610	87084000	18
300068770BSG	Solis Tractor HI LOW INTERMEDIATE SHAFT	2540	87084000	18
300068852GSG	Solis Tractor 3 CYL FENDER ASSY NON ROPS STAGE IV LH T	18054	87089900	18
300068855GSG	Solis Tractor 3 CYL FENDER ASSY NON ROPS STAGE IV RH	20196	87089900	18
300069523ASG	Solis Tractor TYRE (6.5X16) - APOLLO	8739	40139049	18
300069524ASG	Solis Tractor TUBE (6.5X16) - APOLLO	734	40139049	18
300069526BSG	Solis Tractor LAY GEAR Z-42 (FINISH NO.)	2188	87084000	18
300069527BSG	Solis Tractor LAY GEAR Z-43 (FINISH NO.)	2084	87084000	18
300069528BSG	Solis Tractor LAY GEAR Z-44 (FINISH NO.)	2192	87084000	18
300069920ASG	Solis Tractor LOCK MOUNTING BRACKET BONNET	67	87089900	18
300069920BSG	Solis Tractor LOCK MOUNTING BRACKET BONNET	59	87089900	18
300070047DSG	Solis Tractor FRONT MESH ASSY BLACK PAINT	3100	87089900	18
300070075BSG	Solis Tractor FIXED GEAR 5TH Z-49	1863	87084000	18
300070080BSG	Solis Tractor FIXED GEAR 5TH Z-50 (FINISH NO.)	1973	87084000	18
300070084ASG	Solis Tractor FIXED GEAR 5TH Z-50 (FINISH NO.)	2026	87084000	18
300070090BSG	Solis Tractor FIXED GEAR 5TH Z-51	2167	87084000	18
300070094ASG	Solis Tractor FIXED GEAR 5TH Z-52 (FINISH NO.)	2074	87084000	18
300070094BSG	Solis Tractor FIXED GEAR 5TH Z-52 (FINISH NO.)	2045	87084000	18
300070101ESG	Solis Tractor DOG CLUTCH GEAR 5TH ASSY Z-16	1115	87084000	18

300070102ASG	Solis Tractor DOG CLUTCH GEAR 5TH ASSY. Z-16	902	87084000	18
300070102ESG	Solis Tractor DOG CLUTCH GEAR 5TH ASSY Z-16	854	87084000	18
300070103ESG	Solis Tractor DOG CLUTCH GEAR 5TH ASSY Z-17	1182	87084000	18
300070105ESG	Solis Tractor DOG CLUTCH GEAR 5TH ASSY Z-19	901	87084000	18
300070147ASG	Solis Tractor TAPER ROLLER BAERING 30211 (DIA 55*100*2	775	84822012	18
300070151BSG	Solis Tractor SPACER (FOR INTERMEDIATE SHAFT)	297	87089900	18
300070522BSG	Solis Tractor GEAR BOX HOUSING (FINISH NO.)	28289	87084000	18
300070755ASG	Solis Tractor GROOMET FOR FENDER	28	40169310	18
300071298ASG	Solis Tractor INTERMEDIATE PIPE FROM PUMP TO DCV	747	87089900	18
300071309ASG	Solis Tractor SUCTION PIPE FROM STRAINER TO HOSE	271	73061929	18
300071666ASG	Solis Tractor RTUG FOR MITA REAR COVER GT	277	87089900	18
300074013ASG	Solis Tractor DV LEVER (UNPAINTED)	82	87089900	18
300074078ASG	Solis Tractor FEATURE STICKER TORQUE 230NM	19	39191000	18
300074358ASG	Solis Tractor HEAD LAMP (RHD) LH BLACK	4241	85122020	18
300074358BSG	Solis Tractor HEAD LAMP (RHD) LH BLACK	4495	85122010	18
300074359ASG	Solis Tractor HEAD LAMP (RHD) RH BLACK	4241	85122020	18
300074359BSG	Solis Tractor HEAD LAMP (RHD) RH BLACK	4495	85122010	18
300074399ASG	Solis Tractor INJECTOR_CRDI (360CC X 7 HOLE)	16092	73182990	0
300074765BSG	Solis Tractor PISTON DIA 107_CR16.5	2016	84099112	28
300075180BSG	Solis Tractor FUEL TANK CAP WITHOUT LOCK	229	87089900	18
300075593BSG	Solis Tractor OIL SCOOP (FORK)	15	87089900	18
300076047ASG	Solis Tractor SUCTION PIPE DIFFERENTIAL TO STRAINER	521	73061929	18
300076364BSG	Solis Tractor PIN ASSY FOR TRAILOR HOOK	608	87089900	18
300076416ASG	Solis Tractor CLAMP ASSY	70	87089900	18
300076437DSG	Solis Tractor FEATHERING VALVE ASSY.	8805	87089900	18
300076837ASG	Solis Tractor POWER STICKER 60 CATEGORY	22	39191000	18
300077453ASG	Solis Tractor FUEL TANK FRAME ASSY	2988	87089900	18
300077453BSG	Solis Tractor FUEL TANK FRAME ASSY	4126	87089900	18
300077981ESG	Solis Tractor REAR COVER PLATE	1014	87089900	18
300078025ASG	Solis Tractor YANMAR SUPERIOR RED	1982	87085000	18
300078027ASG	Solis Tractor TSA MATT BLACK	999	32081090	0
300078380ASG	Solis Tractor FRONT COVER PLATE	120	87089900	18
300078394ASG	Solis Tractor CARTRIDGE-0.6ltr._1F(500hr) F002 H20 364	512	84213990	18
300078425BSG	Solis Tractor CAP RV	135	87089900	18
300078771ASG	Solis Tractor DCV LEVER (UNPAINTTED)	89	87089900	18
300078794ASG	Solis Tractor SCREW RV	55	87089900	18
300081406DSG	Solis Tractor DELIVERY ADOPTER	360	87089900	18
300083197ASG	Solis Tractor FLY-WHEEL DC (IMI)	7582	84835090	18
300083663BSG	Solis Tractor THRUST WASHER	109	73182300	18
300083675BSG	Solis Tractor THRUST WASHER	103	73182300	18
300083757BSG	Solis Tractor STICKER SOLIS CHROME FRONT LH	25	39191000	18
300083764BSG	Solis Tractor STICKER SOLIS CHROME REAR LH	19	39191000	18
300083767BSG	Solis Tractor STICKER SOLIS 5015 LH	49	39191000	18
300083768ASG	Solis Tractor STICKER SOLIS 4015 LH	40	39191000	18
300083770BSG	Solis Tractor STICKER SOLIS 4515 LH	43	39191000	18
300083773BSG	Solis Tractor STICKER SOLIS CHROME FRONT RH	25	39191000	18
300083774BSG	Solis Tractor STICKER SOLIS CHROME REAR RH	19	39191000	18
300083775BSG	Solis Tractor SOLIS BADGE LH	414	39191000	18
300083777BSG	Solis Tractor STICKER SOLIS 5015 RH	55	39191000	18
300083778ASG	Solis Tractor STICKER SOLIS 4015 RH	40	39191000	18
300083781BSG	Solis Tractor STICKER SOLIS 4515 RH	43	39191000	18

300084214ASG	Solis Tractor ROD (FUEL TANK STRAP)	42	87089900	18
300084215BSG	Solis Tractor STICKER SOLIS CHROME FRONT LH	51	39191000	18
300084216BSG	Solis Tractor STICKER SOLIS CHROME REAR LH	66	39191000	18
300084217BSG	Solis Tractor SOLIS BADGE LH	954	39191000	18
300084218BSG	Solis Tractor STICKER SOLIS FRONT RH	51	39191000	18
300084219BSG	Solis Tractor STICKER SOLIS CHROME REAR RH	66	39191000	18
300084220ASG	Solis Tractor BADGE SOLIS RH	954	39191000	18
300084733ASG	Solis Tractor SENSOR WASHER	110	73182990	18
300084733BSG	Solis Tractor SENSOR WASHER	139	87089900	18
300086390BSG	Solis Tractor OIL SEAL (50X68X8)	63	40169330	18
300086593BSG	Solis Tractor AIR CLEANER MTG BKT	232	87089900	18
300087610FSG	Solis Tractor DASHBOARD ASSY RX-FACELIFT TC MAG RED	5952	87089900	18
300087611CSG	Solis Tractor DASHBOARD ASSY MST-FL TC MAG 1ST BC RED	4854	87089900	18
300087611FSG	Solis Tractor DASHBOARD ASSY MST-FACELIFT TC_MAG IST	4823	87085000	18
300087896ASG	Solis Tractor CLUTCH PLATE ASSY.	7589	87089300	18
300088158BSG	Solis Tractor BUSH FOR REAR COVER HOUSING	23	87084000	18
300088177ASG	Solis Tractor CLEVIS SENSOR	331	87084000	18
300088334ASG	Solis Tractor ASSY CLUTCH PADEL LEVER RX	1337	87089900	18
300088334CSG	Solis Tractor ASSY CLUTCH PADEL LEVER RX	1390	87089900	18
300088574ASG	Solis Tractor CLEVIS SENSOR	199	87089900	18
300088574CSG	Solis Tractor CLEVIS SENSOR	271	87089900	18
300089440ASG	Solis Tractor ACTUATOR FORK ASSY RH	80	87089900	18
300089441ASG	Solis Tractor ACTUATOR FORK ASSY LH	80	87089900	18
300089578ASG	Solis Tractor FRONT FLOOR ASSEMBLY	3700	87089900	18
300089579ASG	Solis Tractor FRONT FLOOR ASSEMBLY WITH LESS HUMP	2775	87089900	18
300089732CSG	Solis Tractor PCDC COVER	939	40169990	18
300089732DSG	Solis Tractor PCDC COVER	904	87089900	18
300089763ASG	Solis Tractor AIR INTAKE PIPE	501	40091100	18
300090518ASG	Solis Tractor SENSOR WASHER	132	73181600	18
300090542ASG	Solis Tractor GUIDE BUSH	232	87089900	18
300090570BSG	Solis Tractor FLOOR MOUNTING BRACKET ASSEMBLY LH	998	87089900	18
300090611ASG	Solis Tractor ACTUATOR DRAFT ASSY.	312	87089900	18
300090684DSG	Solis Tractor SENSOR SPRING	893	73201011	18
300090725ASG	Solis Tractor REAR FLOOR ASSY LH	671	87089900	18
300090745ASG	Solis Tractor AIR CLEANER MTG. CLAMP	253	87089900	18
300090745BSG	Solis Tractor AIR CLEANER MTG. CLAMP	304	87089900	18
300090784ASG	Solis Tractor LINK DRAFT	136	87089900	18
300090792ASG	Solis Tractor BRACKET ASSY. SPRING MTG (RX FACELIFT)	218	87089900	18
300091216ASG	Solis Tractor RUBBER BUTTON	17	40161000	18
300091365ASG	Solis Tractor TOOL BOX MTG BRACKET ASSY.	301	87089900	18
300092328ASG	Solis Tractor Steering Wheel CAP_10045744AD	51	87089400	18
300092396ASG	Solis Tractor BONNET GUIDE	20	87089900	18
300092529BSG	Solis Tractor LINK PLATE	27	87089900	18
300092689CSG	Solis Tractor WD09	49	40169990	18
300092775ASG	Solis Tractor CYLINDER HEAD BOLT (M12*1.25X120)	87	73181600	18
300093202ASG	Solis Tractor LIFT ARM PIN	107	87089900	18
300093359ASG	Solis Tractor PIVOT PIN	271	73181500	18
300093500ASG	Solis Tractor BELLOW THROTTLE LEVER	291	40169310	18
300093720ASG	Solis Tractor PTO END COVER	483	87089900	18
300093975ASG	Solis Tractor DASHBOARD HANDLE CAP	11	87089900	18
300094643BSG	Solis Tractor GASKET_EXHAUST	44	84099111	18

300094675BSG	Solis Tractor FUEL FILLER LID ASSY	780	87089900	18
300094687ASG	Solis Tractor OIL SEAL PLATE	180	87089900	18
300094703ASG	Solis Tractor PISTON WITH LKZ OIL RING (GT ENG.)	976	84099113	28
300094704ASG	Solis Tractor PISTON OIL RING LKZ	380	84099912	28
300094845BSG	Solis Tractor LOCK ASSEMBLY	144	87089900	18
300094975ASG	Solis Tractor REAR FLOOR ASSY LH	520	87089900	18
300094975BSG	Solis Tractor REAR FLOOR ASSY LH	1000	87089900	18
300095111ASG	Solis Tractor SPINDLE DENSOR	234	87084000	18
300095388ASG	Solis Tractor STICKER SOLIS 6024 LH	47	39191000	18
300095389ASG	Solis Tractor STICKER SOLIS 6024 RH	47	39191000	18
300096166BSG	Solis Tractor TENSION SPRING	22	73201011	18
300096362BSG	Solis Tractor COVER BEARING HOUSING FRONT	240	87084000	18
300096503ASG	Solis Tractor BEADING FOR RADIATOR SEALING	107	40082990	18
300096585ASG	Solis Tractor INJ. ASSY(E080 3648 00)1549-2mm-NTP	3503	84133010	28
300096821ASG	Solis Tractor TRB 30207	503	84822090	18
300096822ASG	Solis Tractor SPACER	49	87089900	18
300096876ASG	Solis Tractor COOLANT TANK SUPPORT PLATE	68	87089900	18
300097252ASG	Solis Tractor CRANK CASE Assy.(Increase Counter) 3cyl.	31272	87081010	18
300097510ASG	Solis Tractor BOTTOM BEADING	96	40091100	18
300097727BSG	Solis Tractor HEX HEAD SCREW M6X55 8-8 SA4GS	8	73181600	18
300097767ASG	Solis Tractor FOAM SIDE SEALING	9	39201019	18
300097825ASG	Solis Tractor RADIATOR ASSY COWL ID 400	7197	87089100	18
300102708ASG	Solis Tractor BENJO CONNECTION	156	87089900	18
300102852ASG	Solis Tractor SPACER PILOT BEARING	45	87089900	18
300102863ASG	Solis Tractor SPACER FOR BEVEL GEAR Z-27	56	87089900	18
300104155ASG	Solis Tractor REGISTRATION PLATE FRONT	186	83100010	18
300104156ASG	Solis Tractor REGISTRATION PLATE REAR	201	83100010	18
300104458ASG	Solis Tractor C.A.SHAFT ASSYEMBLY	603	87089900	18
300104496ASG	Solis Tractor BOLT SPECIAL FOR STEERING ARM	51	73181500	18
300104763BSG	Solis Tractor FRONT THRESH GUARD SOLIS 26 FACELIFT	334	87089900	18
300105106ASG	Solis Tractor SEC PIPE ASSY PUMP TO DCV P	776	87084000	18
300105455ASG	Solis Tractor PRIMARY PIPE FROM PUMP TO DCV P	594	73061929	18
300105479ASG	Solis Tractor INTERMEDIATE PIPE ASSY FROM PUMP TO	520	73061929	18
300106107ASG	Solis Tractor OIL SCOOP (FORK)	12	87089900	18
300106270BSG	Solis Tractor FLOOR MAT	4138	40161000	18
300106455ASG	Solis Tractor FLEXIBLE PIPE FROM STEERING UNIT TO TANK	771	40091100	18
300106572BSG	Solis Tractor PIPE FROM STEERING UNIT L TO STEERING CY	692	73061929	18
300106626ASG	Solis Tractor OIL SEAL SLINGER	42	87089900	18
300106714ASG	Solis Tractor SECONDARY PIPE ASSY FROM PUMP TO DCV P	798	73061929	18
300106911ASG	Solis Tractor LOCTITE 5900 300ML MAKE-HENKEL	31	35069999	18
300107110CSG	Solis Tractor SIDE CENTER PANEL ASSEMBLY 3 CYL LH	687	87089900	18
300107111CSG	Solis Tractor SIDE CENTER PANEL ASSEMBLY 3 CYL RH	687	87089900	18
300107113CSG	Solis Tractor SIDE CENTER PANEL ASSEMBLY 4 CYL LH	698	87089900	18
300107114ASG	Solis Tractor SIDE CENTER PANEL ASSY. 4CYL RH	578	87089900	18
300107114CSG	Solis Tractor SIDE CENTER PANEL ASSEMBLY 4 CYL RH	698	87089900	18
300107539ASG	Solis Tractor FLOOR MAT SIDE CHROME STRIP ASSY.	306	87089900	18
300107605BSG	Solis Tractor FRONT FLOOR ASSY	3296	87089900	18
300107655ASG	Solis Tractor LIGHT REGISTRATION PLATE ROUND	185	85122010	18
300107769ASG	Solis Tractor REGISTRATION PLATE BRACKET FRONT	13	87089900	18
300107908ASG	Solis Tractor PIPE DCV TO REAR COVER HPCO ASS	770	73061929	18
300107920ASG	Solis Tractor COVER 4WD	392	87089900	18

300107956ASG	Solis Tractor PIPE DCV TO REAR COVER HPCO ASS	681	73061929	18
300108075ASG	Solis Tractor REGISTRATION PLATE BRACKET W/O PAINT	292	87089900	18
300108160ASG	Solis Tractor PTO LEVER ASSY.	278	87089900	18
300109053CSG	Solis Tractor REAR COVER FINISH	12037	73251000	18
300109054CSG	Solis Tractor OIB ASSY RIGHT (3 CYL.)	13028	87081010	18
300109209ASG	Solis Tractor RUBBER BOOT	40	40169310	18
300110179ASG	Solis Tractor RADIATOR COWL ID 400 (W/O PAINT)	538	87089100	18
300110279ASG	Solis Tractor FENDER MTG. BLOCK LH FINISH (FOR OIB)	897	87089900	18
300110283ASG	Solis Tractor FENDER MTG. BLOCK RH FINISH (FOR OIB)	897	87089900	18
300110956ASG	Solis Tractor HEAT GUARD RH	158	87089900	18
300111332BSG	Solis Tractor POWER STEERING COLUMN	3303	87089400	18
300111867ASG	Solis Tractor HOUSING ASSSY POS 1-2-3-4 120219012	19008	87089900	18
300111869ASG	Solis Tractor BRONZINA DU 44/40*40 BUSH 400014000	466	87089900	18
300111872ASG	Solis Tractor BRONZINA BUSH 400018000	305	87089900	18
300111878ASG	Solis Tractor TAPPER PLUG 440149000	55	87089900	18
300111882ASG	Solis Tractor LOCK NUT 310037000	7	87089900	18
300111883ASG	Solis Tractor O'RING D7.6 T1.78 360045000	43	87089900	18
300111884ASG	Solis Tractor PLUG 440281000	247	87089900	18
300111885ASG	Solis Tractor PRESELECTOR KNOB 430028000	140	87089900	18
300111886ASG	Solis Tractor PRE-SELECTOR 120003150	338	87089900	18
300111887ASG	Solis Tractor CONTROL VALVE ASSEMBLY 110144004	14310	87089900	18
300111888ASG	Solis Tractor CRANK 130021050	2467	73250000	18
300111889ASG	Solis Tractor CON ROD 130013040	752	87089900	18
300111890ASG	Solis Tractor PIN 340212000	67	87089900	18
300111891ASG	Solis Tractor GRUB SCREW M8*16 300036000	54	87089900	18
300111892ASG	Solis Tractor ELASTIC PIN 6*40 380024000	60	87089900	18
300111893ASG	Solis Tractor CYLINDER 130030010	2346	87089900	18
300111894ASG	Solis Tractor ALLEN BOLT M12*25 300154000	99	87089900	18
300111896ASG	Solis Tractor PLUG 300052010	187	87089900	18
300111897ASG	Solis Tractor PISTON 130019020	1149	84090000	28
300111898ASG	Solis Tractor LIMIT SWITCH SUPPORT WITH PIN 140005142	737	87089900	18
300111899ASG	Solis Tractor LIMIT SWITCH SUPPORT 140004140	334	87089900	18
300111900ASG	Solis Tractor LIMIT SWITCH LEVER 140006142	669	87089900	18
300111901ASG	Solis Tractor PIN 340593000	108	87089900	18
300111902ASG	Solis Tractor ELASTIC PIN DIA 3*14 380071000	18	87089900	18
300111904ASG	Solis Tractor NUT M8 310076000	25	87089900	18
300111905ASG	Solis Tractor SPRING SEAT 140002210	209	87089900	18
300111906ASG	Solis Tractor SPRING 350060000	55	87089900	18
300111907ASG	Solis Tractor PUSH ROD ASSEMBLY 140007222	537	87089900	18
300111909ASG	Solis Tractor LEVER 140005200	208	87089900	18
300111911ASG	Solis Tractor WHEEL 140082080	147	87089900	18
300111913ASG	Solis Tractor PIN 340106000	48	87089900	18
300111914ASG	Solis Tractor RADIAL CIRCLIP 5MM 330014000	6	87089900	18
300111915ASG	Solis Tractor SUPPORT PIN 340177000	77	87089900	18
300111916ASG	Solis Tractor COMPENSATOR 140024012	990	87089900	18
300111917ASG	Solis Tractor LINK 140013060	88	87089900	18
300111918ASG	Solis Tractor SUPPORT PIN 340161000	179	87089900	18
300111919ASG	Solis Tractor COPPER WASHER 14.5/20*1 320011000	44	87089900	18
300111920ASG	Solis Tractor HUB WITH PIN 340592003	1267	87089900	18
300111921ASG	Solis Tractor ALLEN BOLT M8*20 300064000	42	87089900	18
300111922ASG	Solis Tractor LEVER WITH PIN 140018102	922	87089900	18

300111924ASG	Solis Tractor O'RING 360202000	115	40161000	18
300111925ASG	Solis Tractor CIRCLIP 330011000	29	73182300	18
300111926ASG	Solis Tractor INTERNAL DRAFT LEVER 140038160	379	87089900	18
300111927ASG	Solis Tractor LEVER 140037160	328	87089900	18
300111928ASG	Solis Tractor COPPER WASHER 6.4*10*1 320268000	35	73182300	18
300111929ASG	Solis Tractor RING 320269000	55	40161000	18
300111930ASG	Solis Tractor EXTERNAL CIRCLIP E14 330012000	32	73182300	18
300111931ASG	Solis Tractor FLANGE 150029060	565	87089900	18
300111932ASG	Solis Tractor COVER 150005030	459	87089900	18
300111933ASG	Solis Tractor CAM WITH PIN 150025102	737	87089900	18
300111934ASG	Solis Tractor TIE ROD 150052090	221	87089900	18
300111935ASG	Solis Tractor SCREW 300012010	226	87089900	18
300111936ASG	Solis Tractor NUT M12 310127000	134	87089900	18
300111937ASG	Solis Tractor GROWER D=8.1 DIN 7980-ZINC 32.0001	7	87089900	18
300111938ASG	Solis Tractor GROWER D10.2 DIN 7980 320018000	7	87089900	18
300111939ASG	Solis Tractor PIN 340591000	388	87089900	18
300111940ASG	Solis Tractor SEEGER 330015000	20	87089900	18
300111941ASG	Solis Tractor SPRING D24*46 FILO D7.5 350019000	477	87089900	18
300111942ASG	Solis Tractor BRACKET 150062010	1412	87089900	18
300111943ASG	Solis Tractor BUSH D12.5/35*42.5 40003000	300	87089900	18
300111945ASG	Solis Tractor LOCK NUT 310087000	38	87089900	18
300111946ASG	Solis Tractor POSITION SHAFT 160075090	657	87089900	18
300111947ASG	Solis Tractor O'RING 360202000	49	40169320	18
300111948ASG	Solis Tractor DRAFT TUBE 160058062	1661	87089900	18
300111950ASG	Solis Tractor O'RING 360035000	21	40169320	18
300111951ASG	Solis Tractor LEVER 160180043	948	87089900	18
300111952ASG	Solis Tractor FLANGE ASSEMBLY 160016103	727	87089900	18
300111953ASG	Solis Tractor CONTROL LEVER 160118083	1189	87089900	18
300111954ASG	Solis Tractor SUPPORT 160075010	1268	87081010	18
300111955ASG	Solis Tractor VITE M8*70 SCREW 300267000	118	87089900	18
300111956ASG	Solis Tractor O'RING 360203000	114	87089900	18
300111957ASG	Solis Tractor PLAN WASHER 320024000	11	87089900	18
300111958ASG	Solis Tractor SEEGER E12 330011000	22	87089900	18
300111959ASG	Solis Tractor WASHER 360267000	25	87089900	18
300112020BSG	Solis Tractor DRAFT LEVER	479	87089900	18
300112811ASG	Solis Tractor LEVER ASSEMBLY 4WD	322	87089900	18
300113032ASG	Solis Tractor FOOT STEP RH	680	87089900	18
300113057ASG	Solis Tractor BRACKET ASSEMBLY FENDER AND SEAT MTG. LH	103	87089900	18
300113174ASG	Solis Tractor TIE ROD ASSY IDLER HUB TO INPUT SHAFT HU	50	87084000	18
300113405ASG	Solis Tractor SPACER 50X20X16	41	73181500	18
300113799BSG	Solis Tractor POWER STEERING COLUMN	3025	87089400	18
300114247ASG	Solis Tractor FEATURES STICKER DC AND 24 SPEED	13	39191000	18
300114248ASG	Solis Tractor FEATURES STICKER IPTO AND 24 SPEED	13	39191000	18
300114249ASG	Solis Tractor FEATURES STICKER DC AND 15 SPEED	13	39191000	18
300114293ASG	Solis Tractor MANIFOLD EXHAUST TOP MOUNTED	8233	84099990	28
300114696ASG	Solis Tractor FOOT STEP LH	664	87089900	18
300114857BSG	Solis Tractor FENDER FLAP ASSEMBLY LH W/O PAINT	791	87089900	18
300114862ASG	Solis Tractor SHUTTLE LEVER BRACKET ASSEMBLY	710	87089900	18
300114864ASG	Solis Tractor HUB ASSY INPUT SHAFT	102	87089900	18
300114866ASG	Solis Tractor HUB ASSY IDLER	182	87089900	18
300114869ASG	Solis Tractor HUB ASSY SHUTTLE LEVER	130	87089900	18

300114870BSG	Solis Tractor FENDER FLAP ASSEMBLY RH W/O PAINT	791	87089900	18
300115364ASG	Solis Tractor ACTUATING ROD	47	87084000	18
300115396BSG	Solis Tractor POSITION LEVER	470	87089900	18
300115444ASG	Solis Tractor TIE ROD ASSY CA SHAFT TO HUB	439	87084000	18
300115447ASG	Solis Tractor IDLER HUB ASSEMBLY	369	87089900	18
300115453BSG	Solis Tractor TIE ROD ASSTIE ROD ASSY CA SHAFT TO HUB	443	87084000	18
300115455ASG	Solis Tractor FLOOR ASSY LH	1255	87089900	18
300115455BSG	Solis Tractor FLOOR ASSY LH	7239	87089900	18
300115489ASG	Solis Tractor IPTO LEVER AND HUB ASSY	248	87089900	18
300115503ASG	Solis Tractor SUPPORT BRACKET ASSEMBLY	88	87089900	18
300115520ASG	Solis Tractor FLOOR ASSY RH	1632	87089900	18
300115520BSG	Solis Tractor FLOOR ASSY RH	7170	87089900	18
300115693ASG	Solis Tractor FLOOR MAT	2245	40169340	18
300115693BSG	Solis Tractor FLOOR MAT	2245	39073010	18
300115817ASG	Solis Tractor HEAT GUARD LH	163	87089900	18
300115973ASG	Solis Tractor ACRYLIC SHEET SUPPORT ASSY RH	817	87089900	18
300115974ASG	Solis Tractor ACRYLIC SHEET SUPPORT ASSY LH	826	87089900	18
300116085ASG	Solis Tractor BRACKET ASSEMBLY FENDER AND SEAT MTG. RH	103	87089900	18
300116173ASG	Solis Tractor FENDER SUPPORT BAR ASSY	307	87089900	18
300116189ASG	Solis Tractor SHIELD PLATE RH	190	87089900	18
300116311BSG	Solis Tractor FENDER FLAP ASSEMBLY LH SILVER PAINT	1041	87089900	18
300116312BSG	Solis Tractor FENDER FLAP ASSEMBLY RH SILVER PAINT	1041	87089900	18
300116484ASG	Solis Tractor KNOB ASSY HAND ACCELERATOR	60	87089900	18
300116598DSG	Solis Tractor REAR COVER (FINISH)	12264	87089900	18
300116619ASG	Solis Tractor SHIFTER KNOB DIFFERENT SPEED (12+12)	87	87089900	18
300116621ASG	Solis Tractor SHIFTER KNOB (IPTO)	88	87089900	18
300116649ASG	Solis Tractor FLOOR MOUNTING BRACKET ASSY LH IPTO	1131	87089900	18
300117429ASG	Solis Tractor HEX. BOLT M8X1.25X80 8.8 SA4GS	15	73181600	18
300117623DSG	Solis Tractor TIE ROD IDLER HUB TO TRANSMISSION	159	87089900	18
300117641BSG	Solis Tractor ROCKER LINK ASSY.	1270	87089900	18
300117664BSG	Solis Tractor RADIATOR TOP SEALING PLATE ASSY	345	87089100	18
300117676ASG	Solis Tractor OIL SEAL 60X35X19	544	40169330	18
300117682ASG	Solis Tractor METALLIC SPACER	48	87089900	18
300119070ASG	Solis Tractor FENDER MTG RUBBER PAD	130	40161000	18
300119225ASG	Solis Tractor HOSE AIR CLEANER TO SUCTION PIPE	341	40091100	18
300119657BSG	Solis Tractor BELL HOUSING 3CYL FINISH	14519	87085000	18
300119824ASG	Solis Tractor COVER FOR DUAL PTO	1452	87085000	18
300119833ASG	Solis Tractor CRB (80X35X21)	1061	87089200	18
300119839ASG	Solis Tractor COVER ASSY IPTO LEVER	344	87089900	18
300119840BSG	Solis Tractor IPTO LEVER	340	87089900	18
300119841ASG	Solis Tractor IPTO LEVER GUIDE PLATE	102	87089900	18
300119996ASG	Solis Tractor PLUNGER SWITCH NC	668	85369030	18
300120034ASG	Solis Tractor TIE ROD ASSY (FOR CLUTCH PEDAL)	617	87089900	18
300120342CSG	Solis Tractor T COUPLING	25	87089900	18
300120522ASG	Solis Tractor KNOB FOR PTO LEVER	84	87089900	18
300120528ASG	Solis Tractor KNOB FOR REVERSE PTO	84	87089900	18
300120815ASG	Solis Tractor PLASTIC CAP	12	40161000	18
300120977BSG	Solis Tractor LOWER LINK ASSY.	3445	87089900	18
300121009ASG	Solis Tractor DRIVER SEAT ASSY SOLIS	10464	94012000	18
300121052ASG	Solis Tractor DRIVER SEAT ASSY SOLIS MST	8588	94012000	18
300121079ASG	Solis Tractor KNOB (FUEL CUT OFF) Solis Domestic.	20	87089900	18

300121154ASG	Solis Tractor AXLE ASSY RIGHT	3589	87089900	18
300121163ASG	Solis Tractor KING PIN STUB AXLE ASSY LEFT	3589	87089900	18
300121492ASG	Solis Tractor FENDER ASSY RH RED PAINT	4571	87089900	18
300121495ASG	Solis Tractor FENDER ASSY LH RED PAINT	4616	87089900	18
300121550ASG	Solis Tractor CLUTCH DISC (TRANSMISSION SIDE)_L-03028-	3614	87089300	18
300121566ASG	Solis Tractor PRESSURE PLATE (TRANSMISSION SIDE)_L-021	2328	87089300	18
300121569ASG	Solis Tractor PRESSURE PLATE ASSY (ENGINE SIDE)_L-0210	2942	87089300	18
300121613ASG	Solis Tractor AIR CLEANER MOUNTNG BRACKET ASSY	89	87089900	18
300122186BSG	Solis Tractor ROCKER BASE	566	87084000	18
300122359BSG	Solis Tractor STOPPER ASSY	249	87084000	18
300122411ASG	Solis Tractor IPTO LEVER MTG PLATE ASSY 3 CYL NON ROPS	279	87089900	18
300122496ESG	Solis Tractor RADIATOR ASSY. 4 CYLINDER	12596	87089100	18
300122498ASG	Solis Tractor RADIATOR ASSEMBLY MST	14868	87089100	18
300122498BSG	Solis Tractor RADIATOR ASSY. MST	14868	87089100	18
300122731ASG	Solis Tractor RADIATOR BOTTOM SEALING PLATE ASSY	447	87089900	18
300122743BSG	Solis Tractor POSITION ACTUATOR	259	87089900	18
300122750BSG	Solis Tractor SPACER (POSITION)	39	87089900	18
300122778ASG	Solis Tractor RADIATOR MTG BKT ASSEMBLY W/O PAINT	444	87089900	18
300122808CSG	Solis Tractor SUPPORT ACTUATOR	305	87089900	18
300122828ASG	Solis Tractor HOSE CONNECTOR TO INTAKE MANIFOLD	629	40091100	18
300122836ASG	Solis Tractor PIN	32	87089900	18
300123041DSG	Solis Tractor BRAKE HOUSING LEFT	7087	87087000	18
300123050DSG	Solis Tractor BRAKE HOUSING RIGHT	6421	87087000	18
300123092BSG	Solis Tractor FENDER ASSY RH RED PAINT	7604	87089900	18
300123156ASG	Solis Tractor FLEXIBLE SHAFT ASSY.	94	40091100	18
300123222ASG	Solis Tractor OIB BRAKE ASSY (JMFT)	2792	87083000	18
300123314BSG	Solis Tractor PIN FOR TRAILER HOOK 30 (L167)	304	73182400	18
300123371BSG	Solis Tractor OUTER ROD FOR DRAFT	51	87089900	18
300123396ASG	Solis Tractor MUFFLER ASSY.	3185	87089200	18
300123431CSG	Solis Tractor PLATE ASSY FOR DRAFT	88	87089900	18
300123555ASG	Solis Tractor FEATHERING PIPE INLET	231	73061929	18
300126188ASG	Solis Tractor FLOOR MTG BKT ASSY RH	112	87089900	18
300126192ASG	Solis Tractor FLOOR MTG BKT ASSY LH	84	87089900	18
300126192BSG	Solis Tractor FLOOR MTG BKT ASSY LH	92	87089900	18
300126270BSG	Solis Tractor CAM	301	87089900	18
300126339ASG	Solis Tractor PIN	22	87089900	18
300126643BSG	Solis Tractor SPOOL ACTUATOR ASSY.	63	87089900	18
300126855ASG	Solis Tractor LIFT ARM MACHINING	1381	87089900	18
300126991ASG	Solis Tractor SOLIS S BADGE	574	39191000	18
300127062CSG	Solis Tractor DIFFERENTIAL HOUSING FINISH (2WD REV PTO	53518	73251000	18
300127066CSG	Solis Tractor SLIDING GEAR Z-23 (FINISH NO.)	1799	87084000	18
300127069ASG	Solis Tractor PTO LAY GEAR Z-14	1182	87084000	18
300127090ASG	Solis Tractor THREADED CAP	52	87089900	18
300127113BSG	Solis Tractor IDLER GEAR Z-14 FINISH	593	87084000	18
300127404BSG	Solis Tractor REAR COVER OIB WITH DCV	12744	87089900	18
300127407ASG	Solis Tractor REAR COVER CASTING	10151	73251000	18
300127810ASG	Solis Tractor LIGHT REGISTRATION PLATE ROUND WP	202	85122010	18
300128159BSG	Solis Tractor FRONT AXLE 4WD (CARRARO PORTAL TYPE)	171756	87085000	18
300128180ASG	Solis Tractor RTUG GASKET FOR STEERING COLUMN	105	84841010	18
300128996CSG	Solis Tractor SLIDING GEAR Z-28 (FINISH NO.)	1311	87084000	18
300129260BSG	Solis Tractor PTO LAY GEAR Z-31	1128	87084000	18

300129409ASG	Solis Tractor IDLER SHAFT	363	87089900	18
300129539ASG	Solis Tractor TICKER 5 YEAR WARRANTY	23	39191000	18
300129540ASG	Solis Tractor STICKER YANMAR JAPAN	12	39191000	18
300129541ASG	Solis Tractor SOLIS FEATURE STICKER 4WD LH	36	39191000	18
300129582BSG	Solis Tractor STICKER SOLIS 4215 RH	49	39191000	18
300129584BSG	Solis Tractor STICKER SOLIS 4215 LH	49	39191000	18
300130232BSG	Solis Tractor NYLON SPACER	32	39269099	18
300130287ASG	Solis Tractor DASHBOARD LOWER COVER	818	87089900	18
300130287BSG	Solis Tractor DASHBOARD LOWER COVER-SOLIS GT	622	87089900	18
300130451ASG	Solis Tractor PIN DIFFERENTIAL	96	87084000	18
300130461BSG	Solis Tractor HOUSING INPUT PINION	1641	87085000	18
300130476BSG	Solis Tractor GEAR BEVEL OUTER Z37	3865	87084000	18
300130481BSG	Solis Tractor GEAR BEVEL LOWER Z11	1119	87084000	18
300130482BSG	Solis Tractor COVER (BOTTOM)	204	87089900	18
300130484BSG	Solis Tractor GEAR BEVEL UPPER Z20	1721	87084000	18
300130485BSG	Solis Tractor COVER (TOP)	509	87089900	18
300130486BSG	Solis Tractor GEAR BEVEL INNER Z12	916	87084000	18
300130971CSG	Solis Tractor CRANK POSITION ASSY	134	87089900	18
300131066ASG	Solis Tractor PTO FIXED GEAR Z-28 (FINISH NO.)	1519	87084000	18
300131068ASG	Solis Tractor PTO LAY SHAFT Z-30 (FINISH NO.)	2973	87084000	18
300131286ASG	Solis Tractor NYLON SPACER	21	39269099	18
300131419ASG	Solis Tractor Clutch Plate Assy	8159	87089300	18
300131436BSG	Solis Tractor SPACER FOR PTO OUTPUT SHAFT	61	87089900	18
300131846ASG	Solis Tractor PTO LAY SHAFT Z-28 (FINISH NO.)	2254	87089900	18
300131847ASG	Solis Tractor PTO FIXED GEAR Z-30 (FINISH NO.)	1506	87084000	18
300132751ASG	Solis Tractor FRONT AXLE BRACKET	7648	87081010	18
300132751CSG	Solis Tractor FRONT AXLE BRACKET	8746	87089900	18
300132969ASG	Solis Tractor SHIFTER HOUSING	101796	87084000	18
300132969BSG	Solis Tractor SHIFTER HOUSING	2993	87084000	18
300133082ASG	Solis Tractor SHIFTER HOUSING COVER	1191	87089900	18
300133165ASG	Solis Tractor COVER PLATE GT SIDE SHIFT	72	87089900	18
300134109ASG	Solis Tractor HAND ACCELERATOR ASSY	270	87089900	18
300134109BSG	Solis Tractor HAND ACCELERATOR ASSY	337	87089900	18
300134116ESG	Solis Tractor FUEL TANK FRAME REAR ASSEMBLY 55L	1181	87089900	18
300134177ASG	Solis Tractor PRIMARY SUCTION PIPE	415	73061929	18
300134197ASG	Solis Tractor PIPE DELIVERY PRIORITY VALVE TO REAR COV	454	73061929	18
300134201ASG	Solis Tractor STICKER STEERING WHEEL CAP	35	39191000	18
300134259BSG	Solis Tractor HIGH PRESSURE PIPE 4TH CYL	861	73061929	18
300134263DSG	Solis Tractor DASHBOARD ASSY RX-FACELIFT (TC MAG RED	7423	87089900	18
300134272ASG	Solis Tractor PUSH ROD ASSY. THROTTLE TO MID	50	87084000	18
300134272BSG	Solis Tractor PUSH ROD ASSY. THROTTLE TO MID	49	87089900	18
300134392ASG	Solis Tractor PARKING BRAKE LINK ASSY.	65	87083000	18
300134437ASG	Solis Tractor STEERING WHEEL ASSY.-HST (RED)	1985	87089400	18
300134656ASG	Solis Tractor DRIVER SEAT ASSY. (GT-SOLIS)	7327	94012000	18
300134660ASG	Solis Tractor LEVER ASSEMBLY 12+4	336	87089900	18
300134861ASG	Solis Tractor REAR WHEEL WEIGHT	8706	87087000	18
300135162ASG	Solis Tractor INPUT SHAFT Z15	1944	87084000	18
300135326ASG	Solis Tractor BRACKET ASSY. TELIMATICS UNIT	88	87089900	18
300135367ASG	Solis Tractor LEVER HOLDER FINISH	413	87085000	18
300135400ASG	Solis Tractor PTO LEVER ASSY	428	87089900	18
300135400BSG	Solis Tractor PTO LEVER ASSY	513	87089900	18

300136235ASG	Solis Tractor ACCELERATOR FRONT LINK ASSY.	77	87084000	18
300136235BSG	Solis Tractor ACCELERATOR FRONT LINK ASSY.	54	87089900	18
300136293ASG	Solis Tractor SOLIS FEATURE STICKER LH	44	39191000	18
300136294ASG	Solis Tractor SOLIS FEATURE STICKER RH	34	39191000	18
300136469BSG	Solis Tractor SPACER FOR PTO LAY SHAFT 2.0	50	87089900	18
300136470BSG	Solis Tractor SPACER FOR PTO LAY SHAFT 2.4	55	87089900	18
300136471BSG	Solis Tractor SPACER FOR PTO LAY SHAFT 2.8	53	87089900	18
300136473BSG	Solis Tractor SPACER FOR PTO LAY SHAFT 3.2	53	87089900	18
300136535CSG	Solis Tractor DIFFERENTIAL HOUSING FINISH (4WD REV PTO	53690	73251000	18
300136820ASG	Solis Tractor STICKER 12+4	7	39191000	18
300137252ASG	Solis Tractor DEAD WEIGHT (UNPAINTED)	2400	87081010	18
300137384BSG	Solis Tractor TIE ROD ASSEMBLY 12+4 (WITHOUT	120	87089900	18
300137507ASG	Solis Tractor FRONT LAMP ASSY. LH	1149	85122020	18
300137531ASG	Solis Tractor FRONT LAMP ASSY. RH	1149	85122020	18
300137629ASG	Solis Tractor HOSE AIR CLEANER TO CONNECTOR	215	40092200	18
300137629BSG	Solis Tractor HOSE AIR CLEANER TO CONNECTOR	161	40091100	18
300137654ASG	Solis Tractor AIR CLEANER ASSY DRY (6 ELBOW TYPE)	2711	84213990	18
300137829ASG	Solis Tractor SEAT MTG BKT ASSY	1331	87089900	18
300138156ASG	Solis Tractor INTERMEDIATE HOUSING FOR IHE	170858	87085000	18
300138156BSG	Solis Tractor INTERMEDIATE HOUSING FOR MHI	5549	87085000	18
300138179BSG	Solis Tractor SHIM FOR CENTER BEAM (0.2MM)	14	73182200	18
300138290ASG	Solis Tractor F.I.P TIMING GEAR (LS CRDI)	1061	84834000	18
300138378CSG	Solis Tractor INPUT SHAFT Z25 SOLIS GT26 G081002B (L)	2145	87084000	18
300138707ASG	Solis Tractor SPACER (DRAFT)	42	87089900	18
300138825ASG	Solis Tractor SPACER FOR IDLER SHAFT	227	87089900	18
300138956ASG	Solis Tractor HOSE AIR CLEANER TO CONNECTOR	237	40092200	18
300139133ASG	Solis Tractor SPECIAL BOLT M16 X 1.5	100	73181600	18
300139184BSG	Solis Tractor HIGH PRESSURE PIPE 3RD CYL	580	73182990	18
300139516ASG	Solis Tractor THRUST WASHER FOR IDLER GEAR Z-14	95	73181600	18
300139550ASG	Solis Tractor ECU ASSY MD1CS162(WITHOUT ETK)	16432	73182990	18
300139557ASG	Solis Tractor LINK ASSY	82	87089900	18
300139748BSG	Solis Tractor REAR TAIL LAMP ASSY.LH	1105	85122010	18
300139749BSG	Solis Tractor REAR TAIL LAMP ASSY. RH	1105	85122010	18
300139764CSG	Solis Tractor CYLINDER_¥110_MACHINING	3947	87089400	18
300139855DSG	Solis Tractor SPOOL ACTUATION ASSY.	147	87089900	18
300139875ASG	Solis Tractor PIVOT PIN FOR LINKAGES	65	87089900	18
300140012ASG	Solis Tractor PRIMARY PIPE FROM PRIORITY VAL	291	73061929	18
300140012BSG	Solis Tractor PRIMARY PIPE FROM PRIORITY VAL	291	73061929	18
300140084ASG	Solis Tractor FLEXIBLE PIPE PRIORITY VALVE L	518	40091100	18
300140084BSG	Solis Tractor FLEXIBLE PIPE PRIORITY VALVE L	620	73061929	18
300140112ASG	Solis Tractor BRACKET ASSY SUCTION STRAINER	188	87089900	18
300140138ASG	Solis Tractor CLAMP ASSY. QRC PIPE MTG	19	87089900	18
300140563ASG	Solis Tractor SCREW RIVET	14	73181190	18
300140628ASG	Solis Tractor REGISTRATION PLATE ASSY	226	87089900	18
300140934ASG	Solis Tractor SECONDARY SUCTION PIPE	376	73061929	18
300140949ASG	Solis Tractor BONNET RESTING PLATE ASSEMBLY 2WD	1185	87089900	18
300141536ASG	Solis Tractor BONNET RESTING PLATE ASSEMBLY 4WD	1056	87089900	18
300141550ASG	Solis Tractor FRONT WEIGHT ASSEMBLY SOLIS 4WD	11544	87089900	18
300141677ASG	Solis Tractor PTO SHAFT COVER	44	87085000	18
300141677BSG	Solis Tractor PTO SHAFT COVER	37	87085000	18
300141778BSG	Solis Tractor RUBBER GROMMET RADIATOR SEALING PLATE	19	40169990	18

300141973ASG	Solis Tractor ANGLE BRACKET FUEL TANK FRAME TG	109	87089900	18
300142754ASG	Solis Tractor PIN FOR STABILIZER AND LIFT ARMS	179	73181500	18
300142943ASG	Solis Tractor COVER CENTER SHIFT	871	87089900	18
300142989ASG	Solis Tractor KNOB FOR REVERSE PTO BLACK	76	87089900	18
300143588BSG	Solis Tractor SHIM (BOTTOM COVER)r (T 0.2)	8	73182200	18
300143591BSG	Solis Tractor SHIM TRB PRELOAD 15X24 (0.5MM)	6	73182200	18
300143592BSG	Solis Tractor SHIM TRB PRELOAD 15X24 (0.2MM)	6	73182200	18
300143593BSG	Solis Tractor SHIM TRB PRELOAD 15X24 (0.1MM)	5	73182200	18
300143648BSG	Solis Tractor LOCKING PLATE	20	87089900	18
300143716BSG	Solis Tractor METALLIC SPACER(Ø24.5 X Ø50 X 12)	84	87089900	18
300143724ASG	Solis Tractor FRONT COVER 4WD ASSEMBLY.	516	87089900	18
300143744ASG	Solis Tractor REAR COVER 4WD ASSEMBLY.	447	87089900	18
300143749ASG	Solis Tractor COVER FRONT PTO 4WD	686	87089900	18
300143905ASG	Solis Tractor SEALING HOSE	173	40091100	18
300143960ASG	Solis Tractor INSTRUMENT CLUSTER	3958	90292020	18
300144039ASG	Solis Tractor RTUG GASKET	88	84841010	18
300144351ASG	Solis Tractor BULB HB3 12V 60W_005.635-307	560	85129000	18
300144748ASG	Solis Tractor STUD	28	87089900	18
300145582ASG	Solis Tractor KNOB FOR GT/SOLIS 12+4 ORANGE	79	87089900	18
300145681ASG	Solis Tractor DCV MOUNTING BKT ASSY.	546	87089900	18
300145859ASG	Solis Tractor UNIVERSAL JOINT	2260	73071190	18
300145877ASG	Solis Tractor PTO GUARD ASSY	193	87089900	18
300146016ASG	Solis Tractor STEERING BELLOWS	136	87089400	18
300146041BSG	Solis Tractor INPUT SHAFT Z25 SOLIS	2059	87084000	18
300146045ASG	Solis Tractor HEX HEAD SREW M20X1.5X40	60	73181600	18
300146391ASG	Solis Tractor TOP LINK HOLDING BKT. ASSY	141	87089900	18
300146498CSG	Solis Tractor INNER BUSH ASSY 1	747	87084000	18
300146542BSG	Solis Tractor INNER BUSH ASSY 2 FOR MHI	584	87084000	18
300146665CSG	Solis Tractor HARNESS ASSY	8072	85443000	18
300146970BSG	Solis Tractor UNIVERSAL JOINT COVER LH -SOLIS GT	73	73071190	18
300146973BSG	Solis Tractor UNIVERSAL JOINT COVER RH -SOLIS GT	73	73071190	18
300147155BSG	Solis Tractor HEAD LAMP FRAME SILVER COLOUR	367	87089900	18
300147453ASG	Solis Tractor BRACKET ASSEMBLY FENDER MTG W/	873	87089900	18
300147571ASG	Solis Tractor LUBRICATION PIPE FIP CRDI	223	73182990	18
30014771AASG	Solis Tractor CCC CLUTCH THRUST BRG.	2600	84821020	18
30014772AASG	Solis Tractor CCC CLUTCH THRUST BRG.	1922	84820000	18
300147974ASG	Solis Tractor SOLIS SIDE BRANDING LH	886	83100010	18
300147987ASG	Solis Tractor HIGH PRESSURE PIPE 1ST CYL	868	73061929	18
300147989ASG	Solis Tractor HIGH PRESSURE PIPE 2ND CYL	861	73061929	18
300148602BSG	Solis Tractor REAR COVER OPTION OIB WITH DCV	12233	73251000	18
300149012ASG	Solis Tractor FRONT WEIGHT ASSEMBLY 2WD	10630	87089900	18
300149978BSG	Solis Tractor SENSOR SPINDLE	144	87089900	18
300149978DSG	Solis Tractor SENSOR SPINDLE FO16	180	87089900	18
300150498ASG	Solis Tractor PTO LEVER ASSY	264	87089900	18
300150555ASG	Solis Tractor SHAFT FRONT PTO 4WD ASSY. W/O IPTO 8+2/1	3733	87084000	18
300153187ASG	Solis Tractor BEADING FOR THRASH GUARD	62	40082990	18
300153585ASG	Solis Tractor HOSE FOR 4WD GUARD	135	40092200	18
300153738ASG	Solis Tractor TOOL BOX COVER	885	87089900	18
300153738BSG	Solis Tractor TOOL BOX COVER	1250	87089900	18
300153980ASG	Solis Tractor RADIATOR SIDE BOTTOM BEADING	17	40082990	18
300153980BSG	Solis Tractor RADIATOR SIDE BOTTOM BEADING	16	40161000	18

300154047ASG	Solis Tractor CAGE CARRIER LEFT	609	87085000	18
300154055ASG	Solis Tractor CAGE CARRIER RIGHT	660	87085000	18
300154094CSG	Solis Tractor POSITION LEVER SOLIS	64	87089900	18
300154113ASG	Solis Tractor RADIATOR ASSY RXMM	8711	87089100	18
300154951ASG	Solis Tractor KNOB MAIN GEAR SHIFTER LEVER	89	87089900	18
300155268ASG	Solis Tractor SPEED LEVER ASSY	425	87089900	18
300155650DSG	Solis Tractor KNOB POSITION LEVER)	52	87089900	18
300155965ASG	Solis Tractor IDLER REV GEAR (Z-41) FINISH NO.	1422	87084000	18
300155984ASG	Solis Tractor SOLIS FEATURE STICKER LH	32	39191000	18
300156469ASG	Solis Tractor LOCKING SCREW M8*1	26	73181600	18
300161261ASG	Solis Tractor STICKER SOLIS 5724 LH	47	39191000	18
300161262ASG	Solis Tractor STICKER SOLIS 5724 RH	47	39191000	18
300161330ASG	Solis Tractor FENDER ASSY LH TC MAG IST BC RED PAINT	4649	87089900	18
300161330BSG	Solis Tractor FENDER ASSY LH TC MAG IST BC RED PAINT	8802	87081010	18
300161337ASG	Solis Tractor FENDER ASSY RH TC MAG IST BC RED PAINT	3289	87089900	18
300161337BSG	Solis Tractor FENDER ASSY RH TC MAG IST BC RED PAINT	6981	87089900	18
300161644ASG	Solis Tractor STICKER SOLIS 2516 LH	20	39191000	18
300161646ASG	Solis Tractor STICKER SOLIS 2516 RH	18	39191000	18
300162122ASG	Solis Tractor RUBBER FLAP LH	36	40082990	18
300162140ASG	Solis Tractor RUBBER FLAP RH	36	40161000	18
300162754BSG	Solis Tractor SENSOR SPRING	762	73201011	18
300162817ASG	Solis Tractor SOLIS SIDE BRANDING RH	886	83100010	18
300163144ASG	Solis Tractor SUSPENSION SCREW (OR LOCK BOLT) New	26	87089900	18
300163332ASG	Solis Tractor HYDR. LIFT SEAL KIT	1725	87089900	18
300163353BSG	Solis Tractor STICKER SOLIS BRANDING 4015	9	39191000	18
300163354BSG	Solis Tractor STICKER SOLIS BRANDING 4215	11	39191000	18
300163355BSG	Solis Tractor STICKER SOLIS BRANDING 4515	11	39191000	18
300163357BSG	Solis Tractor STICKER SOLIS BRANDING 5015	11	39191000	18
300163359BSG	Solis Tractor STICKER SOLIS BRANDING 5515	10	39191000	18
300163360BSG	Solis Tractor STICKER SOLIS BRANDING 5724	11	39191000	18
300163460ASG	Solis Tractor RUBBER WASHER 14 X 6.4 X 2	23	40169100	18
300164958ASG	Solis Tractor THERMOSTAT ASSY_31A4605100	2622	84099199	28
300166416DSG	Solis Tractor TAIL PINION & CROWN WHEEL SET	11981	87084000	18
300166597ASG	Solis Tractor GASKET EXHAUST +DOC BT-4	59	73182990	18
300167261ASG	Solis Tractor GROMMET SOLID (RADIATOR FRAME)	38	40161000	18
300167664ASG	Solis Tractor INPUT GEAR Z-43 (FINISH NO.)	1314	87084000	18
300168417ASG	Solis Tractor BONNET TOP LOUVER	211	87089900	18
300169256ASG	Solis Tractor GROMMET FOR FUEL RETURN PIPES	96	40169990	18
300169326ASG	Solis Tractor GROMMET FOR HARNESS	32	40169990	18
300169373ASG	Solis Tractor TOP LINK PIN CAT I	139	87089900	18
300169382ASG	Solis Tractor HEAT SHIELD LH	165	87089900	18
300169383ASG	Solis Tractor HEAT SHIELD RH	149	87089900	18
300169821ASG	Solis Tractor FEATURES STICKER SKY SMART 4D PS	28	39191000	18
300169824ASG	Solis Tractor FEATURE STICKER DC 2000 KGÃ,Ã,Ã	19	39191000	18
300169867CSG	Solis Tractor FRONT AXLE BRACKET (FINISH)	28307	87085000	18
300169868ASG	Solis Tractor COVER PLATE 12+4	399	87089900	18
300169907ASG	Solis Tractor LEVER FOR 12+4	204	87089900	18
300169993ASG	Solis Tractor SPECIAL SCREW 12+4	43	73181600	18
300170171ASG	Solis Tractor FUEL TANK FRAME 65 LTR RX FL	4537	87089900	18
300170175ASG	Solis Tractor FUEL TANK FRAME 55 LTR RX FL	5427	87089900	18
300171112BSG	Solis Tractor LAY SHAFT RANGE Z-26/38/76 (FINISH)	7640	87084000	18

300171507ASG	Solis Tractor KNOB FOR POSITION LEVER	48	87089900	18
300171598ASG	Solis Tractor HYD. PUMP ASSY.-PS (08cc) 2mtg.	5659	84138190	18
300171811ASG	Solis Tractor FLYWHEEL-12" _DC (FOR CRDI)	8169	73182990	18
300172030ASG	Solis Tractor NRB B 26X42X27.5 TMB	512	84824000	18
300172044ASG	Solis Tractor IPDLER REV GEAR Z-25(FINISH)	917	87084000	18
300172107CSG	Solis Tractor ASSEMBLY DIFFERENTIALCASE	4708	87084000	18
300172674BSG	Solis Tractor LEVER ASSY. HI-LOW	277	87089900	18
300173582ASG	Solis Tractor HAND ACC COVER	292	87089900	18
300174049ASG	Solis Tractor GROMMET (HARNESS)	38	40169990	18
300174705BSG	Solis Tractor BUSH 1ST WHEEL (FINISH)	547	87084000	18
300175020ASG	Solis Tractor STICKER DRY FILTER SERVICE	55	39191000	18
300175125BSG	Solis Tractor FUEL PIPE FUEL TANK TO FEED WA-20 WB07	608	87089900	18
300175523ASG	Solis Tractor WASHER FIBRE	15	73182990	18
300175636ASG	Solis Tractor O-RING FOR REAR TRUNION WC22	55	40169330	18
300175969ASG	Solis Tractor HAND ACC LOWER COVER	176	87089900	18
300176031ASG	Solis Tractor Oil Seal 25*35*7(JKFenner)	32	40161000	18
300176222ASG	Solis Tractor SOLIS BADGE RH	414	39191000	18
300176416ASG	Solis Tractor HUB ASSY INPUT SHAFT	131	87089900	18
300176750ASG	Solis Tractor SETTING LINK LH & RH	62	87089900	18
300177178ASG	Solis Tractor STEERING COLUMN BELLOW	270	87089900	18
300177332ASG	Solis Tractor FRONT WHEEL RIM W7X20 (GOLDEN BEIGE)	7734	87087000	18
300177335ASG	Solis Tractor REAR WHEEL RIM W12X28(GOLDEN BEIGE)	14892	87087000	18
300177337ASG	Solis Tractor FRONT WHEEL 5.5FX16(GOLDEN BEIGE)	4415	87087000	18
300177338ASG	Solis Tractor REAR WHEEL W13X28(GOLDEN BEIGE)	17233	87087000	18
300177339ASG	Solis Tractor REAR WHEEL W15LX28(GOLDEN BEIGE)	20691	87087000	18
300177341ASG	Solis Tractor REAR WHEEL W15LX28(GOLDEN BEIGE)	23296	87087000	18
300178559ASG	Solis Tractor BUSH	88	87089900	18
300178802BSG	Solis Tractor HARNESS ASSY	7327	85446090	18
300179262BSG	Solis Tractor HARNESS ASSY	7408	85446090	18
300179263BSG	Solis Tractor HARNESS ASSY	7439	85446090	18
300180062ASG	Solis Tractor SHUTTLE LEVER HUB ASSY DI AND TG	207	87089900	18
300180078ASG	Solis Tractor BRACKET ASSY PIVOT PIN	271	87089900	18
300180486ASG	Solis Tractor FUSE BOX MTG ASSY	110	87089900	18
300180502ASG	Solis Tractor IDLER HUB TIGER ASSY	286	87089900	18
300180568ASG	Solis Tractor PTO IDLER SHAFT	439	87089900	18
300180762ASG	Solis Tractor PISTON ¥110	1433	87089900	18
300180984ASG	Solis Tractor PIPE FROM REAR COVER TO CYL.	212	73061929	18
300180984BSG	Solis Tractor PIPE FROM REAR COVER TO CYL.	510	87089900	18
300181213CSG	Solis Tractor ANGLE BRACKET ASSEMBLY LH	1036	87089900	18
300181215CSG	Solis Tractor ANGLE BRACKET ASSEMBLY RH	1036	87089900	18
300181377CSG	Solis Tractor POSITION LEVER ASSY.	349	87089900	18
300181378ASG	Solis Tractor FLASHER ASSY.	513	85361010	18
300181380CSG	Solis Tractor DRAFT LEVER ASSY.	325	87089900	18
300181619BSG	Solis Tractor SHUTTLE LEVER TIGER	391	87089900	18
300181881ASG	Solis Tractor SLEEVE BIG	495	87084000	18
300181971BSG	Solis Tractor LIFT ROD ASSY.	873	87089900	18
300182001DSG	Solis Tractor RADIATOR COWL RX	621	87089100	18
300182330ASG	Solis Tractor 4 CYL FUEL CUT OFF ROD	81	87089900	18
300182351BSG	Solis Tractor RAM ARM	2209	87089900	18
300182386ASG	Solis Tractor ROCKER LINK_ MACHINING	1446	87085000	18
300183665ASG	Solis Tractor SPACER 3.0MM	28	87089900	18

300183666ASG	Solis Tractor SPACER 1.0 MM	17	87089900	18
300183667ASG	Solis Tractor SPACER 1.1MM	17	87089900	18
300183668ASG	Solis Tractor SPACER 1.2MM	17	87089900	18
300183669ASG	Solis Tractor SPACER 1.3MM	17	87089900	18
300183670ASG	Solis Tractor SPACER 1.4MM	17	87089900	18
300183674ASG	Solis Tractor SPACER 1.5MM	18	87089900	18
300183816ASG	Solis Tractor THREADED SENSOR	110	87084000	18
300183983DSG	Solis Tractor FEATHERING VALVE ASSY FOR MST	10203	84818050	18
300183983ESG	Solis Tractor FEATHERING VALVE ASSY FOR MST	9915	84811000	18
300184114BSG	Solis Tractor SENSOR TUBE	721	87089900	18
300184285CSG	Solis Tractor SPRING FOR DRAFT LEVER	11	73201011	18
300184508ASG	Solis Tractor SEC. PIPE PUMP TO DCV	1634	73061929	18
300184667BSG	Solis Tractor BUSH	27	87089900	18
300184701BSG	Solis Tractor WASHER POSITION LEVER	28	87089900	18
300184795CSG	Solis Tractor COVER INPUT SEAL	191	87084000	18
300184996CSG	Solis Tractor FLOOR MTG BKT ASSY LH	943	87089900	18
300185014CSG	Solis Tractor FLOOR MTG BKT ASSY RH	960	87089900	18
300185724ASG	Solis Tractor DIFFERENTIAL HOUSING (WITHOUT DIFF LOCK)	55324	73251000	18
300185726ASG	Solis Tractor DIFFERENTIAL HOUSING (WITHOUT DIFF LOCK)	56261	73251000	18
300185988ASG	Solis Tractor ADOPTER M16X1.5	80	73071190	18
300186948ASG	Solis Tractor FLOOR ASSY.	6797	87089900	18
300187317BSG	Solis Tractor UJ PROPELLER SHAFT ASSY.	23243	87085000	18
300187317CSG	Solis Tractor UJ PROPELLER SHAFT ASSY.	14695	84835010	18
300187635ASG	Solis Tractor FRONT MTG ASSY FOR FLOOR RH	771	87089900	18
300187635CSG	Solis Tractor FRONT MTG ASSY FOR FLOOR RH	507	87089900	18
300187656ASG	Solis Tractor COWL FOR RADIATOR (TIGER/SOLIS)	522	87089100	18
300187772ASG	Solis Tractor SHIFTER KNOB ASSEMBLY	62	87089900	18
300187802ASG	Solis Tractor FRONT MTG ASSY FOR FLOOR LH	836	87089900	18
300187802CSG	Solis Tractor FRONT MTG ASSY FOR FLOOR LH	603	87089900	18
300188402BSG	Solis Tractor LIFT ARM (FINISH)	1688	87089900	18
300188551ASG	Solis Tractor LIFT ARM RIGHT HAND	1947	87089900	18
300189058BSG	Solis Tractor SPINDLE 4WD - MUD SEALED 8+2 DANA AXLE	2331	87084000	18
300189174BSG	Solis Tractor SPACER ON SPINDLE 4WD	141	87089900	18
300189445ASG	Solis Tractor Hex Head Nut M8 Grade 10 High Tensile	7	73181600	18
300189910ASG	Solis Tractor ALTERNATOR 90AMP FOR BT-IV	10760	85114000	28
300190766BSG	Solis Tractor BUSH FOR 3RD GEAR	330	87084000	18
300190851BSG	Solis Tractor NEUTRAL SAFETY SWITCH	398	85361010	18
300191002BSG	Solis Tractor ENGINE HARNESS BT-IV	5694	73182990	18
300191426BSG	Solis Tractor FLOOR CUSHION	77	40169990	18
300191430ASG	Solis Tractor LEVER COMBINATION SWITCH	1268	85361010	18
300191540ASG	Solis Tractor BUMPER PIPE ASSY RH	481	73061929	18
300191541ASG	Solis Tractor BUMPER PIPE ASSY LH	481	73061929	18
300192819BSG	Solis Tractor RADIATOR COWL ₹440	446	87089100	18
300193055ASG	Solis Tractor LEVER ASSY. PARKING BRAKE	258	87089900	18
300193107ASG	Solis Tractor SPECIAL SCREW M8	15	73181600	18
300193235ASG	Solis Tractor REAR TYRE 8.3-20 MRF SHAKTI LIFE 6PR	12669	40117000	18
300193238ASG	Solis Tractor REAR TUBE 8.3-20MRF TR 218A	1392	40139049	18
300193281ASG	Solis Tractor FRONT TYRE 6-12 MRF SHAKTI PT	5158	40117000	18
300193286ASG	Solis Tractor FRONT TUBE 6-12 MRF TR-15	594	40139049	18
300193288CSG	Solis Tractor INSTRUMENT CLUSTER BT-IV	14717	87089900	28
300193414ASG	Solis Tractor BUMPER PIPE ASSY MIDDLE	866	87089900	18

300193603ASG	Solis Tractor SOCKET HEAD CAP SCREW M5X20 8.8 SA4GS	7	73181600	18
300193683ASG	Solis Tractor HEX. BOLT M10X110-SA4GS	32	73181600	18
300193914BSG	Solis Tractor EXHAUST ASSY.	3274	87089200	18
300194139ASG	Solis Tractor WHEELRIM ASSY(FRONT)5"-20"(GOLDEN BEIGE)	8399	87087000	18
300194308ASG	Solis Tractor SOLIS CHROME REAR LH	111	39191000	18
300194309ASG	Solis Tractor SOLIS CHROME REAR RH	111	39191000	18
300195500ASG	Solis Tractor PTO GUARD ASSY	316	87089900	18
300195741ASG	Solis Tractor INSTRUMENT CLUSTER ASSEMBLY	4668	90292020	18
300195805ASG	Solis Tractor UNIVERSAL JOINT COVER REAR	272	73071190	18
300195861BSG	Solis Tractor TUBE & SIDE COVER ASSY.	1644	87089900	18
300196196ASG	Solis Tractor IPTO STOPPER BKT	71	87089900	18
300196264BSG	Solis Tractor SPRING FOR POSITION LEVER	15	73201011	18
300196547BSG	Solis Tractor SHAFT DRAFT FOR IGUS BUSH	464	87089900	18
300196708ASG	Solis Tractor LOCKING PLATE	71	87089900	18
300197481ASG	Solis Tractor BRACKET FENDER SUPPORT BAR MTG	58	87089900	18
300197496ASG	Solis Tractor BRACKET FENDER SUPPORT BAR MTG	58	87089900	18
300197666ASG	Solis Tractor PIPE EGR COOLER TO EGR VALVE	1275	73061929	18
300198639BSG	Solis Tractor CRANK POSITION ASSY. FOR IGUS BUSH	898	84099941	28
300199164ASG	Solis Tractor SPECIAL HEX HEAD SCREW M8X1.25 - 50	18	73181600	18
300199413ASG	Solis Tractor EXHAUST MANIFOLD	1188	87089200	18
300199621ASG	Solis Tractor SPECIAL HEX HEAD SCREW M8X1.25 - 42	16	73181600	18
300199632ASG	Solis Tractor CONICAL SPRING FOR GEAR SHIFTE	23	87089900	18
300199644ASG	Solis Tractor RADIATOR COWL SEALING FOAM TOP	27	40082990	18
300199710ASG	Solis Tractor RADIATOR COWL SEALING FOAM BOTTOM	28	40082990	18
300199726ASG	Solis Tractor THERMOSTAT ASSY. 85DEG. BT4	1009	84099111	28
300199796ASG	Solis Tractor FRONT RIM ASSY (Golden)	3167	87087000	18
300200273ASG	Solis Tractor 5 AMP BLADE TYPE FUSE	6	87089900	18
300200286BSG	Solis Tractor HOUSING HUB STUB AXLE	1305	87089900	18
300200287ASG	Solis Tractor SHAFT STUB AXLE	1779	87084000	18
300200308ASG	Solis Tractor DOG GEAR ASSY CODE	1085	87084000	18
300200424ASG	Solis Tractor CLUSTER GEAR	1701	87084000	18
300200486ASG	Solis Tractor FLEXIBLE PIPE FROM STG UNIT T	281	73061929	18
300200667CSG	Solis Tractor MOUNTING BRACKET ASSY. 4WD COVER	297	87089900	18
300201044ASG	Solis Tractor PUSH ROD ASSEMBLY	97	87089900	18
300201269ASG	Solis Tractor SHIFTER FORK SHUTTLE	843	87089900	18
300201314ASG	Solis Tractor RING FAN ASSY. 400MM	788	87089100	18
300201502ASG	Solis Tractor Rear RIM ASSY (Golden)	10545	87087000	18
300202099ASG	Solis Tractor TIE ROD ASSY	85	87089900	18
300202193BSG	Solis Tractor STICKER SOLIS S-SERIES	23	39199090	18
300202194BSG	Solis Tractor STICKER SOLIS E-SERIES	19	39199090	18
300202205ASG	Solis Tractor CYLINDER 'f+#90 (FINISH)	3033	87089900	18
300202218ASG	Solis Tractor SHUTTLE LEVER BKT ASSY TG	720	87089900	18
300202417ASG	Solis Tractor FORK M10X1.5 LH	77	87089900	18
300202522ASG	Solis Tractor SOLIS FEATURE STICKER RH WITH TELEMATICS	25	39191000	18
300203204ASG	Solis Tractor Loctite 5900 / 5910_50ml	184	35069999	18
300203205ASG	Solis Tractor Loctite 5188_50ml	647	35069999	18
300203206ASG	Solis Tractor LOCTITE 5060/9060_25GM	218	35069999	18
300203207ASG	Solis Tractor Loctite 518_50ml	531	35069999	18
300203886ASG	Solis Tractor REVERSE IDLER SHAFT	496	87084000	18
300203887ASG	Solis Tractor IDLER GEAR Z-41 FINISH NO.	1586	87084000	18
300205441ASG	Solis Tractor GEAR 1ST WHEEL Z-73 (FINISH NO.)	2930	87084000	18

300205518BSG	Solis Tractor LOWER LINK ASSY	4250	87089900	18
300206280ASG	Solis Tractor TOP LINK ASSY	3379	87089900	18
300207897ASG	Solis Tractor PTO CONNECTING SHAFT (FINISH NO.)	3345	87084000	18
300207898BSG	Solis Tractor PTO OUTPUT SHAFT (FINISH NO.)	1645	87084000	18
300207904ASG	Solis Tractor PTO CONNECTING SHAFT (FINISH NO.)	2866	87084000	18
300207905ASG	Solis Tractor PTO CONNECTING SHAFT (FINISH NO.)	2883	87084000	18
300208954BSG	Solis Tractor PIPE STG UNIT TO STG CYLINDER LH WB14	874	87089900	18
300208955BSG	Solis Tractor PIPE STG UNIT TO STG CYLINDER RH	886	87089900	18
300209112CSG	Solis Tractor TOP LINK ASSY	3615	87089900	18
300214314ASG	Solis Tractor FRONT BUMPER ASSY GORKHA SOLIS / TIGER	12006	87081010	18
300214565DSG	Solis Tractor FORK PTO	490	87089900	18
300217310ASG	Solis Tractor HOSE (RETURN LINE TO THERMOSTAT)	208	40092200	18
300217311ASG	Solis Tractor HOSE (THERMOSTAT TO WATER PUMP)	146	40092200	18
300218228ASG	Solis Tractor FRONT WHEEL RIM W7X18 (GOLDEN BEIGE)	5972	87085000	18
300219286CSG	Solis Tractor 4 CYL FENDER ASSEMBLY NON ROPS LH MST W/	12479	87089900	18
300220093CSG	Solis Tractor 4 CYL FENDER ASSEMBLY NON ROPS RH MST W/	12502	87089900	18
300220140ASG	Solis Tractor PIPE FOR RELEASE VALVE	299	73061929	18
300220522ASG	Solis Tractor POSITION SHAFT	382	87089900	18
300220523ASG	Solis Tractor SHAFT DRAFT	257	87089900	18
300220587ASG	Solis Tractor POSITION LEVER ASSEMBLY	467	87089900	18
300220827ASG	Solis Tractor FIXED GEAR HI Z-22 FINISH	502	87084000	18
300222002ASG	Solis Tractor INTERMEDIATE SHAFT	770	87084000	18
300222223ASG	Solis Tractor SLIDING GEAR Z-33 (1ST / REV) : FINISH	750	87084000	18
300222225ASG	Solis Tractor DRAFT LUG ASSY FOR SOLIS	98	87089900	18
300222225BSG	Solis Tractor DRAFT LUG ASSY FOR SOLIS	71	87089900	18
300222995ASG	Solis Tractor PIPE FROM ADOPTER TO VALVE	390	73061929	18
300223208ASG	Solis Tractor REAR FLOOR COVER MOUNTING BKT	34	87089900	18
300223737ASG	Solis Tractor SUPPORT COVER REAR FLOOR COVER	115	87089900	18
300223762ASG	Solis Tractor LEVER ASSY 4WD	328	87089900	18
300223764ASG	Solis Tractor REAR FLOOR COVER ASSY	584	87089900	18
300225056BSG	Solis Tractor GEAR SHIFTER LEVER FINISH HILOW	774	87089900	18
300225056CSG	Solis Tractor GEAR SHIFTER LEVER HI LOW	729	87089900	18
300225520ASG	Solis Tractor PISTON ASSY ¥76	849	87089900	18
300226060ASG	Solis Tractor BUSH ¥42X¥51	229	87089900	18
300226220ASG	Solis Tractor SEAT MTG BKT ASSY	642	87089900	18
300226317ASG	Solis Tractor SPRING INNER BUSH	14	73201011	18
300229312BSG	Solis Tractor SEAL 32X50X14	260	40169990	18
300230059ASG	Solis Tractor TRUMPET HSG ECO MST (FINISH)	15252	87089900	18
300230194CSG	Solis Tractor 4 CYL FENDER ASSEMBLY NON ROPS LH MST TC	13379	87089900	18
300230195CSG	Solis Tractor 4 CYL FENDER ASSEMBLY NON ROPS RH MST T	13407	87089900	18
300231286ASG	Solis Tractor TUBE ASSY	871	87089900	18
300231815ASG	Solis Tractor IGUS WASHER	32	84834000	18
300232459ASG	Solis Tractor RELIEF VALVE ASSY	314	84811000	18
300232500ASG	Solis Tractor REAR SUPPORT(550390)	5508	87089900	18
300232501ASG	Solis Tractor BUSHING(473097)	2152	87089900	18
300232502ASG	Solis Tractor SEAL(473214)	1315	87089900	18
300232503ASG	Solis Tractor BUSHING(462036)	1930	87089900	18
300232504ASG	Solis Tractor THRUST WASHER(473213)	1218	87089900	18
300232505ASG	Solis Tractor O.RING(28155)	18	87089900	18
300232506ASG	Solis Tractor DIFFERENTIAL SUPPORT(483663)	16138	87089900	18
300232507ASG	Solis Tractor CENTERING BUSH(117270)	37	87089900	18

300232508ASG	Solis Tractor BOLT M12X75(462037)	254	87089900	18
300232509ASG	Solis Tractor MAGNETIC PLUG_143620	491	87089900	18
300232510ASG	Solis Tractor AXLE HOUSING(550392)	21296	87089900	18
300232511ASG	Solis Tractor BOLT M12X45(21258)	101	87089900	18
300232512ASG	Solis Tractor BUSHING(462032)	1621	87089900	18
300232513ASG	Solis Tractor FRONT SUPPORT(550388)	5523	87089900	18
300232514ASG	Solis Tractor OIL DIPSTICK(483686)	362	84213990	18
300232515ASG	Solis Tractor O.RING(28606)	67	87089900	18
300232516ASG	Solis Tractor STEERING CYLINDER(483660)	28234	87089900	18
300232517ASG	Solis Tractor SCREW M14X40(21760)	92	87089900	18
300232518ASG	Solis Tractor SCREW M12X75(453098)	103	87089900	18
300232519ASG	Solis Tractor STEERING ARM ASSY(483672)	3423	87089900	18
300232520ASG	Solis Tractor SEALS KIT(561390)	8949	84213990	18
300232521ASG	Solis Tractor ROD(561392)	11470	84213990	18
300232522ASG	Solis Tractor SNAP RING(561395)	398	84213990	18
300232523ASG	Solis Tractor HEAD(561391)	4478	84213990	18
300232524ASG	Solis Tractor SNAP RING(49149)	398	84213990	18
300232525ASG	Solis Tractor PLUG (21570)	103	87089900	18
300232526ASG	Solis Tractor BEVEL GEAR SET(561307)	17446	87084000	18
300232527ASG	Solis Tractor WASHER(462028)	54	87089900	18
300232528ASG	Solis Tractor COLLAPSIBLE SPACER(462027)	595	87089900	18
300232529ASG	Solis Tractor WASHER(462029)	49	87089900	18
300232530ASG	Solis Tractor LOCKWASHER(462026)	143	87089900	18
300232531ASG	Solis Tractor RING NUT(462025)	719	87089900	18
300232532ASG	Solis Tractor SHIMS KIT 2.40-3.30MM(63412)	1431	73182910	18
300232533ASG	Solis Tractor BEARING(462023)	983	87089900	18
300232534ASG	Solis Tractor BEARING(462024)	844	87089900	18
300232535ASG	Solis Tractor BUSHING(467640)	579	87089900	18
300232536ASG	Solis Tractor OIL SEAL RING(462030)	2098	87089900	18
300232537ASG	Solis Tractor SNAP RING (24779)	16	87089900	18
300232538ASG	Solis Tractor SPLINED SLEEVE(488575)	1052	87085000	18
300232539ASG	Solis Tractor SPACER(483687)	125	87089900	18
300232540ASG	Solis Tractor GEARS DIFFERENTIAL KIT(63505)	9209	87089900	18
300232541ASG	Solis Tractor THRUST WASHER(473096)	173	87089900	18
300232542ASG	Solis Tractor SHAFT(473099)	824	87089900	18
300232543ASG	Solis Tractor COUNTERPLATE(524210)	105	87089900	18
300232544ASG	Solis Tractor LOCKING PLATE(453121)	89	87089900	18
300232545ASG	Solis Tractor RING NUT(462012)	1020	87089900	18
300232546ASG	Solis Tractor BEARING(462019)	625	87089900	18
300232547ASG	Solis Tractor DIFFERENTIAL HOUSING(473210)	3802	87089900	18
300232548ASG	Solis Tractor BOLT M10X40(480238)	55	87089900	18
300232549ASG	Solis Tractor SHAFT(473073)	3448	87089900	18
300232550ASG	Solis Tractor COVER(473212)	1557	87089900	18
300232551ASG	Solis Tractor SNAP RING(473039)	332	87089900	18
300232552ASG	Solis Tractor SHIM MM 0.50(473049)	81	87089900	18
300232553ASG	Solis Tractor SHIM MM 0.40(473050)	75	87089900	18
300232554ASG	Solis Tractor SHIM MM 0.30(473051)	81	87089900	18
300232555ASG	Solis Tractor SHIM MM 0.10(473052)	55	87089900	18
300232556ASG	Solis Tractor SHIM MM 0.05(473053)	49	87089900	18
300232557ASG	Solis Tractor BEARING(25905)	2036	87089900	18
300232558ASG	Solis Tractor GEARS KIT(473023)	7976	87085000	18

300232559ASG	Solis Tractor SCREW M8X20(21115)	18	87089900	18
300232560ASG	Solis Tractor COVER TOP(473037)	1686	87089900	18
300232561ASG	Solis Tractor RH KING PIN HOUSING(521824)	1981	87089900	18
300232562ASG	Solis Tractor LH KING PIN HOUSING(521825)	7189	87089900	18
300232563ASG	Solis Tractor RH SWIVEL HOUSING(521822)	16453	87089900	18
300232564ASG	Solis Tractor LH SWIVEL HOUSING(521823)	12790	87089900	18
300232565ASG	Solis Tractor ROLLER BEARING(473070)	795	87089900	18
300232566ASG	Solis Tractor SEAL(473055)	3001	87089900	18
300232567ASG	Solis Tractor SEAL(473054)	1806	87089900	18
300232568ASG	Solis Tractor O.RING(28216)	35	87089900	18
300232569ASG	Solis Tractor BEARING(521826)	1294	87089900	18
300232570ASG	Solis Tractor BEARING(521827)	1042	87089900	18
300232571ASG	Solis Tractor WASHER(473074)	166	87089900	18
300232572ASG	Solis Tractor RING NUT(473075)	768	87089900	18
300232573ASG	Solis Tractor SHAFT(473028)	3538	87089900	18
300232574ASG	Solis Tractor STRAIGHT BEVEL GEAR Z 12(473026)	1959	87089900	18
300232575ASG	Solis Tractor BEARING(467630)	1008	87089900	18
300232576ASG	Solis Tractor SHIM MM 0.50(473064)	120	87089900	18
300232577ASG	Solis Tractor SHIM MM 0.40(473065)	108	87089900	18
300232578ASG	Solis Tractor SHIM MM 0.30(473066)	122	87089900	18
300232579ASG	Solis Tractor SHIM MM 0.20(473067)	114	87089900	18
300232580ASG	Solis Tractor SHIM MM 0.10(473068)	80	87089900	18
300232581ASG	Solis Tractor SHIM MM 0.05(473069)	72	87089900	18
300232582ASG	Solis Tractor O.RING(28530)	36	87089900	18
300232583ASG	Solis Tractor COVER(473047)	1362	87085000	18
300232585ASG	Solis Tractor WHEEL SHAFT(527169)	8690	87085000	18
300232589ASG	Solis Tractor WHEEL HUB(473040)	5373	87089900	18
300232590ASG	Solis Tractor SCREW(20784)	17	87089900	18
300232591ASG	Solis Tractor BEARING(462017)	1092	87089900	18
300232592ASG	Solis Tractor STRAIGHT BEVEL GEAR(473027)	11929	87089900	18
300232593ASG	Solis Tractor O.RING(28491)	629	87089900	18
300232594ASG	Solis Tractor SHIM MM 0.50(473056)	20	87089900	18
300232595ASG	Solis Tractor SHIM MM 0.40(473057)	19	87089900	18
300232596ASG	Solis Tractor SHIM MM 0.30(473058)	20	87089900	18
300232597ASG	Solis Tractor SHIM MM 0.20(473059)	19	87089900	18
300232598ASG	Solis Tractor SHIM MM 0.10(473060)	16	87089900	18
300232599ASG	Solis Tractor SHIM MM 0.05(473061)	16	87089900	18
300232600ASG	Solis Tractor WASHER(473062)	154	87089900	18
300232601ASG	Solis Tractor ING NUT(473063)	487	87089900	18
300232955BSG	Solis Tractor MTG BKT ASSY FOR MODULAR BOX	109	87089900	18
300233003ASG	Solis Tractor BRACKET FOR QRC	27	87089900	18
300233131CSG	Solis Tractor UNIVERSAL JOINT COVER RH	66	87089900	18
300233588BSG	Solis Tractor LOCKING WASHER	7	73182200	18
300234013ASG	Solis Tractor SPECIAL TYPE SCREW M5	28	73181600	18
300234998ASG	Solis Tractor PIPE ASSY. DCV TO TANK	198	73061929	18
300235197ASG	Solis Tractor SPACER 4MM	60	87085000	18
300237233ASG	Solis Tractor STABLIZER ASSY.	3430	87089900	18
300238747ASG	Solis Tractor OIB BRAKE 3-CYL LH ASSY H	11397	87089900	18
300238748ASG	Solis Tractor OIB BRAKE 3-CYL RH ASSY H	11397	87089900	18
300240335CSG	Solis Tractor UNIVERSAL JOINT COVER LH	66	87089900	18
300240409BSG	Solis Tractor SHAFT LOWER LINK	1510	87089900	18

300240480ASG	Solis Tractor FEATHERING VALVE ASSY	8930	84811000	18
300246434BSG	Solis Tractor BRAKE HOUSING (LEFT)(OIB)	3802	87083000	18
300246435BSG	Solis Tractor BRAKE HOUSING (RIGHT) (OIB)	4210	87083000	18
300246966BSG	Solis Tractor OIB ASSY RIGHT (3 CYL.	12568	87081010	18
300246967BSG	Solis Tractor OIB ASSY LEFT (3 CYL.)	12798	87089900	18
300248554ASG	Solis Tractor PTO GEAR Z-56 FINISH	3227	87084000	18
300248599BSG	Solis Tractor DRIVE SHAFT Z-18 DOUBLE CLUTCH FINISH	3946	87085000	18
300248972BSG	Solis Tractor DRIVE SHAFT Z-18 DUAL CLUTCH FINISH	3796	87084000	18
300248993ASG	Solis Tractor GEAR IDLER PTO Z-26/26 FINISH	1719	87084000	18
300249066ASG	Solis Tractor SUPPORT, FRONT F	3417	87085000	18
300249067BSG	Solis Tractor SUPPORT, FRONT R	4403	87085000	18
300249302ASG	Solis Tractor FRONT WHEEL ASSY.(Golden) DISC W 8*24	13382	87081010	18
300249383CSG	Solis Tractor FRONT AXLE BEAM	12774	87089900	18
300250415ASG	Solis Tractor COVER 4WD DANA AXLE	392	87084000	18
300250416ASG	Solis Tractor NOK OIL SEAL	1752	40169320	18
300251909ASG	Solis Tractor SPINDLE 4WD	2570	87084000	18
300252302BSG	Solis Tractor CASE, FRONT AXLE	14414	87084000	18
300252329CSG	Solis Tractor SPINDLE, FRONT (FINISH)	3163	87089900	18
300252331ASG	Solis Tractor CASE, FRONT BEARING	3488	87085000	18
300252332BSG	Solis Tractor GEAR, FAINAL 49	7405	87084000	18
300252333BSG	Solis Tractor SHAFT, FRONT 2ND (FINISH)	826	87084000	18
300254057BSG	Solis Tractor HARNESS ASSEMBLY	6645	85443000	18
300254581CSG	Solis Tractor HAND ACC LEVER AND BKT ASSY	608	87089900	18
300255335ASG	Solis Tractor LIFT ROD ASSY [o44] BACK	1553	87089900	18
300255340ASG	Solis Tractor LEVELING ROD ASSY [o44] BACK	1958	87089900	18
300256013ASG	Solis Tractor MAIN DISC ASSEMBLY-4P (3CYL)	5221	87089300	18
300256017ASG	Solis Tractor Ø280 DUAL CLUTCH ASSEMBLY (4CYL)	13697	87089300	18
300257082ASG	Solis Tractor TANK UNIT-FLS	845	90268010	18
300257492ASG	Solis Tractor PTO SHAFT	3749	87084000	18
300257516ASG	Solis Tractor MAIN SPINDLE (4WD) LOW COST	2225	87084000	18
300257731ASG	Solis Tractor COVER 4WD (FINISH)	438	87089900	18
300257734ASG	Solis Tractor PTO END COVER (FINISH)	534	87089900	18
300257782ASG	Solis Tractor OIL SEAL 60X35X19	566	40169320	18
300258788ASG	Solis Tractor MAIN SPINDLE 4WD	1877	87085000	18
300260094ASG	Solis Tractor BRACKET FOR MOUNTING	34	87089900	18
300260271BSG	Solis Tractor CWTP ASSY Z-13X32	4469	87084000	18
300260677ASG	Solis Tractor SEAL KIT OF ECO HYD CYL (PS)_10029003BB	1990	87081010	18
300260832ASG	Solis Tractor BAR RELEIF VALVE_600114200033	2070	84814000	18
300260836ASG	Solis Tractor POSITIONER_600114200070	863	84814000	18
300260837ASG	Solis Tractor Lever Group HDM140_600114200045	2070	84814000	18
300260884ASG	Solis Tractor SEAL KIT_600918200424	346	84814000	18
300261157ASG	Solis Tractor TRANSMISSION HOUSING (FINISH)	18128	73251000	18
300261158ASG	Solis Tractor TRANSMISSION HOUSING (FINISH)	23687	87085000	18
300261310BSG	Solis Tractor NEUTRAL SAFETY SWITCH	392	85365090	18
300261498BSG	Solis Tractor FRONT WHEEL (4.5X16)GOLDEN BEIGE	3238	87087000	18
300262030ASG	Solis Tractor BREATHER ASSEMBLY P/N IS 112-01-018-06	915	87089900	18
300262256BSG	Solis Tractor EP STICKER	6	39199010	18
300263961BSG	Solis Tractor GEARBOX, FRONT R	6809	87085000	18
300263973ASG	Solis Tractor CASE, FRONT GEAR R	7993	87085000	18
300263973BSG	Solis Tractor CASE, FRONT GEAR R	9296	87085000	18
300264179ASG	Solis Tractor CASE, FRONT GEAR L	7993	87085000	18

300264179BSG	Solis Tractor CASE, FRONT GEAR L	9296	87085000	18
300264183BSG	Solis Tractor GEARBOX, FRONT L	6809	87085000	18
300265365ASG	Solis Tractor LEVELLING ROD ASSY.	2729	87089900	18
300268255ASG	Solis Tractor FLYWHEEL-11" DC CRDI (RG-329.7)	8323	73182990	18
300268292ASG	Solis Tractor QUAD SEAL ¥29.82X¥2.62	17	40169330	18
300268734CSG	Solis Tractor MTG BKT ASSY ACRYLIC SHEET RH	368	87089900	18
300268736CSG	Solis Tractor MTG BKT ASSY ACRYLIC SHEET LH	370	87089900	18
300268813ASG	Solis Tractor CAGE ASSY (WITHOUT DIFF LOCK)	6102	73251000	18
300270079ASG	Solis Tractor IPTO GUIDE PAD	48	87089900	18
300270774ASG	Solis Tractor IPTO GUIDE PAD	45	87089900	18
300270893ASG	Solis Tractor IPTO GUIDE PLATE	189	87089900	18
300271558CSG	Solis Tractor AIR INTAKE PIPE	426	87089900	18
300272122ASG	Solis Tractor O-RING Ø90.6XØ5.7	37	40169320	18
300272128ASG	Solis Tractor CASSETTE SEAL (35 X 56 X 12) FOR PADDY F	1935	87084000	18
300273191BFG	Solis Tractor REAR WHEEL RIM W13X28 GOLDEN BIEGE	17685	84213990	18
300273191BSG	Solis Tractor REAR WHEEL RIM W13X28 GOLDEN BIEGE	17685	84213990	18
300276517ASG	Solis Tractor PTO SHIFTER COVER FINISH	575	87084000	18
300278056ASG	Solis Tractor RADIATOR BOTTOM SEALING PLATE (W/O PAINT	799	87089900	18
300278627ASG	Solis Tractor FOAM RADIATOR SEALING	87	87089900	18
300278666ASG	Solis Tractor RADIATOR TOP BEEDING	165	40091100	18
300278691ASG	Solis Tractor RADIATOR BOTTOM SEALING PLATE (W/O PAINT	391	87089900	18
300278695ASG	Solis Tractor BEADING FOR RADIATOR SEALING	145	40091100	18
300279775ASG	Solis Tractor STICKER SOLIS BRANDING 4015	31	39199010	18
300279778ASG	Solis Tractor STICKER SOLIS BRANDING 4215	31	39199010	18
300279779ASG	Solis Tractor STICKER SOLIS BRANDING 4415	31	39199010	18
300279788ASG	Solis Tractor STICKER SOLIS BRANDING 5015	31	39199010	18
300279802ASG	Solis Tractor STICKER SOLIS BRANDING 6024	31	39199010	18
300280710ASG	Solis Tractor SPACER FOR PTO OUTPUT SHAFT	61	87089900	18
300280899ASG	Solis Tractor RUBBER GROMMET	36	40169990	18
300281367ASG	Solis Tractor SIDE FOAM RH	143	39211310	18
300281563BSG	Solis Tractor MAIN INPUT GEAR (Z-55) (FINISH)	1983	87084000	18
300281840BSG	Solis Tractor 3 CYL BOTTOM SEALING PLATE 2WD W/O PAI	329	87089900	18
300282309ASG	Solis Tractor FOAM	11	39211310	18
300282383BSG	Solis Tractor INPUT SHAFT (Z-19) LH DUAL CLUTCH (FINIS	2717	87084000	18
300282574BSG	Solis Tractor 3 CYL BOTTOM SEALING PLATE 4WD W/O PAI	261	87089900	18
300283433ASG	Solis Tractor SIDE FOAM LH	143	39211310	18
300283512BSG	Solis Tractor 4 CYL BOTTOM SEALING PLATE 2WD	544	87089900	18
300283513BSG	Solis Tractor 4 CYL BOTTOM SEALING PLATE 4WD	394	87089900	18
300283869ASG	Solis Tractor PTO SHAFT (FINISH)	1025	87084000	18
300283873ASG	Solis Tractor LOCKING PLATE	118	87089900	18
300284130BSG	Solis Tractor INPUT SHAFT (Z-19) DOUBLE CLUTCH (FINISH	2873	87084000	18
300284743ASG	Solis Tractor SHIFTER FORK 1ST/REVERSE (FINISH)	501	87089900	18
300284745ASG	Solis Tractor SHIFTER FORK 2ND/3RD (FINISH)	501	87089900	18
300286472ASG	Solis Tractor SHUTTLE KIT For SPD	10585	87081010	18
300287667ASG	Solis Tractor O-RING DIA. 77X DIA. 2.62	20	40169330	18
300287674ASG	Solis Tractor O-RING DIA. 97X DIA. 2.62	27	40169330	18
300287688ASG	Solis Tractor O-RING DIA. 173 X DIA. 2.62	33	40169330	18
300287693ASG	Solis Tractor O-RING DIA. 106 X DIA. 2.62	27	40169330	18
300288651ASG	Solis Tractor MUFFLER ASSY	1593	87089200	18
300288813ASG	Solis Tractor LOWER LINK ASSY	4487	87089900	18
300289341BSG	Solis Tractor MUFFLER ASSY	3131	87089200	18

300289341CSG	Solis Tractor MUFLER ASSY	2254	87089200	18
300290178ASG	Solis Tractor HOUSING AXLE KING SHAFT	3722	73251000	18
300290673ASG	Solis Tractor EXAUST PIPE ASSY	1286	87089900	18
300290691ASG	Solis Tractor SHAFT KING PIN	773	87084000	18
300291000ASG	Solis Tractor BRONZE BUSH 57X67X42	1426	87089900	18
300291014ASG	Solis Tractor NYLON SPACER 58X66X15	29	87089900	18
300293581ASG	Solis Tractor T-ASSY FOR SOLIS 24 HST EPA	338365	87081010	18
300294790ASG	Solis Tractor UJ Kit Sub Assy Ref.-300187317C	2305	87084000	18
300295034ASG	Solis Tractor DRAG LINK ASSY	1291	87089400	18
300296917ASG	Solis Tractor INPUT CONNECTING SHAFT	1480	87084000	18
300298172BSG	Solis Tractor FEATHERING VALVE ASSY (OIB)	8853	87089900	18
300299123ASG	Solis Tractor AIR INTAKE PIPE MOUNTING ASSEMBLY	198	87089900	18
300300743ASG	Solis Tractor GUIDING RING	97	87089900	18
300300751ASG	Solis Tractor GLYDING RING	100	87089900	18
300300754ASG	Solis Tractor RUBBER RING	21	87089900	18
300302288ASG	Solis Tractor MIDDLE BAR 3 CYL	55	87089900	18
300302290ASG	Solis Tractor FRONT BAR	90	87089900	18
300302855BSG	Solis Tractor MIDDLE BAR 4 CYL	68	87089900	18
300303005ASG	Solis Tractor DCV KIT UNIT	18734	87089900	18
300303131ASG	Solis Tractor FRONT WEIGHT MTG. ASSY.	2753	87089900	18
300303367ASG	Solis Tractor C.A FORK PTO FOR DOUBLE CLUTCH FINISH	875	87089900	18
300303395ASG	Solis Tractor REAR BAR	90	87089900	18
300303633BSG	Solis Tractor STICKER FOR WARNING JAPANESE LANGUAGE	18	39199010	18
300303634BSG	Solis Tractor STICKER FOR DRY CLEANER JAPANESE LANG.	42	39199010	18
300303635BSG	Solis Tractor STICKER MAGNETIC STRAINER JAPANESE LANG.	10	39199010	18
300303638ASG	Solis Tractor STICKER OK FILTER JAPANESE LANG YELLOW	3	39199010	18
300304330ASG	Solis Tractor 1DA DCV ASSY	5188	84818090	18
300304331ASG	Solis Tractor 1SA DCV ASSY	3326	84818090	18
300304332ASG	Solis Tractor 1DA DCV ASSY	5261	84818090	18
300304582ASG	Solis Tractor 4WD ACTUATOR ROD RT	283	87089900	18
300305117ASG	Solis Tractor RELIEF VALVE ASSY.	287	84811000	18
300305307ASG	Solis Tractor ANTIRUST COOLING AGENT ORGANIC ADDITIVES	241	38200000	18
300305456ASG	Solis Tractor STICKER OK FILTER JAPANESE LANG GREEN	3	39199010	18
300307457ASG	Solis Tractor AIR CLEANER MTG. CLAMP	289	87089900	18
300308235ASG	Solis Tractor PTO SHIFTER COVER (FINISH)	964	87084000	18
300309820BSG	Solis Tractor SHIFTER ROD HI	404	87084000	18
300312097ASG	Solis Tractor CLUSTER SOLIS	5250	87089900	28
300312221ASG	Solis Tractor BRAKE HUB ASSY RH-BIMETALIC	755	87089900	18
300312224ASG	Solis Tractor LOWER LINK ASSY_LH_T SECTION_1420H	3010	87089900	18
300312269ASG	Solis Tractor BRAKE HUB ASSY LH-BIMETALIC	877	87089900	18
300312274ASG	Solis Tractor REAR HUB ASSY RH-BIMETALIC	739	87089900	18
300312571ASG	Solis Tractor Radiator Cowl Plastic - 430 mm	351	84213990	18
300312876ASG	Solis Tractor RUBBER CAP(18105-B)_300224694A	16	84213990	18
300313737ASG	Solis Tractor FENDER SEAT GUARD WITHOUT SLEEVE	867	87089900	18
300316151ASG	Solis Tractor SLEEVE G PTO (FINISH)	1000	87084000	18
300317120ASG	Solis Tractor FRONT RIM ASSY(GOLDEN) (IN)	2148	87087000	18
300318579ASG	Solis Tractor PIN FOR STAY BAR ASSY	289	87089900	18
300318609BSG	Solis Tractor SHIM FA WHEEL END 0.5	15	73182200	18
300318708ASG	Solis Tractor SHIFTER LEVER ASSY.	616	87089900	18
300320600ASG	Solis Tractor LOWER LINK ASSY_RH_T SECTION_1420H	3010	87089900	18
300330101ASG	Solis Tractor LIFT ROD ASSY_3CYL_W/O ADDITIONAL HOLE	1554	87089900	18

300330102ASG	Solis Tractor LEVELLING ROD ASSY_3 CYL_W/O ADD. HOLE	2179	87089900	18
300330356ASG	Solis Tractor LOCKING PIN	21	87089900	18
300330501ASG	Solis Tractor DOOR HANDLE ASSY RH	1949	87089900	18
300331452ASG	Solis Tractor HARNESS ASSY. 3CYL SOLIS WITH DRL	7106	85443000	18
300335129ASG	Solis Tractor HYDRAULIC FILTER	634	84212300	18
300335201ASG	Solis Tractor BALL BEARING 6205CNR	231	84821020	18
300335592BSG	Solis Tractor SHIM FA WHEEL END 0.1	7	73182200	18
300335593BSG	Solis Tractor SHIM FA WHEEL END 0.15	8	73182200	18
300335595BSG	Solis Tractor SHIM FA WHEEL END 0.2	9	73182200	18
300336102ASG	Solis Tractor BUSH, 91X96X25	314	84833000	18
300337207ASG	Solis Tractor SHIFTER ROD LOW MEDIUM	403	87089900	18
300338152ASG	Solis Tractor FRONT BAR 4CYL	134	87089900	18
300338159ASG	Solis Tractor REAR BAR 4CYL	134	87089900	18
300340142BSG	Solis Tractor BEARING COVER	253	87085000	18
300340221ASG	Solis Tractor PINION, FINAL 11	1026	87089900	18
300340252ASG	Solis Tractor TRB 33207_35X72X28	687	84821090	18
300340294BSG	Solis Tractor COLLAR, 68X72X5.0	48	87089900	18
300340301BSG	Solis Tractor COLLAR, 68X72X5.1	51	87089900	18
300340306BSG	Solis Tractor COLLAR 62.5X70.5X5.75	69	87089900	18
300340600ASG	Solis Tractor SPACER, SEAL DRIVE	298	87089900	18
300340655ASG	Solis Tractor WASHER, 72X91X1.6	74	73181900	18
300341121ASG	Solis Tractor UNIVERSAL JOINT ASSY (FRONT AXLE 4WD) AK	20876	87085000	18
300341689ASG	Solis Tractor INTERNAL CIRCLIP B-72 H	45	73182910	18
300341697ASG	Solis Tractor BUSH 33X28X30	145	84833000	18
300342815ASG	Solis Tractor FRONT LAMP LH	1073	85122020	18
300342816ASG	Solis Tractor FRONT LAMP RH	1073	85122020	18
300342817ASG	Solis Tractor TAIL LAMP LH	1073	85122020	18
300342818ASG	Solis Tractor TAIL LAMP RH	1073	85122020	18
300343182ASG	Solis Tractor SEAL KIT OIPL_10028583AA	4145	87085000	18
300343289BSG	Solis Tractor COLLAR, 68X72X4.8	48	87089900	18
300343291BSG	Solis Tractor COLLAR, 68X72X4.9	48	87089900	18
300343296BSG	Solis Tractor COLLAR, 68X72X5.2	50	87089900	18
300343333ASG	Solis Tractor SEAL KIT Rane_10028583AA	3098	87085000	18
300343343ASG	Solis Tractor SEAL KIT OIPL_10008355BA	3189	87085000	18
300345732ASG	Solis Tractor BONNET SIDE SEALING PLATE LH W/O PAINT	177	87089900	18
300345735ASG	Solis Tractor BONNET SIDE SEALING PLATE RH W/O PAINT	177	87089900	18
300345857ASG	Solis Tractor RUBBER FLAP 3CYL 4WD	88	40169990	18
300346245ASG	Solis Tractor BONDED SEAL M14 ENGINE DIV. ONLY	18	40169330	18
300346249ASG	Solis Tractor BONDED SEAL M18 ENGINE DIV. ONLY	20	40169330	18
300346479ASG	Solis Tractor BONNET TOP SEALING FOAM	133	87089900	18
300347363ASG	Solis Tractor RUBBER FLAP 4CYL 2WD	139	40169990	18
300347386ASG	Solis Tractor RUBBER FLAP 3CYL 2WD	103	40169990	18
300347397ASG	Solis Tractor RUBBER FLAP 4CYL 4WD	93	40169990	18
300347884ASG	Solis Tractor HEX FLANGE NUT M16X1.5	32	73181600	18
300348203ASG	Solis Tractor Sealing Kit 3 Cyl.	1574	40169980	18
300349464ASG	Solis Tractor ASSY PROTECTION GUARD 4 CYL LH	348	87089900	18
300349478ASG	Solis Tractor ASSY PROTECTION GUARD 4 CYL RH	312	87089900	18
300349495ASG	Solis Tractor ASSY PROTECTION GUARD 3 CYL RH	245	73181600	18
300349496ASG	Solis Tractor ASSY PROTECTION GUARD 3 CYL LH	275	87089900	18
300350241ASG	Solis Tractor SPACER	80	87089900	18
300350319ASG	Solis Tractor ECU DASHBOARD HARNESS	11043	85443000	18

300351705ASG	Solis Tractor LOCK PLATE	20	87089900	18
300352336ASG	Solis Tractor SLEEVE FOR LOW Z-25	1260	87084000	18
300352871ASG	Solis Tractor WIRE FOOT THROTTLE BT IV	241	87083000	18
300355671ASG	Solis Tractor Dummy Stub Axle L.H.S	21717	87081010	18
300355672ASG	Solis Tractor Dummy Stub Axle R.H.S	21717	87081010	18
300355768ASG	Solis Tractor DCV PLATE	735	87089900	18
300356898ASG	Solis Tractor HOSE ASSY	1408	87089900	18
300358190ASG	Solis Tractor DCV	3609	84818090	18
300358397ASG	Solis Tractor SEAL KIT OIPL_300040375A / 300005290B	2424	87085000	18
300358416ASG	Solis Tractor SEAL KIT Rane_10052959BA	1910	87085000	18
300358432ASG	Solis Tractor SEAL KIT Rane_10008355AD/BA	2528	87085000	18
300358435ASG	Solis Tractor SEAL KIT DHPL_10008355BA	3604	87085000	18
300358436ASG	Solis Tractor SEAL KIT DHPL_10029003BB	2201	87085000	18
300359433ASG	Solis Tractor CIRCLIP 50X3 H IS:3075 (PART-1)	38	73182910	18
300361946ASG	Solis Tractor PIN_499144	109	73182990	18
300362094ASG	Solis Tractor LEVER KIT CLUTCH PTO_L-02615-1042-00	1770	87089300	18
300363580ASG	Solis Tractor COVER (BOTTOM WINDOW)	591	87084000	18
300365452ASG	Solis Tractor PISTON RING SET (DIA-105)	720	84099941	28
300365455ASG	Solis Tractor PISTON/PIN/CIRCLIP-SET (DIA-105)	3056	84099913	28
300370326ASG	Solis Tractor PISTON RING-SET (DIA-105)	719	84099913	28
300370335ASG	Solis Tractor PISTON/PIN/CIRCLIP-SET (DIA-105)	2735	84099913	28
300370969ASG	Solis Tractor RADIATOR ASSY 5 FPI	7506	87089100	18
300370974ASG	Solis Tractor RADIATOR ASSY. 5 FPI GT 22-1390	7821	87089100	18
300370981ASG	Solis Tractor RADIATOR ASSY. 5 FPI RX-50	9104	87089100	18
300372626ASG	Solis Tractor TIE ROD ASSY DIA 40	2287	87089900	18
300372627ASG	Solis Tractor SELF LOCKING NUT	49	87089900	18
300373455ASG	Solis Tractor DOUBLE CLUTCH COVER ASSY.	16540	87089900	18
300376201ASG	Solis Tractor STIFFENER FOR BOTTOM PLATE	114	87089900	18
300378473ASG	Solis Tractor Dummy For Bumper	16723	87089900	18
300380985ASG	Solis Tractor CUP FACE SEAL (KNUCKLE)-10168818	501	87081010	18
300382082ASG	Solis Tractor INPUT SHAFT Z-19 (FINISH)	2725	87084000	18
300384473ASG	Solis Tractor CRANK CASE Assy.(Increase Counter) 3cyl.	1334	87081010	18
300401988ASG	Solis Tractor 3 CYL BONNET ASSEMBLY WITH TOP MESH RED	15533	87089900	18
300405801ASG	Solis Tractor GASKET, THERMOSTAT_31N4600500	243	84099990	28
300405805ASG	Solis Tractor BASE FRAME ASSY.FRONT MUDGUARD RH	74	87089900	18
300412535ASG	Solis Tractor STOPPER BOLT ROUND HEAD M12X1.75X35	29	73181500	18
300413702ASG	Solis Tractor STUB AXLE LH	38778	87084000	18
300413856ASG	Solis Tractor STUB AXLE RH	38250	87084000	18
300416325ASG	Solis Tractor Radiator sealing kit – SN series	7520	87089900	18
300419192ASG	Solis Tractor DIPSTICK	147	87085000	18
300424077ASG	Solis Tractor SOLIS 3CYL 2WD	3387	87089900	18
300424078ASG	Solis Tractor SOLIS 3CYL 4WD	2218	87089900	18
300424079ASG	Solis Tractor SOLIS 4CYL	2446	87089900	18
300424080ASG	Solis Tractor SOLIS 4CYL 4WD MST	2656	87089900	18
300445334ASG	Solis Tractor RELIEF VALVE ASSY.	287	87089900	18
300445823BSG	Solis Tractor PLUG M8X1	15	87089900	18
300493396ASG	Solis Tractor FAN ASSY Ø350 (8 BLADE PLASTIC) - GT	410	87089900	28
33085038AASG	Solis Tractor PLASTIC STRAP LENGTH=390MM	32	39261011	18
40000529AASG	Solis Tractor Gasket for Exhaust Linking Tube-IVECO ENG	19	84841010	18
40000735BCSG	Solis Tractor HYD.HOSE FROM RIGID PIPE TO R.H STR. CYL	609	40091100	18
40000741AASG	Solis Tractor CCC Steering unit	20948	87089400	18

400402016ASG	Solis Tractor SIDE COVER (Almn.) 4 cyl.	426	87089900	18
41000738AASG	Solis Tractor VACCUATOR VALVE	85	84213990	18
41000739AASG	Solis Tractor ELEMENT ASSEMBLY, PRIMARY	745	84213990	18
41000740AASG	Solis Tractor ELEMENT ASSEMBLY, SAFETY	467	84213990	18
41000745AASG	Solis Tractor ELEMENT ASSEMBLY, PRIMARY	1442	84213990	18
41000746AASG	Solis Tractor ELEMENT ASSEMBLY, SAFETY	979	84213990	18
41571-050000-1S	Solis Tractor NUT, FLANGE M5	2	73181600	18
41571-060420-0S	Solis Tractor NUT, M6	2	73181600	18
41571-080000-1S	Solis Tractor NUT, FLANGE M8	4	73181600	18
41571-080000-2S	Solis Tractor NUT, FLANGE M8	4	73181600	18
41571-080420-0S	Solis Tractor NUT, M8	3	73181600	18
41571-120000-2S	Solis Tractor NUT, FLANGE M12	13	73181600	18
41573-020000-1S	Solis Tractor CLIP, HOSE 20	8	73181500	18
41574-030100-1S	Solis Tractor KEY, 3 X 10	5	87089900	18
41575-120350-1S	Solis Tractor BOLT, M12X35	26	73181600	18
41575-120450-1S	Solis Tractor BOLT ,M12X45	28	73181600	18
41575-140500-1S	Solis Tractor BOLT ,M14X50	79	73181500	18
41586-120300-1S	Solis Tractor BOLT, M12X30 FINE	30	73181600	18
603401001ESG	Solis Tractor FRONT BEARING CAP	544	84830000	18
603401002CSG	Solis Tractor CENTRE BEARING CAP	435	84833000	18
603401003ESG	Solis Tractor REAR BEARING CAP	541	84830000	18
603403002ASG	Solis Tractor Conn.rod-SMALL END BUSH	125	84833000	18
603404002DSG	Solis Tractor GEAR LINING	223	84834000	18
700401036ASG	Solis Tractor OIL INDICATOR ENG.(4 CYL.)	31	87089900	18
700401096ASG	Solis Tractor PLUG OIL GALLERY (MUV ENG.)	18	73182300	18
700402005ASG	Solis Tractor GROMMET	11	40161000	18
700402006CSG	Solis Tractor GASKET_(side cover_Almn) 2 & 4cyl.	68	84841010	18
700402060BSG	Solis Tractor SIDE BAR (3 Holes-~10.5)	50	84099111	28
700402172GSG	Solis Tractor OIL PAN 4cyl. (Sheet Metal-1.5 Thick)	1613	87089900	18
700402214ASG	Solis Tractor GASKET (OIL PAN-4 CYL.) NON ASB.	269	84841090	18
700402243ESG	Solis Tractor OIL PAN 4cyl. (Sheet Metal) For CARRARO	1782	84099111	28
700402243FSG	Solis Tractor OIL PAN 4CYL. (SHEET METAL) FOR CARRARO	2215	84099111	28
700403095ISG	Solis Tractor FLY WHEEL-D.C (118ST.) FOR CARRARO	7605	84834000	18
700404060ISG	Solis Tractor CAM SHAFT Ø42 (4cyl.)	3518	84831099	18
700405164FSG	Solis Tractor Return Line (4cyl.) uh	1192	76169990	18
700405278ASG	Solis Tractor INLET MANIFOLD 4cyl-TC (Almn.) coldstart	2933	87089900	18
700405284ASG	Solis Tractor EXHAUST FLANGE_Rx (4cyl.) EGR_U/H	2992	87089200	18
700405284GSG	Solis Tractor EXHAUST FLANGE_U/H (4cyl.-TC) EGR	2992	87089200	18
700405286FSG	Solis Tractor EXHAUST FLANGE_RX (4CYL.-NA) EGR	2722	87089200	18
700406102CSG	Solis Tractor Water HOSE_L-type (Heat Exch.)	72	40091100	18
700406103ASG	Solis Tractor W. HOSE_straight (EGR) OUTLET_Reinforced	65	40091100	18
700407001BSG	Solis Tractor DELIVERY PIPE ASSY. (4 CYL)	213	87081010	18
700407017BSG	Solis Tractor CENTERING GUIDE	22	87089900	18
700407037CSG	Solis Tractor GASKET_OIL FILTER (4 cyl.)	17	84841010	18
700408113DSG	Solis Tractor HIGH PRESSURE PIPE(Ø1.8XØ6X500)3RD.	353	87089900	18
700414061ASG	Solis Tractor PIPE_Exhaust Manifold to EGR-U/H (TC_Rx)	423	84099111	28
700414062ESG	Solis Tractor INLET PIPE_Inlet manifold(U/H-TL)EGR 4cy	898	87081010	18
700414069BSG	Solis Tractor GASKET_EGR VALVE INLET (CRDI) PADMANI	20	84849000	18
700414070BSG	Solis Tractor GASKET_EGR VALVE OUTLET(CRDI)PADMANI	21	84841090	18
703001037BSG	Solis Tractor OIL INDICATOR ENG.(3 CYL.)	38	87089900	18
703001068BSG	Solis Tractor MAIN BEARING LINER TOP	79	84839000	18

703001069ASG	Solis Tractor MAIN BEARING LINER_BOTTOM	79	84839000	18
703001076ASG	Solis Tractor THRUST BEARING BOTTOM	321	84833000	18
703001085CSG	Solis Tractor BEARING CAP-CENTRE M/C	588	87081010	18
703001088BSG	Solis Tractor BEARING CAP-FRONT M/C	602	87081010	18
703001089DSG	Solis Tractor BEARING CAP-CENTRE-THRUST_GARDENTRAC	588	87081010	18
703001090BSG	Solis Tractor BEARING CAP-REAR M/C	602	87081010	18
703002011BSG	Solis Tractor REAR BAR	48	87089900	18
703002012BSG	Solis Tractor FRONT BAR	46	87089900	18
703002013CSG	Solis Tractor SIDE BAR (4 Holes)	66	87089900	18
703002016ESG	Solis Tractor GASKET (SIDE COVER_Almn.) 3 cyl.	108	84841010	18
703002017BSG	Solis Tractor GASKET-OIL PAN 3cyl.(CAF)	107	68129922	18
703002054BSG	Solis Tractor GASKET (FRONT COVER- C.I)	145	68129922	18
703002271ASG	Solis Tractor OIL PAN (3 cyl.) DANA	1119	84099941	28
703003085ASG	Solis Tractor WASHER DIA36	32	73182300	18
703003086ASG	Solis Tractor BEARING CONN. ROD - BENARA	64	84821020	18
703003108ASG	Solis Tractor RING GEAR FLY WHEEL	718	84834000	18
703003108CSG	Solis Tractor RING GEAR FLY WHEEL (GT22)	718	84834000	18
703003110BSG	Solis Tractor RING GEAR (FLY WHEEL)_ID329mm	1268	84834000	18
703003123ASG	Solis Tractor HEX HEAD SCREW M12 X 1.5 X 32 - 4H 10.9	31	73182300	18
703003127ASG	Solis Tractor BOLT_CONN. ROD (GARDEN TRAC) M8	44	73182300	18
703003128ASG	Solis Tractor NUT_CONN. ROD (GARDEN TRAC) M8	7	73182300	18
703003143ASG	Solis Tractor NUT H M18 X 1.5 8 PHOSPHATED	43	73182300	18
703003182DSG	Solis Tractor CRANK TIMING GEAR	707	87081010	18
703003226ASG	Solis Tractor WOODRUFF-KEY 6X9X22	12	87081010	18
703004053LSG	Solis Tractor CAM SHAFT Ã~42 (3cyl) CHILLED	3641	84831099	18
703004107CSG	Solis Tractor NUT (For F.I.P.)	123	73182300	18
703005036FSG	Solis Tractor RETURN LINE (3CYL.)	945	76161000	18
703005137ASG	Solis Tractor GASKET EXHAUST MANIFOLD	20	84841090	18
703005156ASG	Solis Tractor GASKET FLANGE INLET	11	87081010	18
703005190BSG	Solis Tractor FLANGE INLET MANIFOLD	304	87089900	18
703005200BSG	Solis Tractor Inlet Manifold (sheet metal) 3 cyl.-CE	986	84834000	18
703005246DSG	Solis Tractor EXHAUST FLANGE 3cyl. (Rx.)	1924	87089200	18
703005294BSG	Solis Tractor INLET VALVE	167	87089900	18
703005295BSG	Solis Tractor EXHAUST VALVE	230	84099111	28
703005296ASG	Solis Tractor VALVE GUIDE	50	87089900	18
703005297ASG	Solis Tractor VALVE SPRING	60	73201011	18
703005299BSG	Solis Tractor RETAINER VALVE SPRING	49	87081010	18
703005301BSG	Solis Tractor VALVE COTTER	13	87089900	18
703005310BSG	Solis Tractor HOLLOW DOWEL SLEEVE	18	73201011	18
703005313BSG	Solis Tractor CYL. HEAD HEX HEAD BOLT_M10X1.25X95	55	73181600	18
703005315ASG	Solis Tractor VALVE OIL SEAL	72	40161000	18
703005317ASG	Solis Tractor ADAPTOR GLOW PLUG	39	90328910	18
703005318ASG	Solis Tractor SLOTTED PAN HEAD M/C SCREW M4 X 0.7 - 8	11	73182300	18
703005367BSG	Solis Tractor INLET MANIFOLD (3CYL) GT-24HP	661	84099990	28
703005369ASG	Solis Tractor GASKET (INLET MANIFOLD+C.HEAD) 3CYL-GT24	57	84841090	18
703006040BSG	Solis Tractor GASKET WATER PUMP	15	84841010	18
703006041BSG	Solis Tractor GASKET PLATE WATER PUMP	12	84841010	18
703006046ASG	Solis Tractor PLATE WATER PUMP	236	87089900	18
703007030CSG	Solis Tractor GASKET (FILTER BODY)	21	84841010	18
703007124DSG	Solis Tractor OIL FILTER TUBE ASSY. 3cyl.-22mm shifted	308	84213990	18
703008118CSG	Solis Tractor FUEL FILTER BODY_GARDEN TRACK	628	87081010	18

703008121ISG	Solis Tractor STOPPER COVER ASSEMBLY	563	84099111	28
703008122ASG	Solis Tractor CLAMP FUEL INJECTOR	82	82050000	18
703008123BSG	Solis Tractor GASKET STOPPER COVER	11	84841010	18
703008209DSG	Solis Tractor F.I.P. LUBRICATION PIPE (3cyl.-CE)	177	73061929	18
703008219BSG	Solis Tractor FUEL FILTER CARTRIDGE_GARDEN TRACK	261	84213990	18
703010005BSG	Solis Tractor ALTERNATOR STRUT	61	73182300	18
703010009ASG	Solis Tractor ALTERNATOR STRUT_(26HP	56	73182300	18
703010010CSG	Solis Tractor SPACER ALTERNATOR_DIA22X7.5 (26HP)	14	73182910	18
703010011ASG	Solis Tractor WASHER ALTERNATOR_DIA24X2 (26HP)	9	73182300	18
703013041CSG	Solis Tractor GASKET THERMOSTAT HSG.	12	84841090	18
703013047ASG	Solis Tractor SUPPORT BRACKET_RADIATOR (MWP)	55	87089100	18
703401004BSG	Solis Tractor BEARING CAP STUD	68	73182300	18
703401005BSG	Solis Tractor NUT M14X1.5	22	73182300	18
703401014ASG	Solis Tractor PLUG WITH GROOVE (M18x1.5)	15	73182300	18
703401015ASG	Solis Tractor OIL CHANNEL PLUG (M18x1.5)	31	87089900	18
703401018ASG	Solis Tractor VALVE GEAR LUBRICATION BOLT(M10)	17	73182300	18
703401019ASG	Solis Tractor SUSPENSION SCREW (OR LOCK BOLT)	29	73182300	18
703401022CSG	Solis Tractor STUD M16X59	66	73182300	18
703401032HSG	Solis Tractor CYLINDER LINER (¥100 FE)	1775	84099111	28
703401033CSG	Solis Tractor CYLINDER SEALING (Ã~100,102)	29	40161000	18
703401034FSG	Solis Tractor CYLINDER LINER (Ã~102)	1836	84099111	28
703401040CSG	Solis Tractor SEALING RING (POLYACRYLATE)	12	40169330	18
703401087BSG	Solis Tractor CYLINDER LINER SEALING-NBR (Ø105)	32	40169310	18
703401095BSG	Solis Tractor ALTERNATOR MOUNTING BRACKET(Bolt Design)	263	85118000	18
703401097ASG	Solis Tractor Thrust Bearing (Bottom-2) Cu	97	84833000	18
703401098CSG	Solis Tractor CYLINDER LINER (Ã~105)	1855	84099111	28
703401131BSG	Solis Tractor CYLINDER LINER ¥73	798	84099111	28
703401132ASG	Solis Tractor CYLINDER SEALING FOR ¥73	16	40161000	18
703401137BSG	Solis Tractor STUD M18*1.5x 65	92	73182300	18
703401148ASG	Solis Tractor BOLT BEARING CAP_M10X1.5 (GARDENTRAC)	28	73181500	18
703402009ASG	Solis Tractor BANJO SCREW (B13) M18 x 1.50 - 6g	51	73182300	18
703402018DSG	Solis Tractor MAGNETIC (Drain) PLUG M20x1.5	53	84213990	18
703402018ESG	Solis Tractor MAGNETIC PLUG M20X1.5	44	84213990	18
703402030ASG	Solis Tractor MAIN OIL SEAL_(REAR)	852	84842000	18
703402030BSG	Solis Tractor MAIN OIL SEAL_(REAR)	685	84842000	18
703402033BSG	Solis Tractor GASKET (TRANSMISSION ELBOW)	10	84841010	18
703402058BSG	Solis Tractor GASKET (For Hyd. Tandem) 4mtg.	15	68129922	18
703402065ASG	Solis Tractor COVER (FOR TRANSMISSION ELBOW)	46	87089900	18
703402093ASG	Solis Tractor FRONT OIL SEAL (Viton)	305	40161000	18
703402101BSG	Solis Tractor TUBE CLIP (For Breather Pipe)	30	73182300	18
703402101ESG	Solis Tractor TUBE CLIP (FOR BREATHER PIPE)	36	87089900	18
703402114ASG	Solis Tractor BANJO BOLT B13 (for FIP lub.)	44	73182300	18
703402187BSG	Solis Tractor BREATHER PIPE_with Nipple connection	194	87081010	18
703402213ASG	Solis Tractor GASKET (FRONT COVER-CI) NON ASB.	156	84841090	18
703402216ASG	Solis Tractor GASKET (REAR COVER) NON ASB.	73	84841090	18
703402240DSG	Solis Tractor COUPLER (FOR HYD. PUMP) SELECT	368	87084000	18
703402246ASG	Solis Tractor Hex Flange Bolt (M10x50)side cover Almn.	24	73182300	18
703402253ASG	Solis Tractor COVER_sheet metal (for Front cover) NA	101	84099111	28
703402258CSG	Solis Tractor REAR COVER (C.I) with Groove	1829	84099111	28
703402259ASG	Solis Tractor SEALING PAD FOR REAR COVER	53	40161000	18
703402263FSG	Solis Tractor FRONT COVER ALUMINIUM (POWER STEERING)	5054	84099199	28

703402264CSG	Solis Tractor REAR COVER_Ribs (Almn.) with Groove	1092	87089900	18
703402274BSG	Solis Tractor PLUG_M26x1.5 (Front cover_Oil filling)	85	40169330	18
703402275ASG	Solis Tractor O Ring-HNBR (for Plug m26x1.5)	10	40161000	18
703402284ASG	Solis Tractor GROMMET (GT22)	5	40169990	18
703403013ASG	Solis Tractor FRONT OIL SPLASH GUARD	36	87089900	18
703403014DSG	Solis Tractor CONNECTING ROD BOLT	146	73182300	18
703403015BSG	Solis Tractor CONNECTING ROD BOLT NUT	67	73182300	18
703403019CSG	Solis Tractor RING GEAR (FLY WHEEL)	1680	87084000	18
703403020DSG	Solis Tractor FLY-WHEEL BOLT	28	73182300	18
703403033ASG	Solis Tractor PISTON PIN_Ã~35x85	330	84099111	28
703403047BSG	Solis Tractor LOCKING WASHER	16	73182300	18
703403048ASG	Solis Tractor NUT(CLAW) M32X1.5	124	73182300	18
703403109DSG	Solis Tractor FLY WHEEL_SC (FOR R. GEAR_329)	10395	84099111	28
703403114DSG	Solis Tractor ENG. BELT PULLEY Ã~35 (for Bal. option)	1608	87089900	18
703403133ASG	Solis Tractor KEY STONE I.D.STEP(PGV)RING-1ST.Ø102	348	84099113	28
703403134ASG	Solis Tractor TAPER COMP. REV. TORSION RING-2ND.Ã~102	202	84099111	28
703403265BSG	Solis Tractor Timing Gear (crank) Ã~35	642	84138190	18
703403316DSG	Solis Tractor FLY-WHEEL_DC (For R. Gear_329)	7937	84835090	18
703403317ASG	Solis Tractor TAPER FACED COMP. RING-2nd.-Ø105_CRDI	191	84099111	28
703403327ASG	Solis Tractor PISTON PIN (FM)_GARDENTRAC	185	84099111	28
703403339BSG	Solis Tractor PULLEY_ENGINE (GT)	618	84835010	18
703404014ASG	Solis Tractor INTERMEDIATE GEAR PIN (Ã~17) For B.I.G.	68	84834000	18
703404015FSG	Solis Tractor BOTTOM INTERMEDIATE GEAR	456	84834000	18
703404016ASG	Solis Tractor INTERMEDIATE GEAR PAD Ã~17 (For B.I.G.)	11	84834000	18
703404019DSG	Solis Tractor TUBE ASSY. (TIG lub.)	73	87089900	18
703404044ASG	Solis Tractor DISC PLUG (Ã~55)	30	84099111	28
703404061ISG	Solis Tractor CAM GEAR (Ã~30)	1057	84834000	18
703404062BSG	Solis Tractor CAM RETAINER(GROOVEÃ~55.5)TANDEM	93	84830000	18
703404069CSG	Solis Tractor PIN-T.I.G WITH LOCK-PLATE	845	84310000	18
703404135ASG	Solis Tractor PUSH ROD ASSY. (L-303.5-Ã~9.5)	125	87089900	18
703404145ASG	Solis Tractor WASHER Ã~40_for cam shaft	43	73182300	18
703404162CSG	Solis Tractor TIMING GEAR (F.I.P.) CE 4DEG.	1147	84830000	18
703405003BSG	Solis Tractor GASKET (RETURN LINE)	15	84841010	18
703405041ASG	Solis Tractor LOWER VALVE SPRING RETAINER	11	73201011	18
703405042ASG	Solis Tractor VALVE OIL SEAL	79	40161000	18
703405043ASG	Solis Tractor INLET VALVE	264	84099111	28
703405044ASG	Solis Tractor EXHAUST VALVE	342	84099111	28
703405045ASG	Solis Tractor VALVE INNER SPRING	47	73201011	18
703405046ASG	Solis Tractor VALVE OUTER SPRING	64	73201011	18
703405047BSG	Solis Tractor UPPER VALVE SPRING RETAINER	50	84099111	28
703405048ASG	Solis Tractor VALVE COTTER	19	84099111	28
703405053ASG	Solis Tractor ADJUSTING SCREW NUT	14	73182300	18
703405054ASG	Solis Tractor PLAIN WASHER	10	73182300	18
703405056BSG	Solis Tractor HOLLOW DOWEL SLEEVE	18	87089900	18
703405061DSG	Solis Tractor CYLINDER HEAD BOLT	159	73182300	18
703405062DSG	Solis Tractor CYLINDER HEAD BOLT (SPL.)	172	73182300	18
703405064DSG	Solis Tractor PLUG_M25x1.5 (RETURN LINE) & M14	47	73182300	18
703405067FSG	Solis Tractor GASKET (EXHAUST FLANGE+CYL. HEAD)	27	84841010	18
703405071BSG	Solis Tractor NUT M8 (FOR VALVE COVER)	16	73182300	18
703405101DSG	Solis Tractor PLUG FOR RETURN LINE (M25X1.5)	45	73182300	18
703405105CSG	Solis Tractor VALVE COVER(Sheet Metal) `P'Type inj	360	84099111	28

703405106CSG	Solis Tractor GASKET (Valve Cover) For 'P'- type	94	40161000	18
703405109CSG	Solis Tractor VALVE GUIDE (For 'P'-Type Inj.)	60	84099111	28
703405112BSG	Solis Tractor ROCKER ARM SUPPORT STUD	49	73182300	18
703405125ASG	Solis Tractor ADAPTOR Inlet Manifold _M24x2 (for EGR)	99	87081010	18
703405167ASG	Solis Tractor INLET VALVE (For Dia 105)	285	84099111	28
703405168ASG	Solis Tractor EXHAUST VALVE (For Dia 105)	392	84099111	28
703405224CSG	Solis Tractor SEALING PAD (Valve cover)	18	40169340	18
703405225ASG	Solis Tractor Sealing CAP for valve cover	20	40161000	18
703405235BSG	Solis Tractor GASKET (INLET) Embossing	17	68129922	18
703405249ASG	Solis Tractor GASKET (RETURN LINE) NON ASB.	12	84841090	18
703405250ASG	Solis Tractor GASKET (EXHAUST) NON ASB.	32	84841090	18
703405251ASG	Solis Tractor GASKET-1.5MM(INLET) NON ASB.	17	84841090	18
703405328BSG	Solis Tractor INTERMEDIATE PLATE _with Hole Ø3mm (EGR)	41	73061919	18
703405378ASG	Solis Tractor GASKET _CYLINDER HEAD (TC) NRT	273	84841090	18
703406001BSG	Solis Tractor GASKET (WATER PUMP HSG.)	25	84841010	18
703406025BSG	Solis Tractor ADAPTOR _water pump OUTLET (M14X1.5) TC	41	84099111	28
703406026ASG	Solis Tractor ADAPTOR _water pump INLET (M16x1.5) TC	41	84099111	28
703406080ASG	Solis Tractor GASKET (WATER PUMP) NON ASB.	23	84841090	18
703406123ASG	Solis Tractor GASKET _Inter-mediate PLATE w.pump _mwp	15	84841010	18
703406151ASG	Solis Tractor GASKET _NON ASB.(INTER-MEDIATE PLATE W.P)	19	84841010	18
703407012ASG	Solis Tractor SHIM (FOR OIL PUMP)	14	73182300	18
703407013ASG	Solis Tractor OIL PUMP CENTRING TUBE	9	87089900	18
703407014ASG	Solis Tractor LOCK PAD	13	40161000	18
703407015ASG	Solis Tractor CONNECTION (M18x1.5)	50	87089900	18
703407025ASG	Solis Tractor NECK FOR SCREWING IN	160	73182300	18
703407144ASG	Solis Tractor O RING-Polyacrylate (side cover)	11	40161000	18
703407145ASG	Solis Tractor O RING-Polyacrylate _Ø14x2 (oil filter)	14	40169320	18
703408026CSG	Solis Tractor BRACKET (FOR F.FILTER)	156	87089900	18
703408029ESG	Solis Tractor GASKET (F.I.P)	29	84841010	18
703408034ASG	Solis Tractor SPHERICAL WASHER (Ã~8.4X17)	17	73182300	18
703408039ASG	Solis Tractor HOLDER	12	87089900	18
703408083BSG	Solis Tractor INJECTOR CLAMP.(ITL03)	101	73182300	18
703408111ASG	Solis Tractor HIGH PRESSURE PIPE(Ø1.8XØ6X500)1st. CE	415	40161000	18
703408111CSG	Solis Tractor HIGH PRESSURE PIPE(Ã~1.8XÃ~6X500)1st. CE	410	84099111	28
703408111DSG	Solis Tractor HIGH PRESSURE PIPE(Ø1.8XØ6X500)1ST. CE	378	87089900	18
703408112CSG	Solis Tractor HIGH PRESSURE PIPE(Ã~1.8XÃ~6X500)2nd.	410	84099111	28
703408112DSG	Solis Tractor HIGH PRESSURE PIPE(Ø1.8XØ6X500)2ND.	378	87089900	18
703408157CSG	Solis Tractor HIGH PRESSURE PIPE(Ø1.8xØ6x500)4th.-CE	302	40161000	18
703408186CSG	Solis Tractor HEX SCREW M8*1.25X29	11	73182300	18
703408225BSG	Solis Tractor GASKET (F.I.P _ROTARY) NON-ASB.	17	84849000	18
703409064CSG	Solis Tractor O RING-Polyacrylate (37.69x3.53)	23	40161000	18
703409071ASG	Solis Tractor FLEXIBLE PIPE (450mm)	118	40091100	18
703409080ASG	Solis Tractor FLEXIBLE Hose-pipe (315mm)	136	40091100	18
703410016ASG	Solis Tractor WASHER _ALTERNATOR _'#22X4	15	84810000	18
703410029ASG	Solis Tractor GASKET (STARTER MOTOR) NON ASB	18	84841090	18
703410040ASG	Solis Tractor SUPPORT BRACKET For Alt. mtg. bkt.(mwp)	42	73182200	18
703410047ASG	Solis Tractor ALTERNATOR STRUT (32mm)	108	73182300	18
703413057ASG	Solis Tractor AVM RUBBER PAD FOR RADIATOR	67	87089100	18
703413076ASG	Solis Tractor COLLECTOR (PLASTIC) DIA430	277	87089100	18
703413103ASG	Solis Tractor Radiator SUPPORT Bracket 4cyl. (MWP)	69	87089900	18
703414030ASG	Solis Tractor GASKET _EGR Inlet pipe	18	84841010	18

703414030CSG	Solis Tractor GASKET_EGR INLET PIPE	18	84841010	18
703414031ASG	Solis Tractor GASKET_(EGR)	20	84841010	18
703414114ASG	Solis Tractor GASKET_S.STEEL (EX. FLANGE+EGR COOLER)	58	84849000	18
720002051BSG	Solis Tractor GASKET-OIL PAN 2CYL.	58	68120000	18
720002105ASG	Solis Tractor GASKET (For Hyd.) 2mtg.	12	84841010	18
720002105BSG	Solis Tractor GASKET (FOR HYD.) 2MTG.	19	68129922	18
720007128ASG	Solis Tractor BRACKET Mtg._Oil filter Body	366	73182300	18
723402121BSG	Solis Tractor SPACER-Ã~11x18x14	16	87081010	18
723402147ASG	Solis Tractor GASKET_cover (For Front cover)	10	68129922	18
723402147CSG	Solis Tractor GASKET_COVER (FOR FRONT COVER)	7	68129922	18
723404116ESG	Solis Tractor TAPPET Mashroom (Ã~18)	182	84099111	28
723410013CSG	Solis Tractor GASKET_STARTER MOTOR	21	84841010	18
729008-01500S	Solis Tractor CASE ASSY, GEAR	27959	84834000	18
729008-53200S	Solis Tractor VALVE ASSY,INJECTION	17676	84099990	28
729402-14580S	Solis Tractor CAMSHAFT ASSY	24783	84839000	18
729402-23100S	Solis Tractor ROD ASSY, CONNECTING	20139	84099990	28
729659-01570S	Solis Tractor BLOCK ASSY, CYLINDER	331003	84839000	18
729659-51410S	Solis Tractor FIE ASSY	207411	84839000	18
729906-53100S	Solis Tractor VALVE ASSY,INJECTION	18400	84099990	28
729907-01559S	Solis Tractor COVER ASSY, CASE	27146	84839000	18
729927-02800S	Solis Tractor BEARING ASSY, MAIN	3978	84833000	18
729962-01560S	Solis Tractor BLOCK ASSY, CYLINDER	322091	84839000	18
729962-51350S	Solis Tractor FIE ASSY	213849	84839000	18
800401216DSG	Solis Tractor CRANK CASE BRG. CAPS 4CYL_NA_CE (M18)	74234	84099941	28
800401225ASG	Solis Tractor CRANK CASE ASSY (4CYL-TC_CE_SOLENOID)	54873	84099941	28
800402020BSG	Solis Tractor HYD. PUMP ASSY. (12cc) 4 mtg._Lift	5156	84138190	18
800407001CSG	Solis Tractor OIL PUMP ASSY. (4 CYL.)	3469	84131990	28
800407003BSG	Solis Tractor REDUCTION VALVE ASSY.	319	87081010	18
800407013ASG	Solis Tractor SUCTION STRAINER ASSY.4cyl (S.M oil pan)	374	87081010	18
800407051BSG	Solis Tractor SUCTION STRAINOR ASSY.(4CYL.)CARRARO_NEW	622	87081010	18
800407066CSG	Solis Tractor Lub. Oil Filter Assy.4cyl(with new Ring)	1215	84219900	18
800408167ASG	Solis Tractor HIGH PRESSURE PUMP CB18 (0 445 B36 108)	45350	40161000	18
800408168ASG	Solis Tractor COMMON RAIL HFR16 (B 445 224 396)	24185	84099111	28
800408169ASG	Solis Tractor PHASE SENSOR (0 281 006 143)	2843	90321090	18
800408170ASG	Solis Tractor SPEED SENSOR (0 281 002 315)	1730	90328910	18
800408171ASG	Solis Tractor BOOST PRESSURE SENSOR (0 261 230 283)	4582	90328910	18
800408172ASG	Solis Tractor TEMP. SENSOR (0281 002 209)	2437	90328910	18
800408174ASG	Solis Tractor FUEL RETURN LINE (CRDI) 1098 A03 30T	4111	40091100	18
800408183BSG	Solis Tractor INJECTOR OVER FLOW PIPE (4cyl.) `P' type	274	84099111	28
800410001ASG	Solis Tractor STARTER MOTOR	12334	85118000	28
803001177CSG	Solis Tractor SEAL_BEARING CAP	70	40161000	18
803001206DSG	Solis Tractor CRANK CASE with Brg.CAP (3cyl.-NA) CE	51943	84099941	28
803002011CSG	Solis Tractor SIDE COVER ASSY_3CYL(WITH BREATHER)ALMN.	739	87081010	18
803002024ASG	Solis Tractor H.YD. PUMP ASSY 22.5CC - BOSCH	5936	84138190	18
803002041BSG	Solis Tractor OIL SEAL REAR 92X70X10	546	40161000	18
803002042ASG	Solis Tractor OIL SEAL 50X35X8 FRONT	258	40161000	18
803002068ASG	Solis Tractor OIL PAN-3cyl. (4x4 TRANSMISSION)	809	87089900	18
803003028BSG	Solis Tractor CRANK SHAFT 78ST. 3CYL.	14312	84834000	18
803003029CSG	Solis Tractor CONNECTING ROD ASSY M/C	1762	84099949	28
803003030ASG	Solis Tractor RADIAL B/BEARING_6001-2Z	141	84824000	18
803005038ASG	Solis Tractor GLOW PLUG (HEATER) M12 X 1.25	742	85114000	28

803005039BSG	Solis Tractor WIRE HARNESS HEATOR	28	85446090	18
803005104DSG	Solis Tractor CYLINDER HEAD ASSY	11388	84099990	28
803007004CSG	Solis Tractor OIL PUMP ASSY. (3 CYL.)	2981	84138190	18
803007059ASG	Solis Tractor OIL FILTER ASSY. 3cyl. (Garden track)	197	84213990	18
803007060ASG	Solis Tractor SUCTION STRAINER (2 & 3 CYL)	356	87081010	18
803007068BSG	Solis Tractor DELIVERY PIPE ASSY. (3 CYL.) 4X4	232	73061929	18
803008045ASG	Solis Tractor F.I.P. ASSY.(3102IL) [F002 A0Z	34436	84138190	18
803008088ASG	Solis Tractor INJECTOR ASSY. E080 240 200	5092	84099111	28
803008182BSG	Solis Tractor INJ. OVER FLOW PIPE 3cyl. ('P' type)	257	84099111	28
803008185ASG	Solis Tractor FUEL FILTER ASSY(0.5LT.)_GARDENTRAC	970	84213990	18
803008268ASG	Solis Tractor F.I.P 3102FLU-42@1800 (F002 A10 459) R22	40231	84133010	28
803008271ASG	Solis Tractor F.I.P Assy_3105ELU-47@1900 (E040 A4Z R23	30329	84133010	28
803008306DSG	Solis Tractor PLUNGER TYPE STOPPER COVER ASSY	1096	87089900	18
803010050BSG	Solis Tractor ALTERNATOR ASSY. (26HP)	5766	84213990	18
803010087ASG	Solis Tractor STARTER MOTOR_Autolek (GT22)	11045	85118000	28
803012006CSG	Solis Tractor AIR CLEANER ASSY.DRY-TYPE (6")	2312	84213990	18
803013099ASG	Solis Tractor FAN ASSY.382D.(NYLON-7 BLADE) MISTUBISHI	712	84099111	28
803013111ASG	Solis Tractor RADIATOR ASSY. (GARDENTRAC) STAGE-V	6363	87089100	18
803402027ASG	Solis Tractor HYD. PUMP ASSY.(9.5cc) 2 mtg._P.Steering	5940	84138190	18
803402039ASG	Solis Tractor HYD. PUMP ASSY. (16cc) 4 mtg._Lift	6277	84138190	18
803402048ASG	Solis Tractor HYD. PUMP ASSY.-spline shaft(12cc)2mtg.	6807	84138190	18
803403014JSG	Solis Tractor CONNECTING ROD ASSY. (common)	2457	84099111	28
803404001JSG	Solis Tractor TOP INTERMEDIATE GEAR ASSY.	2399	84834000	18
803404014ASG	Solis Tractor Cyl. Roller Bearing (30x55x13) NUP-1006	1013	84825011	18
803405032DSG	Solis Tractor ROCKER ARM BKT. ASSY. (common)	1416	84099111	28
803405068GSG	Solis Tractor CYL. HEAD_IW (ASSY) 'P' TYPE -Ø100,102	6185	84099111	28
803405070FSG	Solis Tractor CYL. HEAD_IW (Assy.) 'P' Type -Ã~105	7431	84099111	28
803405070ISG	Solis Tractor CYL. HEAD_IW (Assy.) Ø105	5941	84099941	28
803406064CSG	Solis Tractor WATER PUMP ASSY._V-Ø90-TC (MWP)	4435	84131990	28
803406065DSG	Solis Tractor WATER PUMP ASSY._V-Ø103-TC (MWP)	4650	84133030	28
803406066CSG	Solis Tractor WATER PUMP ASSY._V-Ã~103-NA (MWP)	3814	84131990	28
803406066DSG	Solis Tractor WATER PUMP ASSY._V-¥103-NA (MW	3933	84133030	28
803406067CSG	Solis Tractor WATER PUMP ASSY._V-¥125-NA (MW	4795	84131990	28
803407038ASG	Solis Tractor OIL FILTER TUBE ASSY. 3cyl. (Narrowtrac)	288	87089900	18
803407065CSG	Solis Tractor Lub. Oil Filter Assy.3cyl(with new Ring)	1218	84213990	18
803408047ASG	Solis Tractor INJ. ASSY_P 5x0.206 (F002 C7Z 255)-1568	4862	84099111	28
803408053ASG	Solis Tractor INJ. ASSY_P (F002 C7Z 270)-1651	4862	84099111	28
803408209ASG	Solis Tractor F.I.P. LUBRICATION PIPE (4cyl.-CE)_MWP	207	73061929	18
803408294ASG	Solis Tractor SINGLE STAGE FUEL FILTER (0.6Lt.)	986	84213990	18
803408296ASG	Solis Tractor FUEL PIPE (Feed Pump To Filter)CE_single	193	73061929	18
803408297ASG	Solis Tractor FUEL PIPE (Filter To F.I.P) CE_single	210	73061929	18
803410003BSG	Solis Tractor ALTERNATOR ASSY._36AMP. WITH PULLEY	9273	85118000	28
803412028CSG	Solis Tractor AIR CLEANER ASSY. DRY TYPE (5)	2625	84213990	18
803412032ASG	Solis Tractor AIR CLEANER ASSY. Dry Type (5" _Domestic)	2251	84213990	18
803412034ASG	Solis Tractor AIR CLEANER ASSY. Dry Type (8" _Domestic)	4891	84213990	18
803413016CSG	Solis Tractor THERMOSTAT ASSY.74 Deg.	1242	84099111	28
803413056CSG	Solis Tractor FAN ASSY. Ã~400(sheet metal)6 blade-24de	1193	84099111	28
803413060ASG	Solis Tractor RADIATOR ASSY. Nrx(Almn.) core-48mm	7944	87089100	18
803413068BSG	Solis Tractor FAN ASSY. ¥420 (ALMN)	1765	84099111	28
803413072ASG	Solis Tractor RADIATOR ASSY_RX (ALMN.)80TUBE CORE-48MM	10043	87089100	18
803413075ASG	Solis Tractor Support BRACKET (R.Bottle) Turbo	307	73182300	18

803413106BSG	Solis Tractor RADIATOR ASSY. (218 tube) TC-Rx	19069	87089100	18
803413109ASG	Solis Tractor FAN ASSY. (7 BLADE-Ø400) PLASTIC	859	87089100	18
803414006ASG	Solis Tractor EGR cooler Assy_ Tractor Engine	12737	84099111	28
803414013ASG	Solis Tractor EGR VALVE ASSY (BUTTERFLY) PADMANI_CRDI	12242	84099111	28
820007030ASG	Solis Tractor Lub. OIL FILTER ASSY. (NT)	1253	84213990	18
820007036ASG	Solis Tractor INLET PIPE(c.case to Oil Filter)Narrowtr	244	87081010	18
823009012ESG	Solis Tractor Breather Assy. (Push Type)	153	87089900	18
900402012FSG	Solis Tractor GEAR ã~30 (FOR HYD.PUMP)	585	84099111	28
900402020BSG	Solis Tractor BEARING RETAINER (For Hyd. IPD)	96	73182300	18
900404045BSG	Solis Tractor GASKET_HSG. PLATE (CRDI)	12	68129922	18
900407002DSG	Solis Tractor OIL FILTER TUBE ASSY.4CYL (TANDEM)	273	87089900	18
903003040JSG	Solis Tractor Crank Shaft 3cyl. INTG.-FL(common) 39Cr5	22418	84834000	18
903005073BSG	Solis Tractor PROTECTION CAP_INLET MANIFOLD	38	74190000	0
903008022ASG	Solis Tractor INJ. ASSY_P 5x0.2(F002 C7Z 252)-1549	4862	84099111	28
903401013ASG	Solis Tractor SLOTTED GRUB SCREW A-M8X8	9	73182300	18
903401027ASG	Solis Tractor Crank case Plug-socket (M10x1.0)	15	73182300	18
903405028ASG	Solis Tractor BANJO BOLT M10x1.25	17	73182300	18
903405037ASG	Solis Tractor GASKET_(INLET MANIFOLD+INLET PIPE) Turbo	14	84841010	18
903408044CSG	Solis Tractor STICKER (FILTER) 0.7LT.	16	39191000	18
903408218BSG	Solis Tractor FUEL FILTER_SINGLE (CRDI) E083 424 600	6559	84213990	18
903408256ASG	Solis Tractor FILTER CARTRIDGE OF903408218B(F002H2202	2370	87081010	18
903413003ASG	Solis Tractor PLUG (Thermostat)	15	84099111	28
DN3105NHD117H11ASG	Solis Tractor 3105NH-DC_NT-49@2000(12+12cc) DANA, 1F	199306	84082020	18
GTE02000001ASG	Solis Tractor THRUST BEARING TOP	258	84833000	18
GTE05000002CSG	Solis Tractor GASKET CYLINDER HEAD BANCO	377	84841090	18
GTE08000002ASG	Solis Tractor NUT H M8 X 1.25 10 PHOSPHATED	8	73182300	18
GTE13000004ASG	Solis Tractor FAN ASSY GT 22	605	87089100	18
GTE13000005ASG	Solis Tractor WATER PUMP ASSY.	3203	84131990	28
L4105NGD19P13ABSG	Solis Tractor 4105NG-DC_54.5@2000 (12+P12cc) M18-mwp	248581	84082020	18
L4CNG00D119H11ABSG	Solis Tractor 4105NG-DC (12+12CC) M18, MWP	265415	84082020	18
L4CNG01D119H12ABSG	Solis Tractor 4105NG-54.5@2000_DC (12+16cc)M18-mwp-1F	247652	84082020	18
L4CNU01D119H12ABSG	Solis Tractor 4105NU-58@2100_DC (12+16cc)M18-mwp-1F	247931	84082020	18
W3105NHD116H11ASG	Solis Tractor 3105NH-DC_49@2000 (12+12cc) 1F,Delphi	191263	84082020	18
W3CX03NHD117H11ASG	Solis Tractor 3105NH-DC_49@2000 (12+12cc) 1F, Solis	198961	84082020	18
10026351AA	Solis Tractor ENGINE OIL 15W40	289	27101972	18
11000588SG	Solis Tractor Solis Supreme Coolant (250ml)	113.4	38119000	18
11000670AA	Solis Tractor Solis Supreme Coolant (250ml)_N	108	38119000	18
11000679AA	Solis Tractor Yanmar Engine oil , 5 ltr	2000	27101972	18
11000680AA	Solis Tractor Yanmar Front Axle oil, 5 ltr	2250	27101974	18
1A8252-95500-1	Solis Tractor OIL,ENGINE 10W30 CJ4	390	27101972	18
1A8252-95800-1	Solis Tractor OIL, T/M TF500T	355	27101974	18
20004420AA	Solis Tractor ROTRA MULTI THT	450	27101972	18
300169020A	Solis Tractor SOLIS ENGINE OIL 1Lt.	400	27101972	18
300169021A	Solis Tractor SOLIS ENGISOLIS ENGINE OIL 8.5Lt.	3325	27101972	18
300169022A	Solis Tractor SOLIS TRANSMISSION OIL OIB 5Lt.	1800	27101974	18
300169023A	Solis Tractor SOLIS TRANSMISSION OIL OIB 55Lt.	17500	27101974	18
300169025A	Solis Tractor SOLIS POWER STEERING OIL 1LT.	385	27101974	18
300169027A	Solis Tractor SOLIS FRONT AXLE 4WD OIL 1LT.	454	27101974	18
300169028A	Solis Tractor SOLIS FRONT AXLE 4WD OIL 5LT.	2238	27101974	18
300183080A	Solis Tractor SOLIS PLUS ENGINE OIL 12LT.	4672	27101972	18
300229591A	Solis Tractor Solis Supreme250 Engine Oil 4Lt.	1435	27101972	18

10054680AASG	Solis Tractor PISTON	7603	84099111	28
10054731AASG	Solis Tractor HEAD ASSY,CYLINDER	62877	84099111	28
10054732AASG	Solis Tractor CRANKSHAFT_31620-00203	68922	84099111	28
10054780AASG	Solis Tractor RING SET, PISTON_31A17-00020	6057	84099111	28
10054781AASG	Solis Tractor RING SET, PISTON_31A17-00030	6057	84099111	28
10054829AASG	Solis Tractor PAN ASSY, OIL_31B13-00013	6823	84099111	28
10054962AASG	Solis Tractor PUMP ASSY, WATER_MM409303	9262	84099111	28
10054975AASG	Solis Tractor NOZZLE & HOLDER ASSY_MM435-94101	11275	84099111	28
1682B3-00040S	Solis Tractor VALVE ASSY, MAIN REL	2942	84811000	18
1A8252-56010S	Solis Tractor METER, COMBINATION	9293	90292090	18
24141-320070S	Yanmar Tractor BEARING, 32007	344	84821090	18
114270-59010S	Yanmar Tractor CLAMP, HOSE 12	16	73261910	18
119934-55611S	Yanmar Tractor BRACKET, FILTER	0	87089900	18
124240-01883S	Yanmar Tractor GASKET, HYD. PUMP	117	40169990	18
128300-77920S	Yanmar Tractor TIMER, GLOW PLUG	0	91060000	0
129052-13550S	Yanmar Tractor GASKET, EXHAUST	168	40169990	18
129211-77920S	Yanmar Tractor TIMER, SECTION 1	0	91069000	18
129267-55700S	Yanmar Tractor FILTER, FUEL OIL PRE	5924	84212190	18
129659-55700S	Yanmar Tractor FILTER ASSY, FUEL PRE	0	84213990	18
129907-55801S	Yanmar Tractor FILTER, FUEL OIL	943	84213990	18
129979-55701S	Yanmar Tractor FILTER ASSY,FUEL PRE	0	84213990	18
1682B3-00060S	Yanmar Tractor VALVE ASSY, RELIEFM3	0	84818090	18
1682D2-00031S	Yanmar Tractor VALVE ASSY, PTO	11897	84811000	18
172544-16200S	Yanmar Tractor SWITCH ASSY,BATTERY	0	85367000	18
172B16-17190S	Yanmar Tractor RELAY, CB C TYPE	386	85367000	18
174570-57110S	Yanmar Tractor BUZZER,	0	85310000	18
192180-27940S	Yanmar Tractor SEAL, TC223208	68	40169320	18
194205-63550S	Yanmar Tractor BREATHER, AIR	0	40091100	18
194250-25240S	Yanmar Tractor BEARING, 354019	255	84821090	18
194312-25260S	Yanmar Tractor BEARING, 60/22	0	84822090	18
194441-13880S	Yanmar Tractor BEARING, 202613	0	84822090	18
194454-25750S	Yanmar Tractor BEARING, 16008	0	84822090	18
194464-52190S	Yanmar Tractor SWITCH, SAFETY START	782	85367000	18
194556-42220S	Yanmar Tractor STRAINER	0	84213920	18
194640-42140S	Yanmar Tractor BUSH, 65X70X45	0	87084000	18
194640-44261S	Yanmar Tractor SEAL, SPLINE SHAFT	125	40169990	18
198071-57110S	Yanmar Tractor BUZZER, BACK	0	40091100	18
198071-65610S	Yanmar Tractor NUT, M5	0	73181600	18
198121-25840S	Yanmar Tractor RING, SYNCHRO	1001	87084000	18
198121-25850S	Yanmar Tractor KEY, SYNCHRO	103	87089900	18
198121-25870S	Yanmar Tractor SPRING, SYNCHRO	0	73202000	18
198133-25990S	Yanmar Tractor SPRING, SYNCHRO	0	73202000	18
198162-52111S	Yanmar Tractor SWITCH ASSY, STARTER	3185	85361010	18
198200-01260S	Yanmar Tractor PLATE, FRICTION	0	83100010	18
198200-78731S	Yanmar Tractor MOUNT,ABSORBER 40	0	87089900	18
198212-25680S	Yanmar Tractor BUSH, 34X40X30	0	84833000	18
198212-26090S	Yanmar Tractor BEARING, 63/22NR	0	84822090	18
198212-27350S	Yanmar Tractor SEAL, TC4203507	110	40169990	18
198220-61351S	Yanmar Tractor LOCK, CAM	0	87089900	18
198223-52151S	Yanmar Tractor SWITCH ASSY, LAMP	1042	85361010	18
198361-48750S	Yanmar Tractor BOLT ASSY, JOINT	0	73182910	18

198390-43360S	Yanmar Tractor RING, WEAR 85	494	40169320	18
198448-43260S	Yanmar Tractor PACKING	227	40169990	18
198448-43270S	Yanmar Tractor RING, BACKUP 85	320	40169320	18
198451-28750S	Yanmar Tractor RING, SEAL 26X30X3	0	40169990	18
198475-32660S	Yanmar Tractor SEAL,QLNY 52 75 14.5	646	40169990	18
198535-25880S	Yanmar Tractor BUSH, 30X37X19	0	84833000	18
1A7090-25380S	Yanmar Tractor KEY, SYNCHRO	0	87085000	18
1A7090-26690S	Yanmar Tractor SIGHT WINDOW	0	73061100	18
1A7180-13580FG	Yanmar Tractor BEARING, HR6209UR	426	84821011	18
1A7180-13580S	Yanmar Tractor BEARING, HR6209UR	426	84821011	18
1A7180-13880S	Yanmar Tractor BEARING, TM207UR	0	84821011	18
1A7340-52290S	Yanmar Tractor SWITCH, PTO	1263	85361010	18
1A7450-52450S	Yanmar Tractor SWITCH,HAZARD	1199	85361010	18
1A7510-57200S	Yanmar Tractor RELAY, FLASHER	2885	85367000	18
1A7522-52950S	Yanmar Tractor RELAY, ACM13221M19	175	85361010	18
1A7601-00650S	Yanmar Tractor COOLER, FO H40	0	87089900	18
1A7640-48310S	Yanmar Tractor FILTER,	4522	84213990	18
1A7781-41120S	Yanmar Tractor PUMP ASSY, 8	10338	84133020	28
1A8042-04420S	Yanmar Tractor HOSE, FUEL L	0	40091100	18
1A8042-04540S	Yanmar Tractor HOSE, FUEL 360	0	40091100	18
1A8043-52190S	Yanmar Tractor SWITCH,SAFETY NC	2094	85367000	18
1A8060-04520S	Yanmar Tractor HOSE, FUEL 1250	0	40091100	18
1A8060-15711S	Yanmar Tractor WHEEL,STEERING D400	3871	84213990	18
1A8060-15751S	Yanmar Tractor SCREW,STR WHEEL	0	73181500	18
1A8060-15770S	Yanmar Tractor COVER,STEERING WHEEL	0	87089400	18
1A8060-38400S	Yanmar Tractor BRAKE ASSY, PARKING	0	73182910	18
1A8060-46411S	Yanmar Tractor SEAT, VALVE	0	84818090	18
1A8060-46441S	Yanmar Tractor SPRING, VALVE	0	73202000	18
1A8060-46711S	Yanmar Tractor SCV ASSY, FLOAT	0	87089900	18
1A8060-46721S	Yanmar Tractor SCV ASSY	0	84818090	18
1A8060-52130S	Yanmar Tractor SWITCH ASSY,INTERLOC	0	85367000	18
1A8060-55600S	Yanmar Tractor SENSOR, ACCELERATOR	0	87089900	18
1A8250-48430S	Yanmar Tractor COVER, FILTER	2785	87089900	18
1A8252-14180FG	Yanmar Tractor BEARING, 6209SH2	1023	84821011	18
1A8252-14180S	Yanmar Tractor BEARING, 6209SH2	1023	84821011	18
1A8252-17500S	Yanmar Tractor VALVE ASSY, PST	21344	84811000	18
1A8252-24550S	Yanmar Tractor VALVE ASSY,	9798	84811000	18
1A8252-25460S	Yanmar Tractor HUB ASSY, SYNCHRO	5372	87089900	18
1A8252-25551S	Yanmar Tractor WASHER 35X55X5	0	73182200	18
1A8252-25570S	Yanmar Tractor NUT, M20 LOCK LOWER	0	73182910	18
1A8252-25580S	Yanmar Tractor NUT, M20 LOCK UPPER	0	73182910	18
1A8252-25810S	Yanmar Tractor HUB, SYNCHRO	0	87084000	18
1A8252-25840S	Yanmar Tractor SLIDER, SYNCHRO	0	87084000	18
1A8252-25861S	Yanmar Tractor RING ASSY	0	73269099	18
1A8252-26000S	Yanmar Tractor CLUTCH KIT, PTO	19877	84833000	18
1A8252-26340S	Yanmar Tractor WASHER,38.8X47X1.6	0	73182910	18
1A8252-26390S	Yanmar Tractor CIRCLIP, C 35	0	73181600	18
1A8252-29031S	Yanmar Tractor BEARING 30306	2800	84821020	18
1A8252-29050S	Yanmar Tractor SNAP RING 72	215	73269099	18
1A8252-29510S	Yanmar Tractor SEAL, 356019	488	40169980	18
1A8252-29540S	Yanmar Tractor SEAL, 6911020	1057	40169990	18

1A8252-33100S	Yanmar Tractor SLIDER, DIFFERENTIAL	0	87089900	18
1A8252-41110S	Yanmar Tractor PUMP ASSY, 14	11773	84133020	28
1A8252-45150S	Yanmar Tractor VALVE ASSY, CONTROL	15370	84811000	18
1A8252-46420S	Yanmar Tractor VALVE, POPPET	0	84818090	18
1A8252-47440S	Yanmar Tractor PLATE, FRICTION	0	87083000	18
1A8252-51910S	Yanmar Tractor HARNESS, SA-R	0	85441990	18
1A8252-56011S	Yanmar Tractor METER, COMBINATION	22529	90292020	18
1A8252-56600S	Yanmar Tractor SENSOR ASSY, FUEL	1648	90319000	18
1A8253-47330S	Yanmar Tractor PLATE, FRICTION	0	39269080	18
1A8253-51910S	Yanmar Tractor HARNESS, SA-R	0	85441990	18
1A8253-56010S	Yanmar Tractor METER, COMBINATION	0	90292020	18
1A8254-04200S	Yanmar Tractor BREATHER, AIR	0	87089900	18
1A8254-25370S	Yanmar Tractor BEARING, NEEDLE	0	84822090	18
1A8256-06600S	Yanmar Tractor HOSE, FUEL, 500	0	40091100	18
1A8256-06620S	Yanmar Tractor HOSE, FUEL, 850	0	40091100	18
1A8256-06650S	Yanmar Tractor HOSE, FUEL, 1000	0	40091100	18
1A8256-06660S	Yanmar Tractor HOSE, FUEL, 1550	0	40091100	18
1A8256-06670S	Yanmar Tractor HOSE, FUEL, 1750	0	40091100	18
1A8256-56600S	Yanmar Tractor SENSOR ASSY, FUEL	0	87089900	18
1A8263-56010S	Yanmar Tractor METER, COMBINATION	0	90261090	18
1A8275-24540S	Yanmar Tractor GASKET, PTO VALVE	72	40169990	18
1A8275-24561S	Yanmar Tractor GASKET, VALVE PLATE	72	40169990	18
1A8275-25840S	Yanmar Tractor BEARING, HR6307UR	546	84821090	18
1A8275-27991S	Yanmar Tractor PLATE, KEEP	0	87089900	18
1A8275-36310S	Yanmar Tractor ACTUATOR, L.H.	0	87083000	18
1A8275-36320S	Yanmar Tractor ACTUATOR, R.H.	0	87083000	18
1A8275-36350S	Yanmar Tractor DISC, 226	1469	39199010	18
1A8275-36520S	Yanmar Tractor PLATE, STEEL 3.2	1052	87089900	18
1A8425-15730S	Yanmar Tractor CAP,STEERING WHEEL	1079	39269099	18
1A8425-57100S	Yanmar Tractor RELAY UNIT	4807	85367000	18
1A8426-51400S	Yanmar Tractor CABLE, - BATTERY	0	85443000	18
1A8470-00300S	Yanmar Tractor RADIATOR ASSY	11498	73182300	18
1A8470-04600S	Yanmar Tractor HOSE, FUEL 250	0	40091100	18
1A8470-04610S	Yanmar Tractor HOSE, FUEL 450	0	40091100	18
1A8470-04670S	Yanmar Tractor HOSE, FUEL 300	0	40091100	18
1A8470-11520FG	Yanmar Tractor BUSH, 65X70X30	210	84829900	18
1A8470-11520S	Yanmar Tractor BUSH, 65X70X30	210	84829900	18
1A8470-11570S	Yanmar Tractor BUSH, 80X85X25	0	84829900	18
1A8470-13740FG	Yanmar Tractor SEAL, QLF7510017	832	40169990	18
1A8470-13740S	Yanmar Tractor SEAL, QLF7510017	832	40169990	18
1A8470-52100S	Yanmar Tractor PUMP, FUEL FEED	0	84133020	0
1A8470-61360S	Yanmar Tractor DAMPER, GAS 700	0	87089900	18
1A8475-06100S	Yanmar Tractor CLEANER ASSY,AIR5.5W	2090	84213990	18
1A8475-57200S	Yanmar Tractor RELAY UNIT, FLASHER	1819	85364100	18
1A8476-57103S	Yanmar Tractor RELAY UNIT,EU	4807	85367000	18
1A8485-06100S	Yanmar Tractor CLEANER ASSY,AIR6.5W	3196	84213990	18
1C6720-47610S	Yanmar Tractor BALL, LINK BL6D	0	84822090	18
1C6720-47690S	Yanmar Tractor BALL, LINK BL6DL	0	84821020	18
1C7100-15100FG	Yanmar Tractor PLUG, 90	343	40169990	18
1C7100-15100S	Yanmar Tractor PLUG, 90	343	40169990	18
1D4270-17650S	Yanmar Tractor SOCKET,POWER SOUCE	0	85367000	18

1E4760-43090S	Yanmar Tractor LINK BALL BL8D	195	84828000	18
1E6210-54920S	Yanmar Tractor SPRING, 23	0	73202000	18
1E6740-64200S	Yanmar Tractor BALL BL8DL, LINK	0	84821030	18
1E6C20-81300S	Yanmar Tractor SWITCH, LAMP OR NL	0	85367000	18
1E8255-81180S	Yanmar Tractor LEVER, NV ROLLER	0	40091100	18
1E8665-81300S	Yanmar Tractor SWITCH, BUZZER STOP	0	85367000	18
1E8915-81450S	Yanmar Tractor SWITCH, MICRO	0	40091100	18
1RF001-00212S	Yanmar Tractor CONTROLLER, SA-R	0	85171290	18
1RF001-00213S	Yanmar Tractor CONTROLLER, SA-R	0	85171290	18
1RF001-00312S	Yanmar Tractor CONTROLLER, SA-R 3G	0	85176290	18
1RF001-00320S	Yanmar Tractor CONTROLLER, SA-R BR3G	0	85171290	18
1RF001-00330S	Yanmar Tractor CONTROLLER, SA-R 3G IND	0	85171290	18
22272-000190S	Yanmar Tractor RING, 19	0	73182910	18
22351-050070S	Yanmar Tractor PIN, 5.0A X 70	0	73182910	18
22351-080070S	Yanmar Tractor PIN, 8.0A X 70	0	87089900	18
23414-080000S	Yanmar Tractor GASKET, 8 X 1.0	58	40169990	18
23414-100000S	Yanmar Tractor GASKET, 10 X 1.0	0	40169990	18
23414-140000S	Yanmar Tractor GASKET, 14 X 1.0	0	40169990	18
23414-160000S	Yanmar Tractor GASKET, 16 X 1.0	0	40169340	18
23414-190000S	Yanmar Tractor GASKET, 19X1.0	0	87089900	18
23414-200026S	Yanmar Tractor GASKET, 20 X 1.0	11	40169990	18
23414-210027S	Yanmar Tractor GASKET, 21 X 1.0	0	40169990	18
23871-010000S	Yanmar Tractor PLUG, R01	0	87089900	18
24101-060054S	Yanmar Tractor BEARING, 6005	0	84822090	18
24101-060064S	Yanmar Tractor BEARING, 6006	0	84822090	18
24101-060074S	Yanmar Tractor BEARING, 6007	0	84822090	18
24101-060094S	Yanmar Tractor BEARING, 6009	0	84822090	18
24101-060104S	Yanmar Tractor BEARING, 6010	0	84822090	18
24101-060114S	Yanmar Tractor BEARING, 6011	0	84822090	18
24101-060124S	Yanmar Tractor BEARING, 6012	530	84822090	18
24101-060174S	Yanmar Tractor BEARING, 6017	1308	84822090	18
24101-062064S	Yanmar Tractor BEARING, 6206	182	84420000	18
24101-062074S	Yanmar Tractor BEARING, 6207	258	84420000	18
24101-062084S	Yanmar Tractor BEARING, 6208	0	84822090	18
24101-062094S	Yanmar Tractor BEARING, 6209	332	84822090	18
24101-062114S	Yanmar Tractor BEARING, 6211	0	84822090	18
24101-062124S	Yanmar Tractor BEARING, 6212	0	84822090	18
24101-063044S	Yanmar Tractor BEARING, 6304	0	84822090	18
24101-063054S	Yanmar Tractor BEARING, 6305	0	84822090	18
24101-063064S	Yanmar Tractor BEARING, 6306	0	84822090	18
24104-062104S	Yanmar Tractor BEARING, 6210UU	418	84822090	18
24107-060094S	Yanmar Tractor BEARING, 6009ZZ	0	84822090	18
24107-060104S	Yanmar Tractor BEARING, 6010ZZ	0	84822090	18
24121-062044S	Yanmar Tractor BEARING, 6204NR	0	84822090	18
24311-000110S	Yanmar Tractor PACKING, P 11.0	0	40169990	18
24311-000160S	Yanmar Tractor PACKING, P 16.0	6	40169990	18
24311-000360S	Yanmar Tractor PACKING, P 36.0	11	40169990	18
24421-203007S	Yanmar Tractor SEAL, TC203007	0	40169990	18
24421-223508S	Yanmar Tractor SEAL, TC223508	60	40169990	18
24421-305512S	Yanmar Tractor SEAL, TC305512	79	40169990	18
24421-355008S	Yanmar Tractor SEAL, TC355008	78	40169990	18

24421-355508S	Yanmar Tractor SEAL, TC355508	214	40169990	18
24421-456209S	Yanmar Tractor SEAL, TC456209	104	40169990	18
26023-030202S	Yanmar Tractor SCREW, 3X20	0	73182910	18
26346-060002S	Yanmar Tractor U-NUT, 6	0	73182910	18
26346-080002S	Yanmar Tractor U-NUT, 8	0	73181600	18
26346-100002S	Yanmar Tractor U-NUT, 10	0	73181600	18
26356-120002S	Yanmar Tractor U-NUT, 12	41	73181900	18
26589-060162S	Yanmar Tractor SCREW, 6 X 16	0	73182910	18
26589-060252S	Yanmar Tractor SCREW, 6 X 25	0	73181500	18
26589-060502S	Yanmar Tractor SCREW, 6 X 50	0	73181500	18
27260-470000S	Yanmar Tractor CAP, SEALING 47	0	40169990	18
300174178ASG	Yanmar Tractor CHARGER WITH ACESSORIES	51246	90268010	18